


ski-doo

1997
VOLUME 1

SHOP MANUAL



**TUNDRA II LT
TOURING E / E LT / LE / SLE
FORMULA S / SL
SKANDIC 380 / 500**

4 8 4 0 6 4 7 0 0



ski-doo®

1997 Shop Manual

VOLUME 1

TUNDRA II LT
TOURING E / LE / LE LT / SLE
FORMULA S / SL
SKANDIC 380 / 500





Legal deposit :

National Library of Quebec

2nd trimester 1996

National Library of Canada 1996

All rights reserved. No parts of this manual may be reproduced in any form without the prior written permission of Bombardier Inc.

©Bombardier Inc. 1996

Technical Publications

Bombardier Inc.

Valcourt (Quebec) Canada

Printed in Canada

®*Registered trademarks of Bombardier Inc.

This document contains the trademarks of the following companies :

Loctite® is a trademark of Loctite Corporation

Metton® is a trademark of Hercules Inc.

Molykote® is a trademark of Dow Corning Corporation

Silastic® is a trademark of Dow Corning Corporation

Snap-on® is a trademark of Snap-on Tools Corporation

Versilube® is a trademark of General Electric Company

Supertanium™ is a trademark of Premier Industrial Corporation

TABLE OF CONTENTS

| SECTION | SUB-SECTION | PAGE |
|---|---|---------|
| SAFETY NOTICE | | III |
| 1997 BOMBARDIER SNOWMOBILES SHOP MANUAL VOLUME 1 (INTRODUCTION) | | IV |
| 01 | LUBRICATION AND MAINTENANCE | |
| | 01 – Lubrication and maintenance chart | 01-01-1 |
| 02 | TROUBLESHOOTING | |
| | 01 – Table of contents..... | 02-01-1 |
| | 02 – Engine | 02-02-1 |
| | 03 – Fuel and oil systems..... | 02-03-1 |
| | 04 – Transmission and brake systems | 02-04-1 |
| | 05 – Electrical system | 02-05-1 |
| | 06 – Suspension system and track | 02-06-1 |
| 03 | ENGINE | |
| | 01 – Table of contents..... | 03-01-1 |
| | 02 – 277 engine type..... | 03-02-1 |
| | 03 – 377, 443 and 503 engine types..... | 03-03-1 |
| | 04 – Leak test and engine dimension measurement..... | 03-04-1 |
| | 05 – CDI system..... | 03-05-1 |
| | 06 – Oil injection system..... | 03-06-1 |
| | 07 – Axial fan cooling system..... | 03-07-1 |
| | 08 – Rewind starter..... | 03-08-1 |
| | 09 – Carburetor and fuel pump | 03-09-1 |
| | 10 – Fuel tank and throttle cable | 03-10-1 |
| 04 | TRANSMISSION | |
| | 01 – Table of contents..... | 04-01-1 |
| | 02 – Drive belt | 04-02-1 |
| | 03 – Drive pulley..... | 04-03-1 |
| | 04 – Driven pulley..... | 04-04-1 |
| | 05 – Pulley distance and alignment..... | 04-05-1 |
| | 06 – Brake | 04-06-1 |
| | 07 – Chaincase | 04-07-1 |
| | 08 – Gearbox | 04-08-1 |
| | 09 – Drive chain..... | 04-09-1 |
| 05 | ELECTRICAL | |
| | 01 – Table of contents..... | 05-01-1 |
| | 02 – Wiring diagrams (see Annexes at the end of this manual)..... | 05-02-1 |
| | 03 – Ignition timing..... | 05-03-1 |
| | 04 – Spark plugs..... | 05-04-1 |
| | 05 – Battery..... | 05-05-1 |
| | 06 – Electric starter | 05-06-1 |
| | 07 – Testing procedure | 05-07-1 |
| 06 | REAR SUSPENSION | |
| | 01 – Table of contents..... | 06-01-1 |
| | 02 – Torque reaction suspension | 06-02-1 |
| | 03 – SC-10 Sport and Touring suspension | 06-03-1 |
| | 04 – Drive axle..... | 06-04-1 |
| | 05 – Track..... | 06-05-1 |
| 07 | STEERING / FRONT SUSPENSION | |
| | 01 – Table of contents..... | 07-01-1 |
| | 02 – Steering system | 07-02-1 |
| | 03 – Suspension and ski system..... | 07-03-1 |

TABLE OF CONTENTS

| SECTION | | SUB-SECTION | PAGE |
|---------------------------|----------------|---------------------------------------|---------|
| 08 | BODY / FRAME | 01 – Table of contents | 08-01-1 |
| | | 02 – Body..... | 08-02-1 |
| | | 03 – Frame..... | 08-03-1 |
| | | | |
| 09 | TECHNICAL DATA | 01 – SI metric information guide..... | 09-01-1 |
| | | 02 – Engines | 09-02-1 |
| | | 03 – Vehicles..... | 09-03-1 |
| | | 04 – Technical data legends..... | 09-04-1 |
| ANNEXES (wiring diagrams) | | | |

SAFETY NOTICE

This manual has been prepared as a guide to correctly service and repair some 1997 Ski-Doo snowmobiles. See model list on next page.

This edition was primarily published to be used by snowmobile mechanics who are already familiar with all service procedures relating to Bombardier made snowmobiles.

Please note that the instructions will apply only if proper hand tools and special service tools are used.

This shop manual uses technical terms which may be slightly different from the ones used in parts catalog.

It is understood that this manual may be translated into another language. In the event of any discrepancy, the English version shall prevail.

The content depicts parts and / or procedures applicable to the particular product at its time of manufacture. It does not include dealer modifications, whether authorized or not by Bombardier, after manufacturing the product.

In addition, the sole purpose of the illustrations throughout the manual, is to assist identification of the general configuration of the parts. They are not to be interpreted as technical drawings or exact replicas of the parts.

The use of Bombardier parts is most strongly recommended when considering replacement of any component. Dealer and / or distributor assistance should be sought in case of doubt.

The engines and the corresponding components identified in this document should not be utilized on product(s) other than those mentioned in this document.

Torque wrench tightening specifications must be strictly adhered to. Locking devices (ex. : locking tab, elastic stop nut, etc.) must be installed or replaced with new ones, where specified. If the efficiency of a locking device is impaired, it must be renewed.

This manual emphasizes particular information denoted by the wording and symbols ;



WARNING : Identifies an instruction which, if not followed, could cause serious personal injury including possibility of death.



CAUTION : Denotes an instruction which, if not followed, could severely damage vehicle components.



NOTE : Indicates supplementary information needed to fully complete an instruction.

Although the mere reading of such information does not eliminate the hazard, your understanding of the information will promote its correct use. Always use common shop safety practice.

This information relates to the preparation and use of Bombardier snowmobiles and has been utilized safely and effectively by Bombardier Inc.. However, Bombardier Inc. disclaims liability for all damages and / or injuries resulting from the improper use of the contents. We strongly recommend that any services be carried out and / or verified by a highly skilled professional mechanic. It is understood that certain modifications may render use of the vehicle illegal under existing federal, provincial and state regulations.

1997 BOMBARDIER SNOWMOBILES SHOP MANUAL

INTRODUCTION

This *Shop Manual VOLUME 1* covers the following Bombardier made 1997 snowmobiles :

| MODELS | MODEL NUMBER |
|------------------------------|-----------------|
| TUNDRA* II LT | 3266 |
| TUNDRA* II LT (Europe)..... | 3267 |
| SKANDIC* 380 (Canada) | 1120 |
| SKANDIC* 380 (U.S.)..... | 1120 |
| SKANDIC* 380 (Europe)..... | 1122 |
| SKANDIC* 500 (Canada) | 1117 |
| SKANDIC* 500 (U.S.)..... | 1118 |
| SKANDIC* 500 (Europe)..... | 1119 |
| TOURING* E (Canada) | 1115 |
| TOURING* E LT (Canada)..... | 1116 |
| TOURING* E LT (Europe) | 1186 |
| TOURING* LE (Canada) | 1112 |
| TOURING* LE (U.S.) | 1113 |
| TOURING* LE (Europe) | 1114 |
| TOURING* SLE (Canada) | 1110 |
| TOURING* SLE (U.S.)..... | 1111 |
| FORMULA* S (Canada) | 1108 |
| FORMULA* S (Europe)..... | 1109 |
| FORMULA* SL (Canada) | 1106 |
| FORMULA* SL (U.S.)..... | 1107 |

*Trademarks of Bombardier Inc.

LIST OF MODELS GROUPED BY COMMUN CHASSIS

S-Series consists of :

Touring E / LE / LE LT / SLE

Skandic 380 / 500

Formula S / SL

S-SERIES





A03A02A

TYPICAL

1997 BOMBARDIER SNOWMOBILES SHOP MANUAL

Each vehicle has its particular vehicle serial number

Serial Number Meaning :




TYPICAL

1. Vehicle serial number

The engine also has a serial number.

Fan-Cooled Engines



1. Engine serial number

ARRANGEMENT OF THE MANUAL

The manual is divided into 10 major sections :

01 LUBRICATION AND MAINTENANCE

02 TROUBLESHOOTING

03 ENGINE

04 TRANSMISSION

05 ELECTRICAL

06 REAR SUSPENSION

07 STEERING / FRONT SUSPENSION

08 BODY / FRAME

09 TECHNICAL DATA

ANNEXES

Each section is divided in various sub-sections, and again, each sub-section has one or more division.

1997 BOMBARDIER SNOWMOBILES SHOP MANUAL

This *Shop Manual* uses technical terms which may be slightly different from the ones in the parts catalog.

TYPICAL PAGE

Page heading indicates section and sub-section detailed.

Sub-section title indicates beginning of the sub-section.

Italic sub-title above exploded view indicate pertaining models.

Drop represents a liquid product to be applied to a surface. In this case Loctite 271 to screw threads.

Bold face number indicates special procedure concerning this part.

Dotted box contains parts of a particular model in this case the short track models only.

Page numbering system:
07: REAR SUSPENSION section
01: SUSPENSION SC-10 SPORT, TOURING AND MOUNTAIN sub-section
1: First page of this sub-section

Explored view assists you in identifying parts and related positions.

Illustration number for publishing process.

Tightening torque nearby fastener. In this case, nut must be torqued to 4 N•m or 35 lbf•in.

CAUTION
Pay attention to torque specifications. Some of these are in lbf•in instead of lbf•ft. Use appropriate torque wrench.

Section 07 REAR SUSPENSION
Sub-Section 01 (SUSPENSION SC-10 SPORT, TOURING AND MOUNTAIN)

SUSPENSION SC-10 SPORT, TOURING AND MOUNTAIN
Grand Touring 500/580, Formula 500/583 and Summit 500

1997 BOMBARDIER SNOWMOBILES SHOP MANUAL

GENERAL INFORMATION

The information and component / system descriptions contained in this manual are correct at time of publication. Bombardier Inc. however, maintains a policy of continuous improvement of its products without imposing upon itself any obligation to install them on products previously manufactured.

Due to late changes, it may have some differences between the manufactured product and the description and / or specifications in this document.

Bombardier Inc. reserves the right at any time to discontinue or change specifications, designs, features, models or equipment without incurring obligation.

USEFUL PUBLICATIONS

Refer to *Parts Catalogs* to order the right parts.

| PARTS CATALOG | |
|---|-------------|
| MODELS | P / N |
| TUNDRA II LT | 480 1422 00 |
| FORMULA S FORMULA SL | 480 1428 00 |
| SKANDIC 380 SKANDIC 500 | 480 1423 00 |
| TOURING E / LT TOURING LE TOURING SLE | 480 1402 00 |

Use *Tools and Accessories Catalog* to order the tools you need.

1994 TOOLS AND ACCESSORIES (P / N 480 1343 00).

Use *Specification Booklet* to find rapidly the right specs.

1990-1997 SPECIFICATION BOOKLET (P / N 480 1420 00).

ILLUSTRATIONS AND PROCEDURES


Illustrations and photos show the typical construction of the different assemblies and, in all cases, may not reproduce the full detail or exact shape of the parts shown, however, they represent parts which have the same or a similar function.

CAUTION : Most components of those vehicles are built with parts dimensioned in the metric system. Most fasteners are metric and must not be replaced by customary fasteners or vice versa. Mismatched or incorrect fasteners could cause damage to the vehicle or possible personal injury.

As many of the procedures in this manual are interrelated, we suggest, that before undertaking any task, you read and thoroughly understand the entire section or sub-section in which the procedure is contained.

A number of procedures throughout the book require the use of special tools. Before commencing any procedure, be sure that you have on hand all the tools required, or approved equivalents.

The use of RIGHT and LEFT indications in the text, always refers to driving position (when sitting on vehicle).



TYPICAL

- 1. Left
- 2. Right

1997 BOMBARDIER SNOWMOBILES SHOP MANUAL

TIGHTENING TORQUES

Tighten fasteners to torque mentioned in exploded views and text. When they are not specified refer to following table.

| N•m | FASTENER SIZE (8.8) | Lbf•in |
|-----|---------------------|--------|
| 1 | | 9 |
| 2 | M4 | 18 |
| 3 | M4 | 27 |
| 4 | M5 | 35 |
| 5 | | 44 |
| 6 | | 53 |
| 7 | | 62 |
| 8 | M6 | 71 |
| 9 | M6 | 80 |
| 10 | M6 | 89 |
| 11 | M6 | 97 |
| 12 | M6 | 106 |
| 13 | | 115 |
| 14 | | 124 |
| 15 | | 133 |
| 16 | | 142 |
| 17 | | 150 |
| 18 | | 159 |
| 19 | | 168 |

| N•m | FASTENER SIZE (8.8) | Lbf•ft |
|-----|---------------------|--------|
| 20 | | 15 |
| 21 | M8 | 15 |
| 22 | M8 | 16 |
| 23 | M8 | 17 |
| 24 | M8 | 18 |
| 25 | M8 | 18 |
| 26 | | 19 |
| 27 | | 20 |
| 28 | | 21 |
| 29 | | 21 |
| 30 | | 22 |
| 31 | | 23 |
| 32 | | 24 |
| 33 | | 24 |
| 34 | | 25 |
| 35 | | 26 |
| 36 | | 27 |
| 37 | | 27 |
| 38 | | 28 |

| N•m | FASTENER SIZE (8.8) | Lbf•ft |
|-----|---------------------|--------|
| 39 | | 29 |
| 40 | | 30 |
| 41 | | 30 |
| 42 | | 31 |
| 43 | M10 | 32 |
| 44 | M10 | 32 |
| 45 | M10 | 33 |
| 46 | M10 | 34 |
| 47 | M10 | 35 |
| 48 | M10 | 35 |
| 49 | M10 | 36 |
| 50 | M10 | 37 |
| 51 | M10 | 38 |
| 52 | M10 | 38 |
| 53 | M10 | 39 |
| 54 | | 40 |
| 55 | | 41 |
| 56 | | 41 |
| 57 | | 42 |
| 58 | | 43 |
| 59 | | 44 |
| 60 | | 44 |
| 61 | | 45 |
| 62 | | 46 |
| 63 | | 46 |
| 64 | | 47 |
| 65 | | 48 |
| 66 | | 49 |
| 67 | | 49 |
| 68 | | 50 |
| 69 | | 51 |
| 70 | | 52 |
| 71 | | 52 |
| 72 | | 53 |
| 73 | | 54 |
| 74 | | 55 |
| 75 | | 55 |
| 76 | M12 | 56 |
| 77 | M12 | 57 |
| 78 | M12 | 58 |
| 79 | M12 | 58 |
| 80 | M12 | 59 |
| 81 | M12 | 60 |
| 82 | M12 | 60 |
| 83 | M12 | 61 |

1997 BOMBARDIER SNOWMOBILES SHOP MANUAL

| N•m | FASTENER SIZE (8.8) | Lbf•ft |
|-----|---------------------|--------|
| 84 | M12 | 62 |
| 85 | | 63 |
| 86 | | 63 |
| 87 | | 64 |
| 88 | | 65 |
| 89 | | 66 |
| 90 | | 66 |
| 91 | | 67 |
| 92 | | 68 |
| 93 | | 69 |
| 94 | | 69 |
| 95 | | 70 |
| 96 | | 71 |
| 97 | | 72 |
| 98 | | 72 |
| 99 | | 73 |
| 100 | | 74 |
| 101 | | 74 |
| 102 | | 75 |
| 103 | | 76 |
| 104 | | 77 |
| 105 | | 77 |
| 106 | | 78 |
| 107 | | 79 |
| 108 | | 80 |
| 109 | | 80 |
| 110 | | 81 |
| 111 | | 82 |
| 112 | | 83 |
| 113 | | 83 |
| 114 | | 84 |
| 115 | | 85 |
| 116 | | 86 |
| 117 | | 86 |
| 118 | | 87 |
| 119 | | 88 |
| 120 | | 89 |
| 121 | M14 | 89 |
| 122 | M14 | 90 |
| 123 | M14 | 91 |
| 124 | M14 | 91 |
| 125 | M14 | 92 |
| 126 | M14 | 93 |
| 127 | M14 | 94 |
| 128 | M14 | 94 |

| N•m | FASTENER SIZE (8.8) | Lbf•ft |
|-----|---------------------|--------|
| 129 | M14 | 95 |
| 130 | M14 | 96 |
| 131 | M14 | 97 |
| 132 | M14 | 97 |
| 133 | M14 | 98 |
| 134 | M14 | 99 |
| 135 | M14 | 100 |
| 136 | M14 | 100 |
| 137 | M14 | 101 |
| 138 | M14 | 102 |
| 139 | M14 | 103 |
| 140 | M14 | 103 |
| 141 | M14 | 104 |
| 142 | M14 | 105 |
| 143 | M14 | 105 |
| 144 | M14 | 106 |
| 145 | M14 | 107 |
| 146 | M14 | 108 |
| 147 | M14 | 108 |
| 148 | M14 | 109 |
| 149 | M14 | 110 |
| 150 | M14 | 111 |

TIGHTENING TORQUES FOR 8.8 GRADE BOLTS AND NUTS




Section 01 LUBRICATION AND MAINTENANCE
Sub-Section 01 (LUBRICATION AND MAINTENANCE CHART)

LUBRICATION AND MAINTENANCE CHART

| | | ① | ② | ③ | ④ | ⑤ | ⑥ | REFER TO |
|---|---|---|---|---|---|---|---|--|
|  | Starting Rope Condition | | | | | | ✓ | — |
| | Engine Head Nuts | ✓ | | | ✓ | | | Appropriate section : See Top End |
| | Engine Mount Nuts | ✓ | | | ✓ | | | Appropriate section : See ENGINE REMOVAL |
| | Exhaust System | ✓ | | ✓ | | | | Appropriate section : See ENGINE REMOVAL |
| | Engine Lubrication | | | | | ✓ | | This section no. 1 |
| | Cooling System Condition | ✓ | | | ✓ | | | Sub-section 03-07 |
| | Coolant Replacement (Except Fan Cooled) | | | | | | ✓ | Not applicable |
| | Condition of Seals | | | | | | ✓ | Sub-sections 03-02 and 03-03 |
|  | Injection Oil Filter Condition | | | ✓ | | | | Sub-section 03-06 |
| | Injection Oil Filter Replacement | | | | | | ✓ | Sub-section 03-06 |
| | Oil Injection Pump Adjustment | ✓ | | | ✓ | | | Sub-section 03-06 |
|  | Fuel Stabilizer | | | | | ✓ | | This section no. 2 |
| | Fuel Filter Replacement | | | | | | ✓ | This section no. 3 |
| | Fuel Lines and Connections | ✓ | | | | | ✓ | Sub-section 03-10 |
|  | Carburetor Adjustment | ✓ | | | ✓ | | | Sub-section 03-09 |
| | Throttle Cable Inspection | ✓ | | | ✓ | | ✓ | Sub-section 03-10 |
| | Air Filter Cleaning | | | ✓ | | | | This section no. 4 |
|  | Drive Belt Condition | ✓ | ✓ | | | | | This section no. 5 |
| | Condition of Drive and Driven Pulleys | ✓ | | ✓ | | ✓ | | Sub-sections 04-03 and 04-04 |
| | Cleaning of Drive and Driven Pulleys | | | | | | ✓ | Sub-sections 04-03 and 04-04 |
| | Retorquing of Drive Pulley Screw | ✓ | | | | | | Sub-section 04-03 |
| | Driven Pulley Preload | ✓ | | | ✓ | | | Sub-section 04-04 |
|  | Brake Condition | ✓ | ✓ | | | | | Sub-section 04-06 |
| | Brake Adjustment | | | ✓ | | | | Sub-section 04-06 |
| | Lubrication of Ratchet Wheel or Fluid Change | | | | | | ✓ | Sub-section 04-06 |
|  | Drive Chain Tension | ✓ | | ✓ | | | | Sub-sections 04-07 and 04-08 |
| | Countershaft Lubrication (S and F Series) | ✓ | | ✓ | | ✓ | | Sub-section 04-06 |
| | Chaincase / Gearbox Oil Level | ✓ | | ✓ | | ✓ | | Sub-sections 04-07 and 04-08 |
| | Chaincase / Gearbox Oil Change | | | | | ✓ | | Sub-sections 04-07 and 04-08 |
| | Lubrication of drive axle bearing | ✓ | | ✓ | | ✓ | | Sub-section 06-04 |
|  | Handlebar Bolts. Retorque to 26 N•m (19 lbf•ft) | ✓ | | | | | | Sub-section 07-02 |
| | Steering and Front Suspension Mechanism | ✓ | | ✓ | | ✓ | | Sub-sections 07-02 and 07-03 |
| | Wear and Condition of Skis and Runners | ✓ | ✓ | | | | | Sub-section 07-03 |
| | Steering and Ski Leg Camber Adjustment | ✓ | | ✓ | | | | Sub-section 07-02 |

Section 01 LUBRIFICATION AND MAINTENANCE

Sub-Section 01 (LUBRICATION AND MAINTENANCE CHART)

| | | ① | ② | ③ | ④ | ⑤ | ⑥ | REFER TO |
|--|--|-------------|-------------|---|---|---|---|--|
|  | Suspension Adjustments | AS REQUIRED | | | | | | Section 06 : See appropriate sub-section and <i>Operator's Guide</i> |
| | Suspension Lubrication | | | ✓ | | ✓ | | Section 06 : See appropriate sub-section |
| | Suspension Condition | ✓ | | | ✓ | | | Section 06 : See appropriate sub-section |
| | Suspension Stopper Strap Condition | | | | ✓ | | | Section 06 : See appropriate sub-section |
| | Track Condition | ✓ | | ✓ | | | | Sub-section 06-05 |
| | Track Tension and Alignment | ✓ | AS REQUIRED | | | | | |
|  | Spark Plugs* | ✓ | | | | | | Sub-section 05-04 |
| | Engine Timing | ✓ | | | | | ✓ | Sub-section 05-03 |
| | Battery Condition | ✓ | | ✓ | | ✓ | | Sub-section 05-05 |
| | Headlight Beam Aiming | | | | ✓ | | | Sub-section 08-02 |
| | Wiring Harnesses, Cables and Lines | ✓ | | ✓ | | | | Sub-section 08-02 |
| | Operation of Lighting System (HI / LO Beam, Brake Light, etc.) Test Operation of Emergency Cut-Out Switch and Tether Cut-Out Switch | ✓ | ✓ | | | ✓ | | <i>Operator's Guide</i> |
|  | Rags in Air Intake and Exhaust System | | | | | ✓ | ✓ | This section no. 6 |
| | Engine Compartment | ✓ | | ✓ | | | | This section no. 7 |
| | General Inspection | ✓ | | ✓ | | ✓ | | This section no. 8 |

* Before installing new spark plugs at pre-season preparation, it is suggested to burn excess storage oil by starting the engine with the old spark plugs. Only perform this operation in a well ventilated area.

① 10-HOUR OR 500 km (300 mi) INSPECTION (To be performed by dealer)

② WEEKLY OR EVERY 240 km (150 mi)

③ MONTHLY OR EVERY 800 km (500 mi)

④ ONCE A YEAR OR EVERY 3200 km (2000 mi)

⑤ STORAGE (To be performed by dealer)

⑥ PRE-SEASON PREPARATION (To be performed by dealer)

NO. 1 ENGINE LUBRICATION

Engine internal parts must be lubricated to protect them from possible rust formation during the storage period.

To perform the storage procedures, proceed as follows :

Start the engine and allow it to run at idle speed until the engine reaches its operating temperature.


◆ **WARNING :** Ensure the track is free of all particles which could be thrown out while it is rotating. Keep hands, tools, feet and clothing clear of track. Ensure no one is standing in close proximity to the vehicle.

Stop the engine.

Models With a Primer

To prevent fuel from draining, primer button should be pushed all the way in.

Disconnect the outlet primer hose from the primer valve (straight coupling).



- 1. Straight coupling
- 2. To intake manifold

Insert storage oil (P / N 496 0141 00) nozzle into primer outlet hose.

Models With a Choke

Remove air silencers to spray storage oil into each carburetor bore.

All Models

Restart engine and run at idle speed.

Inject storage oil until the engine stalls or until a sufficient quantity of oil has entered the engine (approximately half a can).

With the engine stopped, remove the spark plug and spray storage oil (P / N 496 0141 00) into each cylinder.

Crank slowly 2 or 3 revolutions to lubricate cylinders.

Reinstall the spark plugs and the outlet primer hose or air silencers.

◆ **WARNING :** This procedure must only be performed in a well ventilated area. Do not run engine during storage period.

NO. 2 FUEL STABILIZER

A fuel stabilizer (P / N 413 4086 00) can be added in fuel tank to prevent fuel deterioration and avoid draining fuel system for storage. Follow manufacturer's instructions for proper use.


If above fuel stabilizer is not used, drain fuel system including fuel tank and carburetor(s).

▼ **CAUTION :** Fuel stabilizer should be added prior engine lubrication to ensure carburetor(s) protection against varnish deposit.

NO. 3 FUEL FILTER REPLACEMENT

Drain fuel tank.

Remove fuel line grommet from fuel tank and pull out inlet fuel line from tank.



TYPICAL

- 1. Inlet fuel line
- 2. Position of grommet when installing
- 3. Fuel filter

Section 01 LUBRICATION AND MAINTENANCE

Sub-Section 01 (LUBRICATION AND MAINTENANCE CHART)

Replace fuel filter. To facilitate the fuel line installation, slide grommet on fuel line about 50 mm (2 in) away from elbow then install grommet on fuel tank and push elbow through grommet.

NO. 4 AIR FILTER CLEANING


Check that the air box is clean and dry then properly reinstall the filter.

▼ **CAUTION :** These snowmobiles have been calibrated with the filter installed. Operating the snowmobile without it may cause engine damage.

Tundra II LT

Air filter is located on lower side portion of air intake silencer. Lift hood and remove belt guard. Gently pull air filter sideward.


Ensure it is clean and dry. Shake snow out. Clean with a solvent and dry as necessary.



1. Intake silencer
2. Air filter

S-Series

Lift hood and remove air filter from air intake silencer.



TYPICAL

1. Filter

To clean the filter, shake the snow out of it then, dry it out.

NO. 5 DRIVE BELT CONDITION

Inspect belt for cracks, fraying or abnormal wear (uneven wear, wear on one side, missing cogs, cracked fabric). If abnormal wear is noted, probable cause could be pulley misalignment, excessive RPM with frozen track, fast starts without warm-up period, burred or rusty sheave, oil on belt or distorted spare belt.

Check the drive belt width. Replace the drive belt if width is less than the minimum width recommended in DRIVE BELT 04-02.

NO. 6 RAGS IN AIR INTAKE AND EXHAUST SYSTEM

At storage preparation, block air intake hole and exhaust system hole using clean rags.

Remove those rags at pre-season preparation.

NO. 7 ENGINE COMPARTMENT

Keep clean of grass, twigs, cloth, etc. These are combustible under certain conditions.

NO. 8 GENERAL INSPECTION

Remove any dirt or rust.

To clean the entire vehicle, use only flannel clothes or Kimtowels® wipers no. 58-380 from Kimberly-Clark.

▼ **CAUTION :** It is necessary to use flannel cloths or “Kimtowels” wipers on windshield and hood to avoid damaging further surfaces to clean.

To clean the entire vehicle, including metallic parts with a **thick** coat of grease, use “Endust” imported by Bristol Myers, available at hardware stores or supermarkets.

To clean the entire vehicle, including metallic parts with a **thin** coat of grease, use “Simple Green” from Sunshine Makers Inc., available at hardware stores or at automotive parts retailer.

To remove scratches on windshield or hood : Start with “Slip Streamer Motorcycle Windshield Heavy Duty Scratch, Remover”. Finish with “Slip Streamer Motorcycle Cleaner and Polish”.

○ **NOTE :** The latest product may be use alone if only light scratches are noticeable.

▼ **CAUTION :** Never clean plastic parts or hood with strong detergent, degreasing agent, paint thinner, acetone, products containing chlorine, etc.

Inspect the hood and repair any damage. Touch up all metal spots where paint has been scratched off. Spray all metal parts including shock chromed rods with Bombardier Lube (P / N 293 6000 06). Wax the hood and the painted portion of the frame for better protection.

○ **NOTE :** Apply wax on glossy finish only. Protect the vehicle with a cover to prevent dust accumulation during storage.

▼ **CAUTION :** The snowmobile has to be stored in a cool and dry place and covered with an opaque tarpaulin This will prevent sun rays and grime from affecting plastic components and vehicle finish.

| | |
|---|----------------|
| ENGINE | 02-02-1 |
| FUEL AND OIL SYSTEMS | 02-03-1 |
| TRANSMISSION AND BRAKE SYSTEMS | 02-04-1 |
| TRANSMISSION | 02-04-1 |
| BRAKE SYSTEM | 02-04-7 |
| MECHANICAL BRAKE | 02-04-7 |
| HYDRAULIC BRAKE | 02-04-7 |
| MECHANICAL AND HYDRAULIC BRAKES | 02-04-8 |
| ELECTRICAL SYSTEM..... | 02-05-1 |
| SUSPENSION SYSTEM AND TRACK | 02-06-1 |

ENGINE

The following chart is provided to help in diagnosing the probable source of troubles. It should be used as a guideline. Some causes or corrections may not apply to a specific model.

| SYMPTOM | ENGINE BACKFIRES. |
|-------------------|---|
| CONDITION | NORMAL USE. |
| Test / Inspection | 1. Check spark plug(s). a. Carbon accumulation caused by defective spark plug(s). <i>Clean carbon accumulation and replace spark plug(s).</i> |
| | 2. Check cooling system. a. Loose fan belt. <i>Adjust or replace fan belt (refer to TECHNICAL DATA 09).</i> b. Low antifreeze level. <i>Adjust antifreeze level. Then check clamps or hoses.</i> c. Defective tank cap. <i>Replace cap.</i> d. Air in system. <i>Bleed system.</i> |
| | 3. Check ignition timing. a. Timing is too advanced. <i>Set timing according to specifications (refer to TECHNICAL DATA 09).</i> |

Section 02 TROUBLESHOOTING
Sub-Section 02 (ENGINE)

| SYMPTOM | ENGINE SUDDENLY TURNS OFF. |
|-------------------|--|
| CONDITION | NORMAL USE. |
| Test / Inspection | 1. Perform engine leak test. Refer to engine leak verification flow chart. Check possible piston seizure. a. Damaged gasket and / or seal. <i>Replace defective parts.</i> |
| | 2. "Four-corner" seizure of piston(s). a. Accelerating too fast when engine is cold. Piston expands faster than cylinder. <i>Replace piston(s). Ask driver to refer to warm-up procedure in Operator's Guide.</i> |
| | 3. Piston(s) seizure on exhaust side (color on piston dome is correct). a. Kinked fuel tank vent tube. <i>Relocate fuel tank vent tube.</i> b. Leaks at fuel line connections or damaged fuel lines. <i>Replace defective lines.</i> c. Fuel does not flow through carburetor(s) (plastic particles in needle area and / or varnish formation in carburetor(s)). <i>Clean carburetor(s).</i> d. Spark plug heat range is too warm. <i>Install spark plug(s) with appropriate heat range (refer to TECHNICAL DATA 09).</i> e. Improper ignition timing. <i>Adjust according to specifications (refer to TECHNICAL DATA 09).</i> f. Restriction in exhaust system. <i>Replace.</i> g. Compression ratio is too high. <i>Install genuine parts.</i> h. Carburetor calibration is too lean. <i>Adjust according to specifications (refer to TECHNICAL DATA 09).</i> i. Improper rotary valve timing or improper valve. <i>Adjust according to specifications (refer to TECHNICAL DATA 09) and / or install Bombardier's recommended rotary valve.</i> j. Poor quality oil. <i>Use Bombardier Rotax oil.</i> k. Leaks at air intake silencer. <i>Replace air intake silencer grommets.</i> |

| | |
|--------------------------|--|
| | <p>4. Melted and / or perforated piston dome ; melted section at ring end gap.</p> <p>a. When piston reaches TDC, mixture is ignited by heated areas in combustion chamber. This situation is due to an incomplete combustion of a poor quality oil. <i>Clean residue accumulation in combustion chamber and replace piston(s). Use Bombardier Rotax oil.</i></p> <p>b. Spark plug heat range is too high. <i>Install recommended spark plug(s) (refer to TECHNICAL DATA 09).</i></p> <p>c. Ignition timing is too advanced. <i>Adjust according to specifications (refer to TECHNICAL DATA 09).</i></p> <p>d. Inadequate fuel quality. <i>Use appropriate fuel.</i></p> <p>e. Carburetion is too lean. <i>Adjust according to specifications (refer to TECHNICAL DATA 09).</i></p> |
| | <p>5. Seized piston all around the circumference (dry surface).</p> <p>a. Lack of oil, damaged oil line or defective injection pump. <i>Replace defective part(s).</i></p> |
| | <p>6. Grooves on intake side of piston only.</p> <p>a. Oil film eliminated by water (snow infiltration in engine). <i>Replace piston(s) and check if intake system leaks.</i></p> |
| | <p>7. Piston color is dark due to seizure on intake and exhaust sides.</p> <p>a. Broken or loose fan belt. <i>Replace fan belt or adjust its tension (refer to TECHNICAL DATA 09).</i></p> <p>b. Cooling system leaks and lowers coolant level. <i>Tighten clamps or replace defective parts. Add antifreeze in cooling system until appropriate level is reached.</i></p> <p>c. Accumulation of foreign particles in needle and / or main jet area. <i>Clean carburetor(s).</i></p> |
| | <p>8. Cracked or broken piston(s).</p> <p>a. Cracked or broken piston(s) due to excessive piston / cylinder clearance or engine overrevving. <i>Replace piston(s). Check piston / cylinder clearance (refer to TECHNICAL DATA 09). Adjust drive pulley according to specifications (refer to TECHNICAL DATA 09) and / or clean pulley sheaves if they are contaminated with greasy particles.</i></p> |
| SYMPTOM | PISTON RING AND CYLINDER SURFACES ARE GROOVED. |
| CONDITION | NORMAL USE. |
| Test / Inspection | <p>1. Check oil quality.</p> <p>a. Poor oil quality. <i>Use Bombardier Rotax oil.</i></p> |
| | <p>2. Check injection pump and its hoses.</p> <p>a. Inadequate injection pump adjustment and / or defective hoses. <i>Adjust pump according to specifications (refer to ENGINE 03) and / or replace hoses.</i></p> |

Section 02 TROUBLESHOOTING
Sub-Section 02 (ENGINE)

| SYMPTOM | ENGINE DOES NOT OFFER MAXIMUM POWER AND / OR DOES NOT REACH MAXIMUM OPERATING RPM. |
|-------------------|--|
| CONDITION | NORMAL USE. |
| Test / Inspection | 1. Check spark plug condition. a.Fouled spark plug(s). <i>Replace.</i> |
| | 2. Check if there is water in fuel. a.There is water in fuel. <i>Drain fuel system, then fill it with appropriate fuel.</i> |
| | 3. Check items listed in "Engine runs out of fuel" (refer to fuel and oil system sub-section 02). |
| | 4. Check carburetor adjustments and cleanliness. a.Inadequate carburetor adjustments or dirt accumulation. <i>Adjust according to specifications (refer to TECHNICAL DATA 09) or clean.</i> |
| | 5. Check drive belt. a.Worn belt. <i>Replace belt if width is 3 mm (1/8") less than nominal dimension (refer to TECHNICAL DATA 09).</i> |
| | 6. Check track adjustment. a.Too much tension and / or improper alignment. <i>Align track and adjust its tension to specifications (refer to TECHNICAL DATA 09).</i> |
| | 7. Check drive pulley. a.Improper calibration screw adjustments (TRA pulley) and / or worn bushing(s). <i>Adjust according to specifications (refer to TECHNICAL DATA 09) and / or replace bushing(s).</i> |
| | 8. Check driven pulley. a.Worn bushing and / or spring tension. <i>Replace spring and / or adjust its tension according to specifications (refer to TECHNICAL DATA 09).</i> |
| | 9. Check exhaust system. a.Restriction. <i>Replace.</i> |
| | 10. Check ignition timing. a.Decrease in power due to retarded ignition. <i>Adjust according to specification (refer to TECHNICAL DATA 09).</i> |
| | 11. Check engine compression. a.Worn piston(s) and ring(s). <i>Replace (refer to TECHNICAL DATA 09 for specification).</i> |
| | 12. Check engine cooling system. a.Engine overheats. Improper fan belt tension. <i>Adjust fan belt (refer to TECHNICAL DATA 09).</i> b.Antifreeze level is low, cap fails to pressurize system or air circulates through lines. <i>Adjust level, replace cap or bleed cooling system.</i> |

| | |
|--------------------------|--|
| SYMPTOM | ENGINE DETONATION AT MAXIMUM RPM. |
| CONDITION | NORMAL USE. |
| Test / Inspection | 1. Check which type of fuel is used. a. Octane number is too low and / or alcohol level is too high. <i>Use recommended fuel type.</i> |
| | 2. Check spark plug type. a. Improper spark plug heat range. <i>Install recommended spark plug(s) (refer to TECHNICAL DATA 09).</i> |
| | 3. Check exhaust system. a. Too much restriction. <i>Replace.</i> |
| | 4. Check ignition timing. a. Timing is too advanced. <i>Adjust according to specification (refer to TECHNICAL DATA 09).</i> |
| | 5. Check carburetion. a. Fouled and / or improper carburetor components. <i>Clean or replace according to specification (refer to TECHNICAL DATA 09).</i> |
| | 6. Check compression ratio and squish area. a. Compression ratio is too high. <i>Install genuine parts.</i> |
| SYMPTOM | ENGINE TURNS OVER BUT FAILS TO START. |
| CONDITION | NORMAL USE. |
| Test / Inspection | 1. Check switches. a. Ignition switch, emergency cut-out switch or tether switch is in the OFF position. <i>Place all switches in the RUN or ON position.</i> |
| | 2. Check fuel level. a. Mixture not rich enough to start cold engine. <i>Check fuel tank level and use primer.</i> |
| | 3. Check spark plug. a. Defective spark plug (no spark). <i>Replace spark plug(s).</i> |
| | 4. Check amount of fuel on spark plug. a. Flooded engine (spark plug wet when removed). <i>Do not overprime. Remove wet spark plug(s), turn ignition switch to OFF and crank engine several times. Install clean dry spark plug. Start engine following usual starting procedure.</i> |
| | 5. Check fuel lines. a. No fuel to the engine (spark plug dry when removed). <i>Check fuel tank level; turn fuel valve on if applicable; check fuel filter, replace if clogged; check condition of fuel and impulse lines and their connections.</i> |
| | 6. Check engine compression. a. Insufficient engine compression. <i>Replace defective part(s) (ex. : piston(s), ring(s), etc.).</i> |

Section 02 TROUBLESHOOTING
Sub-Section 02 (ENGINE)

| | |
|--------------------------|--|
| SYMPTOM | IRREGULAR ENGINE IDLE. |
| CONDITION | NORMAL USE AFTER ENGINE WARM UP. |
| Test / Inspection | 1. Check primer. a. Fuel leaks at primer nipple which is mounted to carburetor. <i>Replace.</i> |
| | 2. Check choke. a) Choke plunger may be partially opened. <i>Readjust.</i> |
| | 3. Check carburetor adapter. a. Air enters through a crack. <i>Replace.</i> |
| | 4. Check air screw position. a. Inadequate fuel / air mixture. <i>Adjust according to specifications (refer to TECHNICAL DATA 09).</i> |
| | 5. Check ignition system trigger coil air gap. a. Air gap is too large. <i>Adjust according to specifications (refer to TECHNICAL DATA 09).</i> |
| | 6. Check dimension of pilot jet. a. Inadequate fuel / air mixture. <i>Adjust according to specifications (refer to TECHNICAL DATA 09).</i> |
| | 7. Perform engine leak test. a. Leaking gaskets allow air to enter in engine. <i>Replace defective parts.</i> |
| SYMPTOM | HIGH ENGINE OPERATING TEMPERATURE. |
| CONDITION | NORMAL USE. |
| Test / Inspection | 1. Check temperature gauge sensor. a. False reading. <i>Replace.</i> |
| | 2. Check fan belt. a. Belt slides because it is too loose. <i>Adjust according to specifications (refer to TECHNICAL DATA 09).</i> |
| | 3. Verify antifreeze level and check if there is air infiltration in the system or if there are leaks in gasket areas. a. Low antifreeze level or air in system. <i>Add antifreeze until recommended level is reached, bleed system and / or tighten clamps at fitting.</i> |
| | 4. Check if antifreeze flows through system properly. a. Foreign particles and / or broken coolant pump impeller. <i>Clean cooling system and / or replace coolant pump impeller.</i> |
| | 5. Check thermostat. a. Thermostat reacts slowly or not at all. <i>Replace.</i> |


| | |
|--------------------------|--|
| | 6. Check antifreeze concentration. a.Antifreeze concentration is too high. <i>Adjust concentration according to Bombardier's recommendations.</i> |
| | 7. Check tank cap. a.Cap does not hold pressure. <i>Replace.</i> |
| | 8. Check carburetion. a.Improperly adjusted or inadequate carburetor components. <i>Adjust according to specifications (refer to TECHNICAL DATA 09) or replace inadequate component(s).</i> |
| | 9. Check cylinder head gaskets. a.Worn gaskets. <i>Replace.</i> |
| | 10. Check ignition timing. a.Ignition timing is too advanced. <i>Adjust according to specifications (refer to TECHNICAL DATA 09).</i> |
| | 11. Check if there are leaks at air intake silencer and / or engine crankcase. a.Leak(s). <i>Repair or replace.</i> |
| | 12. Check condition and heat range of spark plug(s). a.Melted spark plug tip or inadequate heat range. <i>Replace.</i> |
| SYMPTOM | ENGINE EQUIPPED WITH "RAVE" VALVE DOES NOT REACH ITS FULL OPERATING RPM (500 TO 1000 RPM SLOWER). |
| CONDITION | NORMAL USE. |
| Test / Inspection | 1. Check "RAVE" valve pistons. a.Valve piston(s) is (are) too far out. <i>Screw valve piston(s) to bottom.</i> |
| | 2. Check "RAVE" valve stems. a.Bent "RAVE" valve stem(s). <i>Replace.</i> |
| | 3. Check "RAVE" valves. a.Jamed valve(s). <i>Clean.</i> |
| | 4. Check tension of "RAVE" springs. a.Inadequate spring tension. <i>Replace.</i> |
| | 5. Check "RAVE" pressure holes. a.Clogged holes. <i>Clean.</i> |
| | 6. Check clamps or sleeves. a.Damaged clamp(s) or sleeve(s). <i>Replace.</i> |

Section 02 TROUBLESHOOTING
Sub-Section 02 (ENGINE)

| | |
|--------------------------|---|
| SYMPTOM | ENGINE EQUIPPED WITH "RAVE". ENGINE HESITATES AT MID-SPEED AND REACHES MAXIMUM PERFORMANCE ONLY AFTER A WHILE. |
| CONDITION | NORMAL USE. |
| Test / Inspection | 1. Check "RAVE" valve spring(s). a. Spring tension is too weak or spring(s) is (are) broken. <i>Replace.</i> |
| | 2. Check "RAVE" valve cover red adjustment screws. a. Adjustment screw(s) is (are) too loose. <i>Fully tighten.</i> |
| | 3. Check "RAVE" valve movement ("RAVE" movement indicator P / N 861 7258 00). a. Valve(s) is (are) stuck in open position. <i>Clean.</i> |
| SYMPTOM | REWIND STARTER ROPE DOES NOT REWIND. |
| CONDITION | NORMAL USE. |
| Test / Inspection | 1. Check rewind spring. a. Broken spring. <i>Replace spring.</i> |
| SYMPTOM | REWIND STARTER PAWL DOES NOT ENGAGE. |
| CONDITION | NORMAL USE. |
| Test / Inspection | 1. Check stopper spring. a. Broken stopper spring. <i>Replace.</i> |
| | 2. Check pawl and pawl lock. a. Pawl and pawl lock have stuck together because of heat. <i>Replace.</i> |
| | 3. Check pawl and rope sheave. a. Pawl and rope sheave have stuck together because of heat. <i>Replace.</i> |

| | |
|--------------------------|--|
| SYMPTOM | ENGINE PINGING. |
| CONDITION | NORMAL USE. |
| Test / Inspection | 1. Check fuel lines. a. Bent fuel lines (preventing fuel from flowing through). <i>Relocate or replace fuel lines.</i> |
| | 2. Check if carburetor(s) is (are) clean. a. Dirt prevents fuel from flowing through. <i>Clean.</i> |
| | 3. Check ignition timing. a. Timing is too advanced. <i>Adjust according to specifications (refer to TECHNICAL DATA 09).</i> |
| | 4. Check compression ratio. a. Compression ratio is too high. <i>Replace inadequate part(s) to obtain manufacturer's recommended compression ratio or use a higher grade fuel.</i> |
| SYMPTOM | ENGINE GENERATES A LOT OF VIBRATIONS. |
| CONDITION | NORMAL USE. |
| Test / Inspection | 1. Check engine supports. a. Loose broken supports or interference between support(s) and chassis. <i>Retighten to specification (refer to TECHNICAL DATA 09) or replace.</i> |
| | 2. Check drive pulley (refer to : vibrations coming from drive pulley). |
| | 3. Check carburetor synchronization. a. Throttle slide heights are adjusted differently and / or throttle slide openings are unsynchronized. <i>Adjust throttle slide heights and throttle cable.</i> |

Engine Leak Verification Flow Chart



FUEL AND OIL SYSTEMS

The following chart is provided to help in diagnosing the probable source of troubles. It should be used as a guideline. Some causes or corrections may not apply to a specific model.

| | |
|--------------------------|---|
| SYMPTOM | HIGH FUEL CONSUMPTION (OR RICH MIXTURE). |
| CONDITION | NORMAL USE. |
| Test / Inspection | 1. Check fuel tank. a. Perforated fuel tank. <i>Replace fuel tank.</i> |
| | 2. Check fuel pump reservoir and carburetor fittings. a. Leaking fittings. <i>Replace defective part.</i> |
| | 3. Check primer. a. Fuel flows through primer while engine runs. <i>Replace primer.</i> |
| | 4. Check float height in carburetor(s). a. Fuel level is too high in float bowl(s). <i>Adjust according to specifications (refer to TECHNICAL DATA 09).</i> |
| | 5. Check needle valve. a. Foreign particles prevent needle valve(s) from closing and / or worn seating area. <i>Clean or replace needle valve(s), then clean seating area.</i> |
| | 6. Check H.A.C. system. a. Connection to atmosphere is plugged. <i>Clean.</i> b. Leakage in H.A.C. to carburetor tube. <i>Replace.</i> c. Leak in H.A.C. sealed chamber. <i>Replace.</i> d. H.A.C. frozen. <i>Replace.</i> |
| SYMPTOM | FUEL LEAKS IN ENGINE BASE WHEN ENGINE IS STOPPED. |
| CONDITION | NORMAL USE. |
| Test / Inspection | 1. Check items 3, 4 and 5 of "High fuel consumption". |
| | 2. Check fuel pump diaphragm. a. Cracked diaphragm. <i>Replace.</i> |

Section 02 TROUBLESHOOTING
Sub-Section 03 (FUEL AND OIL SYSTEMS)

| | |
|--------------------------|---|
| SYMPTOM | ENGINE LACKS POWER OR STALLS AT HIGH RPM. |
| CONDITION | NORMAL USE. |
| Test / Inspection | 1. Check fuel tank vent hose. a. Kinked or clogged hose. <i>Relocate or replace.</i> |
| | 2. Check fuel filter. a. Clogged filter. <i>Replace.</i> |
| | 3. Check fuel lines. a. Kinked or clogged lines. <i>Relocate or replace.</i> |
| | 4. Check fuel pump flow. a. Dried diaphragm. <i>Replace.</i> |
| | 5. Check if carburetor(s) is (are) clean. a. Varnish. <i>Clean.</i> |
| SYMPTOM | HIGH INJECTION OIL CONSUMPTION. |
| CONDITION | NORMAL USE. |
| Test / Inspection | 1. Check oil injection pump adjustment. a. Oil injection pump adjusted too rich. <i>Adjust.</i> |
| | 2. Check injection oil lines and their fitting. a. Leaking lines and / or cover. <i>Replace defective part(s).</i> |
| | 3. Check injection pump cover gasket. a. Worn gasket. <i>Replace.</i> |
| | 4. Pressurize crankcase rotary valve gear reservoir. a. Leaking gasket(s). <i>Replace gasket(s).</i> |

| | |
|--------------------------|--|
| SYMPTOM | ENGINE RUNS OUT OF FUEL (OR LEAN MIXTURE). |
| CONDITION | NORMAL USE. |
| Test / Inspection | 1. Check fuel filter ball located in fuel tank. Ball must move freely. a. Corrosion due to oxidation at installation. <i>Replace fuel filter.</i> |
| | 2. Check if lines are perforated or kinked and make sure they do not leak at fittings. a. Lines are too big for their fittings or are improperly routed. <i>Replace or properly relocate lines.</i> |
| | 3. Check fuel pump outlet flow. a. Dirt clogging fuel pump lines or torn membrane. <i>Clean or replace fuel pump.</i> |
| | 4. Check carburetor needle valve(s). a. Dirt (varnish, foreign particle) clogging fuel line inlets. <i>Clean.</i> |
| | 5. Check main jet. a. Dirt (varnish, foreign particle) accumulation at main jet. <i>Clean.</i> |
| | 6. Check float height in carburetor bowl(s). a. Running out of fuel at high speed because float height is too low. <i>Adjust float lever height according to specification.</i> |
| | 7. Check H.A.C. system. a. Plugged hole in air jet inlet. <i>Clean.</i> b. H.A.C. frozen. <i>Replace.</i> |

TRANSMISSION AND BRAKE SYSTEMS

The following charts are provided to help in diagnosing the probable source of troubles. It should be used as a guideline. Some causes or corrections may not apply to a specific model.


TRANSMISSION

| | |
|--------------------------|--|
| SYMPTOM | THE SNOWMOBILE ACCELERATES SLOWLY, ESPECIALLY WHEN IT IS STOPPED. |
| CONDITION | NORMAL USE. |
| Test / Inspection | 1. Check drive belt condition. a. Belt is too narrow (drive belt engagement is higher in drive pulley). <i>Replace belt if width is 3 mm (1/8") less than a new one (refer to TECHNICAL DATA 09).</i> |
| | 2. Check distance between pulleys and / or drive belt deflection. a. Distance is too small between pulleys or deflection is too high (drive belt engagement is higher in drive pulley). <i>Adjust distance between pulleys and / or drive belt deflection according to specifications (refer to TECHNICAL DATA 09).</i> |
| | 3. Check driven pulley sliding half play. a. Jammed sliding half. <i>Replace.</i> |
| | 4. Check spring tension of driven pulley sliding half. a. Sliding half rotation is accelerated when spring tension is too weak. <i>Adjust according to specifications (refer to TECHNICAL DATA 09).</i> |
| | 5. Refer to "Vibrations originating from driven pulley" and check items listed. |
| | 6. Check drive pulley spring tension. a. Spring tension is too weak. <i>Replace.</i> |
| SYMPTOM | ENGINE MAXIMUM RPM IS TOO HIGH AND TOP SPEED IS NOT REACHED. |
| CONDITION | NORMAL USE. |
| Test / Inspection | 1. Check items 1, 2 and 3 of "The snowmobile accelerates slowly, especially when it is stopped". |
| | 2. Check driven pulley spring tension. a. Spring tension is too stiff. <i>Adjust according to specification (refer to TECHNICAL DATA 09).</i> |
| | 3. Check position of the calibration screws. (TRA drive pulley) a. Selected numbers are too high. <i>Adjust according to specification (refer to TECHNICAL DATA 09).</i> |
| | 4. Refer to "Vibrations originating from driven pulley" and check items listed. |

Section 02 TROUBLESHOOTING
Sub-Section 04 (TRANSMISSION AND BRAKE SYSTEMS)



| | |
|--------------------------|---|
| SYMPTOM | LOOSENESS IS FELT IN DRIVE SYSTEM WHEN ACCELERATING / DECELERATING. |
| CONDITION | NORMAL USE. |
| Test / Inspection | 1. Check drive chain tension. a. Drive chain is too loose. <i>Adjust.</i> |
| | 2. Check play of driven pulley Woodruff key (aluminum frame models) a. Worn Woodruff key or keyway. <i>Replace.</i> |
| SYMPTOM | VIBRATIONS ORIGINATING FROM DRIVEN PULLEY. |
| CONDITION | NORMAL USE. |
| Test / Inspection | 1. Check drive belt. a. Belt width is uneven at many places. <i>Replace (refer to TECHNICAL DATA 09 for the part number).</i> |
| | 2. Check tightening torque of drive pulley screw. a. Moving governor cup. <i>Retighten bolt.</i> |
| | 3. Spring cover bolts. a. Spring cover moves and restrains sliding half movement. <i>Retighten bolts.</i> |
| | 4. Check spring cover (TRA TYPE) and / or outer half bushings. a. Excessive gap between bushings and inner half shaft, thus restraining sliding half movements. <i>Replace bushing(s).</i> |
| | 5. Check sliding half slider shoes. a. Worn slider shoes. <i>Replace.</i> |
| SYMPTOM | VIBRATIONS ORIGINATING FROM DRIVEN PULLEY. |
| CONDITION | NORMAL USE. |
| Test / Inspection | 1. Check sliding half play. a. Sliding half runout. <i>Replace sliding half bushing.</i> |
| | 2. Check sliding half and fixed half straightness. a. Sliding half / fixed half runout. <i>Replace.</i> |
| | 3. Check cam slider shoes. a. One or two slider shoes out of three are broken. <i>Replace.</i> |

Section 02 TROUBLESHOOTING
Sub-Section 04 (TRANSMISSION AND BRAKE SYSTEMS)




| | |
|---|--|
| SYMPTOM | PULLEYS DO NOT DOWN SHIFT PROPERLY. |
| CONDITION | NORMAL USE. |
| Test / Inspection | 1. Check driven pulley spring tension. a. Spring tension is too weak. <i>Adjust according to specifications (refer to TECHNICAL DATA 09).</i> |
| | 2. Refer to "Vibrations coming from driven pulley" and check items listed. |
| | 3. Check drive pulley bushings (cleanliness, wear, etc.). a. Bushings stick to fixed half pulley shaft. <i>Clean or replace.</i> |
| | 4. Check driven pulley spring tension. a. Spring tension is too weak. <i>Replace.</i> |
| SYMPTOM | IT IS DIFFICULT TO ENGAGE TRANSMISSION IN FORWARD OR REVERSE GEAR. |
| CONDITION | NORMAL USE. |
| Test / Inspection | 1. Check position of gear shift lever adjustment screw. a. Improper adjustment. <i>Adjust according to specifications (refer to TRANSMISSION 04).</i> |
| SYMPTOM | UNEVEN BELT WEAR ON ONE SIDE ONLY. |
| CONDITION | NORMAL USE. |
|  | 1. Check tightening torque of engine mount bolts. a. Loose engine mount. <i>Tighten engine mount nuts / bolts equally.</i> |
| | 2. Check pulley alignment. a. Pulley misalignment. <i>Align pulleys.</i> |
| | 3. Check drive belt contact area on pulleys. a. Rough or scratched pulley surfaces. <i>Repair or replace pulley half.</i> |
| | 4. Check driven pulley sliding half play. a. Driven pulley bushing worn. <i>Replace bushing.</i> |

A00D09Y





Section 02 TROUBLESHOOTING
Sub-Section 04 (TRANSMISSION AND BRAKE SYSTEMS)

| SYMPTOM | BELT GLAZED EXCESSIVELY OR HAVING BAKED APPEARANCE. |
|---|--|
| CONDITION | NORMAL USE. |
| Test / Inspection  A00D0AY | 1. Check if drive pulley bushings are worn. a. Insufficient pressure on belt sides. <i>Replace bushing.</i> |
| | 2. Check condition of drive pulley fixed half shaft. a. Rusted drive or driven pulley shafts. <i>Clean shaft with fine steel wool and lubricate with low temperature grease (If applicable only).</i> |
| | 3. Check if pulley halves are clean. a. Oil on pulley surfaces. <i>Clean pulley halves.</i> |
| | 4. Check pulley calibration. a. Improper pulley calibration. <i>Calibrate according to specification.</i> |
| SYMPTOM | BELT WORN EXCESSIVELY IN TOP WIDTH. |
| CONDITION | NORMAL USE. |
| Test / Inspection  A00D0BY | 1. Check drive pulley. a. Excessive slippage due to irregular outward actuation movement of drive pulley. <i>Carry out drive pulley inspection.</i> |
| | 2. Check drive belt identification number. a. Improper belt angle. (wrong type of belt). <i>Replace belt with an appropriate drive belt.</i> |
| | 3. Check drive belt width. a. Considerable use. <i>Replace belt if 3 mm (1/8") less than recommended width (see TECHNICAL DATA 09).</i> |

Section 02 TROUBLESHOOTING
Sub-Section 04 (TRANSMISSION AND BRAKE SYSTEMS)

| | |
|--|--|
| SYMPTOM | BELT WORN NARROW IN ONE SECTION. |
| CONDITION | NORMAL USE. |
| Test / Inspection  A00D0CY | 1. Check if parking brake is released. a. Parking brake is engaged. <i>Release parking brake.</i> |
| | 2. Check track tension / alignment. a. Frozen or too tight track. <i>Liberate track from ice or check track tension and alignment.</i> |
| | 3. Check drive pulley. a. Drive pulley not functioning properly. <i>Repair or replace drive pulley.</i> |
| | 4. Check idle speed. a. Engine idle speed too high. <i>Adjust according to specification.</i> |
| | 5. Check drive belt length. a. Incorrect belt length. <i>Replace belt with an appropriate drive belt (refer to TECHNICAL DATA 09).</i> |
| | 6. Check distance between pulleys. a. Incorrect pulley distance. <i>Readjust according to specification.</i> |
| | 7. Check belt deflection. a. Deflection is too small. <i>Adjust according to specification.</i> |
| SYMPTOM | BELT SIDES WORN CONCAVE. |
| CONDITION | NORMAL USE. |
| Test / Inspection  A00D0DY | 1. Check pulley half surfaces. a. Rough or scratched pulley half surfaces. <i>Repair or replace.</i> |
| | 2. Check drive belt identification number. a. Unspecified type of belt. <i>Replace belt with an appropriate drive belt (refer to TECHNICAL DATA 09).</i> |
| SYMPTOM | BELT DISINTEGRATION. |
| CONDITION | NORMAL USE. |
| Test / Inspection  A00DOEY | 1. Check drive belt identification number. a. Excessive belt speed. <i>Using unspecified type of belt. Replace belt with proper type of belt (refer to TECHNICAL DATA 09).</i> |
| | 2. Check if pulley halves are clean. a. Oil on pulley surfaces. <i>Clean pulley surfaces with fine emery cloth and wipe clean using Loctite Safety Solvent (P / N 413 7082 00) and a cloth.</i> |

Section 02 TROUBLESHOOTING
Sub-Section 04 (TRANSMISSION AND BRAKE SYSTEMS)

| | |
|--|--|
| SYMPTOM | BELT EDGE CORD BREAKAGE. |
| CONDITION | NORMAL USE. |
| Test / Inspection  A00D0FY | 1. Check pulley alignment. a. Pulley misalignment. <i>Align pulley according to specifications (refer to TECHNICAL DATA 09).</i> |
| SYMPTOM | FLEX CRACKS BETWEEN COGS. |
| CONDITION | NORMAL USE. |
| Test / Inspection  A00D0GY | 1. Check drive belt condition. a. Considerable use, belt wearing out. <i>Replace.</i> |
| SYMPTOM | SHEARED COGS, COMPRESSION SECTION FRACTURED OR TORN. |
| CONDITION | NORMAL USE. |
| Test / Inspection  A00D0HY | 1. Check drive belt rotational direction. a. Improper belt installation. <i>Replace.</i> |
| | 2. Check if drive belt rubs against components. a. Belt rubbing on stationary object. <i>Relocate components.</i> |
| | 3. Check drive pulley. a. Violent engagement of drive pulley. <i>Check drive pulley engagement speed, drive pulley bushings and components.</i> |
| SYMPTOM | BELT "FLIP-OVER" AT HIGH SPEED. |
| CONDITION | NORMAL USE. |
| Test / Inspection  A00D0IY | 1. Check pulley alignment. a. Pulley misalignment. <i>Align pulley according to specifications (refer to TECHNICAL DATA 09).</i> |
| | 2. Check drive belt identification number. a. Using unspecified type of belt. <i>Replace belt with an appropriate drive belt.</i> |

BRAKE SYSTEM

MECHANICAL BRAKE

| | |
|--------------------------|--|
| SYMPTOM | BRAKE DOES NOT ADJUST AUTOMATICALLY. |
| CONDITION | NORMAL USE. |
| Test / Inspection | 1. Check ratchet wheel spring. a. Broken ratchet wheel tag. <i>Replace.</i> |
| | 2. Check mobile pad stud. a. Stud rotates in pad. <i>Replace.</i> |
| SYMPTOM | BRAKE HANDLE DOES NOT RETURN COMPLETELY. |
| CONDITION | NORMAL USE. |
| Test / Inspection | 1. Check brake return spring. a. Broken return spring. <i>Replace.</i> |
| | 2. Check if brake cable moves freely in its housing. a. Brake cable movement is limited due to oxidation or dirt accumulation. <i>Replace.</i> |
| | 3. Check distance between brake lever and caliper. a. Distance is too wide. <i>Adjust according to specifications (refer to TRANSMISSION 04).</i> |

HYDRAULIC BRAKE

| | |
|--------------------------|---|
| SYMPTOM | SPONGY BRAKE CONDITION. |
| CONDITION | NORMAL USE. |
| Test / Inspection | <i>Replace brake fluid and bleed system. If problem still occurs, replace master cylinder.</i> |
| SYMPTOM | BRAKE FLUID LEAKING. |
| CONDITION | NORMAL USE. |
| Test / Inspection | 1. Check for loosen hose connectors. <i>Retighten.</i> |
| | 2. Check for damaged hose, master cylinder and caliper. <i>Replace part(s) and check for proper mounting.</i> |

MECHANICAL AND HYDRAULIC BRAKES

| | |
|-------------------|--|
| SYMPTOM | BRAKE SYSTEM IS NOISY. |
| CONDITION | NORMAL USE. |
| Test / Inspection | <div>1. Check brake pad thickness.</div> <div>a. Pads are worn up to wear warner. Replace.</div> |

ELECTRICAL SYSTEM

The following chart is provided to help in diagnosing the probable source of troubles. It should be used as a guideline. Some causes or corrections may not apply to a specific model.


| | |
|--------------------------|--|
| SYMPTOM | STARTER DOES NOT TURN. |
| CONDITION | NORMAL USE. |
| Test / Inspection | 1. Check fuse. a. Burnt fuse. <i>Check wiring condition and replace fuse.</i> |
| | 2. Check continuity of starter switch contact points. a. Poor contact of starter switch contact points. <i>Repair or replace switch.</i> |
| | 3. Check continuity between starter switch and solenoid. a. Open circuit between starter switch and solenoid switch. <i>Repair.</i> |
| SYMPTOM | STARTER TURNS ; BUT DOES NOT CRANK THE ENGINE. |
| CONDITION | NORMAL USE. |
| Test / Inspection | 1. Check battery capacity. a. Shorted battery cell(s). <i>Replace.</i> |
| | 2. Check battery charge. a. Weak battery. <i>Recharge.</i> |
| | 3. Check wire connection. a. Inadequate connection (too much resistance). <i>Clean and reconnect.</i> |
| | 4. Check solenoid switch contact disc. a. Burnt or poor contact of solenoid switch contact disc. <i>Replace solenoid switch.</i> |
| | 5. Check continuity of solenoid switch pull-in winding. a. Open circuit of solenoid switch pull-in winding. <i>Replace solenoid switch.</i> |
| | 6. Check continuity of solenoid switch hold-in winding. a. Open circuit of solenoid switch hold-in winding. <i>Replace solenoid switch.</i> |
| | 7. Check brushes. a. Poor contact of brushes. <i>Replace brushes.</i> |
| | 8. Check commutator. a. Burnt commutator. <i>Turn commutator in lathe.</i> |

Section 02 TROUBLESHOOTING
Sub-Section 05 (ELECTRICAL SYSTEM)

| | |
|--------------------------|--|
| | 9. Check height of commutator mica. a.Commutator mica too high. <i>Undercut mica.</i> |
| | 10. Check field coil resistance. a.Shorted field coil. <i>Repair or replace yoke.</i> |
| | 11. Check armature resistance. a.Shorted armature. <i>Repair or replace armature.</i> |
| | 12. Check tension of brush springs. a.Weak brush spring tension. <i>Replace springs.</i> |
| | 13. Check yoke assembly magnets. a.Weak magnets. <i>Replace yoke assembly.</i> |
| | 14. Check if bushings are worn. a.Worn bushings. <i>Replace bushings.</i> |
| SYMPTOM | STARTER TURNS, BUT OVERRUNNING CLUTCH PINION DOES NOT MESH WITH RING GEAR. |
| CONDITION | NORMAL USE. |
| Test / Inspection | 1. Check clutch pinion gear. a.Worn clutch pinion gear. <i>Replace clutch.</i> |
| | 2. Check clutch. a.Defective clutch. <i>Replace clutch.</i> |
| | 3. Check movement of clutch on splines. a.Poor movement of clutch on splines. <i>Clean and correct.</i> |
| | 4. Check clutch bushing. a.Worn clutch bushing. <i>Replace clutch.</i> |
| | 5. Check starter bushings. a.Worn starter bushing(s). <i>Replace bushing(s).</i> |
| | 6. Check ring gear. a.Worn ring gear. <i>Replace ring gear.</i> |

| | |
|--------------------------|---|
| SYMPTOM | ELECTRIC STARTER KEEPS TURNING WHEN ENGINE IS STARTED. |
| CONDITION | NORMAL USE. |
| Test / Inspection | 1. Check clutch. a. Jammed clutch pinion gear. <i>Replace or clean.</i> |
| | 2. Check movement of clutch on splines. a. Clutch is stuck on splines. <i>Clean.</i> |
| | 3. Check ignition switch. a. Ignition switch does not return to its ON position or is short-circuited. <i>Adjust retaining screw or replace switch.</i> |
| | 4. Check solenoid. a. Shorted solenoid switch winding(s). <i>Replace solenoid switch.</i> |
| | 5. Check solenoid switch contacts. a. Melted solenoid switch contacts. <i>Replace solenoid switch.</i> |
| | 6. Check starter switch. a. Starter switch returns poorly. <i>Replace ignition switch.</i> |
| SYMPTOM | NOISE OCCURENCE WHEN STARTING ENGINE. |
| CONDITION | NORMAL USE. |
| Test / Inspection | 1. Check if ring gear is well mounted to drive pulley inner half. a. Loose and / or broken bolts. <i>Retighten bolts using thread locker or replace ring gear and drive pulley inner half.</i> |
| SYMPTOM | ELECTRIC STARTER SOMETIMES DOES NOT WORK WHEN TURNING IGNITION SWITCH. |
| CONDITION | NORMAL USE. |
| Test / Inspection | 1. Check battery cables and starter wires. a. Corroded and / or loose connection(s). <i>Clean and / or retighten.</i> |
| | 2. Check fuse. a. Oxidized fuse. <i>Clean.</i> |
| | 3. Check wiring harness connections. a. Oxidized connections. <i>Clean or replace defective terminals.</i> |

Section 02 TROUBLESHOOTING
Sub-Section 05 (ELECTRICAL SYSTEM)

| | |
|--------------------------|---|
| | 4. Check ignition switch. a. Defective contacts in ignition switch. <i>Replace.</i> |
| | 5. Check solenoid of electric starter. a. Shorted solenoid wiring harness or eroded contact washer. <i>Replace.</i> |
| SYMPTOM | HEADLAMP NOT LIGHTING. |
| CONDITION | WHITE BULB. |
| Test / Inspection | 1. Check bulb. a. Gas leak. <i>Replace bulb.</i> |
| CONDITION | BROKEN ELEMENT. |
| Test / Inspection | 1. Check for loose headlamp housing and bulb socket. a. Vibration problem. <i>Tighten headlamp mounting screws. Lock bulb in socket. Replace bulb.</i> |
| CONDITION | MELTED FILAMENT (ENDS OF ELEMENT HOLDER) AND BLACK BULB. |
| Test / Inspection | 1. Check voltage at headlamp at different speeds. It must not be above 15 VAC.  NOTE : If quartz halogen bulb is involved, ensure that proper voltage regulator is installed. a. Excessive voltage in lighting circuit. <i>Replace voltage regulator and ensure proper grounding. Retest.</i> |
| SYMPTOM | HEADLAMP DIMING. |
| CONDITION | NORMAL USE. |
| Test / Inspection | 1. Check voltage at headlamp at different speeds. It must not be below 11 VAC. a. Insufficient voltage in lighting circuit. <i>Replace voltage regulator and retest.</i> |
| | 2. Visually inspect wiring harness for damaged and / or melted wires and / or bad wire terminal crimping and / or connections. a. Heating, rotating or sharp part in contact with harness. Improper harness routing. <i>Repair / replace damaged wires and / or terminals. Reroute harness where necessary.</i> |
| | 3. On manual start models : Verify regulator ground. a. Rusted or loose retaining screws. <i>Clean, apply lithium grease (LMZ1) and firmly tighten screws.</i> |
| | 4. Verify if there is an interconnection between AC and DC current. a. Faulty installation of optional equipment. <i>Find optional equipment connected directly to DC ground (BK wire or chassis) or to any DC hot wire (RD, RD / BL). Disconnect and reconnect to AC current (YL and YL / BK wires).</i> |

| | |
|--------------------------|--|
| | 5. Verify if optional electric accessories are overloading the magneto / generator. a. Excessive electrical load to magneto / generator. <i>Reduce the electrical load by removing excess accessories. Reconnect as recommended by manufacturer.</i> |
| | 6. Hot Grips brand : Verify if they were connected in parallel by mistake. a. Excessive electrical load to magneto / generator. <i>Reconnect as recommended by manufacturer.</i> |
| | 7. Bombardier heating grips : Verify if the return wires of the elements were grounded to the chassis by mistake. a. Faulty installation of optional equipment. <i>Reconnect as recommended by manufacturer.</i> |
| | 8. Verify if heating grips installation overloads the magneto / generator capacity. a. Excessive electrical load to magneto / generator. <i>Reduce the electrical load by removing accessories.</i> |
| SYMPTOM | FALSE FUEL AND / OR TEMPERATURE GAUGE READINGS. |
| CONDITION | NORMAL USE. |
| Test / Inspection | 1. Verify if gauge was connected on DC current by mistake (in case of optional installation). a. Faulty installation of optional equipment. <i>Find optional wires connected directly to DC ground (BK wire to chassis) or to any DC hot wire (RD, RD / BL). Disconnect and reconnect to AC current (YL and YL / BK wires).</i> |
| | 2. Verify sender unit for free movement and / or correct arm position. a. Defective or damaged part. <i>Correct or replace sender unit.</i> |
| | 3. Verify sender unit / gauge wiring harness condition. a. Heating, rotating or sharp part in contact with harness. Improper harness routing. <i>Replace or repair damaged wires. Reroute where necessary.</i> |

Section 02 TROUBLESHOOTING
Sub-Section 05 (ELECTRICAL SYSTEM)

| | |
|--------------------------|--|
| SYMPTOM | ENGINES DOES NOT START – NO SPARK AT SPARK PLUG. |
| CONDITION | AT ENGINE CRANKING. |
| Test / Inspection | 1. Verify spark plug condition. a. Defective, improperly set, worn-out, fouled. <i>Identify source of problem and correct. Replace spark plug.</i> |
| | 2. Verify spark plug cap resistance with an ohmmeter. a. Defective part. <i>Replace cap.</i> |
| | 3. Verify if problem originated from electrical system wiring harness and / or accessories and / or ignition cut-out switches by unplugging the 4-wire connectors between the magneto / generator and the vehicle wiring harness. Check condition of connectors. a. Heating, rotating or sharp part in contact with harness. Improper harness routing. Defective switch(es). Corroded connector terminals. <i>Replace or repair damaged wires. Reroute where necessary. Replace defective switch(es). Clean terminals and apply silicone dielectric grease.</i> |
| | 4. Verify trigger coil resistance with an ohmmeter and connector condition. a. Defective coil. Corroded connector terminals. <i>Replace defective coil. Clean terminals and apply silicone dielectric grease.</i> |
| | 5. Verify condition of ignition coil. a. Mechanically damaged part. Vibration problem. Electrically damaged part. <i>Tighten mounting screws. Replace ignition coil.</i> |
| | 6. Verify condition of ignition generator coils. a. Mechanically damaged part. Vibration problem. Electrically damaged part. <i>Tighten mounting screws. Replace coils.</i> |
| | 7. Verify CDI (Capacitor discharge ignition) module. a. Mechanically damaged part. Vibration problem. Electrically damaged part. <i>Tighten mounting screws. Replace CDI module, retest and verify ignition timing.</i> |
| SYMPTOM | ENGINE STALLS. |
| CONDITION | AT LOW SPEED. |
| Test / Inspection | 1. Verify items 4, 5 and 6 above. |
| SYMPTOM | IRREGULAR ENGINE SPEED. |
| CONDITION | AT HIGH SPEED. |
| Test / Inspection | 1. Verify items 4, 5 and 6 above. |
| CONDITION | AT LOW SPEED. |
| Test / Inspection | 1. Verify items 4 and 5 above and trigger coil / flywheel protrusion air-gap. a. Air-gap too large. <i>Readjust air-gap.</i> |

| | |
|--------------------------|---|
| SYMPTOM | ENGINE IS MISFIRING – ERRATIC SPARK AT SPARK PLUG. |
| CONDITION | RIDING ON WET SNOW. |
| Test / Inspection | 1. Verify if spark plug wires and / or spark plug cap seals are sealing-out moisture. a. Defective wires and / or seals. <i>Replace defective part.</i> |
| | 2. Verify if ignition system wiring harness connectors are in good condition and / or are sealing-out moisture. a. Loose connectors, corroded terminals or defective parts. <i>Clean terminals and apply silicone dielectric grease. Replace defective parts.</i> |
| CONDITION | NORMAL USE. |
| Test / Inspection | 1. Verify misfiring by observing flash of stroboscopic timing light ; unplug connectors between magneto / generator and vehicle wiring harness to isolate problem. Check condition of connectors. a. Defective spark plug and / or cables / caps. Defective electrical system wiring harness and / or accessories and / ignition cut-out switches. Condition of connector terminals. <i>Replace defective parts and / or repair damaged wires. Replace defective switch(es). Clean terminals and apply silicone dielectric grease.</i> |
| CONDITION | RIDING IN DEEP AND THICK SNOW. |
| Test / Inspection | 1. Perform all verifications outlined under “Engine does not start – no spark at spark plug”. |
| | 2. Verify spark plug(s). Proceed with spark plug analysis in order to identify source of problem. a. Defective and / or worn spark plug(s) and / or cable(s) and / or cap(s). <i>Replace defective part(s). Proceed with ignition system testing procedures. Perform engine analysis.</i> |

Section 02 TROUBLESHOOTING
Sub-Section 05 (ELECTRICAL SYSTEM)

| | |
|--------------------------|--|
| SYMPTOM | FOULED (BLACK) SPARK PLUG TIP. |
| CONDITION | NORMAL USE. |
| Test / Inspection | 1. Check carburetor(s). a. Carburetion is too rich. <i>Adjust according to specifications (refer to TECHNICAL DATA 09).</i> |
| | 2. Check injection oil consumption. a. Injection pump flow is too high. <i>Adjust according to specification or replace.</i> |
| | 3. Check oil quality. a. Poor oil quality that creates deposits. <i>Use Bombardier oil.</i> |
| | 4. Check engine compression. a. Leaking piston ring(s). <i>Replace.</i> |
| SYMPTOM | SPARK PLUG TIP(S) IS (ARE) LIGHT GREY. |
| CONDITION | NORMAL USE. |
| Test / Inspection | 1. Refer to “Engine slows down or stops at high RPM” and check items listed. |
| | 2. Check spark plug heat range. a. Spark plug heat range is too high. <i>Replace by Bombardier’s recommended spark plug (refer to TECHNICAL DATA 09).</i> |
| | 3. Check if air intake silencer leaks. a. Air surplus coming from opening(s) located between halves. <i>Seal.</i> |
| | 4. Check carburetor adapter collars. a. Loose collar(s). <i>Tighten.</i> |
| | 5. Check carburetor adapter(s). a. Cracked or deformed adapter(s). <i>Replace.</i> |
| SYMPTOM | BRAKE LIGHT REMAINS ON. |
| CONDITION | NORMAL USE. |
| Test / Inspection | 1. Check if bulb is properly installed. a. Bulb is not installed correctly (contact elements are reversed). <i>Install bulb correctly.</i> |
| | 2. Check brake switch. a. Switch contact remains closed. <i>Adjust brake cable or brake switch.</i> |

| | |
|--------------------------|--|
| SYMPTOM | REAR LIGHT BULB FLASHES. |
| CONDITION | NORMAL USE. |
| Test / Inspection | 1. Check bulb tightness in housing. a. Looseness at bulb contact elements. <i>Install bulb correctly.</i> |
| | 2. Check if rear light is properly connected. a. Connector housing is partially connected. <i>Install connector housing properly.</i> |
| | 3. Check continuity of wires. a. Corroded terminals and / or broken wires. <i>Replace terminal(s) or crimp defective wires.</i> |
| SYMPTOM | TACHOMETER DOES NOT WORK. |
| CONDITION | NORMAL USE. |
| Test / Inspection | 1. Check fuse. a. Burnt fuse. <i>Replace.</i> |
| | 2. Check continuity of wires. a. Corroded terminals and / or broken wires. <i>Replace terminal(s) or crimp defective wires.</i> |

SUSPENSION SYSTEM AND TRACK

The following chart is provided to help in diagnosing the probable source of troubles. It should be used as a guideline. Some causes or corrections may not apply to a specific model.

| | |
|--------------------------|---|
| SYMPTOM | REAR SUSPENSION BOTTOMS OUT. |
| CONDITION | NORMAL USE. |
| Test / Inspection | 1. Check rear spring preload or rear arm spring preload. a. Spring tension is too low. <i>Increase rear arm spring preload.</i> |
| SYMPTOM | SLIDER SHOES WEAR OUT PREMATURELY. |
| CONDITION | NORMAL USE. |
| Test / Inspection | 1. Check track tension. a. Pressure is too great on slider shoes. <i>Adjust according to specifications (refer to TECHNICAL DATA 09). Replace defective parts.</i> |
| SYMPTOM | TRACK CLEATS BECOME BLUE. |
| CONDITION | NORMAL USE. |
| Test / Inspection | 1. Check track tension. a. Pressure is too great on cleats. <i>Adjust according to specifications (refer to TECHNICAL DATA 09).</i> |
| | 2. Check slider shoes and / or suspension retaining screws. a. Worn slider shoes or lost retaining screws. <i>Replace defective parts and / or tighten loose screws.</i> |
| SYMPTOM | NOISE OR VIBRATIONS ORIGINATING FROM THE TRACK. |
| CONDITION | NORMAL USE. |
| Test / Inspection | 1. Check slide suspension retaining bolts. a. Missing bolt(s) allowing movement of certain components which in turn interfere with track rotation. <i>Replace missing bolt(s).</i> |
| | 2. Check condition of idler wheel(s). a. Idle wheel rubber is damaged. <i>Replace.</i> |
| | 3. Check guide cleats. a. Top portion of guide cleat(s) is bent. <i>Replace.</i> |
| | 4. Check sprockets. a. One or various teeth of drive shaft sprockets are broken. <i>Replace sprocket(s).</i> |
| | 5. Check track rods and / or internal traction teeth. a. One or various track rods and / or teeth are broken. <i>Replace track.</i> |

Section 02 TROUBLESHOOTING
Sub-Section 06 (SUSPENSION SYSTEM AND TRACK)

| | |
|--------------------------|--|
| SYMPTOM | DERAILING TRACK. |
| CONDITION | NORMAL USE. |
| Test / Inspection | 1. Check track tension. a. Track is too loose. <i>Adjust.</i> |
| | 2. Check if track and slider shoes are properly aligned. a. Improper alignment. <i>Adjust.</i> |
| SYMPTOM | REAR SUSPENSION IS LOW OR TOO STIFF. |
| CONDITION | NORMAL USE. |
| Test / Inspection | 1. Check track tension. a. Track is too tight. <i>Adjust.</i> |
| | 2. Check if axles are properly lubricated. a. Improper lubrication and / or contaminated grease (sticky oil sludge). <i>Clean and / or lubricate.</i> |
| | 3. Check rear spring preload. a. Insufficient preload. <i>Increase preload using shock adjustment cams.</i> |
| SYMPTOM | WHEN HANDLEBAR IS TURNED, SNOWMOBILE UNDERSTEERS. |
| CONDITION | NORMAL USE. |
| Test / Inspection | 1. Check ski runner condition. a. Worn ski runners. <i>Replace.</i> |
| | 2. Check tension of front spring adjustment cams. a. Insufficient ski pressure on the ground. <i>Increase spring preload.</i> |
| | 3. Check if front arm stopper strap is too long. a. Insufficient ski pressure on the ground. <i>Shorten stopper strap.</i> |
| | 4. Check front arm spring tension. a. Insufficient ski pressure on the ground. <i>Slacken spring tension.</i> |

| | |
|--------------------------|--|
| SYMPTOM | HANDLE BAR IS DIFFICULT TO TURN. |
| CONDITION | NORMAL USE. |
| Test / Inspection | 1. Check position of front spring adjustment cams. a. More pressure on the ground when cam increases spring preload. <i>Reduce front spring preload.</i> |
| | 2. Check position of stopper strap. a. More weight when stopper strap is short. <i>Lengthen front arm stopper strap.</i> |
| | 3. Check position of front arm shock adjustment cam(s). a. When spring tension is weak, more weight is transferred to the skis. <i>Increase spring preload.</i> |
| | 4. Check condition of ball joints. a. Corrosion restrains movement. <i>Lubricate or replace.</i> |
| | 5. Check swing arm camber (liquid cooled models). a. Too much ski leg inclination. <i>Adjust camber to $0^{\circ} \pm .5^{\circ}$.</i> |
| SYMPTOM | THE SNOWMOBILE IS UNSTABLE (IT MOVES FROM LEFT TO RIGHT AND VICE VERSA). |
| CONDITION | NORMAL USE. |
| Test / Inspection | 1. Check ski runner condition. a. Worn or bent ski runners. <i>Replace ski runners.</i> |
| | 2. Check ski alignment. a. Improper ski alignment. <i>Align skis in order to obtain proper toe-out (opening) (to adjust, refer to STEERING SYSTEM 07).</i> |
| | 3. Check if bushings are too loose in steering system. a. Bushings are too loose. <i>Replace.</i> |

| | |
|--|--------------------|
| 277 ENGINE TYPE | 03-02-1 |
| ENGINE REMOVAL AND INSTALLATION..... | 03-02-1 |
| REMOVAL FROM VEHICLE | 03-02-2 |
| ENGINE SUPPORT AND MUFFLER DISASSEMBLY AND ASSEMBLY | 03-02-2 |
| INSTALLATION ON VEHICLE | 03-02-2 |
| TOP END | 03-02-3 |
| TROUBLESHOOTING | 03-02-4 |
| TOP END REMOVAL (WITHOUT REMOVING ENGINE FROM CHASSIS) | 03-02-4 |
| CLEANING | 03-02-4 |
| DISASSEMBLY | 03-02-4 |
| INSPECTION | 03-02-5 |
| ASSEMBLY..... | 03-02-5 |
| BOTTOM END..... | 03-02-7 |
| CLEANING | 03-02-8 |
| DISASSEMBLY | 03-02-8 |
| INSPECTION | 03-02-8 |
| ASSEMBLY..... | 03-02-8 |
| 377, 443 AND 503 ENGINE TYPES | 03-03-1 |
| ENGINE REMOVAL AND INSTALLATION..... | 03-03-1 |
| ENGINE REMOVAL AND INSTALLATION | 03-03-3 |
| TUNED PIPE IDENTIFICATION | 03-03-3 |
| TOP END | 03-03-4 |
| CLEANING | 03-03-5 |
| DISASSEMBLY | 03-03-5 |
| INSPECTION | 03-03-6 |
| ASSEMBLY..... | 03-03-6 |
| BOTTOM END..... | 03-03-10 |
| CLEANING | 03-03-11 |
| DISASSEMBLY | 03-03-11 |
| INSPECTION | 03-03-11 |
| ASSEMBLY..... | 03-03-11 |


Section 03 ENGINE
Sub-Section 01 (TABLE OF CONTENTS)

| | |
|---|----------------|
| LEAK TEST AND ENGINE DIMENSION MEASUREMENT | 03-04-1 |
| LEAK TEST..... | 03-04-1 |
| PREPARATION | 03-04-1 |
| PROCEDURE..... | 03-04-1 |
| FINALIZING REASSEMBLY | 03-04-4 |
| COOLING SYSTEM LEAK TEST | 03-04-4 |
| ENGINE DIMENSION MEASUREMENT | 03-04-5 |
| CYLINDER TAPER..... | 03-04-5 |
| CYLINDER OUT OF ROUND..... | 03-04-5 |
| CYLINDER / PISTON CLEARANCE | 03-04-5 |
| RING / PISTON GROOVE CLEARANCE | 03-04-6 |
| RING END GAP..... | 03-04-6 |
| CRANKSHAFT DEFLECTION | 03-04-6 |
| CONNECTING ROD BIG END AXIAL PLAY | 03-04-7 |
| CONNECTING ROD / PISTON PIN CLEARANCE..... | 03-04-7 |
| CONNECTING ROD / CRANKPIN CLEARANCE..... | 03-04-8 |
| CRANKSHAFT END-PLAY | 03-04-8 |
| CHECKING SURFACE FLATNESS | 03-04-10 |
| RECTIFYING SURFACES..... | 03-04-10 |
| CHECKING CRANKSHAFT ALIGNMENT | 03-04-10 |
| CDI SYSTEM..... | 03-05-1 |
| NIPPONDENSO IGNITION SYSTEM WITH SINGLE GENERATING COIL..... | 03-05-1 |
| CLEANING | 03-05-2 |
| DISASSEMBLY | 03-05-2 |
| REPAIR | 03-05-2 |
| ASSEMBLY | 03-05-4 |
| DUCATI IGNITION SYSTEM | 03-05-5 |
| CLEANING | 03-05-6 |
| DISASSEMBLY | 03-05-6 |
| REPAIR | 03-05-6 |
| ASSEMBLY | 03-05-7 |
| OIL INJECTION SYSTEM..... | 03-06-1 |
| OIL INJECTION PUMP | 03-06-1 |
| OIL PUMP IDENTIFICATION | 03-06-3 |
| CLEANING | 03-06-3 |
| DISASSEMBLY | 03-06-3 |
| ASSEMBLY | 03-06-3 |
| ADJUSTMENT..... | 03-06-3 |
| CHECKING OPERATION | 03-06-4 |

| | |
|---|----------------|
| AXIAL FAN COOLING SYSTEM | 03-07-1 |
| REMOVAL | 03-07-2 |
| CLEANING | 03-07-2 |
| DISASSEMBLY AND ASSEMBLY | 03-07-2 |
| REWIND STARTER | 03-08-1 |
| REMOVAL | 03-08-3 |
| DISASSEMBLY | 03-08-3 |
| ASSEMBLY | 03-08-3 |
| INSTALLATION | 03-08-4 |
| CARBURETOR AND FUEL PUMP | 03-09-1 |
| REMOVAL | 03-09-2 |
| CLEANING AND INSPECTION | 03-09-2 |
| IDENTIFICATION | 03-09-2 |
| DISASSEMBLY AND ASSEMBLY | 03-09-2 |
| CARBURETOR FLOAT LEVEL ADJUSTMENT | 03-09-3 |
| INSTALLATION | 03-09-4 |
| CARBURETOR ADJUSTMENTS | 03-09-5 |
| PRELIMINARY IDLE SPEED ADJUSTMENT | 03-09-7 |
| IDLE SPEED FINAL ADJUSTMENT | 03-09-7 |
| CHOKE | 03-09-8 |
| FUEL PUMP | 03-09-9 |
| REMOVAL | 03-09-10 |
| PUMP VERIFICATION | 03-09-10 |
| DISASSEMBLY | 03-09-10 |
| CLEANING AND INSPECTION | 03-09-10 |
| ASSEMBLY | 03-09-11 |
| INSTALLATION | 03-09-11 |
| FUEL TANK AND THROTTLE CABLE | 03-10-1 |

277 ENGINE TYPE

ENGINE REMOVAL AND INSTALLATION



REMOVAL FROM VEHICLE

Remove or disconnect the following then lift engine from vehicle :

- belt guard
- drive belt
- muffler
- carburetor
- oil injection pump cable
- oil injection inlet fitting
- impulse line
- electrical connectors
- hood retaining cable
- engine mount nuts

ENGINE SUPPORT AND MUFFLER DISASSEMBLY AND ASSEMBLY

Torque the manifold screws **no. 16** to 25 N•m (18 lbf•ft).

Torque the engine support screws **nos. 4** and **10** to 48 N•m (35 lbf•ft).


Torque the engine mount screws to 21 N•m (15 lbf•ft).

INSTALLATION ON VEHICLE

To install engine on vehicle, reverse removal procedure. However, pay attention to the following :

- Check tightness of engine mount nuts, and drive pulley screw.
- After throttle cable installation, check maximum throttle slide opening.
- Check pulley alignment and drive belt tension.
- Should a light exhaust leak is experienced at muffler ball joint, Dow Corning sealer no. 736 RTV (P / N 413 7092 00) can be used.

TOP END



TROUBLESHOOTING

Before completely disassemble engine, check airtightness. Refer to LEAK TEST AND ENGINE DIMENSION MEASUREMENT 03-04.

○ **NOTE :** The following procedures can be done without removing the engine from chassis.

TOP END REMOVAL (without removing engine from chassis)

Remove the following then lift cylinder head **no. 3** and cylinder **no. 4** :

- belt guard
- carburetor
- exhaust system
- spark plug
- oil injection inlet
- fan cowl and hood cable
- cylinder head nuts **no. 1** and washers **no. 2**

CLEANING

Discard all gaskets.

Clean all metal components in a non-ferrous metal cleaner.

Scrape off carbon formation from cylinder exhaust port, cylinder head and piston dome using a wooden spatula.

○ **NOTE :** The letters "AUS" (over an arrow on the piston dome) must be visible after cleaning.

Clean the piston ring grooves with a groove cleaner tool, or with a piece of broken ring.

DISASSEMBLY


5, Piston

On this engine, piston pin needle bearing **no. 6** is mounted without a cage.

Use piston pin puller (P / N 529 0210 00) along with expansion sleeve and locating sleeve.


Place a clean cloth or rubber pad (P / N 529 0234 00) over crankcase to prevent circlips **no. 8** from falling into crankcase. Then with a pointed tool inserted in piston notch, remove circlips from piston **no. 5**.

Insert piston pin puller (P / N 529 0210 00) then install expansion sleeve over puller rod.



1. Expansion sleeve

Pull out piston pin **no. 7** by unscrewing puller until first thread of puller rod aligns with 277 mark.




1. 277 mark on puller

Screw in puller in order to remove it from piston.

Remove piston from connecting rod.

Install locating sleeve. Then push needle bearings along with thrust washers using a 21 mm (.826 in) diameter pusher.



1. Pusher 21mm (.826 in)

NOTE : 0.25 and 0.5 mm oversize pistons and rings are available if necessary.


Use a locking tie to fasten all needles and thrust washers along with sleeves.

INSPECTION

Refer to LEAK TEST AND ENGINE DIMENSIONS MEASUREMENT 03-04.


ASSEMBLY

When reinstalling original needle bearings, make sure that 31 needles are inserted between expansion sleeve and locating sleeve.




1. Expansion sleeve
2. 31 needles
3. Locating sleeves

- Grease thrust washers and install them on each end of needles.
- Using a 21 mm (.826 in) diameter pusher, insert needles into connecting rod.




Mount piston over connecting rod with the letters "AUS" (over an arrow on the piston dome) facing in the direction of exhaust port.



1. Exhaust

Install piston pin puller (P / N 529 0210 00) and turn handle until piston pin is correctly positioned in piston.




Remove piston pin puller and expansion sleeve.

Section 03 ENGINE


Sub-Section 02 (277 ENGINE TYPE)

When installing new needle bearing, insert needles with thrust washers. Instead of expansion sleeve, needles are held in place by 2 inner plastic cage halves.


Use piston pin puller (P / N 529 0210 00) to insert piston pin. Plastic halves should come off piston. If not, pull them using a long nose pliers.



To minimize the effect of acceleration forces on circlip, install each circlip so the circlip break is at 6 o'clock as illustrated. Use piston circlip installer (P / N 529 0169 00).



1. Place circlip in
2. Restrain
3. Oil




1. Piston notch
2. Circlip break

CAUTION : Circlips must not move freely in the groove after installation. If so, replace them.

Before inserting piston in the cylinder, lubricate the cylinder with new injection oil or equivalent.

Position cylinder head on cylinder with fins in line with crankshaft center line. Cross torque retaining nuts to 26 N•m (19 lbf•ft) for 277 engine type.

BOTTOM END



Section 03 ENGINE

Sub-Section 02 (277 ENGINE TYPE)

NOTE : Engine must be removed from chassis to perform the following procedures.

CLEANING

Discard all oil seals and gaskets.

Clean all metal components in a non-ferrous metal cleaner.

DISASSEMBLY


General

To remove drive pulley, refer to DRIVE PULLEY 04-03.

To remove magneto, refer to MAGNETO 03-05.


2,6, Crankcase Half

Heat to 110-120°C (230-248°F) all around bearing seat on PTO side. Install puller (P / N 420 8762 98) to plate (P / N 529 0249 00) with washer under screw heads and extract PTO side crankcase half **no. 1**.



1. Plate
2. Flat washer


Heat to 110-120°C (230-248°F) all around bearing seat on MAG side. Install puller with plate, long bolts M8 x 110 mm and flat washers. Extract MAG side crankcase half **no. 2**.



1. Plate
2. Flat washers

To remove seals **nos. 3** and **4**, push from outside the crankcase towards the inside.

To remove bearings **nos. 5** and **6** from crankshaft use a protective cap and special puller as illustrated.



1. Protective cap
2. Special puller

INSPECTION

Refer to ENGINE DIMENSIONS MEASUREMENT 03-04.

ASSEMBLY


Smear anti-seize lubricant (P / N 413 7010 00) on part of crankshaft where bearing fits.

Prior to installation, place bearings into an oil container and heat the oil to 75°C (167°F) for 5 to 10 min. This will expand bearings and ease installation.

Install bearings with groove outward.

NOTE : Crankshaft end play requires adjustment only when crankshaft and / or crankcase is replaced. Prior to magneto side bearing installation, determine crankshaft end play and install required shim(s) on crankshaft extension. For the crankshaft end play adjustment procedure, refer to LEAK TEST AND ENGINE DIMENSION MEASUREMENT 03-04.

To install new seal **nos. 3 and 4** into crankcase use oil seal pusher (P / N 420 9779 20).




1. Crankcase half

Prior to crankcase adjoining, install a protector sleeve on each crankshaft extension to prevent oil seal damage. Apply a light coat of lithium grease on seal lip. Spray some new injection oil on all moving parts of the crankshaft.


Install crankshaft seals with pusher (P / N 420 2778 75) for MAG side seal **no. 4** and (P / N 420 8766 60) for PTO side seal **no. 3**.

CAUTION : To ensure appropriate crankshaft bearing lubrication, seal outer surface must be pressed on seal crankcase shoulder.

Using a press, install crankshaft into MAG side crankcase half.




Press down PTO side crankcase half onto crankshaft using appropriate spacer(s).



Section 03 ENGINE

Sub-Section 02 (277 ENGINE TYPE)


Torque the screws **no. 7** to 22 N•m (16 lbf•ft) following illustrated sequence.



377, 443 AND 503 ENGINE TYPES


ENGINE REMOVAL AND INSTALLATION

377 and 443 Engine Types



Section 03 ENGINE
Sub-Section 03 (377, 443 AND 503 ENGINE TYPES)

503 Engine Type



A03C13S

ENGINE REMOVAL AND INSTALLATION

Disconnect or remove the following :


◆ **WARNING :** Before disconnecting any electrical wire in starter system always first disconnect the **BLACK** negative battery cable (on electric starting models).

- negative cable from battery (on electric starting models)
- belt guard
- drive belt
- drive pulley using appropriate puller, refer to 04-03 DRIVE PULLEY
- air silencer and carburetors
- impulse line from engine crankcase
- 4-connector housing
- exhaust pipe and exhaust cooling hose on so equipped models
- oil pump inlet tube and plug it
- oil pump cable

TUNED PIPE IDENTIFICATION


This part is identified on welded support.

Second number sequence of P / N is stamped on part.



1. Identification : 0467 for 514 0467 00

TOP END



A23C05S

○ **NOTE :** The following procedures can be done without removing the engine from chassis.

CLEANING

Discard all gaskets. Use Gasket Remover (P / N 413 7085 00) to clean mating surfaces.

Clean all metal components in a non-ferrous metal cleaner.

Scrape off carbon formation from cylinder exhaust port, cylinder head and piston dome using a wooden spatula.

○ **NOTE :** The letters "AUS" and arrow on the piston dome must be visible after cleaning.

Clean the piston ring grooves with a groove cleaner tool, or with a piece of broken ring.

DISASSEMBLY

Remove top fan cowl, intake sockets and lower fan cowl.


Remove cylinder heads.

All Engines Except 503

Place a clean cloth over crankcase to prevent circlips **no. 10** from falling into crankcase. Then with a pointed tool inserted in piston notch, remove circlip from piston **no. 8**.

To remove piston pin **no. 9**, use piston pin puller (P / N 529 0210 00) as follows :

- Fully screw puller handle.
- Insert puller end into piston pin.
- Screw (LH threads) extracting nut.
- Hold puller firmly and rotate puller handle counterclockwise to pull piston pin.




○ **NOTE :** The PTO cylinder or fan housing have to be removed to give access to MAG piston pin with the puller.

503 Engine

On these 503 engines, piston pin needle bearing is mounted without a cage.


Use piston pin puller (P / N 529 0210 00) along with expansion sleeve and locating sleeve.

- Place a clean cloth or rubber pad (P / N 529 0234 00) over crankcase to prevent circlips from falling into crankcase. Then with a pointed tool inserted in piston notch, remove piston circlip on side where piston pin puller will be inserted.
- Insert piston pin puller (P / N 529 0210 00) then install expansion sleeve over puller rod.



1. Expansion sleeve

- Pull out piston pin by unscrewing puller until first thread of puller rod aligns with 503 mark.




1. 503 mark on puller

Section 03 ENGINE

Sub-Section 03 (377, 443 AND 503 ENGINE TYPES)

- Screw in puller in order to remove it from piston.
- Remove piston from connecting rod.
- Install locating sleeve. Then push needle bearings along with thrust washers using a 21 mm (.826 in) diameter pusher.



1. Pusher 21 mm (.826)

NOTE : 0.25 and 0.5 mm oversized piston and rings are available if necessary.

Use a locking tie to fasten all needles and thrust washers along with sleeves.


INSPECTION

Refer to ENGINE DIMENSIONS MEASUREMENT 03-04.

ASSEMBLY


503 Engine

When reinstalling original needle bearings, make sure that 31 needles are inserted between expansion sleeve and locating sleeve.




- 1. Expansion sleeve
- 2. 31 needles
- 3. Locating sleeve


- Grease thrust washers and install them on each end of needles.
- Using a 21 mm (.826 in) diameter pusher, insert needles into connecting rod.




- Mount piston over connecting rod with the letters "AUS" (over an arrow on the piston dome) facing in the direction of exhaust port (see illustration below).
- Install piston pin puller (P / N 529 0210 00) and turn handle until piston pin is correctly positioned in piston.



- Remove piston pin puller and expansion sleeve.
- Install circlips as described below.
- When installing new needle bearing, insert needles with thrust washers. Instead of expansion sleeve, needles are held in place by 2 inner plastic cage halves.
- Use piston pin puller (P / N 529 0210 00) to insert piston pin. Plastic halves should come off piston. If not, pull them out using long nose pliers.




- Install circlips as described below.
- At assembly, place the pistons over the connecting rods with the letters "AUS" (over an arrow on the piston dome) facing in the direction of the exhaust port.



1. Exhaust

All Engines Except 503


To center the piston pin with the connecting rod bearing, use centering tool (P / N 529 0091 00).



NOTE : The circlip on the opposite side can be installed before pin installation, the tool will easily go out.


All Models

To minimize the effect of acceleration forces on circlip, install each circlip so the circlip break is at 6 o'clock as illustrated. Use piston circlip installer (P / N 529 0169 00).



1. Place circlip in
2. Restrain
3. Oil

Section 03 ENGINE
Sub-Section 03 (377, 443 AND 503 ENGINE TYPES)



1. Piston notch
2. Circlip break at 6 o'clock

▼ **CAUTION :** Circlips must not move freely in the groove after installation. If so, replace them.

○ **NOTE :** Be sure to restore the chamfer around all cylinder sleeve port openings.

Before inserting piston in cylinder **no. 4**, lubricate the cylinder with new injection oil or equivalent.

Install proper ring compressor on piston assembly.



| ENGINE TYPE | RING COMPRESSOR P / N |
|-------------|--------------------------|
| 377 | 420 8760 90 |
| 503 | 420 8769 70 |

○ **NOTE :** The ring compressor will not fit on over size pistons.

Check flatness of intake sockets **no. 6**. Refer to ENGINE DIMENSION MEASUREMENT 03-04 and look for **checking surface flatness**.


At cylinder **no. 4** and / or cylinder head **no. 3** installation, use aligning tool or exhaust manifold itself to ensure sealing of intake manifold and exhaust before tightening cylinder head nuts.

| ENGINE TYPE | ALIGNING TOOL P / N |
|------------------|------------------------|
| 377, 443 and 503 | 420 8761 71 |




1. Or use exhaust manifold to align cylinders

Position distance nuts **no. 2** as illustrated.



377 ENGINE TYPE

- 1. Exhaust
- 2. Distance nuts



503 ENGINE TYPE

- 1. Distance nuts


Cross torque cylinder head nuts **nos. 1** and **2** to 22 N•m (16 lbf•ft) ; torque each cylinder head individually.

Install armature plate, fan housing and then air deflector.

Install a gasket on each side of the air deflector.

Torque intake socket bolts to 22 N•m (16 lbf•ft).

BOTTOM END



NOTE : Engine must be removed from chassis to perform the following procedures.

Remove engine from chassis.

Remove fan guard, rewind starter, starting pulley, trigger coil wire from 4-connector housing, magneto flywheel then fan housing.

Remove stator plate.

CLEANING

Discard all seals, gaskets and O-rings.

Clean all metal components in a non-ferrous metal cleaner. Use gasket remover (P / N 413 7085 00) accordingly.


Remove all trace of Loctite 242 from crankshaft taper.

Remove old sealant from crankcase mating surfaces with Bombardier gasket remover (P / N 413 7085 00).

CAUTION : Never use a sharp object to scrape away old sealant as score marks incurred are detrimental to crankcase sealing.

DISASSEMBLY

To remove bearings nos. 3 and 4 from crankshaft, use a protective cap and a special puller, as illustrated.



- 1. PTO side
- 2. MAG side

INSPECTION


Refer to ENGINE DIMENSIONS MEASUREMENT 03-04.

ASSEMBLY

Smear anti-seize lubricant (P / N 413 7010 00) on part of crankshaft where bearing fits.

To check proper clearance between bearing no. 3 and counterweight, use feeler gauge (P / N 420 8766 20).

Mount second bearing with distance gauge (P / N 420 8768 22) for 377 and 443 and (P / N 420 8768 24) for 503 for proper positioning.




- 1. Feeler gauge
- 2. Distance gauge

Prior to installation, place bearings into an oil container filled with oil heated to 75°C (167°F).

This will expand bearings and ease installation. Install bearings with groove as per exploded view.

Bearings are pressed on crankshaft until they rest against radius. These radius maintain the gap needed for bearings lubrication.

When installing crankshaft, position drive pins no. 10 as illustrated.



- 1. Drive pins


At seal no. 2 assembly, apply a light coat of lithium grease on seal lip.

Section 03 ENGINE

Sub-Section 03 (377, 443 AND 503 ENGINE TYPES)

For bearing lubrication purpose, a gap of 1.0 mm (.040 in) must be maintained between seals and bearings.

When installing plain oil seals (seal without locating ring or without spacing legs), ensure to maintain 1.0 mm (.040 in) gap.



- 1. Bearing
- 2. Feeler gauge
- 3. Plain oil seal
- A. 1 mm (.040 in)

Crankcase halves **nos. 1 and 9** are factory matched and therefore, are not interchangeable as single halves.

Prior to joining of crankcase halves, spray some new injection oil (or equivalent) on all moving parts of the crankshaft. Spray Primer N (P / N 413 7081 00) on one of mating surfaces. Let it dry for 10 to 20 minutes.


Apply paste gasket (P / N 413 7027 00) **no. 5** on the other mating surface.

NOTE : Primer N allows Loctite 515 to fully cure on aluminum surfaces. It increases filling capacity and reduce curing time.

Position the crankcase halves together and tighten bolts by hand then install and tighten armature plate on magneto side to correctly align the crankcase halves.


503 Engine Type

Torque screws **nos. 6, 7, 8 and 11** to 22 N•m (16 lbf•ft) following illustrated sequence.



377 and 443 Engines

Torque screws to proper torque in the following sequence.



- A. 10 N•m (89 lbf•in)
- All the other screws are torqued to 21 N•m (15 lbf•ft)

All Engines

To install magneto, refer to CDI MAGNETO 03-05.

LEAK TEST AND ENGINE DIMENSION MEASUREMENT

LEAK TEST

The following gives verification procedures for liquid cooled engines though it also applies to fan cooled engines. For FC engines, do not consider information pertaining to coolant system and crankcase rotary valve gear reservoir / components.

On twin-cylinder engines, each cylinder can not be verified individually due to leakage from one cylinder to the other through rotary valve (except on engines with separate intake manifolds). Besides, on FC engines, leak will occur through labyrinth sleeve in center of crankshaft.

PREPARATION

1. Remove tuned pipe / muffler and exhaust manifold.
2. Install plug(s) over exhaust flange(s). Tighten with previously removed screws.
3. On engines with RAVE system, remove RAVE valves and install plugs over flanges. Tighten with previously removed screws.
4. Remove carburetor(s).
5. Insert plug(s) in intake rubber boot(s). Tighten with clamps already there.
6. Using a hose pincher(s) (P / N 529 0099 00), block impulse hose(s).

○ **NOTE** : Do not block large hoses of rotary valve gear lubrication system.

7. Install air pump on any valve of exhaust plug.

○ **NOTE** : If necessary, lubricate air pump piston with mild soap.

▼ **CAUTION** : Using hydrocarbon lubricant (such as engine oil) will damage rubber seal of pump piston.

8. Rotate crankshaft so that piston goes to B.D.C. (Bottom Dead Center) on side where the pump is installed. This will open exhaust port.
9. Activate pump and pressurize engine to 34 kPa (5 PSI). Do not exceed this pressure.

10. Engine must stand this pressure during 3 minutes. If pressure drops before 3 minutes, check tester kit by spraying a soapy solution on pump piston, all plugs and fittings.

–If tester kit is leaking, bubbles will indicate where leak comes from.

–If tester kit is not leaking, check engine as per following procedure.

PROCEDURE

○ **NOTE** : A flow chart has been prepared as a visual reference. See last page of sub-section ENGINE 03-01.

Using flow chart and following text, pressurize area to be tested and spray soapy solution at the indicated location.

**TEST PRESSURE : 34kPa (5 PSI)
for 3 minutes**


–If there is a leak at the tested location, it is recommended to continue testing next items before overhauling engine. There is a possibility of more than one leak.

–If there is no leak at the tested location, continue pumping to maintain pressure and continue with next items until leak is found.

Section 03 ENGINE

Sub-Section 04 (LEAK TEST AND ENGINE DIMENSION MEASUREMENT)


Engine



TYPICAL

1. Blocked intake flanges
2. Blocked impulse fitting
3. Open ends (if applicable)
4. Blocked RAVE valve flanges (if applicable)
5. Blocked exhaust flanges

When exhaust manifold is installed, use rubber plug. (In this case it is not necessary to move piston to B.D.C.).




1. Rubber Plug

Check the following :

1. All jointed surfaces and screw / stud threads of engine :

- spark plug base, insulator
- cylinder head
- cylinder base
- crankcase halves (joint)
- rotary valve cover
- oil injection pump mounting flange (O-ring, seal)
- coolant pump housing
- bleed screws / plugs

2. Small injection oil lines coming from pump.




1. Banjo fittings
2. Small injection oil lines

Check for air bubbles or oil column going toward pump. It indicates defective check valve in banjo fitting (or lines).

3. Remove cooling system cap.

Check for air bubbles in antifreeze. It indicates defective cylinder head O-ring or cylinder base gasket.

4. Block both hoses of rotary valve gear lubrication system with hose pinchers.



1. Block both hoses


If leakage stops, ignore remaining items and check crankcase rotary valve gear reservoir as per **Crankcase Rotary Valve Gear Reservoir** of this section.

5. Remove clutch then check crankshaft outer seal.
6. Remove rewind starter and magneto system then check crankshaft outer seal.
7. Check crankcase rotary valve gear reservoir.

Crankcase Rotary Valve Gear Reservoir

Block one hose of rotary valve gear lubrication system with a hose pincher and install an adapter in remaining hose.

Install air pump on adapter and pressurize as before.



1. Blocked hose


1. Remove a spark plug or any plug of leak tester kit on PTO side.

If pressure drops, it indicates defective crankshaft inner seal on PTO side.

2. Remove a spark plug or any plug of leak tester kit on MAG side.


If pressure drops, it indicates defective crankshaft inner seal on MAG side.

3. Check drain hole below coolant pump housing with soapy water.



1. Drain hole

If there is a leak, it indicates defective seal of rotary valve shaft (oil seal beside coolant seal).




1. Oil seal

Section 03 ENGINE

Sub-Section 04 (LEAK TEST AND ENGINE DIMENSION MEASUREMENT)

4. Remove rotary valve cover and check for leak of rotary valve seal with soapy water.



1. Seal

5. If leak still persists, it indicates a defective casting somewhere in engine.

Disassemble engine and carefully check for defects in castings. Pay attention to tapped holes which may go through engine sealed area and thus leading to leakage.


FINALIZING REASSEMBLY

After reassembling engine, always recheck for leakage.

COOLING SYSTEM LEAK TEST

Install special plug (radiator cap) (P/N 529 0214 00) and hose pincher (P/N 529 0099 00) on overflow hose. Pressurize all system through coolant reservoir to 15 PSI.

Check all hoses and cylinder/base for coolant leaks. Spray a soap/water solution and look for presence of air bubbles.



ENGINE DIMENSION MEASUREMENT

This section covers all engine types.


CYLINDER TAPER

| ENGINE TYPE | MAXIMUM |
|-------------|-------------------|
| All | 0.08 mm (.003 in) |

Compare cylinder diameter 16 mm (5/8 in) from top of cylinder to just below its intake port area.

On rotary valve engines, measure just below auxiliary transfer port, facing exhaust port. If the difference exceeds the specified dimension the cylinder should be rebored and honed or should be replaced.

NOTE : Be sure to restore the chamfer around all cylinder sleeve port openings.




1. Below the intake port
A. 16 mm (5/8 in) from top

CYLINDER OUT OF ROUND

| ENGINE TYPE | MAXIMUM |
|-------------|-------------------|
| All | 0.05 mm (.002 in) |

Measuring 16 mm (5/8 in) from top of cylinder with a cylinder gauge, check if the cylinder out of round is more than the specified dimension. If larger, cylinder should be rebored and honed or should be replaced.

NOTE : Be sure to restore the chamfer around all cylinder sleeve port openings.



1. Piston pin position
2. Measures to be compared
A. 16 mm (5/8 in)

CYLINDER / PISTON CLEARANCE

Measurement (used parts)


Check cylinder taper and out-of-round as described above before proceeding with piston / cylinder clearance.

To accurately determine piston to cylinder clearance, the piston should be measured under the axis hole and 90° to piston pin axis. Find the biggest diameter.

The cylinder should be measured 16 mm (5/8 in) below its top edge. Find the smallest diameter.

Section 03 ENGINE

Sub-Section 04 (LEAK TEST AND ENGINE DIMENSION MEASUREMENT)



A. 16 mm (5/8 in)

The difference between these 2 measurements should be within specified tolerance. Refer to TECHNICAL DATA 09-02.

Measurement (fitting new parts)


With an inside micrometer, measure cylinder diameter above the exhaust port.

With a micrometer, measure the piston diameter perpendicularly (90°) to piston axis and 3 mm (1/8 in) above bottom edge.

The difference of both measurements is the clearance.

RING / PISTON GROOVE CLEARANCE

Using a feeler gauge check clearance between rectangular ring and groove. Replace piston. If clearance exceeds specified tolerance. Refer to TECHNICAL DATA 09-02.




RING END GAP

Position ring half way between transfer ports and intake port. On rotary valve engines, position ring just below transfer ports.

NOTE : In order to correctly position the ring in the cylinder, use piston as a pusher.

Using a feeler gauge, check ring end gap. Replace ring. If gap exceeds specified tolerance, refer to TECHNICAL DATA 09-02.



1. Transfer port
2. Intake port

CRANKSHAFT DEFLECTION


Crankshaft deflection is measured with a dial indicator.

Measuring (In Engine)

First, check deflection with crankshaft in engine. If deflection exceeds the specified tolerance, re-check deflection using V-shaped blocks to determine the defective part(s). See below.

Measuring (On bench)

Once engine is disassembled, check crankshaft deflection on V-shaped blocks. If deflection exceeds the specified tolerance, it can be worn bearings or a bent crankshaft. Remove crankshaft bearings and check deflection again on V-shaped blocks to determine the defective part(s). See measurement A in following illustration.



TYPICAL

1. Measure at mid point between the key and the first thread
A. See table below

Crankshaft Deflection on PTO Side

| ENGINE TYPE | DISTANCE A mm (in) | MAXIMUM ON PTO SIDE mm (in) |
|-------------|-----------------------|--------------------------------|
| 377, 443 | 75.5 (2.972) | 0.05 (.002) |
| 503 | 82.5 (3.248) | 0.06 (.002) |

Crankshaft Deflection on MAG Side

| ENGINE TYPE | MAXIMUM ON MAG SIDE mm (in) |
|-------------|--------------------------------|
| All | 0.03 (.001) |

Crankshaft Deflection in Center of Crankshaft

| ENGINE TYPE | MAXIMUM IN CENTER OF CRANKSHAFT |
|-------------|------------------------------------|
| All | 0.08 mm (.0031 in) |


NOTE : Crankshaft deflection can not be correctly measured between centers of a lathe.

If the deflection exceeds the specified tolerance, crankshaft should be repaired or replaced.

CONNECTING ROD BIG END AXIAL PLAY

| ENGINE TYPE | NEW PARTS MIN. – MAX. | WEAR LIMIT |
|-------------------------|------------------------------------|----------------------|
| 277, 377 443 and 503 | 0.20 – 0.53 mm (.008 – .021 in) | 1.00 mm (.039 in) |


Using a feeler gauge, measure distance between thrust washer and crankshaft counterweight. If the distance exceeds specified tolerance, repair or replace the crankshaft.




TYPICAL

CONNECTING ROD / PISTON PIN CLEARANCE

Measure piston pin with its needle bearing. Compare to inside diameter of connecting rod.





| ENGINE TYPE | NEW PARTS MIN. - MAX. | WEAR LIMIT |
|-------------|-----------------------------------|------------------------|
| All | 0.03-0.012 mm (.0001-.0005 in) | 0.015 mm (.0006 in) |

CONNECTING ROD / CRANKPIN CLEARANCE

| ENGINE TYPE | NEW PARTS MIN. – MAX. | WEAR LIMIT |
|------------------|--|-----------------------|
| 277 | 0.020 – 0.030 mm (.0008 – .0012 in) | 0.05 mm (.0020 in) |
| 377, 443 and 503 | 0.020 – 0.033 mm (.0008 – .0013 in) | |


CRANKSHAFT END-PLAY

277 Engine Type

| ENGINE TYPE | MINIMUM | MAXIMUM |
|-------------|----------------------|----------------------|
| 277 | 0.10 mm (.004 in) | .030 mm (.012 in) |

Adjustment

Crankshaft end-play is adjusted with shims located between crankshaft and magneto side bearing.



- 1. Distance ring
- 2. Shim location
- 3. Bearing
- 4. PTO
- 5. MAG

CAUTION : Always install end-play adjustment shims on the magneto side between bearing and crankshaft counterweight.

The following is required for the adjustment procedure :

- adjustment shims (refer to parts catalog)
thicknesses available : 0.10 mm (.004 in)
0.20 mm (.008 in)
0.30 mm (.012 in)
0.50 mm (.020 in)
1.00 mm (.040 in)

- micrometer
- caliper


Total shim thickness needed for the end-play adjustment is determined with the following procedure :

- a. Measure crankcase halves as illustrated (M₁ and M₂).

A standard compressed crankcase gasket will have a 0.30 mm (.012 in) thickness (M₃). **Add these measurements to obtain dimension A.**

Section 03 ENGINE


Sub-Section 04 (LEAK TEST AND ENGINE DIMENSION MEASUREMENT)



MEASURING M_1 AND M_2

1. Bearing seat


b. Measure the thickness of each bearing (M_4 and M_5).



MEASURING M_4 AND M_5

1. Bearing thickness

c. Measure distance between bearing shoulders on crankshaft (M_6).



MEASURING M_6

d. Measure the distance ring (M_7) and adjustment shims thickness (M_8). Add these measurements to obtain dimension B.

e. From dimension A, subtract dimension B.

The result is the actual crankshaft end-play that must be within specification.

If the result is over specification, add adjustment shim(s) to reach this specification.

If the result is under specification, remove adjustment shim(s) to reach this specification.


To Summarize

$$A = M_1 + M_2 + M_3$$

$$B = M_4 + M_5 + M_6 + M_7 + M_8$$

$A - B$ = Actual end-play that must be within specification.

M_8 is the dimension that must be adjusted to obtain the specified crankshaft end-play.



1. End-play is adjusted with shims

2. PTO

3. MAG

377, 443, 503 Engine Types

End-play is not adjustable but it should be between 0.10 – 0.30 mm (.004 – .012 in).

Section 03 ENGINE

Sub-Section 04 (LEAK TEST AND ENGINE DIMENSION MEASUREMENT)

CHECKING SURFACE FLATNESS

Intake manifold, intake manifold cover, rotary valve cover can be checked for perfectly mating surfaces.

Lay part on a surface plate (marble, mirror or thick glass plate).

Holding down one end of part, try pushing down the other end.


If any play is felt, part must be rectified.

RECTIFYING SURFACES

Stick a fine sand paper sheet on the surface plate then lightly oil the sand paper.

Rub manifold mating surface on sand paper using 8-figure movements.

Sand until mating surface is perfectly straight.



CHECKING CRANKSHAFT ALIGNMENT

Install a degree wheel (P / N 414 3529 00) on crankshaft end.

Remove both spark plugs.


Install a TDC gauge (P/N 414 1047 00) in spark plug hole on MAG side.

Bring MAG piston at top dead center.

Rotate degree wheel (not crankshaft) so that 360° mark aligns with center of crankcase. Scribe a mark on crankcase.

Remove TDC gauge and install it on PTO side.

Bring PTO piston to top dead center.




Interval between cylinders must be exactly 180°. Any other reading indicates a misaligned (twisted) crankshaft.

CDI SYSTEM

NIPPONDENSO IGNITION SYSTEM WITH SINGLE GENERATING COIL

277 Engine



Section 03 ENGINE

Sub-Section 05 (CDI SYSTEM)

○ **NOTE :** The following procedures can be done without removing the engine from chassis.

CLEANING

Clean all metal components in a non-ferrous metal cleaner.

▼ **CAUTION :** Clean armature and magneto using only a clean cloth.

DISASSEMBLY


To gain access to magneto assembly, remove the following parts as needed on different engines :

- tuned pipe and muffler
- oil injection pump mounting plate from rewind starter
- rewind starter
- starting pulley **no. 10** and fan **no. 11**

To remove magneto flywheel retaining nut **no. 13**, install puller ring (P / N 420 8760 80) and M8 x 20 screws.

- Remove magneto flywheel nut, using a 30 mm socket machined to 40 mm (1.580 in) outside diameter by 16 mm (5/8 in) long.


○ **NOTE :** To correctly remove a threadlocked fastener it is first necessary to tap on the fastener to break threadlocker bond. This will eliminate the possibility of thread breakage.



TYPICAL

1. 30 mm socket

To remove magneto flywheel **no. 9**, install the magneto puller (P / N 529 0225 00).



TYPICAL


- Tighten puller bolt and at same time, tap on bolt head using a hammer to release magneto flywheel from its taper.

○ **NOTE :** Before disassembling armature plate, indexing marks should be scribed to facilitate reassembly.

REPAIR

To replace generator coil **no. 2** :


- Heat the armature plate to 93°C (200°F) around the screw holes to break the threadlocker bond.



1. Heat
2. Protect harness from flame

▼ **CAUTION :** Protect harness from flame.

- Remove screws.
- Uncrimp and unsolder BLACK/RED wire from coil terminal.




1. Uncrimp and unsolder wire here

- Strip end of old wire then crimp and solder on new coil.

Apply Loctite 242 (blue) to screws nos. 6 and 8 then install the new coil on armature plate.


Use magneto coil centering tool (P/N 420 8769 22) and install it so that it fits around armature plate before tightening screws.



CAUTION : Before reinstalling the magneto, remove the loose epoxy from harness.

To replace lighting generator coil no. 7 :


- Heat the armature plate to 93°C (200°F) around the screw holes to break the threadlocker bond.



1. Protect harness from flame
2. Heat

CAUTION : Protect harness from flame.

- Remove screws.
- Uncrimp and unsolder YELLOW and YELLOW/BLACK wires from coil terminals.
- Uncrimp and unsolder ground wire (BLACK) from coil core.




1. Uncrimp and unsolder ground wire (BLACK) here
2. Uncrimp and unsolder YELLOW and YELLOW/BLACK wires here

- Position new coil, crimp and solder all wires.
- Prior to assembly, apply Loctite 242 (blue).

Use magneto coil centering tool (P / N 420 8769 22) and install it so that it fits around armature plate before tightening screws.

Section 03 ENGINE

Sub-Section 05 (CDI SYSTEM)



▼ **CAUTION :** Before reinstalling magneto, remove the loose epoxy from harness.

ASSEMBLY

Position the armature plate **no. 1** on the crankcase, aligning the marks on both parts.

Put a drop of Loctite 242 (blue) on screw threads and tighten.

Clean crankshaft extension (taper).

Apply Loctite 242 (blue) on taper.

Position Woodruff key, magneto flywheel **no. 9** and lock washer **no. 12** on crankshaft.

Clean nut threads and apply Loctite 242 (blue) before tightening nut **no. 13**.

Torque nut to 90 N•m (66 lbf•ft).

At reassembly coat all electric connections with silicone dielectric grease (P / N 413 7017 00) to prevent corrosion or moisture penetration.

▼ **CAUTION :** Do not use silicone “sealant”, this product will corrode contacts.


Reinstall fan and starting pulley. Make sure yellow fin of fan is aligned with timing hole when piston is at TDC.

Ignition Timing

Check ignition timing as described in IGNITION TIMING 05-03.

DUCATI IGNITION SYSTEM

377, 443 and 503 Engines



○ **NOTE :** The following procedures can be done without removing the engine from chassis.

CLEANING

Clean all metal components in a non-ferrous metal cleaner.


▼ **CAUTION :** Clean armature and magneto using only a clean cloth.

DISASSEMBLY

To gain access to magneto assembly, remove the following parts as needed on different engines :

- tuned pipe and muffler
- oil injection pump mounting plate from rewind starter
- rewind starter
- starting and V-belt pulleys

○ **NOTE :** Before disassembling armature plate, indexing marks should be scribed to facilitate reassembly.



To remove magneto flywheel retaining nut **no. 3**, install puller ring (P/N 420 8760 80) and M8 x 20 screws.

- Remove magneto flywheel nut, using a 30 mm socket machined to 40 mm (1.580 in) outside diameter by 16 mm (5/8 in) long.

○ **NOTE :** To correctly remove a threadlocked fastener it is first necessary to tap on the fastener to break threadlocker bond. This will eliminate the possibility of thread breakage.

To remove magneto flywheel **no. 2**, install the magneto puller (P/N 529 0225 00).

- Tighten puller bolt and at the same time, tap on bolt head using a hammer to release magneto flywheel from its taper.

REPAIR

To replace generator coil **no. 1** :

- Heat the armature plate to 93°C (200°F) around the screw holes to break the threadlocker bond.

To replace trigger coil **no. 4**:


- Disconnect trigger coil wire (RED).
- Remove grommet from crankcase where trigger coil wire exits magneto housing.
- Remove retaining screws **no. 9**.
- Remove trigger coil and carefully pull wire.
- Install new trigger coil and other parts removed.

Adjustment

Whenever the trigger coil or the magneto flywheel is removed or replaced, the air-gap between the trigger coil and the flywheel protrusion must be checked and adjusted. The purpose of this adjustment is to obtain the minimum clearance between these parts – without touching at any RPM – so that the trigger coil produces its proper electrical output. Ignition timing must also be checked.

Proceed as follows :

1. Rotate flywheel so that one protrusion aligns with trigger coil.
2. Using a feeler gauge of 0.45 mm (.018 in) to 0.55 mm (.022 in) thick, check air-gap between center pole of trigger coil and flywheel protrusion.
3. If necessary, adjust by slackening retaining screws and moving trigger coil toward or away of protrusion.
4. Retighten screws and recheck air-gap.



ADJUSTING TRIGGER COIL AIR-GAP

1. Flywheel protrusion
2. Trigger coil

To replace armature :

- Disconnect the 2-wire connector (GREEN and WHITE wires).
- Disconnect YELLOW/BLACK and YELLOW wires.
- Remove grommet from crankcase where magneto harness exits magneto housing.
- Remove armature plate retaining screws.
- Remove armature plate with armature and carefully pull wires.
- Install new parts and other parts removed.

ASSEMBLY

Clean crankshaft extension (taper).

Apply Loctite 242 (blue) on taper.

Position Woodruff key, flywheel and lock washer on crankshaft.

Clean nut threads and apply Loctite 242 (blue) before tightening nut to 105 N•m (77 lbf•ft).

At reassembly coat all electric connections with silicone dielectric grease (P / N 413 7017 00) to prevent corrosion or moisture penetration.

▼ **CAUTION :** Do not use silicone “sealant”, this product will corrode contacts.


Ignition Timing

Check as described in IGNITION TIMING 05-03.

OIL INJECTION SYSTEM

OIL INJECTION PUMP


277 Engine



A05C07S

Section 03 ENGINE
Sub-Section 06 (OIL INJECTION SYSTEM)

377, 443 and 503 Engines



OIL PUMP IDENTIFICATION

Different engines need different pumps. See identification on pump lever **no. 7**.

▼ **CAUTION** : Always mount proper pump on engine.

| ENGINE TYPE | OIL PUMP IDENTIFICATION |
|-------------|-------------------------|
| 277 | 135 T |
| 377 | L4 |
| 443 | E4 |
| 503 | E4 |

○ **NOTE** : The following procedures can be done without removing the engine from chassis.

CLEANING


Clean all metal components in a non-ferrous metal cleaner.

DISASSEMBLY

○ **NOTE** : Some oil pump components are not available as single parts.

To remove gear retaining nut **no. 1**, first extract the needle roller **no. 4** with pliers then lock gear **no. 2** in place using the following gear holder :

| ENGINE TYPE | TOOL P / N |
|-----------------|-------------|
| 377 / 443 / 503 | 420 8766 95 |



ASSEMBLY

At gear **no. 2** assembly, apply a light coat of low temperature grease (P / N 413 7061 00) on gear teeth.

The needle roller **no. 4** must be engaged as deep as possible in the pump mounting flange.

Always check for spring clips **no. 5** and clamps **no. 6** tightness.

Torque screws **no. 3** to 5 N•m (44 lbf•in).

Make sure cable barrel is well seated in oil pump lever.

Secure barrel with plastic washer and circlip.

Verify cable and oil pump lever operation.

ADJUSTMENT

Prior to adjusting the pump, make sure all carburetor adjustments are completed.


Synchronizing Pump with Carburetor :

Eliminate the throttle cable free-play by pressing the throttle lever until a light resistance is felt, then hold in place. The aligning marks on the pump casting and on the lever must align. If not, loosen the adjuster nut and adjust accordingly.

Section 03 ENGINE

Sub-Section 06 (OIL INJECTION SYSTEM)

Retighten the adjuster nut.



TYPICAL

1. Adjuster nuts
2. Bleeder screw
3. Marks must align


▼ **CAUTION :** Proper oil injection pump adjustment is very important. Any delay in the opening of the pump can result in serious engine damage.

To Bleed Oil Lines :

All oil lines should be full of oil. If required, bleed the main oil line (between tank and pump) by loosening the bleeder screw until all air has escaped from the line.

Make sure the tank is sufficiently filled.

Check the small oil lines (between pump and intake manifold). If required, fill the lines by running the engine at idle speed while holding the pump lever in fully open position.



TYPICAL — ENGINE AT IDLE

1. Fully open position

◆ **WARNING :** Ensure not to operate carburetor throttle mechanism. Secure the rear of the vehicle on a stand.

CHECKING OPERATION


On Vehicle

○ **NOTE :** Main oil line must be full of oil. See bleeding procedure above.

Lift rear of vehicle and support with a mechanical stand. Unbolt banjo fittings from pump. Start engine and stop it as soon as it fires.

Check that oil level in small oil lines is passed banjo fittings end by about 25 mm (1 in) (this will be indicated by a clear section of small oil lines of about 25 mm (1 in)). Repeat the procedure until this condition is attained.

Reconnect banjo fittings with a washers on each side, start engine and run at idle while holding the pump lever in fully open position. Oil columns must advance into small oil lines.



TYPICAL — ENGINE AT IDLE


1. Oil columns advancing
2. Washer on each side
3. Fully open position

If not, remove pump assembly and check the pump gear and drive shaft (if applicable) for defects, replace as necessary. Test pump as describes below.

NOTE : Through normal use, oil level must not drop in small tubes. If oil drops, verify check valve operation in banjo fittings. Replace as necessary.

Oil Pump Test Bench

Connect a hose filled with injection oil to main line fitting. Insert other hose end in an injection oil container. Using a counterclockwise rotating drill rotate pump shaft. Oil must drip from outer holes while holding lever in a fully open position. If not replace pump.




TYPICAL

1. Fully open position
2. Counterclockwise rotating drill
3. Main line

AXIAL FAN COOLING SYSTEM

○ NOTE : For 277 engine radial fan cooling system, refer to 277 engine type 03-02.

377, 443 and 503 Engines



○ NOTE : The following procedures can be done without removing engine from chassis.

REMOVAL

○ NOTE : To facilitate further disassembly, fan nut may be removed before removing fan housing.

Remove rewind starter, starting pulley, trigger coil wire from 4-connector housing then fan housing ass’y.


CLEANING

Clean all metal components in a non-ferrous metal cleaner.

DISASSEMBLY AND ASSEMBLY


Remove fan protector.

To remove or install fan pulley retaining nut no. 17, lock fan pulley with special holder wrench (P / N 420 8763 57). At assembly, torque nut to 65 N•m (48 lbf•ft).




1. Deflection

To adjust tension, add or remove shim(s) no. 15 between pulley halves nos. 14 and 16. Install excess shim(s) between distance sleeve no. 13 and half pulley no. 14 (housing side).



- 1. Unused shim(s) here
- 2. Adjust here
- 3. Positioning noses
- 4. Some engines only

Some engines have a separate metal pulley half instead of using back of fan as pulley half. On first mentioned engines, select pulley halves so that the one with 2 positioning noses will be on fan side. Ensure to insert these noses into fan notches.




TYPICAL


Fan belt deflection must be as specified when applying the proper force midway between pulleys.

| ENGINE TYPE | BELT DEFLECTION | FORCE APPLIED |
|-------------|-------------------|---------------|
| 377, 443 | 8.5 mm (11/32 in) | 5 kg (11 lb) |
| 503 | 9.5 mm (3/8 in) | |

Using a press, drive the fan shaft **no. 9** out.



Support fan housing **no. 12** with a ring. With a punch, working all around bearing **no. 10** inner race, drive bearing out of fan housing. Keep shims for installation.



1. Ring supporting fan housing

Remove circlip **no. 11** then remaining bearing.

To install, press one bearing in place then install circlip and shims. Press the other bearing from opposite side until it is flush with housing. Press fan shaft from engine side of fan housing. Check for free rolling action.

At assembly, apply a light coat of Loctite 242 (blue) on screw **no. 1** threads.


A gasket must be placed on both sides (inner and outer) of intake and exhaust holes of cylinder cowl **nos. 4 and 5**.

Reinstall fan protector **no. 18** properly.

◆ **WARNING :** Always reinstall fan protector after servicing.


REWIND STARTER

277, 377, 443 and 503 Touring SLE



Section 03 ENGINE
Sub-Section 08 (REWIND STARTER)

503 Skandic 500 and Formula SL



REMOVAL

Using a small screwdriver, extract rope knot from starter grip **no. 15**. Cut rope close to knot. Tie a knot near starter.


Remove screws **no. 3** and washers **no. 2** securing rewind starter **no. 1** to engine then remove rewind starter.

On fan cooled models with oil injection pump remove pump from rewind starter cover.

DISASSEMBLY

To remove rope from rewind starter mechanism :

- First remove locking ring **no. 12**, locking spring **no. 11**, circlip **no. 10**, pawl lock **no. 9** and pawl **no. 8**.
- Remove sheave **no. 5** from starter housing **no. 1**.
- Disengage key **no. 7** and pull out rope **no. 6**.




GENTLY TAP ON KEY

ASSEMBLY

At assembly, position spring **no. 4** outer end into spring guide notch then wind the spring counter-clockwise into guide.

◆ **WARNING** : Since the spring is tightly wound inside the guide it may fly out when rewind is handled. Always handle with care.




1. Outer end into guide notch

○ **NOTE** : Due to dust accumulation, rewind starter must be periodically cleaned, inspected and relubricated.

▼ **CAUTION** : It is of the utmost importance that the rewind starter spring(s) be lubricated periodically using specific lubricants. Otherwise, rewind starter component life will be shortened and / or rewind starter will not operate properly under very cold temperatures.

Lubricate spring assembly with silicone compound grease (P / N 420 8970 61) and position into starter housing as illustrated.

▼ **CAUTION** : This lubricant must NOT be used on rewind starter locking spring as it does not stay on under vibration.




1. Grease inside spring guide

Section 03 ENGINE

Sub-Section 08 (REWIND STARTER)

▼ **CAUTION :** The use of standard multi-purpose grease could result in rewind starter malfunction.

To install a new rope **no. 6** : insert rope into sheave **no. 5** orifice and lock it with the key **no. 7** as illustrated.




1. Push to lock

To adjust rope tension :

Wind rope on sheave and place rope sheave into starter housing making sure that the sheave hub notch engages in the rewind spring hook.


Rotate the sheave counterclockwise until rope end is accessible through starter housing orifice.

Pull the rope out of the starter housing and temporarily make a knot to hold it. One turn preload will give 7 turns of tension when fully extended.



Position pawl **no. 8**, pawl lock **no. 9** and circlip **no. 10**.

Install locking spring **no. 11** and lubricate with MOLYKOTE G-n paste from Dow Corning® or equivalent.



1. Spring coated with MOLYKOTE G-n paste

Install locking ring.


▼ **CAUTION :** This lubricant must NOT be used on rewind springs as it does not stay on when dry.

INSTALLATION


On fan cooled models with oil injection pump, re-install oil pump on rewind starter assembly.

Reinstall rewind starter assembly on engine.

Thread starter rope **no. 6** through rope guide when applicable.




Prior to installing starter grip **no. 15** on new rope, it is first necessary to fuse the rope end with a lit match. pass rope through rubber buffer **no. 14** and starter grip and tie a knot in the rope end. fuse the knot with a lit match then insert rope end down and pull the starter grip over the knot.



TYPICAL

CARBURETOR AND FUEL PUMP

Carburetors VM 30-190
VM 34-443
VM 34-467
VM 34-481
VM 34-482



A15C2AS

REMOVAL

Remove air silencer(s). For S-Series, see BATTERY 05-05.

Disconnect fuel inlet line.

Disconnect primer line from carburetor on some models.

Disconnect choke cable on some models.

Unscrew carburetor cover **no. 1** then pull out throttle slide **no. 5** from carburetor.

◆ **WARNING :** Exercise care when handling throttle slide. Scratches incurred may cause throttle slide to stick open in operation.

Disconnect throttle cable from throttle slide.

Untighten rubber flange clamps then remove carburetor from engine.

CLEANING AND INSPECTION

The entire carburetor should be cleaned with a general solvent and dried with compressed air before disassembly.

▼ **CAUTION :** Heavy duty carburetor cleaner may be harmful to the float material and to the rubber parts, O-rings, etc. Therefore, it is recommended to remove those parts prior to cleaning.

Carburetor body and jets should be cleaned in a carburetor cleaner following manufacturer's instructions.

◆ **WARNING :** Solvent with a low flash point such as gasoline, naphtha, benzol, etc., should not be used as they are flammable and explosive.

Check inlet needle tip condition. If worn, the inlet needle and seat must be replaced as a matched set.


○ **NOTE :** Install needle valve for snowmobile carburetor only. It is designed to operate with a fuel pump system.

Check throttle slide for wear. Replace as necessary.

Check idle speed screw straightness. Replace as necessary.

IDENTIFICATION

All carburetors are identified on their body.



1. Identification : 34-482


Check for fuel inside float **no. 12**.

If fuel is noticed :

- Check cap **no. 11** for fuel tightness ; replace as necessary.
- Check float for cracks or other damage affecting fuel tightness; replace as necessary.

DISASSEMBLY AND ASSEMBLY

○ **NOTE :** To ease the carburetor disassembly and assembly procedures it is recommended to use carburetor tool kit (P / N 404 1120 00).



2,3, E-clip and Needle

Remove screws from needle retaining plate to withdraw the needle.


The position of the needle in the throttle slide is adjustable by means of an E-clip inserted into 1 of 5 grooves located on the upper part of the needle. Position 1 (at top) is the leanest, 5 (at bottom) the richest.

NOTE : The last digit of the needle identification number gives the recommended position of the E-clip **from the top** of the needle.

Example : **6DH4-3**


Needle identification

Recommended position of the E-clip **from top**



CLIP POSITIONS

The size of the throttle slide cut-away affects the fuel mixture between 1/8 to 1/2 throttle opening.



1. Low cut-away (high air speed)
2. Rich mixture
3. High cut-away (low air speed)
4. Lean mixture

8, Main Jet


The main jet installed in the carburetor has been selected for a temperature of -20°C (0°F) at sea level. Different jetting can be installed to suit temperature and / or altitude changes. Always check spark plug tip and / or piston dome color to find out correct jetting.

CARBURETOR FLOAT LEVEL ADJUSTMENT

9,10, Float Arm and Float Arm Pin


Correct fuel level in float chamber is vital toward maximum engine efficiency. To check for correct float level proceed as follows :

- Make sure that float arm is symmetric — not distorted.
- Remove float bowl and gasket from carburetor.
- With carburetor chamber upside-down on a level surface, measure height H between bowl seat and top edge of float arm. Keep ruler perfectly vertical and in line with main jet hole.



TYPICAL

H : Float height




1. Ruler vertical and in line with main jet

| CARBURETOR MODEL | FLOAT HEIGHT H | |
|---------------------|----------------|-------------|
| | ± 1 mm | (± .040 in) |
| VM 30 VM 34 | 23.9 | (.941) |

To Adjust Height H :


- Bend the contact tab of float arm until the specified height is reached.



1. Contact tab

The following illustration shows the part of the carburetor which begins and stops to function at different throttle slide openings.

Note that the wider part of symbol corresponds to the opening mostly affected. For instance, throttle slide cut-away begins to function at closed position but it is most effective at 1/4 opening and decreases up to 1/2 opening.



VIEW FROM AIR INTAKE OPENING

- **NOTE :** For fine tuning refer to TECHNICAL DATA 09 and to SPARK PLUG 05-03.
- **NOTE :** For high altitude regions, the High Altitude Technical Data Booklet (P / N 484 0648 00 and 484 0545 00 for binder) gives information about calibration according to altitude and temperature.

INSTALLATION

- ▼ **CAUTION :** Never allow throttle slide(s) to snap shut.

To install carburetor on engine, inverse removal procedure.

However, pay attention to the following :

- Inspect throttle cable and housing prior to installation.

On applicable models, make sure to align tab of carburetor and air intake silencer (if applicable) with notch of adaptor(s). On applicable models, install adaptor with up mark facing up.


- ▼ **CAUTION :** The rubber flange must be checked for cracks and/or damage. At assembly, the flange must be perfectly matched with the air intake manifold or severe engine damage will occur.

Install clamps in a way that their tightening bolts are staggered — not aligned.

Hook throttle cable into the needle retainer plate.

- **NOTE :** Do not obstruct hole in throttle slide when installing needle retaining plate. This is important to allow air escaping through and thus allowing a quick response.

CARBURETOR ADJUSTMENTS




CENTER POST TYPE

1. Throttle cable
2. Needle retaining plate
3. Throttle slide


Make sure the nylon packing no. 4 is installed on all applicable throttle slides.

▼ **CAUTION : Serious engine damage can occur if this notice is disregarded.**



CENTER POST TYPE

1. E-clip
2. Needle retaining plate
3. Screw
4. Needle
5. Nylon packing



1. Idle speed screw
2. Air screw

6, Air Screw Adjustment

Completely close the **air screw** (until a slight seating resistance is felt) then back off as specified.

Turning screw in clockwise enrichens mixture and conversely, turning it out counterclockwise leans mixture.

Refer to TECHNICAL DATA section 09 for the specifications.

Carburetor Synchronization

Twin Carburetor Models Only

Both carburetor slides must start to open at the same time.

Completely unscrew idle speed screw on both carburetors.


Unlock cable adjustment lock nut then screw in adjuster until throttle slide bottoms out. Proceed the same for both carburetors.

Unscrew cable adjuster to eliminate all cable play but without raising throttle slide. Proceed with care on both carburetors then tighten jam nuts. Both carburetor slide must start to open at the same time, depress throttle lever to check it and turn cable adjuster as required.

Check throttle slide position at wide open throttle. Throttle slide must be flush or 1 mm (.040 in) lower than carburetor **outlet** bore. At that same position, check that throttle slide does not contact carburetor cover. Turn cable adjuster and recheck synchronization.

Section 03 ENGINE

Sub-Section 09 (CARBURETOR AND FUEL PUMP)



TYPICAL

1. Screw in and out until no cable free play exists
2. Check that throttle slide does not move
3. Idle speed screw completely unscrewed

▼ **CAUTION :** If the throttle slide rests against the carburetor cover at full throttle opening, this will create too much strain and may damage the throttle cable or other components in throttle mechanism.

Throttle Slide Adjustment

All Models

◆ **WARNING :** Ensure the engine is turned OFF, prior to performing the throttle slide adjustment.

For maximum performance, correct carburetor throttle slide adjustment is critical.

The following method should be used with engine turned off :

- **Idle speed** screw must be completely unscrewed. It must not contact throttle slide.

Turn the **idle speed** screw clockwise until it contacts the throttle slide then continue turning 2 additional turns.

Twin Carburetor Models Only


Repeat on the other one. This will ensure identical throttle slide preliminary idle setting. Recheck carburetor synchronization. Adjust idle by turning both idle speed screws of the same amount.

▼ **CAUTION :** On twin carburetor models, make sure both carburetors start to operate simultaneously. Beside do not interchange carburetors, the jetting may be different on each side. A red dot is printed on one carburetor and on the engine. Match the carburetor and the engine dots when applicable.

▼ **CAUTION :** On oil injection models, the oil injection pump adjustment must be checked each time carburetor is adjusted. Refer to OIL INJECTION SYSTEM 03-06.

All Models


Throttle slide must be flush or 1.0 mm (.040 in) lower than the top of carburetor outlet bore (engine side).



THROTTLE LEVER AGAINST HANDLE GRIP

1. Throttle cable adjuster
2. Throttle slide flush or 1.0 mm (.040 in) lower than carburetor outlet bore (engine side)

Once carburetor adjustment is performed, check that **with the throttle lever fully depressed**, there is a free play between the carburetor cover and top of throttle slide.



THROTTLE LEVER AGAINST HANDLE GRIP

1. Cover
2. Free play
3. Throttle slide

◆ **WARNING :** This gap is very important. If the throttle slide rests against the carburetor cover at full throttle opening, this will create too much strain and may damage the throttle cable or other components in throttle mechanism.

On twin-carburetor models : Recheck carburetor synchronization.


▼ **CAUTION :** On oil injection models, the oil injection pump adjustment must be checked each time carburetor is adjusted. Refer to OIL INJECTION SYSTEM 03-06.

PRELIMINARY IDLE SPEED ADJUSTMENT

Adjust throttle slide height (see table) by turning idle speed screw no. 7.

Final adjustment (engine running at idle speed) should be within 1/2 turn of idle speed screw from preliminary adjustment.

| Models | Throttle Slide height mm (in) |
|---|----------------------------------|
| Tundra II LT, Skandic 380, Touring E / LE / SLE, Formula S, Alpine II | 1.3 (.051) |
| Touring SLE, Skandic 500, Formula SL | 1.5 (.059) |
| Touring LE | 1.6 (.063) |



TYPICAL

1. Drill bit used as gauge for throttle slide height

IDLE SPEED FINAL ADJUSTMENT

7, Idle Speed Screw

Start engine and allow it to warm then adjust idle speed to specifications by turning **idle speed** screw clockwise to increase engine speed or counterclockwise to decrease it.

○ **NOTE :** On twin-carburetor models : Turn adjustment screw the same amount to keep carburetors synchronized.

Refer to TECHNICAL DATA 09 for the specifications.

▼ **CAUTION :** Do not attempt to set the idle speed by using the air screw. Severe engine damage can occur.


CHOKE

Touring E / E LT / LE / SLE, Skandic 380 / 500 and Formula SL

Choke Plunger Adjustment

Adjust cable length to obtain the following plunger / adaptor distance. Retighten lock nut.


| CARBURETOR | PLUNGER / ADAPTOR DISTANCE ± 0.3 mm (± .012 in) |
|------------|--|
| PTO | 32.5 (1.280) |
| MAG | 31.3 (1.232) |



- 1. Plunger
- 2. Adaptor
- 3. Lock nut
- 4. Distance


The above adjustment can be easily checked with a service tool which is not available at time of printing.

FUEL PUMP



REMOVAL

Install a hose pincher (P / N 529 0099 00) on fuel supply line close to pump inlet.




1. Hose pincher (P / N 529 0099 00)

Disconnect fuel outlet line(s).


Disconnect impulse line.

Remove screws (or nuts if applicable) securing fuel pump.



LOW-SUPPLY FUEL PUMP WITH SINGLE OUTLET

1. Fuel outlet line
2. Impulse line
3. Fuel inlet line



HIGH-SUPPLY FUEL PUMP WITH TWIN OUTLETS

1. Inlet
2. Outlets
3. Impulse

PUMP VERIFICATION

Check fuel pump valves operation as follows :

Connect a clean plastic tubing to the inlet nipple and alternately apply pressure and vacuum with pump of leak test kit. The inlet valve should release with pressure and hold under vacuum.

Repeat the same procedure at the outlet nipple. This time the outlet valve should hold with pressure and release under vacuum.

NOTE : On model fitted with 2 outlets, plug 1 outlet with finger while checking outlet valve.

Check impulse diaphragm and gasket on high-supply fuel pump with twin outlets as follows :

Connect a clean plastic tubing to the impulse nipple and plug vent hole on top cover. Either apply pressure or vacuum. The diaphragm / gasket must not leak.

DISASSEMBLY

1,2, Grommet and Valve (high-supply pump with twin outlets only)

Do not disassemble valves unless replacement is necessary.

CLEANING AND INSPECTION

The entire pump should be cleaned with general purpose solvent before disassembly.

Fuel pump components should be cleaned in general purpose solvent and dried with compressed air.

◆ **WARNING :** Solvent with a low flash point such as gasoline, naphtha, benzol, etc., should not be used as each is flammable and explosive.


Inspect diaphragm. The pumping area should be free of holes, tears or imperfections. Replace as needed.

High-supply pump with twin outlets : Thoroughly clean filter on top cover. Replace filter if necessary.

ASSEMBLY

To install a new valve, proceed as follows :

- Place new valve flat on its seat.
- Slightly oil taper tip of grommet.
- Push grommet with a rotational movement until it crosses its housing.



1. Valve
2. Grommet
3. Lubricate tip
4. Pump body

When assembling pump, ensure to properly position stages together. Refer to previous illustrations if necessary.

INSTALLATION


To install, inverse removal procedure.

◆ **WARNING :** Pressure test to ensure there is no leak in fuel system.

FUEL TANK AND THROTTLE CABLE

Fuel Tank Lines

◆ **WARNING :** When draining a fuel tank or when-ever a fuel line is disconnected, obstruct line with a hose pincher (P/N 529 0099 00) or equivalent device. Fuel is flammable and explosive under certain conditions. Ensure work area is well ventilated. Do not smoke or allow open flames or sparks in the vicinity.



Impulse / Fuel Lines Spring Clips


Always reposition spring clips after any repair to prevent possible leaks.

Throttle Cable Circlip at Handlebar

Put silicone grease (P/N 413 7017 00) around cable barrel. Locate circlip as per illustration.

◆ **WARNING :** If this procedure is disregarded, throttle might be half-open at normally closed position and the engine will speed up when starting.


Models with Easy Action Throttle Lever



TYPICAL

1. Circlip

Other Models



1. Throttle cable housing
2. Throttle handle housing
3. Throttle handle
4. Circlip


Section 03 ENGINE

Sub-Section 10 (FUEL TANK AND THROTTLE CABLE)

Throttle Cable Retainer

Tundra II LT Models

The retainer must be pushed on the throttle handle tab until it sits properly.



1. Throttle handle
2. Retainer
3. Cable barrel
4. Silicone grease

Adjust throttle cable as specified in CARBURETOR AND FUEL PUMP 03-09.

Throttle Cable Routing

▼ **CAUTION :** Check that throttle cable is routed away from sharp, edges, hot or vibrating parts. When turning steering while engine is running, idle speed must not vary.

Section 04 TRANSMISSION
Sub-Section 01 (TABLE OF CONTENTS)

| | |
|---|----------------|
| DRIVE BELT | 04-02-1 |
| 1997 APPLICATION CHART | 04-02-1 |
| ROTATION DIRECTION..... | 04-02-1 |
| DRIVE BELT DEFLECTION MEASUREMENT | 04-02-2 |
| DEFLECTION ADJUSTMENT..... | 04-02-3 |
| DRIVE PULLEY..... | 04-03-1 |
| BOMBARDIER LITE | 04-03-1 |
| GENERAL | 04-03-2 |
| REMOVAL..... | 04-03-2 |
| DISASSEMBLY..... | 04-03-2 |
| CLEANING | 04-03-3 |
| INSPECTION | 04-03-3 |
| ASSEMBLY..... | 04-03-3 |
| INSTALLATION | 04-03-3 |
| TRA..... | 04-03-4 |
| GENERAL | 04-03-5 |
| REMOVAL..... | 04-03-5 |
| DISASSEMBLY..... | 04-03-5 |
| CLEANING | 04-03-6 |
| INSPECTION | 04-03-7 |
| ASSEMBLY..... | 04-03-9 |
| INSTALLATION | 04-03-11 |
| DRIVE PULLEY ADJUSTMENT..... | 04-03-12 |
| DRIVEN PULLEY..... | 04-04-1 |
| REMOVAL..... | 04-04-2 |
| DISASSEMBLY..... | 04-04-2 |
| INSPECTION | 04-04-3 |
| ASSEMBLY..... | 04-04-3 |
| INSTALLATION | 04-04-4 |
| ADJUSTMENT | 04-04-4 |
| REMOVAL..... | 04-04-7 |
| DISASSEMBLY..... | 04-04-7 |
| CLEANING | 04-04-7 |
| INSPECTION | 04-04-7 |
| ASSEMBLY..... | 04-04-9 |
| INSTALLATION | 04-04-9 |
| ADJUSTMENT..... | 04-04-10 |
| PULLEY DISTANCE AND ALIGNMENT..... | 04-05-1 |
| GENERAL | 04-05-1 |
| GENERAL PROCEDURE | 04-05-1 |
| PULLEY ALIGNMENT AND DISTANCE SPECIFICATIONS CHART..... | 04-05-2 |

Section 04 TRANSMISSION

Sub-Section 01 (TABLE OF CONTENTS)

| | |
|------------------------------------|----------------|
| BRAKE | 04-06-1 |
| MECHANICAL DISC BRAKE | 04-06-1 |
| HYDRAULIC DISC BRAKE | 04-06-3 |
| REMOVAL | 04-06-4 |
| DISASSEMBLY | 04-06-5 |
| CLEANING | 04-06-5 |
| INSPECTION | 04-06-6 |
| ASSEMBLY | 04-06-6 |
| INSTALLATION | 04-06-6 |
| ADJUSTMENT..... | 04-06-7 |
| CHAINCASE | 04-07-1 |
| REMOVAL | 04-07-2 |
| DISASSEMBLY | 04-07-2 |
| INSPECTION | 04-07-2 |
| GEAR RATIO MODIFICATION | 04-07-2 |
| ASSEMBLY | 04-07-3 |
| INSTALLATION | 04-07-3 |
| ADJUSTMENT..... | 04-07-4 |
| REMOVAL | 04-07-6 |
| INSPECTION | 04-07-6 |
| GEAR RATIO MODIFICATION | 04-07-6 |
| INSTALLATION | 04-07-6 |
| DRIVE CHAIN ADJUSTMENT..... | 04-07-7 |
| ADJUSTMENT..... | 04-07-8 |
| GEARBOX | 04-08-1 |
| 2-SPEED GEARBOX | 04-08-1 |
| DISASSEMBLY | 04-08-2 |
| INSPECTION | 04-08-2 |
| ASSEMBLY | 04-08-2 |
| ADJUSTMENT..... | 04-08-4 |
| OIL CHANGE..... | 04-08-5 |
| DRIVE CHAIN | 04-09-1 |
| GENERAL..... | 04-09-1 |
| SILENT CHAIN..... | 04-09-1 |
| CHAIN ATTACHMENT..... | 04-09-1 |
| CHAIN SEPARATION..... | 04-09-1 |


DRIVE BELT

1997 APPLICATION CHART


| MODEL | PART NUMBER | WIDTH (NEW) ± 0.25 mm (.010 in) | MINIMUM WIDTH (WEAR LIMIT) |
|--------------|-------------|------------------------------------|-------------------------------|
| TUNDRA II LT | 414 8276 00 | 33.3 mm (1-5/16") | 30 mm (1-3/16") |
| S-SERIES | 415 0606 00 | 34.3 mm (1-27/64") | 32 mm (1-1/4") |

ROTATION DIRECTION

The maximum drive belt life span is obtained when the drive belt is installed as shown. This will ensure that correct direction of rotation is respected.



CORRECT



INCORRECT

NOTE : For used drive belt, mark and re-install in the same position.

Section 04 TRANSMISSION

Sub-Section 02 (DRIVE BELT)

DRIVE BELT DEFLECTION MEASUREMENT

NOTE : The drive belt deflection measurement must be performed each time a new drive belt is installed.

NOTE : To obtain an accurate drive belt deflection measurement, it is suggested to allow a break-in period of 50 km (30 mi).

Before checking the belt deflection, ensure vehicle has the proper belt (Refer to the application chart).

Adjust pulley distance and alignment. Refer to 04-05 PULLEY DISTANCE AND ALIGNMENT.

To obtain maximum vehicle performance, the belt tension must be adjusted according to specifications shown in the accompanying chart.


| MODEL | DEFLECTION mm (in) | FORCE kg (lb) | HEIGHT [†] OVER DRIVEN PULLEY |
|--------------|---------------------------|------------------|---|
| Tundra II LT | 32 ± 5 (1-1/4 ± 13/64) | 5(11) | 0 - 1.5 mm (0 - 1/16") |
| S-Series | 32 ± 5 (1-1/4 ± 13/64) | 11.3 (25) | 0 - 1.5 mm (0 - 1/16") |

[†]For reference only

To Check Tension


Position a reference rule on drive belt.

Wooden Stick and Spring Scale Method :




1. Mark specified deflection

Using spring scale and stick, apply specified force on drive belt halfway between pulleys as shown.



1. Read deflection here
2. Reference rule
3. Force

Or use the belt tension tester (P / N 414 3482 00).




1. Lower O-ring
2. Upper O-ring
3. Force (Read Down)
4. Deflection (Read Up)

1. Slide lower O-ring of deflection scale to specified measure.
2. Slide upper O-ring to zero on the force scale.
3. Apply pressure until lower O-ring is flush with edge of rule and read force on the upper scale at top edge of O-ring.

Section 04 TRANSMISSION

Sub-Section 02 (DRIVE BELT)




1. Upper O-ring
2. Force
3. Lower O-ring
4. Reference rule
5. Deflection

DEFLECTION ADJUSTMENT

Tundra II LT


Drive belt deflection is adjusted by moving chain-case.



TYPICAL

1. Movement
2. Retaining nuts

To do so, loosen the 4 chaincase retaining nuts, unlock and raise driven pulley support.



TUNDRA II LT

- Step 1 : Push and hold
Step 2 : Raise support

Adjust pulley distance according to specification, refer to PULLEY DISTANCE AND ALIGNMENT 04-05 and measure drive belt deflection. Readjust pulley distance if required, then tighten the 4 nuts. Adjust driven pulley support and lock it to engine.

S-Series

Adjust pulley distance according to specification, refer to PULLEY DISTANCE AND ALIGNMENT 04-05, then adjust drive belt deflection using Allen screws, as shown.


To increase deflection : turn Allen screws clockwise.

To decrease deflection : turn Allen screws counterclockwise.

NOTE : Turn Allen screws 1/4 turn at a time, then rotate driven pulley to allow drive belt to settle in pulley. Check deflection, repeat as required.

Section 04 TRANSMISSION

Sub-Section 02 (DRIVE BELT)



TUNDRA II LT

1. Raise

Adjust pulley distance according to specification, refer to PULLEY DISTANCE AND ALIGNMENT 04-05 and measure drive belt deflection. Readjust pulley distance if required, then tighten the 4 nuts. Adjust driven pulley support and lock it to engine.


S-Series

Adjust pulley distance according to specification, refer to PULLEY DISTANCE AND ALIGNMENT 04-05, then adjust drive belt deflection using Allen screws, as shown.

To increase deflection : turn Allen screws clockwise.


To decrease deflection : turn Allen screws counterclockwise.

NOTE : Turn Allen screws 1/4 turn at a time, then rotate driven pulley to allow drive belt to settle in pulley. Check deflection, repeat as required.



1. Allen screw with jam nut

Allen screws should be restrained while tightening jam nut to prevent throwing adjustment out. Use drive belt tension adjuster (P / N 529 0087 00).




Restrain Allen screws with the wrench and tighten nut with the socket using socket handle provided in tool box.

DRIVE PULLEY

BOMBARDIER LITE

○ NOTE : This is a lubrication free drive pulley.

Tundra II LT and 377 Engine S-Series



A05D0IS

Section 04 TRANSMISSION

Sub-Section 03 (DRIVE PULLEY)

GENERAL

Some drive pulley components (return spring, calibration disk) can be changed to improve vehicle performance in high altitude regions. The High Altitude Technical Data booklet (P / N 484 0648 00 and 484 0545 00 for binder) gives information about calibration according to altitude.


▼ **CAUTION :** Such modifications should only be performed by experience mechanics since they can greatly affect vehicle performance.

◆ **WARNING :** Any drive pulley repairs must be performed by an authorized Bombardier snowmobile dealer, or other such qualified person. Sub-component installation and assembly tolerances require strict adherence to procedures detailed.

REMOVAL

○ **NOTE :** If disassembling drive pulley, first straighten tab washer **no. 7** then untighten nut **no. 8**.


Use clutch holder (P / N 529 0276 00).



TYPICAL

Remove retaining screw **no. 9**.

Insert drive pulley puller (P / N 529 0314 00) then remove drive pulley.




TYPICAL

DISASSEMBLY

Unscrew nut. Remove tab washer.

Mark governor cup **no. 6** and sliding half **no. 3** for proper indexing at reassembly.

Identify blocks **no. 1** and their respective positive positions for reassembly.




1. Identify

2, Nylon Threaded Plug

These are calibration parts. Refer to TECHNICAL DATA 09-03.

Unscrew set screw **no. 4** then use spring cover tool (P / N 529 0273 00) to unscrew spring cover **no. 5**.

Mount tool in a vise for cover hand-unscrewing.



Remove washer **no. 10** then circlip **no. 11**.

CLEANING

Clean pulley faces and shaft with fine steel wool and clean dry clutch. Clean sliding half bushing with clean dry cloth.

INSPECTION


Check sliding half for excessive lateral play and fixed half shaft for scratches. Replace as required.

ASSEMBLY

Install circlip **no. 11** then washer **no. 10**.

Make sure to install blocks at their original position and with their curved end toward governor cup.

Screw spring cover to 2 to 3 mm (1/16 to 1/8 in) down below sliding half end. Apply Loctite 271 on screw threads. Install set screw aligned with spring cover slot.



- 1. Curved end
- 2. Spring cover slot
- A. 2 to 3 mm (1/16 to 1/8 in)

Tighten nut **no. 8** to 128 N•m (95 lbf•ft).

INSTALLATION

Torque screw to 90 to 100 N•m (66 to 74 lbf•ft).

Install drive belt and belt guard.

Raise and block the rear of the vehicle and support it with a mechanical stand.

◆ **WARNING :** Ensure that the track is free of particles which could be thrown out while track is rotating. Keep hands, tools, feet and clothing clear of track. Ensure nobody is standing near the vehicle.

Accelerate the vehicle at low speed (maximum 30 km/h (20 MPH)) and apply the brake, repeat 5 times.

Recheck the torque of 90 to 100 N•m (66 to 74 lbf•ft).

◆ **WARNING :** After 10 hours of operation the transmission system of the vehicle must be inspected to ensure the retaining screw is properly torqued.


Section 04 TRANSMISSION

Sub-Section 03 (DRIVE PULLEY)

TRA

All Models

○ NOTE : This is a lubrication free drive pulley.



A19D07S

GENERAL

Some drive pulley components (return spring, ramp) can be changed to improve vehicle performance in high altitude regions. The High Altitude Technical Data booklet (P / N 484 0624 00 and 484 0545 00 for binder) gives information about calibration according to altitude.

▼ **CAUTION :** Such modifications should only be performed by experienced mechanics since they can greatly affect vehicle performance. Verify spring specifications before installation. Do not only refer to the spring color code.


○ **NOTE :** TRA clutch stands for Total Range Adjustable clutch.

◆ **WARNING :** Any drive pulley repairs must be performed by an authorized Bombardier snowmobile dealer, or other such qualified person. Sub-component installation and assembly tolerances require strict adherence to procedures detailed.

REMOVAL

30,31, Conical Spring Washer and Screw

Use clutch holder (P / N 529 0064 00).



TYPICAL

1. Retaining screw
2. Insert in any slot

○ **NOTE :** Sliding half can be removed while fixed half remains on crankshaft.

◆ **WARNING :** Never use any type of impact wrench at drive pulley removal and installation.

Remove retaining screw.

To remove drive pulley ass'y and / or fixed half from engine, use puller (P / N 529 0079 00).

▼ **CAUTION :** These pulleys have metric threads. Do not use imperial threads puller. Always tighten puller by hand to ensure that the drive pulley have the same type of threads (metric vs imperial) prior to fully tighten.

To Remove Drive Pulley Ass'y :

Retain drive pulley with clutch holder.

Install puller in pulley shaft then tighten.

DISASSEMBLY


1,2, Screw and Ring Gear

▼ **CAUTION :** Retaining screws must be heated before disassembly.

5,6, Fixed and Sliding Half

▼ **CAUTION :** Do not tap on governor cup.

Screw puller into fixed half shaft about 13 mm (1/2 in). Raise drive pulley and hold it by the sliding half while knocking on puller head to disengage fixed half.



1. Puller
2. Holding sliding half

○ **NOTE :** No components marking is required before disassembling this drive pulley since it has factory mark and arrows as indexing reference.

Section 04 TRANSMISSION

Sub-Section 03 (DRIVE PULLEY)


25,29, Slider Shoe and Governor Cup

Carefully lift governor cup until slider shoes come at their highest position into guides.

Hold a slider shoe set then carefully lift its housing and remove them. Proceed the same way for other housings lifting one at a time.


32, Cushion Drive

▼ **CAUTION :** Do not disassemble cushion drive. Governor cup and cushion drive are factory balanced as an assembly.



1. Hold slider shoes
2. Lift one housing at a time

○ **NOTE :** To ease disassembly, forks (P / N 529 0055 00) should be used to hold slider shoes prior to removing governor cup.




19, Spring Cover Ass'y

It is pushed by clutch spring pressure.

◆ **WARNING :** Clutch spring is very strong. Never attempt to remove spring cover without the recommended tools.

Use spring compressor (P / N 529 0151 00).



1. Washer must be here

Install tools as shown. Remove 3 Allen screws retaining spring cover then unscrew compressor.

CLEANING

5,6, Fixed and Sliding Half

Clean pulley faces and shaft with fine steel wool and dry cloth.

5, Fixed Half and Crankshaft End

Parts must be at room temperature before cleaning.

Using a paper towel with cleaning solvent (P / N 413 7082 00), clean crankshaft tapered end and the taper inside the fixed half of the drive pulley, crankshaft threads and retaining screw threads.

◆ **WARNING :** This procedure must be performed in a well ventilated area.

▼ **CAUTION :** Avoid contact between cleaner and crankshaft seal because damage may occur.

Remove all harden oil deposits that have baked on crankshaft and pulley tapered surfaces with coarse or medium steel wool and / or sand paper no. 600.

▼ **CAUTION :** Do not use any other type of abrasive.

Reclean mounting surfaces with paper towel and cleaning solvent (P / N 413 7082 00).

Wipe off the mounting surfaces with a clean, dry paper towel.

▼ **CAUTION : Mounting surfaces must be free of any oil, cleaner or towel residue.**

7,20, Bushing

Only use petrol base cleaner when cleaning bushings.

▼ **CAUTION : Do not use acetone to clean bushing.**

INSPECTION

Drive pulley should be inspected annually.

16,17, Thrust Washer and Roller

Check roller for roundness of external diameter. Check thrust washer for thickness wear. Replace as required.

▼ **CAUTION : Ensure rollers are in good condition. Replace as required.**

9,12, Fitting Bolt Ass'y and Flanged Bushing

Check for wear, replace as required. When installing old style flanged bushing (made of black plastic), use a size "O" (letter) drill bit to ream inside diameter.

24,25, O-ring and Slider Shoe

Check if O-rings are cracked, cut or crushed. Replace as required.

Check slider shoes for wear. Replace if groove is not apparent on top.

5,29, Fixed Half and Governor Cup

Inspect splines and free play between both parts. Maximum free-play is 0.5 mm (.020 in) measured at calibration screw radius. Replace if required.

7,20, Sliding Half and Spring Cover Kahrlon Bushing

Visually inspect kahrlon coating. Replace if worn.

Sliding Half Bushing Replacement


Use a suitable pusher to remove the old bushing. Clean sliding half with ethyl alcohol.

▼ **CAUTION : Bushing must be bonded with retaining compound (P / N 413 7031 00) then flared to prevent displacement in sliding half.**

To flare bushing, use spring compressor (P / N 529 0151 00) and appropriate flare tools.

| FLARE TOOL | STAMPED LETTER | P / N |
|------------|----------------|-------------|
| INTERIOR | C | 529 0184 00 |
| EXTERIOR | C | 529 0185 00 |

Apply retaining compound (P / N 413 7031 00) outside of bushing then insert into its housing making sure there is the same distance both sides.




1. Washer
2. Flat surface
3. Flaring side
4. Bushing


Then flare bushing.

Section 04 TRANSMISSION

Sub-Section 03 (DRIVE PULLEY)




1. Flaring side
2. Tool with holes
3. Washer



TOOL REMOVAL

1. Strike in holes alternately




TOOL REMOVAL

▼ **CAUTION :** Do not install sliding half on a vise to remove remaining tool.

Spring Cover Bushing Replacement

Under normal use there is no need to replace this bushing.

Use tools (P / N 529 0313 00 and 529 0312 00) to remove old bushing.




▼ **CAUTION :** Bushing must be bonded with retaining compound.

Apply retaining compound outside of bushing then press it down to counterbore from sliding half side. Use spring compressor (P / N 529 0151 00) and appropriate flare tools.


▼ **CAUTION :** Insert bushing from sliding half side (inner) of spring cover.

Start driving bushing into spring cover.



1. Note upper tool side

Press bushing.



1. Note upper tool side.

ASSEMBLY


NOTE : This drive pulley is lubrication free.
 Do not lubricate any component.

1,2,3, Screw, Ring Gear and Loctite 271

Apply Loctite 271 (P / N 413 7029 00) on threads and under head then torque to 15 N•m (133 lbf•in).

26,27,28, Calibration Screw, Washer and Locking Nut

When installing calibration screw, make sure to install washer as shown.



1. Washer


Torque locking nut to 10 N•m (89 lbf•in).

15, Pin

Always use the same type of pin as originally installed when servicing. Different types have different weights for calibration purpose. Refer to TECHNICAL DATA 09-03.

21,22,23, Ramp, Dowel Tube and Screw

Insert dowel tube from chamfered side. Make sure ramp is centered on dowel tube.





1. Chamfered side

Section 04 TRANSMISSION

Sub-Section 03 (DRIVE PULLEY)

Position dowel tube split at the illustrated angle.




1. Equal distance

Torque screws to 10 N•m (89 lbf•in).

9,11,13,14, Screw, Lever Ass'y, Nut and Cotter Pin

Always install lever assemblies so that cotter pins are at the shown side. Besides install cotter pin head on top when lever is sat at bottom of sliding half. Bend cotter pin ends to sit perfectly against lever.

◆ **WARNING :** Whenever replacing centrifugal levers, always replace all 3 at the same time. Otherwise, clutch misbalancing will occur because of levers difference.



1. Head on top
2. All on the same side

▼ **CAUTION :** Lever assemblies must be installed so that cotter pins are on the same side.

Torque nuts to 12 N•m (106 lbf•in).


▼ **CAUTION :** Lever ass'y and rollers must move easily after installation.

5,6,18,19, Fixed Half, Sliding Half, Spring, Spring Cover and Screw

To install spring cover, use spring compressor (P / N 529 0151 00).

Assemble fixed and sliding halves. Note that fixed halves have different cone angle. Match cone angle with crankshaft.

Lift sliding half against spring cover and align spring cover arrow with sliding half mark.




1. Align

Install and torque screws to 10 N•m (89 lbf•in).

6,25,29, Sliding Half, Slider Shoe and Governor Cup


To install governor cup, use following tool :



Insert spring and slider shoes into governor cup so that groove in each slider shoe is vertical to properly slide in guides.


▼ **CAUTION :** Make sure O-rings are installed on slider shoes and their grooves are positioned vertically.

Install fork (P / N 529 0055 00) into slider shoe grooves to maintain them for governor cup installation. Proceed on 3 set of slider shoes.



Make sure to align governor cup arrow with sliding half and fixed half mark.

○ **NOTE :** If fixed half has no mark, align governor cup mark with segment no. 1 of inner half. Segments are identified on engine side.



1. Align

Carefully slide governor cup into sliding half. Align mark of governor cup with mark of fixed half.

Remove forks and push governor cup so that its splines engage with fixed half shaft splines.

▼ **CAUTION :** Make sure splines of both parts are fully engaged.

INSTALLATION

◆ **WARNING :** Do not apply anti-seize or any lubricant on crankshaft and drive pulley tapers.

◆ **WARNING :** Never use any type of impact wrench at drive pulley removal and installation.

Clean mounting surfaces as described in CLEANING above.

Drive Pulley Ass'y

The installation procedure must be strictly adhered to as follows.

Lock crankshaft in position as explained in removal procedure.

Install drive pulley on crankshaft extension.

Install conical washer with its concave side towards drive pulley then install screw.

◆ **WARNING :** Never substitute lock washer and / or screw with jobber ones. Always use Bombardier genuine parts for this particular case.

Torque screw to 90 to 100 N•m (66 to 74 lbf•ft).
Install drive belt and belt guard.

Section 04 TRANSMISSION

Sub-Section 03 (DRIVE PULLEY)

Raise and block the rear of the vehicle and support it with a mechanical stand.

◆ **WARNING :** Ensure that the track is free of particles which could be thrown out while track is rotating. Keep hands, tools, feet and clothing clear of track. Ensure nobody is standing near the vehicle.

Accelerate the vehicle at low speed (maximum 30 km / h (20 MPH) and apply the brake, repeat 5 times.

Recheck the torque of 90 to 100 N•m (66 to 74 lbf•ft).

◆ **WARNING :** After 10 hours of operation the transmission system of the vehicle must be inspected to ensure the retaining screw is properly torqued.

DRIVE PULLEY ADJUSTMENT

The drive pulley is factory calibrated to transmit maximum engine power at a predefined RPM. Factors such as ambient temperature, altitude or surface condition may vary this critical engine RPM thus affecting snowmobile efficiency.

This adjustable drive pulley allows setting maximum engine RPM in the vehicle to maintain maximum power.

Calibration screws should be adjusted so that actual maximum engine RPM in vehicle matches with the maximum horsepower RPM given in TECHNICAL DATA 09.


○ **NOTE :** Use precision digital tachometer for engine RPM adjustment.

○ **NOTE :** The adjustment has an effect on high RPM only.

To adjust, modify ramp end position by turning calibration screws.

26,28,29, Calibration Screw, Locking Nut and Governor Cup


Calibration screw has a notch on top of its head.



1. Notch

Governor cup has 6 positions numbered 2 to 6. Note that in position 1 the number is substituted by a dot (due to its location on casting).

See TECHNICAL DATA 09-03 for original setting.



1. Position 1 (not numbered)

Each number modifies maximum engine RPM by about 200 RPM.

Lower numbers decrease engine RPM in steps of 200 RPM and higher numbers increase it in steps of 200 RPM.

Example :


Calibration screw is set at position 4 and is changed to position 6. So maximum engine RPM is increased of 400 RPM.

To Adjust :

Just loosen locking nut enough to pull calibration screw **partially** out and adjust to desired position. Do not completely remove the locking nut. Torque locking nuts to 10 N•m (89 lbf•in).

▼ **CAUTION :** Do not completely remove calibration screw or its inside washer will fall off.


▼ **CAUTION** : Always adjust all 3 calibration screws and make sure they are all set at the same number.



1. Loosen just enough to permit rotating of calibration screw

DRIVEN PULLEY

Tundra II LT



A09D0QS

Section 04 TRANSMISSION

Sub-Section 04 (DRIVEN PULLEY)

○ **NOTE** : Driven pulley components (support, cam, shoes, etc.) can be serviced without removing the whole driven pulley from chaincase. Refer to the following procedures but neither remove brake caliper nor open chaincase for those cases.

REMOVAL


To remove driven pulley from chaincase, follow this procedure.

Remove belt guard and drive belt from vehicle.

Remove brake support **no. 13** from chaincase with brake ass'y.

Free countershaft support **no. 1** from support clamp.

To remove driven pulley support use support puller (P / N 529 0135 00).



Chaincase

Open chaincase and drain oil. Unlock and remove upper sprocket.

The following is required to have enough space to remove driven pulley from chaincase :

Slacken upper retaining screws of steering column.

Disconnect carburetor boots from intake manifold and air intake silencer.

Disconnect impulse hose from engine.

Disconnect oil injection supply line at injection pump and plug line to prevent draining.

Remove screws retaining rear engine support to chassis.

Tip engine forward just enough to allow driven pulley removal from chaincase. Block in this position.

○ **NOTE** : In some cases, chaincase retaining screws might have to be slackened to allow pivoting of chaincase. In this case, note position of alignment shims. Besides, air intake silencer and oil injection reservoir might have to be slightly moved to get enough space to pull driven pulley.

DISASSEMBLY

Chaincase and Driven Pulley


Remove bearing cone.

Knock driven pulley shaft with a plastic hammer and pull driven pulley out.

Remove support **no. 1** using a suitable puller.

Remove roll pin **no. 2** and slide outer cam **no. 4** out of pulley shaft.

Install tool (P / N 529 0129 00), reinstall washer, lock washer and screw. Tighten tool screws alternately then remove roll pin.




1. Tighten alternately

Note spring original setting (adjusting hole in sliding half).

6,9, Sliding Half Bushing and Bushing

To disassemble a worn bushing (small), use a press and a suitable pusher.




TYPICAL

Remove 3 screws and washers and pry large bushing out.

INSPECTION

3, Slider Shoe

Check cam slider shoes for wear. Replace when inside edge of cam slider shoe slope is worn to 1 mm (.039 in) or less.




1. Measure length of slider shoe slope
2. Sliding pulley side

ASSEMBLY


6, Sliding Half Bushing

Clean mounting surfaces with Loctite Safety Solvent. Using a press and a suitable pusher, install bushing as illustrated.



1. Install bushing from this side of sliding half
2. Bushing

After bushing installation, try fixed half shaft inside bushing. If it is too tight, use burnishing bar (P / N 529 0264 00) then retry. If it is still too tight, use burnishing bar with oil on it.



8,9, Screw and Bushing

Align notches with screw positions and press down. Torque screws to 5 N•m (44 lbf•in).

3, Slider Shoe

When replacing slider shoes, always install a new set (3 shoes) to maintain equal pressure on cam.

Section 04 TRANSMISSION

Sub-Section 04 (DRIVEN PULLEY)

12, Fixed Half Shaft

Thoroughly clean the fixed half shaft. Remove rust with no. 320 grit sand paper.

Apply a light film of anti-seize lubricant (P / N 413 7010 00) on the shaft. Always wipe off surplus.

○ **NOTE :** Activate the sliding half several times to distribute lubricant over full length of shaft. Be careful that lubricant does not get on inner halves of pulley.


13,14, Brake Disc and Screw

Install brake disc on fixed half and torque screws to 13 N•m (115 lbf•in).

Assemble driven pulley components by reversing the disassembly procedure.

2,4,5, Roll Pin, Outer Cam and Spring

One of its ramps facing upwards, hold sliding half with welding clamps. Install spring into sliding half at its original setting (previously noted adjusting hole). Insert other spring end in outer cam and turn clockwise until a slider shoe corresponds with the ramp facing upwards. Push cam all the way in then install roll pin coated with anti-seize lubricant (P / N 413 7010 00).



TYPICAL

1. A ramp facing upwards
2. Welding clamp

INSTALLATION

Driven Pulley and Chaincase

Install a new upper chaincase oil seal and a new chaincase cover seal.

Reinstall the driven pulley on vehicle by reversing the removal procedure.

○ **NOTE :** If chaincase screws have been slackened, chaincase can be reinstalled to its initial position by securing driven pulley support before tightening chaincase retaining screws. Make sure to install alignment shims as noted at removal.


▼ **CAUTION :** Bleed oil injection pump on models that have had their injection oil supply line removed. Refer to INJECTION OIL SYSTEM 03-06.

ADJUSTMENT

10,11, Shim

○ **NOTE :** The following adjustment must be performed with a new drive belt.

For best performance, particularly at starting, top of drive belt should be flush with top of driven pulley halves.



TYPICAL

1. Belt flush with the top of the pulley halves

Shim(s) **no. 10** and **no. 11** provide belt height adjustment between pulley halves. Adding shims will lower the belt in driven pulley, while removing shims will raise the belt. Adjust properly.

5, Spring

Spring Torsional Pre-Load


To check spring pre-load adjustment, use spring scale hook (P / N 529 0065 00) and a spring scale.

Install the hook on the sliding half, making sure the spring scale is perpendicular to the pulley axle.

Take a measurement when opening driven pulley and another one when driven pulley begins to close after a rotation of 10 mm (3/8 in). Spring pre-load is the average measurement between these 2.

$$\frac{\text{1st measurement (when opening)} + \text{2nd measurement (when closing)}}{2} = \text{Spring pre-load}$$

$$\text{Example : } \frac{3.8 \text{ kg (8.4 lb)} + 3.4 \text{ kg (7.9 lb)}}{2} = 3.6 \text{ kg (8 lb)} \text{ Actual spring pre-load}$$




TYPICAL

Step 1 : 1st measurement
 Step 2 : 2nd measurement

Spring pre-load should be as TECHNICAL DATA section 09.

To adjust spring pre-load relocate spring end in sliding pulley, moving it clockwise to decrease the pre-load and counterclockwise to increase it.



1. Decrease
2. Adjusting holes
3. Increase

NOTE : Always recheck torsional pre-load after adjusting.

Chaincase

Check oil level and refill as required. Refer to CHAINCASE 04-07.


Pulley Alignment and Drive Belt Deflection

Refer to PULLEY DISTANCE AND ALIGNMENT 04-05 and DRIVE BELT 04-02 to perform adjustments.

CAUTION : Drive belt and pulley adjustments must always be checked whenever pulleys have been removed, replaced or disassembled.

Section 04 TRANSMISSION
Sub-Section 04 (DRIVEN PULLEY)

S-Series



A15D1DS

REMOVAL

Remove belt guard and drive belt from vehicle.


Remove the cap screw **no. 13**, lock washer **no. 12**, washer **no. 11**, extension **no. 17** and shims **no. 16** then pull the driven pulley from the countershaft.

14, Countershaft

Should countershaft **no. 14** removal be required, refer to BRAKE 04-06 then look for **Countershaft and Brake Disc Removal**.

DISASSEMBLY

Use spring compressor (P / N 529 0151 00).



TYPICAL

1. Insert this pin in keyway

Remove snap ring **no. 2** to disassemble the outer cam and the 2 pulley halves.

◆ **WARNING :** Driven pulley cam is spring loaded, use above mentioned tool.

CLEANING

6,7, Large Bushing and Small Bushing

During break-in period (about 10 hours of use), teflon from bushing moves to cam or shaft surface. A teflon over teflon running condition occurs, leading to low friction. So it is normal to see gray teflon deposit on cam or shaft. Do not remove that deposit, it is not dust.

When a dust deposit has to be removed from the cam or the shaft, use dry cloth to avoid removing transferred teflon.

Pulley Half Cleaning


Use Loctite Safety Solvent (P / N 413 7082 00).

INSPECTION

6,7, Bushings

Check for cracks, scratch and for free movement when assembled to fixed half.

Using a dial bore gauge measure bushing diameter. Measuring point must be at least 5 mm (1/4 in) from bushing edge.




Section 04 TRANSMISSION
Sub-Section 04 (DRIVEN PULLEY)

Replace bushing(s) if worn more than specified.

| DRIVEN PULLEY BUSHING WEAR LIMIT mm (in) | |
|---|---------------|
| Small bushing | 38.30 (1.508) |
| Large bushing | 89.15 (3.510) |

4, Slider Shoe

Check cam slider shoes for wear. Replace when inside edge of cam slider shoe slope base is worn to 1 mm (.039 in) or less.



- 1. Measure thickness of slope base here
- 2. Sliding pulley side
- 3. Slope base

Bushing Replacement

Large Bushing


Remove Allen screws if applicable. Heat to break Loctite bond.

Remove all 3 slider shoes.



Install support plate (P / N 529 0311 03) inside sliding half.

Place puller (P / N 529 0311 02) below bushing.




Mount puller screw head in a vise.

Turn pulley half by hand to extract old bushing.

Before bushing installation, file sliding half bore to remove burrs from crimping areas.

Coat bushing outside diameter with Loctite 609 (P / N 413 7031 00). Place new bushing on sliding half and slightly tap to engage squarely the bushing in the sliding. Use tools (P / N 529 0312 00 and 529 0313 00) to install bushing.




Small Bushing

NOTE : Following procedure can be done with a press using the same tools.

Install puller in a vise.

Heat bushing area.


Turn puller handle and sliding half at once to extract the bushing.



IMPORTANT : Large bushing retaining screws and washers must be removed before small bushing installation.

Coat bushing outside diameter with Loctite 609 (P / N 413 7031 00).

Install bushing as following photo.



ASSEMBLY

4, Cam Slider Shoe

When replacing slider shoes, always install a new set (3 shoes) to maintain equal pressure on the cam.

Assemble driven pulley components by reversing the disassembly procedure.

19, Cam

Coat cam interior with anti-seize lubricant.

INSTALLATION

14,15, Countershaft and Anti-seize Lubricant

CAUTION : Always apply anti-seize lubricant (P / N 413 7010 00) on the countershaft before final pulley installation.


F-Series and S-Series Only

Should installation procedure be required, refer to BRAKE 04-06 then look for **Brake Disc and Countershaft Bearing Adjustment**.

Reinstall the pulley on the countershaft by reversing the removal procedure.

All Models

Check end play of driven pulley on countershaft by pushing pulley towards outer housing so that the inner shims (P / N 504 1082 00) contact it. Measure end play at the mounting screw end between shim(s) and pulley. See illustration.



TYPICAL — TOP VIEW

1. Shim (P / N 504 1082 00) (as required)

2. Contact

A. 0 to 1 mm (0 to 3/64 in)

13, Pulley Retaining Screw

Torque to 25 N•m (18 lbf•ft).

Section 04 TRANSMISSION
Sub-Section 04 (DRIVEN PULLEY)

ADJUSTMENT

Refer to PULLEY DISTANCE AND ALIGNMENT 04-05 to adjust pulley distance. Adjust drive belt height between pulley halves to obtain specified belt deflection.

5, Spring

Spring Torsional Pre-Load

To check spring pre-load adjustment, use spring scale hook (P / N 529 0065 00) and a spring scale. Remove drive belt.

Install the hook on the sliding half. Preventing fixed half from turning, pull sliding half with the spring scale perpendicularly with pulley axle.

Take 1st measurement when sliding half begins to turn. Rotate sliding half to 10 mm (3/8 in) of rotation. Hold fish scale at this position. Slowly release tension from fish scale and take 2nd measurement when sliding half begins to return. Spring pre-load is the average measurement between these 2.

1st measurement
(when opening)

+

2nd measurement
(when closing)

2

= Spring
pre-load

Example :


3.8 kg (8.4 lb)
(when opening)

+

3.4 kg (7.5 lb)
(when closing)

2


= 3.6 kg (8 lb)
Actual
spring
pre-load



TYPICAL
Step 1 : 1st measurement
Step 2 : 2nd measurement

To adjust spring pre-load, relocate spring end in cam, moving it clockwise to increase the pre-load and counterclockwise to decrease it. Refer to TECHNICAL DATA 09-03.

NOTE : If spring pre-load can not be adjusted, try to relocate the other end of spring in sliding pulley (holes A, B, C).



Letters and numbers shown in illustration are actual letters and numbers embossed on parts

NOTE : Always recheck torsional pre-load after adjusting.

Pulley Alignment and Drive Belt Deflection


Refer to PULLEY DISTANCE AND ALIGNMENT 04-05 and DRIVE BELT 04-02 to perform adjustments.

CAUTION : Drive belt and pulley adjustments must always be checked whenever pulleys have been removed, replaced or disassembled.

3, Outer Cam

Make sure to install proper cam. Refer to TECHNICAL DATA 09-03.

Cam angle is identified on cam.



○ **NOTE :** For high altitude regions, the High Altitude Technical Data Booklet (P / N 484 0648 00 and 484 0545 00 for binder) gives information about calibration according to altitude.

PULLEY DISTANCE AND ALIGNMENT

GENERAL

The pulley distance we will refer to in this section, is the space separating the drive and driven pulley outside diameters (Z measurement).

This basic distance is provided as an assembly guide and indicates the dimensions between which satisfactory belt deflection will be obtained.

Both pulley distance adjustment and pulley alignment must be carried out to ensure the highest efficiency of the transmission system. Furthermore, optimum drive belt operation and minimal wear will be obtained only with proper pulley alignment.

▼ **CAUTION :** Before checking pulley adjustment, the rear suspension must be mounted on the vehicle and track tension / alignment must be done. Always check pulley adjustment after suspension is adjusted.

◆ **WARNING :** Failure to correctly perform pulley alignment may cause the vehicle to creep forward at idle.

All pulley alignment specifications refer to :

X = Distance between straight bar and drive pulley fixed half edge, **measured between pulleys.**

Y = Distance between straight bar and drive pulley fixed half edge, **measured at the end of straight bar.**

Z = Distance between outside diameter of pulleys.

GENERAL PROCEDURE


Remove belt guard and drive belt.

By turning and pushing the sliding half, open the driven pulley. Insert a straight bar 9.5 mm (.375 in) square, 48 cm (19 in) long or the proper alignment template into the opened driven pulley.

Measuring Procedure

Using Straight Bar :

Always measure distances X and Y from the farther straight bar side (including its thickness to the fixed half edge.)



1. Straight bar
2. Front of vehicle

The distance Y **must** exceed distance X to compensate for the twist due to the engine torque.

Nominal Value Procedure and Quick Alignment and Distance Check


Alignment template tabs must fully contact fixed half of drive pulley.

Pulley distance is correct when tab contacts both pulley halves.

Refer to below chart for proper alignment template.

Section 04 TRANSMISSION

Sub-Section 05 (PULLEY DISTANCE AND ALIGNMENT)




TYPICAL

1. Contact (alignment)

2. Contact (distance)

Tundra II LT Only

Bottom of alignment template must not seat on shaft nor fixed half shoulder and shim(s).



TYPICAL

1. Shaft

2. Alignment template

3. Fixed half shoulder and shim(s)

Drive Belt Deflection

NOTE : When pulley distance and alignment are adjusted to specifications, refer to DRIVE BELT 04-02 to adjust drive belt deflection.


CAUTION : This section deals mainly with adjustment procedures. For complete assembly requirements, refer to the proper ENGINE or TRANSMISSION installation section.

PULLEY ALIGNMENT AND DISTANCE SPECIFICATIONS CHART

| MODEL | PULLEY DISTANCE | OFFSET | | ALIGNMENT TEMPLATE ① P / N |
|--------------------------------------|----------------------------------|-------------------------|--------------------------------|--|
| | Z | X | Y-X | |
| | + 0, – 1 mm (+ 0, – 0.040 in) | ± 0.50 mm (0.020 in) | ± 0.5 mm (0.020 in) | |
| Tundra II LT | 37.0 (1.460) | 36.0 (1.420) | 0 to 1.5 mm (0 to 0.060 in) | 529 0269 00 |
| Bombardier Lite Equipped S-Series | 25.0 (0.984) | 33.4 (1.315) | 1.0 (0.040) | 529 0300 00 |
| TRA Equipped S-Series | 16.5 (0.650) | 35.0 (1.380) | 1.5 (0.060) | 529 0267 00 |

① Alignment templates have been made according to pulley alignment nominal values. However, they do not take into account allowed tolerances for alignment specifications. They are used as GO / NO GO gauges for quick alignment and pulley distance check and as templates to reach alignment nominal values.

Tundra II LT




1. Driven pulley movement
2. Engine movement

CAUTION : The rear suspension must be mounted on the vehicle and track tension and alignment must be done to provide the right frame width.

Pulley Distance Adjustment Method

Slacken the 4 chaincase retaining bolts, unlock and raise pulley support.

Move chaincase to obtain specific adjustment and adjust driven pulley support length accordingly (light contact).




- Step 1 : Push and hold
- Step 2 : Raise support

Pulley Alignment Method

Engine Movement

Slacken the support retaining bolts and install engine support positioner (P / N 529 0245 00) to keep from altering distance between both supports.



TYPICAL

Section 04 TRANSMISSION


Sub-Section 05 (PULLEY DISTANCE AND ALIGNMENT)

Move the engine to obtain specified pulley alignment, torque engine support bolts to 55 N•m (41 lbf•ft) and remove engine support positioner.

Driven Pulley Movement

Shims can be mounted between chaincase and frame. Use shim (P / N 504 0398 00), 0.53 mm (.021 in) thick.


S-Series



TYPICAL

1. Engine movement
2. Contact

NOTE : Prior to performing pulley adjustment, loosen torque rod nut to allow engine movement. Engine supports have tendency to stick to frame, work engine loose prior to aligning.



1. Loosen

Pulley Distance Adjustment Method

Engine Movement

The engine support has slotted mounting holes. Move engine to obtain specified distance between pulleys.

Pulley Alignment Method


Driven Pulley Movement

When engine slotted mounting holes do not allow to set proper pulley offset X, adjust with shims (P / N 504 1082 00) between pulley and counter-shaft bearing support (pulley pushed toward brake disc).

Engine Movement

Loosen the 4 bolts retaining engine support to the frame. Position engine to obtain the specified alignment.

NOTE : After alignment, adjust torque rod so it slightly contacts stopper plate. Do not over tighten, it will disalign pulleys.




1. Retighten

BRAKE

MECHANICAL DISC BRAKE


Tundra II LT



A05D00S

Section 04 TRANSMISSION
Sub-Section 06 (BRAKE)


Formula S, Touring E / E LT and Skandic 380 / 500



A03D27S

HYDRAULIC DISC BRAKE

Touring LE / SLE, Formula SL



A03D26S

Section 04 TRANSMISSION

Sub-Section 06 (BRAKE)

REMOVAL

Tundra II LT

The split caliper type brake should be removed from chaincase as an assembly. Proceed as follows :


- Remove belt guard.
- Disconnect brake cable.
- Remove bolts **no. 8** securing brake support to chaincase.
- Slide brake caliper ass'y out of brake support.
- To remove brake disc, refer to DRIVEN PULLEY 04-04.

BRAKE DISC REMOVAL

S-Series with Mechanical Brake

Brake disc can be withdraw without removing caliper. Proceed as follows :

- Remove belt guard, belt and driven pulley.
- Remove air silencer.
- Unbolt bearing support from chassis.
- Open chaincase and remove upper sprocket.
- Pull countershaft toward driven pulley side to gain access to clip **no. 25**.
- Remove clip **no. 25** on countershaft.




- Pull countershaft toward driven pulley side to free from chaincase and disc.
- Remove disc.

COUNTERSHAFT REMOVAL


S-Series with Mechanical Brake

Proceed the same as for brake disc removal but unlock bearing collar on driven pulley side.




1. Lock
2. Unlock

Unbolt bearing support then install screw on countershaft.




1. Screw

Push bearing to driven pulley side out of countershaft, using remover (P / N 529 0301 00). Begin with only the remover then add a spacer of different width as the bearing comes out.



1. Spacers

To install bearing on countershaft, use installer (P / N 529 0302 00) and spacer(s) from remover as required.



1. Spacer

COUNTERSHAFT AND BRAKE DISC REMOVAL

S-Series with Hydraulic Brake

- Remove muffler.
- Refer to CHAINCASE 04-07 in order to remove chaincase cover.
- Remove upper sprocket castellated nut.
- Remove belt guard, drive belt and driven pulley referring to DRIVEN PULLEY 04-04.

- Slacken set screw and unlock collar **no. 18** if bearing is needed to be disassembled. See above S-Series illustration and procedure.
- Remove 3 retaining screws **no. 20** from countershaft bearing housing.
- Unbolt oil reservoir support to make room for countershaft or brake disc removal.
- Pull countershaft toward driven pulley side to gain access to clip **no. 25**.
- Remove clip **no. 25** on countershaft.
- Pull countershaft toward driven pulley side to free from chaincase. Withdraw countershaft toward chaincase.
- Remove connecting pipe between tuned pipe and after muffler.
- Disconnect brake line from caliper and plug it.
- Unbolt caliper from chaincase.
- Remove brake disc from countershaft.

DISASSEMBLY

7,15,16,23, Brake Pad, Brake Lever, Pin and Screw

All Models with Mechanical Brake

Pull pin out off caliper and remove lever.

On Tundra II LT, remove self-tapping screw. Unscrew ratchet wheel in order to remove moving pad.

Remove fixed pad.

S-Series with Mechanical Brake

Fixed pad is riveted to chaincase on these models. Caliper must be split to remove moving pad. To removed fixed pad, drill out its rivet then pry disc in order to free fixed pad.

All Models with Hydraulic Brake

Only brake pads are available as spare parts. If caliper or master cylinder are damaged, replace each of them as an assembly.

CLEANING

Clean all metal components in a general purpose solvent. Thoroughly dry all components before assembling.

▼ **CAUTION :** Do not clean brake pads in solvent. Soiled brake pads must be replaced by new ones.

Section 04 TRANSMISSION


Sub-Section 06 (BRAKE)

INSPECTION

7, Brake Pad Thickness

Brake pads must be replaced when fixed pad projects only 1 mm (1/32 in) from caliper.

▼ **CAUTION** : Brake pads must always be replaced in pairs.



TYPICAL

- 1. Fixed pad
- 2. Inner caliper
- A. 1 mm (1/32 in) minimum

Brake Disc

Check for scoring, cracking or heat discoloration, replace as required. Refer to DRIVEN PULLEY 04-04 for replacement procedures on Tundra II LT.

▼ **CAUTION** : Brake disc should never be machined.

ASSEMBLY

14, Ratchet Wheel

Apply low temperature grease (P / N 413 7061 00) on threads and spring seat prior to installing. Fully tighten then back off one turn.

16, Pin

Install so that it can only be removed upward. Lock it in the caliper casting notch.

7, Fixed Brake Pad

Tundra II LT


Torque screw no. 3 to 4 N•m (35 lbf•in). Bend locking tab no. 4 over a flat of screw head.

1,6,11,12, Locking Tab, Inner, Outer Caliper and Nut

Tundra II LT

Assemble both caliper halves. Insert bolts no. 9, locking tab no. 20, then nuts. Torque nuts to 24 N•m (18 lbf•ft). Caliper half side slots must align to allow proper sliding in brake support. Bend locking tab over a flat of each nut.

Install rubber slider no. 12 lubricated with shortening (cooking fat) into side slots of caliper. It must be installed so that the raised edge is upward and on the same side of nuts as shown.



- 1. Raised edge upward and same side of nuts

▼ **CAUTION** : Positioning of rubber slider is important to avoid the possibility of damage against locking tab edges.

INSTALLATION

To install brake, reverse removal procedure paying attention to the following.

◆ **WARNING** : Avoid getting oil on brake pads. Do not lubricate or apply antirust or antifreeze solution in brake cable.

17, Brake Disc


S-Series

The brake disc must be floating on countershaft for efficient operation of brake.

Apply anti-seize lubricant (P / N 413 7010 00) on shaft and check that disc slides freely.

The disc hub exceeds the disc more from one side than from the other. Install disc with the longer exceeding portion toward driven pulley.

Push O-rings inside disc hub.



Countershaft Bearing Adjustment

S-Series

Insert countershaft (with brake disc) from chaincase side through countershaft support (driven pulley side), then insert into chaincase.

Install countershaft bearing **no. 19** and ensure that countershaft is properly aligned, then tighten 3 retaining screws.

○ **NOTE** : A misaligned countershaft will result in difficulty to center the bearing in its support.

Refer to DRIVE AXLE 06-04 then look **Chaincase Perpendicularity Adjustment**.

Torque castellated nut of upper sprocket to 53 N•m (39 lbf•ft).

▼ **CAUTION** : Upper sprocket castellated nut must be tightened **before** adjusting bearing collar.

Slide collar **no. 18** towards bearing and turn, by hand, to engage the eccentric. This should require about a quarter turn.

Turn collar in direction of countershaft rotation until collar and inner race lock together.

Insert a punch into collar hole and strike sharply in the same direction to lock firmly.

Apply Loctite 242 (P / N 413 7030 00) on set screw threads, then tighten.

Close chaincase referring to CHAINCASE 04-07.

1,11,12, Locking Tab, Outer Caliper and Nut

S-Series

Install caliper retaining bolts.

Assemble outer caliper. Install locking tab then nuts. Torque nuts to 24 N•m (18 lbf•ft). Bend locking tab over a flat of each nut.

5,10, Brake Cable and Nut

Insert brake cable into upper hole in brake lever and caliper. Install nut and tighten until a few threads exceed.


◆ **WARNING** : At least 3 threads must exceed the elastic stop nut.

ADJUSTMENT

Brake

Models with Mechanical Brake

Fully depress brake handle several times to obtain 13 mm (1/2 in) between brake handle and handlebar grip when brake is fully applied.



A. 13 mm (1/2 in)

Should this adjustment be unattainable, retighten nut **no. 10** as needed.

Models with Hydraulic Brake

Change brake fluid once a year.

Bleed brake system as follows :

Keep sufficient DOT 4 (DOT 3 for normal use) brake fluid in reservoir at all times.

▼ **CAUTION** : Use only DOT 4 brake fluid for heavy duty or racing applications.

Section 04 TRANSMISSION


Sub-Section 06 (BRAKE)

Install a hose on left side bleeder. Route this hose to a container.

Pump a few times brake lever and while holding brake lever depressed, open bleeder and check for air to escape.

Repeat with the same bleeder until no air appears in hose.

Proceed the same way with the right side bleeder.



1. Open bleeder
2. Clear hose to catch used brake fluid

Brake Light

Models with Mechanical Brake Except Tundra II LT

Brake light should light up before brake pads touch brake disc. To adjust, unscrew nut **no. 10** until brake light goes on.

◆ **WARNING :** At least one full thread must exceed the elastic stop nut.

Check brake adjustment as described above.

○ **NOTE :** If brake light adjustment is unattainable while respecting brake adjustment, ratchet wheel may be too far out. If so, tighten ratchet wheel.

Tundra II LT


Brake light should light up before brake pads touch brake disc. To adjust, unlock nut **no. 21** and turn brake switch **no. 22** accordingly. Lock in position by tightening nut **no. 21**.

Models with Hydraulic Brake

There is no adjustment on these models. Check that switch is securely installed.

CHAINCASE

Tundra II LT



A03D0QS

Section 04 TRANSMISSION


Sub-Section 07 (CHAINCASE)

REMOVAL

Chaincase and driven pulley can be removed from the vehicle as an assembly.

Remove belt guard and drive belt.

Unlock and raise driven pulley support.



Step **1** : Push and hold
Step **2** : Raise support

NOTE : On electric starting model, disconnect and remove battery from its rack.

CAUTION : Be careful not to ground positive terminal with the chassis. Always disconnect **BLACK** negative cable first.


Remove chaincase cover **no. 21** and drain oil.

Pry out drive axle from chaincase.

Unscrew the nut **no. 14** on the upper sprocket **no. 12** and remove circlip **no. 17** on the bottom one **no. 16**. Remove chain tensioner assembly **nos. 2** to **6**, then simultaneously remove chain **no. 18** and both sprockets.

Remove the 4 cap screws **no. 26** securing chaincase to frame. Save alignment shims **no. 8** for installation.

Release track tension, use drive axle holder (P / N 529 0072 00).



1. Drive axle
2. Suspension cross shaft

Chaincase and Driven Pulley Assembly

Using 2 large screwdrivers inserted between chaincase and frame, pry complete assembly from vehicle.

DISASSEMBLY

Disassemble driven pulley from chaincase. Refer to **DRIVEN PULLEY 04-04**.

INSPECTION

Visually inspect the chain for cracked, damaged or missing link rollers. Check for defective bearings, sprockets and worn chain tensioner components.

WARNING : If chain deflection is greater than 38 mm (1.5 in) (without chain tensioner), replace chain and check condition of sprockets.

GEAR RATIO MODIFICATION

For particular applications, the number of teeth of the sprockets can be increased or decreased on lower and upper sprockets.

Available lower sprocket : 27 teeth

Available upper sprockets : 11, 12, 15 teeth

Available chains : 62, 64 links

The chain length may be affected depending the combination of lower / upper sprockets as follows :

| GEAR RATIO / CHAIN LENGTH CHART | | |
|------------------------------------|----------------------|--------------|
| GEAR RATIO | CHAIN LENGTH (LINKS) | STANDARD ON |
| 11 / 27* | 62 | OPT. |
| 14 / 25 | 62 | Tundra II LT |

OPT. = Optional


* Chaincase protector **no. 8** is mandatory with this sprocket.

▼ **CAUTION :** Such modifications should only be performed by experienced mechanics since they can greatly affect vehicle performance.

○ **NOTE :** For high altitude regions, the High Altitude Technical Booklet (P / N 484 0648 00 and P / N 484 0545 00 for binder) gives information about calibration according to altitude.

ASSEMBLY

Position oil deflector ring **no. 10** then sit bearing in chaincase aperture. Install spacer then the other bearing.



- 1. Toward chaincase
- 2. Oil deflector
- 3. Bearing

1, Oil Seal

Using an appropriate pusher, press new oil seal **no. 7** into chaincase hub. Oil seal must sit flush with case hub edge.

INSTALLATION

Reverse removal procedure. Pay particular attention to the following :

Torque castellated nut **no. 7** to 14 N•m (124 lbf•in), slacken then retorque to 0.5-2.5 N•m (5-22 lbf•in).

In case of a vehicle equipped with an 11 teeth sprocket, check the wear of protectors **no. 8**. Replace if required.

Grease new gasket **no. 20** with petroleum jelly, or other suitable product, and install gasket making sure gasket it does not shift from its correct position. Tighten bolts evenly.


○ **NOTE :** Bottom pan has an emboss below chaincase housing to ease installation.

23, Chaincase Oil

Remove filler cap and pour 200 mL (7 fl. oz) of chaincase oil (P / N 413 8019 00) into chaincase.

○ **NOTE :** Chaincase oil capacity is 200 mL (7 fl. oz).

Check the oil level by removing the chaincase oil level plug.



- 1. Filler cap
- 2. Oil level plug

The oil should be leveled with the bottom of the oil level orifice.

Reinstall battery and connect cables on electric starting model.

▼ **CAUTION :** Always connect positive RED cable first to prevent sparks.

Section 04 TRANSMISSION

Sub-Section 07 (CHAINCASE)

ADJUSTMENT

Pulley Alignment

Refer to PULLEY DISTANCE AND ALIGNMENT
04-05.


Track Tension and Alignment

Refer to TRACK 06-05.

Section 04 TRANSMISSION

Sub-Section 07 (CHAINCASE)

S-Series Without Reverse Gear



A06D17S

Section 04 TRANSMISSION

Sub-Section 07 (CHAINCASE)

REMOVAL

To remove chaincase proceed as follows.

Remove tuned exhaust pipe and muffler.

◆ **WARNING :** Never remove exhaust components when engine is hot.

Remove hair pin **no. 18**. Release drive chain tension by unscrewing tensioner adjustment screw.

Drain oil by removing chaincase cover **no. 2**.

3,4,5,6,13,16,17, Cotter Pin, Nut, Sprocket, Shim and Drive Chain


Remove cotter pin **no. 3**, nut **no. 4**, washer **no. 27** retaining upper sprocket **no. 5** and screw **no. 15** retaining lower sprocket **no. 16**. Pull sprockets and drive chain simultaneously. Remove shims **nos. 6** and **17**.

○ **NOTE :** Should countershaft removal be required, refer to BRAKE 04-06 then look for Brake disc.

Remove 5 nuts **no. 14**. Three nuts are behind the lower sprocket.

Unfold locking tab **no. 24**, unscrew nuts **no. 25** then remove caliper retaining screws **no. 23**.

Release track tension, use drive axle holder **no. 21** (P / N 529 0072 00).



TYPICAL

1. Drive axle
2. Suspension cross shaft

Pry out drive axle oil seal **no. 20** from chaincase.

Pull chaincase from drive axle and countershaft.

Using 2 large screwdrivers inserted between chaincase **no. 7** and frame, pry complete assembly from vehicle.

INSPECTION

Visually inspect the chain for cracked, damaged or missing links. Check for worn or defective bearings, sprockets and chain tensioner components.

◆ **WARNING :** If chain deflection is greater than 38 mm (1.5 in) (without chain tensioner), replace chain and check condition of sprockets.

GEAR RATIO MODIFICATION

For particular applications, the number of teeth of the sprockets can be increased or decreased on lower and upper sprockets.

Refer to TECHNICAL DATA 09-03 for gear ratios.

▼ **CAUTION :** Gear ratio modifications should only be performed by experienced mechanics since they can greatly affect vehicle performance.

○ **NOTE :** For high altitude regions, the High Altitude Technical Booklet (P / N 484 0648 00 and P / N 484 0545 00 for binder) gives information about calibration according to altitude.

INSTALLATION

Reverse removal procedure and pay attention to the following. Replace oil seals, gaskets and O-rings.

Refer to DRIVE AXLE 06-04 for drive axle axial play adjustment.

11, Oil Seal

Clean chaincase bore with Loctite Safety Solvent (P / N 413 708200) then apply Loctite 609 to oil seal mounting surface (outside).

Using an appropriate pusher, press the oil seal into chaincase hub. Oil seal must fit flush with the chaincase edge.


○ **NOTE :** Should installation procedure for countershaft be required, refer to BRAKE 04-06 then look for Brake disc and Countershaft bearing adjustment.

5,16, Sprockets

Position the sprockets with the writing facing the chaincase cover.

27, Conical Spring Washer

Install washer with its concave side towards drive pulley.




4, Upper Sprocket Castellated Nut

Torque to 45 to 90 N•m (33 to 66 lbf•ft).

Install new cotter pin in the position shown.

▼ **CAUTION** : When removing a cotter pin always replace with a new one.

▼ **CAUTION** : Cotter pin will rub on chaincase cover if installed otherwise.



1. New
2. Fold cotter pin over castellated nut flats only

18, Circlip

▼ **CAUTION** : It is of the utmost importance to install the circlip otherwise damage to the chaincase components may occur.

DRIVE CHAIN ADJUSTMENT

10, O-ring

Replace O-ring **no. 10** on tensioner adjustment screw. Fully tighten tensioner adjustment screw **by hand**, then back off only far enough for hair pin to engage in locking hole.

This initial adjustment should provide 3-5 mm (1/8-13/64 in) free-play when measured at the outer circumference of the brake disc.

▼ **CAUTION** : Free-play must not exceed 5 mm (13/64 in), readjust if necessary.


◆ **WARNING** : If the specified free-play is not reached with the tensioner screw fully tightened, replace chain and check the condition of sprockets.

22, Chaincase Oil

Pour 250 mL (8.5 fl. oz) of chaincase oil (P / N 413 8019 00) into chaincase.

○ **NOTE** : Chaincase oil capacity is 250 mL (8.5 fl. oz).

Check oil level with the dipstick **unscrewed** then add if required.



TYPICAL

1. Dipstick
2. Oil level
3. Level between marks

○ **NOTE** : Chaincase must be in its proper position when checking oil level.

Section 04 TRANSMISSION

Sub-Section 07 (CHAINCASE)

ADJUSTMENT

Pulley Alignment

Refer to PULLEY DISTANCE AND ALIGNMENT
04-04.


Track Tension and Alignment

Refer to TRACK 06-05.

GEARBOX

2-SPEED GEARBOX

Touring SLE and Skandic 380 / 500



A03D17S

Section 04 TRANSMISSION


Sub-Section 08 (GEARBOX)

DISASSEMBLY

○ **NOTE :** It is possible to see the sliding gear in motion through oil gauge hole.


Unbolt gear shift linkage from shifter.

Unscrew cover screws **no. 5** as well as reverse axle screw **no. 7**.



1. Reverse axle screw


Separate cover **no. 6** from housing and move it toward the front in order to disengage fork from sliding gear.



1. Fork
2. Sliding gear

Slacken chain tension, unscrew sliding gear retaining screw **no. 31**, then remove sliding gear **no. 32**.

First remove 19-tooth reverse gear **no. 18** and then remove reverse axle **no. 20**.



1. Sliding gear screw
2. Reverse axle

Remove coupling shaft **no. 33**, 44-tooth sprocket **no. 34**, spacer **no. 38** and chain **no. 28**.

First unscrew castellated nut **no. 10**, then remove 22-tooth sprocket **no. 12**.

Force 2 spring pins **no. 16** out to disengage fork **no. 17** from its axle.

INSPECTION

14, Chain Slider

Replace slider if maximum wear is 1.0 mm (.039 in) at contact point.

Bearings

Check bearing condition. There must be no discoloration, missing rollers, broken cages, etc.

Sprockets and Gears

Check teeth.

ASSEMBLY

Reinstall drive shaft.

Reinstall gearbox housing.

○ **NOTE :** Adjustment screw can only be installed when housing is removed.

Do not reuse removed oil seals. Replace them by new ones.

Install drive axle with track then bearing and circlip in chaincase bore. Install spacer **no. 38** with its large outer diameter against sprocket, 44-tooth sprocket **no. 34**, coupling shaft **no. 33**, cap **no. 40** and screw **no. 31**.

Place a 25 cm (10-inch) rule against sprockets. Maximum allowable offset is 1 mm (.040 in).

a. If upper sprocket is too far in, possible causes are :


1. Countershaft bearing on driven pulley side may be too far in. To check, pull out bearing using countershaft bearing remover (P / N 529 0301 00) then recheck sprocket alignment. Use bearing installer (P / N 529 0302 00) to reposition bearing. Bearing housing (triangle) must be against frame without preload.
2. Add shim(s) between chaincase and frame and reposition bearing on driven pulley side accordingly.

b. If upper sprocket is too far out, check :

If there are too many shims between chaincase and frame. Remove shims accordingly and reposition bearing on driven pulley side.

Press needle bearing in 44-tooth sprocket. Assemble drive pins **no. 35** and their spring **no. 36** on 44-tooth sprocket. Tighten nut **no. 37** to 5 N•m (44 lbf•in) in a criss-cross sequence.

Insert spring pin **no. 21** in reverse axle up to inside diameter. Press needle bearing in 19-tooth sprocket. Install ring **no. 24** and 19-tooth sprocket on reverse axle.



1. Reverse axle ass'y
2. Sliding gear ass'y

Install shim **no. 13**, 22-tooth sprocket (drive) **no. 12** and washer **no. 11** then tighten castellated nut **no. 10** and conical spring washer. Secure with a new cotter pin.

Install chain **no. 28**, 44-tooth sprocket **no. 34** and its spacer **no. 38**. Spacer's large outer diameter must be against sprocket. Insert coupling shaft **no. 32** in 44-tooth sprocket.


Install needle bearing **no. 15** (wider one) in reverse gear **no. 18**.

Install reverse axle **no. 20** (assembly) making sure to properly position spring pin in housing slot. Install alignment rod **no. 19**, reverse gear **no. 18** and spacer **no. 24**. Drive sprocket hole and driven gear hole must be aligned to insert alignment rod.

Mount chain tensioner (assembly) to adjustment screw already fixed to gearbox. Assemble fork **no. 17** to axle using spring pins **no. 16**. Apply grease on O-rings.

6, Cover

Join cover (assembly) to housing. Make sure fork tabs are behind sliding sprocket thrust washer.



1. Fork tabs
2. Thrust washer

CAUTION : Gearbox cover must completely lay against housing.

Section 04 TRANSMISSION

Sub-Section 08 (GEARBOX)

5,7,8, Screws and Locking Tab

Tighten screws in a criss-cross sequence starting with the one above reverse axle. Install reverse axle screw and bend locking tab against screw head flat. Bolt shift linkage to shifter.

ADJUSTMENT

28, Chain


Fully tighten adjustment screw by hand, then back off only far enough for hair pin to engage in locking hole.

4, Gear Shift Linkage

1. Check proper fit of handle in console.
2. Shift into reverse gear.

○ **NOTE :** If it is impossible to shift into reverse gear, shorten tie-rod and try again. If it is still impossible, check if the fork engages in the sliding gear or disassemble the cover to inspect components.

3. Completely slacken ball joint lock nut on the gear shift linkage.
4. Using tool (P / N 529 0303 00) to push and hold down tie-rod plate to make sure transmission is in reverse gear. Pull shifter handle in reverse position making sure all slack is removed. Lengthen tie-rod until it contacts the rubber washer then add an additional turn.




○ **NOTE :** It is normal to feel a light friction when shifting into gear.

5. Statically test transmission operation in forward and reverse positions.
6. Hold linkage and tighten ball joint jam nut.

29, Alarm Switch

Adjust backup alarm so that it sounds when transmission is in reverse gear while engine is running.



OIL CHANGE

Place a container under bottom pan (gearbox side).

Unbolt gear shift linkage from fork axle. Unbolt and remove cover by separating it from housing and by moving it toward the front in order to release fork from sliding sprocket.


Clean cover interior.

NOTE : It is normal to find metallic particles stuck to dipstick magnet. If bigger pieces of metal are found, disassemble and check all parts.

Reinstall cover as previously described during assembly.

Fill housing with chaincase oil (P / N 413 8019 00). Oil capacity is 250 mL (8.5 oz).

Check oil level with dipstick. With dipstick unscrewed, oil level must be between MIN. and MAX. marks.




1. Dipstick

Shifter can be put in reverse position to ease removal of dipstick.

DRIVE CHAIN

GENERAL

Bombardier drive chains exist in 2 types, for proper use refer to TECHNICAL DATA 09-03.



1. 1/2 in single
2. 3/8 in silent chain

SILENT CHAIN


For 1997 there are 2 types of silent chain. One is 11-plate wide and the other (stronger) is 13-plate wide. Do not interchange sprockets. Fit chain on sprockets to make sure using right ones according to width. Refer to TECHNICAL DATA 09-03.

○ **NOTE** : No work (separation, lengthening) can be done on the silent chain type.

CHAIN ATTACHMENT

When joining chain ends, the open end of the circlip must be on opposite side of chain rotation. The circlip should also be facing the outer side of chaincase.

◆ **WARNING** : Always ensure that the connecting link circlip is in good condition and is properly secured.




TYPICAL

1. Rotation

CHAIN SEPARATION

When separating an endless chain, always use a chain bearing pin extractor. Also, make sure to remove one complete link.




○ **NOTE** : Chain connecting link should only be used to lengthen or shorten a chain when changing the number of teeth of sprocket(s). A stretched chain must never be shortened because the chain pitch has changed (increased) and will not properly match the sprocket pitch, causing premature wear.

○ **NOTE** : Refer to TECHNICAL DATA 09-03, for chain length according to gear ratio of each specific vehicle.


Section 04 TRANSMISSION

Sub-Section 09 (DRIVE CHAIN)




LENGTHENING 1/2 LINK

- A. Connecting link
- B. Link pin
- C. Cranked link
- D. Cotter pin
- E. Outer link
- F. Circlip



LENGTHENING 1 LINK

- A. Connecting link
- B. Inner link
- C. Outer link
- D. Circlip



LENGTHENING 1-1/2 LINK

- A. Connecting link
- B. Outer link
- C. Cranked link
- D. Link pin
- E. Circlip
- F. Cotter pin

| | |
|---|----------------|
| WIRING DIAGRAMS..... | 05-02-1 |
| CHART CODES..... | 05-02-1 |
| UNPLUGGING CONNECTORS..... | 05-02-3 |
| TAB AND RECEPTACLE CONNECTORS REMOVAL | 05-02-3 |
| TAB AND RECEPTACLE CONNECTORS INSTALLATION | 05-02-3 |
| ACCESSORIES INSTALLATION | 05-02-4 |
| IGNITION TIMING | 05-03-1 |
| NIPPONDENSO CDI SYSTEM (WITHOUT TRIGGER COIL) | 05-03-1 |
| DUCATI CDI SYSTEM..... | 05-03-5 |
| SPARK PLUGS | 05-04-1 |
| NGK SPARK PLUG..... | 05-04-1 |
| NGK SPARK PLUG NUMBERING SYSTEM | 05-04-1 |
| 1997 REFERENCE CHART | 05-04-1 |
| DESIGN SYMBOLS USED IN NGK SPARK PLUGS..... | 05-04-2 |
| DISASSEMBLY..... | 05-04-3 |
| HEAT RANGE | 05-04-3 |
| FOULING | 05-04-3 |
| SPARK PLUG ANALYSIS..... | 05-04-3 |
| SPARK PLUG INSTALLATION | 05-04-4 |
| SPARK PLUG TIGHTENING TORQUE | 05-04-4 |
| BATTERY | 05-05-1 |
| REMOVAL..... | 05-05-1 |
| CLEANING | 05-05-1 |
| INSPECTION | 05-05-2 |
| HYDROMETER TEST | 05-05-2 |
| BATTERY STORAGE..... | 05-05-3 |
| ACTIVATION OF NEW BATTERY | 05-05-3 |
| SERVICING..... | 05-05-5 |
| TIPS FOR CHARGING A USED BATTERY | 05-05-5 |
| BATTERY CHARGING EQUIPMENT | 05-05-6 |
| INSTALLATION OF BATTERY..... | 05-05-7 |

Section 05 ELECTRICAL

Sub-Section 02 (WIRING DIAGRAMS)

| | |
|--|-----------------|
| ELECTRIC STARTER..... | 05-06-1 |
| REMOVAL | 05-06-2 |
| DISASSEMBLY | 05-06-2 |
| CLEANING AND INSPECTION | 05-06-4 |
| ASSEMBLY | 05-06-4 |
| INSTALLATION | 05-06-5 |
| CLEANING AND INSPECTION | 05-06-6 |
| CLEANING | 05-06-6 |
| INSPECTION | 05-06-6 |
| SOLENOID SWITCH | 05-06-8 |
| TESTING PROCEDURE | 05-07-1 |
| GENERAL..... | 05-07-1 |
| USE OF BOMBARDIER IGNITION TESTER | 05-07-2 |
| NIPPONDENSO CDI SYSTEM TESTING..... | 05-07-4 |
| IGNITION COIL OUTPUT | 05-07-4 |
| IGNITION MODULE OUTPUT..... | 05-07-4 |
| MAGNETO OUTPUT | 05-07-5 |
| LIGHTING GENERATOR COIL OUTPUT | 05-07-6 |
| SUMMARY TABLE | 05-07-7 |
| RESISTANCE MEASUREMENTS | 05-07-7 |
| DUCATI CDI SYSTEM TESTING | 05-07-9 |
| TRIGGER COIL OUTPUT | 05-07-9 |
| MAGNETO OUTPUT | 05-07-9 |
| IGNITION COIL OUTPUT | 05-07-10 |
| IGNITION MODULE..... | 05-07-10 |
| LIGHTING GENERATOR COIL OUTPUT | 05-07-10 |
| SUMMARY TABLE | 05-07-11 |
| RESISTANCE MEASUREMENTS | 05-07-12 |
| VOLTAGE REGULATOR INSPECTION..... | 05-07-13 |
| INSPECTION OF AC CIRCUIT ISOLATION..... | 05-07-14 |
| INSPECTION | 05-07-14 |
| INSPECTION OF HEATING ELEMENTS | 05-07-15 |

WIRING DIAGRAMS

| MODEL | WIRING DIAGRAM PAGE | HEADLIGHT (watt) | TAILLIGHT (watt) | ELECTRICAL SYSTEM OUTPUT (watt) |
|-----------------------------------|---------------------------|---------------------|---------------------|--|
| Tundra II LT | Annex 1 | 60/55 hal. | 8/27 | 160 |
| Formula S / SL, Skandic 380 / 500 | Annex 2 | 60/55 hal. | 8/27 | 240 |
| Touring E / E LT / LE / SLE | Annex 3 | 60/55 hal. | 8/27 | 240 |

hal. = halogen

CHART CODES

Wiring Color Code

The first color of a wire is the main color, second color is the stripe.

Example: YL/BK is a YELLOW wire with a BLACK stripe.

| COLOR CODE | |
|--|---|
| BK – BLACK WH – WHITE RD – RED BL – BLUE YL – YELLOW | GN – GREEN GY – GREY VI – VIOLET OR – ORANGE BR – BROWN |

Section 05 ELECTRICAL

Sub-Section 02 (WIRING DIAGRAMS)

Following table shows wire colors related to electrical circuits.

| WIRE COLORS | ELECTRICAL CIRCUIT | ADDITIONAL INFORMATION |
|--------------------------|---|---|
| BLACK / YELLOW | ENGINE SHUT OFF – Key switch – Tether cord switch – Emergency switch | Must be grounded to stop engine. |
| BLACK (small) | Ground for shut off | |
| BLACK (Big) | Ground for starter (–) | |
| YELLOW YELLOW / BLACK | 12 volts (A.C.) | If shorted, magneto stops producing electricity. |
| RED | 12 volts (D.C.) (+) For starter motor | |
| RED / GREEN | 12 volts (D.C.) (+) For starter solenoid | |
| RED / BLUE | 12 volts (D.C.) (+) Rectifier output | |
| GREY | 12 volts (A.C.) High beam | Current returns by YELLOW / BLACK wire connected to headlamp. |
| VIOLET / GREY | 12 volts (A.C.) Low beam | |
| WHITE | 12 volts (A.C.) Brake light | Current returns by YELLOW / BLACK wire connected to taillight. |
| WHITE / RED | 12 volts (A.C.) Low oil level | Current returns by YELLOW / BLACK wire connected to oil level sensor. |
| BLUE | 12 volts (A.C.) Fuel level indicator | Current returns by YELLOW wire connected to fuel level sensor. |
| ORANGE | 12 volts (A.C.) Heated grips (max.) | Current returns by YELLOW / BLACK wire connected to heating elements. |
| ORANGE / VIOLET | 12 volts (A.C.) Heated grips (min.) | |
| BROWN | 12 volts (A.C.) Heated throttle lever (max.) | |
| BROWN / YELLOW | 12 volts (A.C.) Heated throttle lever (min.) | |
| GREEN | 12 volts (A.C.) Temperature gauge | Current returns by YELLOW wire connected to sensor. |
| VIOLET | 12 volts (A.C.) Engine overheating light. | |

Connector Location

Connectors on wiring diagrams carry the letter C followed by a number. Use this code with wiring diagram legend to find connector location on vehicle.

UNPLUGGING CONNECTORS

Always unplug connectors by pulling on housing not on wire.




A06E1PA

TYPICAL

TAB AND RECEPTACLE CONNECTORS REMOVAL

Tab Connector

It is locked in its housing by a spring tab on its side. Removal is done by squeezing this tab.




A00E1DA

TAB CONNECTOR

1. Locking tab

To remove:

- Insert a screwdriver or Snap-on TT 600-5 from opposite side of wire and pry locking tab.
- While holding locking tab pried, pull connector toward wire side.




Step 1 : Pull this side

Step 2 : Insert screwdriver here

Locking Receptacle Connector

To remove:

- Insert tool Snap-on TT 600-5 in access opening then pull housing toward wire side.



A06E1QA


TAB AND RECEPTACLE CONNECTORS INSTALLATION

Prior to installing, make sure locking tab is sufficiently lifted to properly lock.


Insert tab and receptacle connectors in their respective housings as shown in following illustrations. Push sufficiently so that they snap. Try pulling wire to ensure they are properly locked.

Section 05 ELECTRICAL

Sub-Section 02 (WIRING DIAGRAMS)



1. Tab
2. Housing



TYPICAL

1. Receptacle
2. Housing

ACCESSORIES INSTALLATION

On all **electric start models**: The direct current (DC) utilizes the snowmobile frame as ground "wire" while all alternating current (AC) consumers (lights, heated grips, fuel gauge, etc.) utilize a separate ground wire.

Never interconnect AC and DC grounds as an AC voltage drop will result. When installing accessories on **any** snowmobile, connect their wires directly to the YELLOW and YELLOW / BLACK lighting coil wires.

Even if **manual start models** have an AC ground to the chassis (on voltage regulator), all accessories utilize a ground wire isolated from chassis. When an electric starter kit is installed, the voltage regulator and its ground wire are replaced by a voltage rectifier / regulator unit permitting a completely isolated AC circuit.

◆ **WARNING** : Never secure electrical wires / cables with fuel lines. Keep wires away from any rotating, moving, heating, vibrating or sharp edge. Use proper fastening devices as required.

IGNITION TIMING

NIPPONDENSO CDI SYSTEM (WITHOUT TRIGGER COIL)

277 Engine Type

The 277 engine type uses a single coil ignition system. Refer to CDI SYSTEM 03-05 for more information.

This section is mainly divided in 2 parts, the first one using a Top Dead Center gauge to **verify the magneto flywheel timing mark position**. The second one using a stroboscopic timing light to **check ignition timing**.


Flywheel timing mark position verification is required to:

1. Troubleshoot a missing or broken magneto flywheel Woodruff key.
2. Troubleshoot a magneto flywheel corresponding to a different engine type.
3. Scribe the timing mark on a new service magneto flywheel.

Always verify magneto flywheel timing mark position before checking ignition timing.

Verifying Magneto Flywheel Timing Mark Position.

1. Disconnect spark plug wire and remove spark plug.
2. Install and adjust TDC gauge on engine as follows:
 - Rotate magneto flywheel clockwise until piston is just Before Top Dead Center.




1. Outer ring
2. Adaptor lock nut
3. Roller lock nut
4. Adaptor

- Loosen adaptor lock nut then holding gauge with dial face toward magneto, screw adaptor in spark plug hole.
 - Slide gauge far enough into adaptor to obtain a reading then finger tighten adaptor lock nut.
 - Rotate magneto flywheel clockwise until piston is at Top Dead Center.
 - Unlock outer ring of dial and turn it until "0" (zero) on dial aligns with pointer.
 - Lock outer ring in position.
3. From this point, rotate magneto flywheel back 1/4 turn then rotate it clockwise to reach the specified position. Refer to TECHNICAL DATA 09-02.

Check if yellow fin aligns with mark on fan cowl.

Section 05 ELECTRICAL

Sub-Section 03 (IGNITION TIMING)



1. Fan cowl timing mark
2. Yellow fin

If marks do not align, there is something wrong with fan mounting. Check Woodruff key and fan.


▼ **CAUTION :** Always check the timing with a stroboscopic timing light at 6000 RPM after the marks have been checked.

Checking Ignition Timing

○ **NOTE :** To perform this procedure we strongly recommend a stroboscopic timing light which is able to exceed 6000 RPM.

To check ignition timing, use a timing light (P/N 529 0092 00).

○ **NOTE :** This timing light is battery powered (2 alkaline batteries, type C) and therefore needs no auxiliary power supply. If a different timing light requiring auxiliary power supply is used on manual start models, use a separate battery to power timing light.




TIMING LIGHT (P/N 529 0092 00)

The ignition components are affected by temperature variation, therefore, timing must be checked when engine is cold, after idling for a MAXIMUM of 20 seconds.

○ **NOTE :** On applicable models, turn heating grips off prior to checking ignition timing.

1. Connect timing light pick-up to the spark plug lead. Use a digital induction type tachometer (P/N 529 0145 00).




TACHOMETER (P/N 529 0145 00)

Connect tachometer wire to spark plug wire or aim tachometer toward spark plug wire without using any connection wire.

◆ **WARNING :** Place ski tips against a wall, raise rear of vehicle on a stand so that track does not contact the ground. Do not allow anyone in front or behind the vehicle while engine is running. Keep clear of track and do not wear loose clothing which can get caught in moving parts.

2. Start the engine and point timing light straight in line with the fan cowl timing mark. Bring engine to 6000 RPM for a brief instant.



1. Fan cowl timing mark
2. Yellow fin

3. Check if the yellow fin aligns with the fan cowl timing mark. Tolerance is 1°.


NOTE : On the NIPPONDENSO ignition system, timing advance decreases as engine speed increases. When marks are aligned at 6000 RPM, spark occurrence is still Before Top Dead Center.

If the yellow fin aligns with the fan cowl timing mark, timing is correct.

If timing adjustment is required, rewind starter and starter pulley have to be removed. For removal procedure, refer to CDI SYSTEM 03-05.

IGNITION TIMING ADJUSTMENT


Timing is performed by moving armature plate, clockwise to retard spark occurrence, counterclockwise to advance.



TYPICAL

1. To retard
2. To advance

To adjust, loosen 3 armature plate retaining screws and lightly rotate armature plate in proper direction.




1. Retaining screws

Refer to the difference between the fan cowl timing mark and the yellow fin to determine the amount of rotation.

When the yellow fin is on **left** side of fan cowl timing mark, it indicates too **advanced** timing.

In this case, turn armature plate clockwise.




1. Turn clockwise to retard

When the yellow fin is on **right** side of fan cowl timing mark, it indicates **retarded** timing.

In this case, turn armature plate counterclockwise.

Section 05 ELECTRICAL

Sub-Section 03 (IGNITION TIMING)



1. Turn counterclockwise to advance

After adjustment, tighten armature plate retaining screws.

▼ **CAUTION :** Make sure armature plate screws are well secured. Armature plate screws must have medium strength thread-locker (P/N 413 7030 00) applied before tightening.

Reinstall removed parts.

Recheck ignition timing (make sure engine is cold).

DUCATI CDI SYSTEM

377, 443 and 503 Engine Types

Proper ignition timing is determined by trigger coil position.

If for any reason, ignition timing accuracy is suspected, it can be verified as follows.


Verifying Magneto Flywheel Timing Mark Position

Prior to checking the timing, it may be necessary to verify the position of the timing mark on the magneto flywheel, for the following reasons:

1. To detect a missing or broken magneto flywheel Woodruff key which would allow a change of timing to occur, with eventual break down of the engine.
2. To correctly locate and mark a timing mark on a new service magneto flywheel.
3. To verify the correct location of the factory timing mark.
4. To detect a wrong magneto flywheel.

To verify the position of the timing mark on the magneto flywheel, proceed as follows:

1. Clean the area around the spark plugs, and remove them.
2. Remove the rewind starter from the engine.
3. Install the TDC gauge in the spark plug hole, (magneto/generator side) and adjust as follows:
 - a. Position the magneto flywheel at approximately TDC.



INSTALLATION OF TDC GAUGE

1. Gauge on MAG side cylinder
2. Adaptor lock nut


- b. Assemble the gauge to the adaptor and tighten the roller lock nut. Do not tighten the adaptor lock nut.
 - c. Screw the adaptor into the spark plug hole and tighten to prevent movement in the plug hole.
 - d. Position the dial face toward the magneto/generator. Move the gauge down until the needle just begins to move, then move down a further 5 or 6 mm (approximately 1/4 in). Tighten adaptor lock nut by hand.
4. Locate the piston TDC position as follows :
 - a. Slowly rotate the magneto flywheel back and forth across TDC while observing the needle. Note that the needle stops moving only as the piston is changing direction.
 - b. Rotate the dial face so that "0" is in line with the needle when it stops moving.
 - c. Again, slowly rotate the magneto flywheel back and forth across TDC and adjust the dial face to "0", until the needle always stops exactly at "0" before changing direction.
 - d. "0" now indicates exact TDC.
5. Verify the position of the timing mark on the magneto flywheel as follows :

Section 05 ELECTRICAL

Sub-Section 03 (IGNITION TIMING)

NOTE : When checking timing, certain procedures require that the magneto flywheel be turned in a clockwise direction, viewed facing the magneto/generator. If it is necessary to turn back (counterclockwise) for any reason, rotate the magneto flywheel at least one-quarter turn counterclockwise, and then rotate it clockwise. The last magneto flywheel movement when making a critical check must always be in a clockwise direction, to ensure that the slack in engine moving parts is taken-up.

- Rotate the magneto flywheel counterclockwise, one-quarter turn then carefully rotate it clockwise until the needle indicates the specified measurement. Refer to 09-02 TECHNICAL DATA.
- Verify that the magneto flywheel mark perfectly aligns with the mark on the trigger coil, refer to illustration.
- If the marks do not align, check magneto flywheel and trigger coil part numbers and check Woodruff key condition. If all parts are the appropriate ones and if Woodruff key is in good condition, continue the procedure.




1. Trigger coil mark
2. Magneto flywheel mark

NOTE : These marks cannot be used to check dynamic (with engine running) ignition timing with a timing light: a new mark must be scribed on magneto flywheel for this purpose.

6. Scribe a new mark on magneto flywheel as follows.
 - Remove the fan cover from the engine.
 - Maintain magneto flywheel so that previous marks remain aligned.

- Scribe or punch a mark on magneto flywheel so that it perfectly aligns with the arrow on crankcase, refer to illustration. This new timing mark should be used for future timing checks (dynamic timing).
- Reinstall rewind starter.
- Check the timing with a timing light.



1. Crankcase arrow
2. Scribe a mark here
3. Maintain verified timing marks aligned (static timing)

Checking Ignition Timing

Use timing light (P/N 529 0092 00).

To check the ignition timing, refer to illustration and proceed as follows:

NOTE : Engine should be cold when checking timing. Do not idle engine for more than 20 seconds and make checks quickly.


WARNING : Place ski tips against a wall, raise rear of vehicle on a stand, so that track does not contact the ground. Do not allow anyone in front of or behind the vehicle while engine is running. Keep clear of track and do not wear loose clothing which can get caught in moving parts.

1. Connect the timing light pick-up to a spark plug cable and the power connections to the battery.

NOTE : To avoid an incorrect reading due to parallax, view the magneto flywheel and the crankcase timing marks in a straight line.

2. Start the engine and raise the engine speed at least to 2000 RPM while observing the timing marks, refer to illustration. The magneto fly-wheel mark scribed previously and the crankcase arrow should be perfectly aligned. If the marks do not align, a faulty trigger coil (check proper grounding of coil) or a faulty CDI module could be the cause : substitute one part at a time and recheck timing marks (check connectors condition prior to substituting any part).

○ **NOTE :** Ignition timing may be verified when engine speed is anywhere within 2000-6000 RPM.



CHECKING IGNITION TIMING

1. Timing light pick-up on MAG side
2. Crankcase arrow
3. Magneto flywheel mark

3. Install parts which were removed.

SPARK PLUGS

NGK SPARK PLUG

All Models

NGK SPARK PLUG NUMBERING SYSTEM

Bombardier is using the NGK spark plug type on most of the 1997 snowmobile models.

The heat range identification system is :

High number —————▶ hot plug

Low number —————▶ cold plug

1997 REFERENCE CHART

NGK spark plugs used on 1997 Bombardier snowmobiles covered in this manual:

- BR9ES

DESIGN SYMBOLS USED IN NGK SPARK PLUGS

PREFIX

B

R

9

E

S

-

15

Thread diameter

A: 18 mm

B: 14 mm

C: 10 mm

D: 12 mm

E: 8 mm

J: 12 mm x 19 mm Reach

Construction

M: Compact Type

P: Projected Insulator Type

R: Resistor Type

U: Surface Discharge

Z: Inductive Suppressor Type

SUFFIX

Heat rating numbers

2 Hot

4

5

6

7

8

9

10 Cold

Reach

E: 19 mm (3/4")

F: Taper Seat

H: 12.7mm (1/2")

L: 11.2 mm (7/16")

Z: 21 mm (53/64")

Blank

18 mm ø 12 mm (31/64")

14 mm ø 9.5 mm (3/8")

WIDE GAP

10: 1.0 mm (.040")

11: 1.1 mm (.044")

13: 1.3 mm (.050")

14: 1.4 mm (.055")

15: 1.5 mm (.060")

20: 2.0 mm (.080")

Firing end construction

A: Special Design

B: Single Ground Special Alloy

C: Dual Ground Special Alloy

G: Racing Type

GV: Racing Version of V-Type

L: Half Heat Range

S: Standard Center Electrode


V: Fine Wire Center Electrode

X: Booster Gap


Y: V-Grooved Center Electrode

A00E4NS


CROSSCUTS AND GAP STYLES OF SPARK PLUGS




Standard Type




Projected Insulator Type



Taper Seat Type



V-Type



Surface Discharge Type

A01E1PS

05-04-2

DISASSEMBLY

First unscrew the spark plug 1 turn.

Clean the spark plug and cylinder head with pressurize air then completely unscrew.

◆ **WARNING :** Whenever using compressed air, always wear protective eye wear.

HEAT RANGE


The proper operating temperature or heat range of the spark plugs is determined by the spark plug ability to dissipate the heat generated by combustion.

The longer the heat path between the electrode tip to the plug shell, the hotter the spark plug operating temperature will be – and inversely, the shorter the heat path, the colder the operating temperature will be.

A “cold” type plug has a relatively short insulator nose and transfers heat very rapidly into the cylinder head.

Such a plug is used in heavy duty or continuous high speed operation to avoid overheating.

The “hot” type plug has a longer insulator nose and transfers heat more slowly away from its firing end. It runs hotter and burns off combustion deposits which might tend to foul the plug during prolonged idle or low speed operation.



1. Cold
2. Hot

▼ **CAUTION :** Severe engine damage might occur if a wrong heat range plug is used.


A too “hot” plug will result in overheating and pre-ignition, etc.

A too “cold” plug will result in fouling (shorting the spark plug) or may create carbon build up which can heat up red-hot and cause pre-ignition or detonation.

FOULING

Fouling of the spark plug is indicated by irregular running of the engine, decreased engine speed due to misfiring, reduced performance, and increased fuel consumption. This is due to a loss of compression. Other possible causes are: prolonged idling, or running on a too rich mixture due to a faulty carburetor adjustment or incorrect fuel and/or fuel mixing. The plug face of a fouled spark plug has either a dry coating of soot or an oily, glossy coating given by an excess either of oil or of oil with soot. Such coatings form a conductive connection between the center electrode and ground.

SPARK PLUG ANALYSIS




1. Overheated (light grey)
2. Normal (brownish)
3. Fouled (black)

The plug electrode (and piston dome) reveals the condition of the engine, operating condition, method of driving and fuel mixture. For this reason it is advisable to inspect the spark plug at regular intervals, examining the plug electrode and the piston dome.

SPARK PLUG INSTALLATION

Prior to installation make sure that contact surfaces of the cylinder head and spark plug are free of grime.

1. Using a wire feeler gauge, set electrode gap according to TECHNICAL DATA 09-02.
2. Apply anti-seize lubricant (P / N 413 7010 00) over the spark plug threads to prevent possible seizure.
3. Hand screw spark plug into cylinder head and tighten with a torque wrench and a proper socket.



1. Proper socket
2. Improper socket

SPARK PLUG TIGHTENING TORQUE

| Models | Spark plugs | Torque N•m (lbf•ft) |
|------------|-------------|------------------------|
| All models | NGK | 27 (20) |

BATTERY

REMOVAL

All Models

◆ **WARNING :** Battery BLACK negative cable must always be disconnected first and connected last.

◆ **WARNING :** Never charge or boost battery while installed on vehicle.


Remove belt guard.

Unfasten spark plug cables from fan housing. Unplug spark plug caps.

Remove throttle cable attachment from air silencer.

Unplug CDI box harness connector.

Slacken collar on carburetor adaptors. Remove air silencer. CDI box will come along with.




1. Attachment
2. CDI box harness connector

Unfasten retaining strips.

Open strips and lift battery protective boot.

Remove vent tube.



- Step 1 : Unfasten and open
Step 2 : Lift protective boot
Step 3 : Remove vent tube

All Models


Withdraw battery from vehicle being careful not lean it so that electrolyte flows out of vent tube.

▼ **CAUTION :** Should any electrolyte spillage occur, immediately wash off with a solution of baking soda and water to prevent damage to vehicle components.

CLEANING

Clean the battery, battery casing, vent tube, caps, cables and battery posts using a solution of baking soda and water.

▼ **CAUTION :** Do not allow cleaning solution to enter battery interior since it will destroy the electrolyte.



1. Baking soda

Section 05 ELECTRICAL
Sub-Section 05 (BATTERY)

Remove corrosion from battery cable terminals and battery posts using a firm wire brush.

INSPECTION


Visually inspect battery casing for cracks or other possible damage. If casing is damaged, replace battery and thoroughly clean battery tray and close area with water and baking soda.

WARNING : Should the battery casing be damaged, wear a suitable pair of non-absorbent gloves when removing the battery by hand.

Inspect battery posts for security of mounting. Inspect for cracked or damaged battery caps, replace defective caps.

WARNING : Battery caps do not have vent holes. Make sure that vent tube is not obstructed.

HYDROMETER TEST



1. Specific gravity 1.260

A hydrometer measures the charge of a battery in terms of specific gravity of the electrolyte. Most hydrometers give a true reading at 27°C (80°F). In order to obtain correct readings, adjust the initial reading by adding .004 points to the hydrometer readings for each 5.5°C (10°F) above 27°C (80°F) and by subtracting .004 point for every 5.5°C (10°F) below 27°C (80°F).

This chart will be useful to find the correct reading.

Table with 3 columns: ELECTROLYTE TEMPERATURE (°C, °F) and OPERATION TO PERFORM. It provides correction factors for hydrometer readings based on temperature.

EXAMPLE NO. 1
Temperature below 27°C (80°F):
Hydrometer Reading:1.250
Electrolyte temperature: -7°C (20°F)
Subtract .024 Sp. Gr.
Corrected Sp. Gr. is 1.226

EXAMPLE NO. 2
Temperature above 27°C (80°F):
Hydrometer Reading:1.235
Electrolyte temperature: 38°C (100°F)
Add .008 Sp. Gr.
Corrected Sp. Gr. is 1.243

CAUTION : Do not install a partially charged battery on a snowmobile since the casing might crack at freezing temperature. The following chart shows the freezing point of the electrolyte in relation to the charge of the battery.

Table with 4 columns: Temperature-corrected Specific Gravity, Battery Charge, and Freezing Point of Electrolyte (in °C and °F). It shows the relationship between battery charge level and electrolyte freezing point.

BATTERY STORAGE

Disconnect and remove battery from the vehicle. Check electrolyte level in each cell, add distilled water up to upper level line.

▼ **CAUTION** : Do not overfill.

The battery must always be stored in fully charged condition. If required, charge until specific gravity of 1.260 is obtained.

▼ **CAUTION** : Battery electrolyte temperature must not exceed 50°C (122°F). The casing should not feel hot.

Clean battery terminals and cable connections using a wire brush. Apply a light coat of dielectric grease (P / N 413 7017 00) or petroleum jelly on terminals.

Clean battery casing and caps using a solution of baking soda and water. Do not allow cleaning solution to enter battery, otherwise it will destroy the electrolyte. Rinse battery with clear water and dry well using a clean cloth.

Store battery on a wooden shelf in a cool dry place. Such conditions reduce self-discharging and keep fluid evaporation to a minimum.

During the storage period, recheck electrolyte level and specific gravity readings at least every 40 days. As necessary, keep the battery at its upper level line and near full charge as possible (trickle charge).

ACTIVATION OF NEW BATTERY

◆ **WARNING** : Never charge or boost battery while installed on vehicle.

▼ **CAUTION** : Prior to charging the battery, always remove it from the vehicle to prevent electrolyte spillage.

A new battery is factory fresh dry charged. For storage purposes, it is fitted with a temporary sealing tube.


Do not remove the sealing tube or loosen battery caps unless activation is desired.

In case of accidental premature removal of caps or sealing tube, battery should be given a full charge.

Perform the following operations anytime a new battery is to be installed.


1. Remove the sealing tube from the vent elbow. Install vent tube, included in the battery kit, to battery elbow.

◆ **WARNING** : Failure to remove the sealing tube could result in an explosion.



1. Battery electrolyte

2. Remove caps and fill battery to UPPER LEVEL line with electrolyte (specific gravity: 1.260 at 20°C (68°F)).
3. Allow the battery to stand for 30 minutes MINIMUM so that electrolyte soak through battery cells.




1. 30 minutes


4. Allow gas bubbles to escape by lightly shaking battery by hand.

Section 05 ELECTRICAL

Sub-Section 05 (BATTERY)




5. Readjust the electrolyte level to the UPPER LEVEL line.



1. Battery electrolyte


6. Connect a 2 A battery charger for 10 to 20 hours.




▼ **CAUTION :** If charging rate raises higher than 2.4 A reduce it immediately. If cell temperature rises higher than 50°C (122°F) (if the casing feels hot) discontinue charging temporarily or reduce the charging rate.

◆ **WARNING :** Gases given off by a battery being charged are highly explosive. Always charge in a well ventilated area. Keep battery away from cigarettes or open flames. Always turn battery charger off prior to disconnecting cables. Otherwise a spark will occur and battery might explode.

7. Disconnect battery charger.




8. Test battery state of charge. Use a hydrometer.




1. Specific gravity 1.260

9. Let battery settle for one hour.




1. 60 minutes

10. Allow gas bubbles to escape by lightly shake battery.




11. Readjust electrolyte level.



1. Battery electrolyte

12. Reinstall caps and clean any electrolyte spillage using a solution of baking soda and water.



1. Baking soda

▼ **CAUTION :** Do not allow cleaning solution to enter battery interior since it will destroy the electrolyte.

○ **NOTE :** It is recommended to verify the battery charge once a month. If necessary, fully charge battery.

SERVICING

Electrolyte Level

Since a battery has been activated (see above), add distilled water to top up electrolyte.

TIPS FOR CHARGING A USED BATTERY

▼ **CAUTION :** Prior to charging the battery, always remove it from the vehicle to prevent electrolyte spillage.

For best results, battery should be charged when the electrolyte and the plates are at room temperature. A battery that is cold may not accept current for several hours after charging begun.

Do not charge frozen battery. If the battery charge is very low, the battery may freeze. If it is suspected to be frozen, keep it in a heated area for about two hours before charging.

◆ **WARNING :** Do not place battery near open flame.

Section 05 ELECTRICAL

Sub-Section 05 (BATTERY)


The time required to charge a battery will vary depending on some factors such as:

- Battery temperature: The charging time is increased as the temperature goes down. The current accepted by a cold battery will remain low. As the battery warms up, it will accept a higher rate of charge.
- State of charge: Because the electrolyte is nearly pure water in a completely discharged battery, it cannot accept current as well as electrolyte. This is the reason the battery will not accept current when the charging cycle first begins. As the battery remains on the charger, the current from the charger causes the electrolytic acid content to rise which makes the electrolyte a better conductor and then, the battery will accept a higher charging rate.
- Type of charger: Battery chargers vary in the amount of voltage and current that they can supply. Therefore, the time required for the battery to begin accepting measurable current will also vary.

Charging a Very Flat or Completely Discharged Battery:

Unless this procedure is properly followed, a good battery may be needlessly replaced.

- Measure the voltage at the battery posts with an accurate voltmeter. If it is below 10 volts, the battery will accept current at very low rate, in terms of milliamperes, because electrolyte is nearly pure water as explained above. It could be some time before the charging rate increases. Such low current flow may not be detectable on some charger ammeters and the battery will seem not to accept any charge.
- Only for this particular case, set the charger to a high rate.

 **NOTE :** Some chargers have a polarity protection feature which prevents charging unless the charger leads are connected to the correct battery terminals. A completely discharged battery may not have enough voltage to activate this circuitry, even though the leads are connected properly. This will make it appear that the battery will not accept a charge. Follow the charger manufacturer's instruction telling how to bypass or override this circuitry so that the charger will turn on and charge a low-voltage battery.

- Since the battery chargers vary in the amount of voltage and current they provide, the time required for the battery to accept measurable charger current might be up to approximately 10 hours or more.
- If the charging current is not up to a measurable amount at the end of about 10 hours, the battery should be replaced.
- If the charging current is measurable before the end or at the end of about 10 hours, the battery is good and charging should be completed in the normal manner as specified in **Activation of a new battery**.
- It is recommended that any battery recharged by this procedure be load tested prior to returning it to service.


BATTERY CHARGING EQUIPMENT

The battery charger should have an adjustable charging rate. Variable adjustment is preferred, but a unit which can be adjusted in small increments is acceptable.

The battery charger must be equipped with an ammeter capable of accurately measuring current of less than one ampere.

If the present charger is not adjustable to the proper current values, a rheostat can be connected in series with the battery to provide adjustment. 12 Ohm, 50 watt rheostat, such as OHMITE – 0314 or MALLORY 50K 12P, are available from electronic parts supply shops and they are suitable for use with most chargers if the peak current is to be held below 2 amps.

If you need an accurate ammeter, we recommend the use of : SHURITE – 5202 (0 to 3 amps) or – 5203 (0 to 5 amps) available from electronic parts supply shops.



1. Charger
2. Rheostat 12Ω 50W
3. Ammeter
4. Battery


For a service application and a permanent installation, both ammeter and rheostat can be built into a small box adjacent to your charger.

▼ **CAUTION :** Adequate ventilation **MUST** be provided to cool the rheostat.

Charging 2 or More Batteries at a Time

Connect all positives together and use a charger with a capacity (rated) equal to : number of battery to be charged multiply by 2 A.

For example: charging five batteries at a time requires a 10 A rated charger ($5 \times 2 \text{ A} = 10 \text{ A}$).



TYPICAL

1. 2 batteries = 4 A

INSTALLATION OF BATTERY

Ensure vent tube is properly installed on battery elbow.


Connect vent tube to vehicle fitting on front frame.

Route RED positive cable behind retaining strip and connect it to positive battery terminal. Connect RED wire (coming from ignition switch).

Connect BLACK negative cable LAST.

▼ **CAUTION :** Negative battery terminal should always be disconnected **FIRST** and reconnected **LAST**.

Apply silicone dielectric grease (P / N 413 7017 00) on battery posts and connectors.



BATTERY CONNECTION

1. Vent tube on fitting

Ensure that vent tube is not kinked or blocked then install protective boot over battery.

Close and fasten retaining strips.


Reinstall air silencer.

Fasten spark plug cables to fan housing.

Reinstall throttle cable to air silencer. See removal illustration.

ELECTRIC STARTER

S-Series with Electric Starting



A03E13S

Section 05 ELECTRICAL

Sub-Section 06 (ELECTRIC STARTER)

REMOVAL

- Disconnect BLACK ground cable from battery.
- Disconnect RED positive cable from battery.

◆ **WARNING :** Always disconnect ground cable first and connect last.

- Disconnect RED cable and RED / GREEN wire from starter solenoid switch.
- Remove starter from engine.

DISASSEMBLY

Disconnect bare wire linking starter and solenoid. Remove nuts **no. 16** then solenoid switch **no. 10** by lifting and pulling to disengage from drive lever **no. 15**.


Unscrew starter longer screws **no. 1** then pull yoke **no. 8** with end frame **no. 2** to separate from drive housing **no. 17**.

Pull armature **no. 9** with drive lever **no. 15**.

Remove insulator **no. 4** then brush springs **no. 7** being careful not to lose them since they will be projected out.

Pull brush holder **no. 5** from yoke **no. 8**.

Insert blade of a small screwdriver between stop collars.



Twist screwdriver to separate stop collars **no. 12** thus giving access to circlip **no. 13**.


Remove outer collar, circlip then inner collar.

Remove overrunning clutch **no. 11**.

Check the wear on bushing **no. 18** by measuring the amount of radial play between the armature shaft and the bushing.


The radial play should not exceed 0.20 mm (0.008 in). If greater, replace the bushing. To replace, press out the old one toward bushing cover and press in a new one with a bushing pusher. The correct size of the bushing pusher to use is given on next illustration.

▼ **CAUTION :** Support drive housing adequately to prevent damage when pressing bushing.




BUSHING PUSHER

- A. 16 mm (5/8 in) dia.
- B. 13 mm (1/2 in)
- C. 11 mm (7/16 in)
- D. 11 mm (.433 in)



- 1. Press-in
- 2. Bushing pusher
- 3. Bushing
- 4. Drive housing

Install bushing cover **no. 19** then, using a punch, stake bushing cover in place.




1. Stake bushing cover
2. Support

3, Bushing (end frame)

Check the wear on bushing **no. 3** by measuring the amount of radial play between the armature shaft and the bushing.

The radial play should not exceed 0.20 mm (.008 in). If greater, replace bushing as follows :

Using a 12 mm tap, cut threads into bushing so that the tap contacts the end frame. Continue to rotate tap until the bushing comes free.




1. Turn until bushing goes out
2. 12 mm tap

To install new bushing, use the same bushing pusher as for drive housing bushing installation.

6, Brush

To replace brush **no. 6**, proceed as follows :

Cut brush wire close to connector at the welded portion.




1. Cut close to connector

Remove burrs with a file on the remaining welded portion.

CAUTION : Be careful not to damage plastic portion of yoke.

Place spare brush plate edge against yoke connector edge (welded portion).

Crimp plate over yoke connector with a pair of pliers.



1. Plate edge
2. Yoke connector
3. Crimp
4. Spare brush

Solder the crimped portion.

CAUTION : Do not overheat and quickly perform soldering to prevent solder from flowing to the brush through the wire. Preferably use a heat sink.

Section 05 ELECTRICAL

Sub-Section 06 (ELECTRIC STARTER)

CLEANING AND INSPECTION

Refer to the end of this sub-section.

ASSEMBLY

Prior to assembling, coat sliding surfaces and moving parts on armature shaft splines, overrunning clutch, solenoid switch plunger, drive lever and bushings with G.E. Versilube G 321 (P / N 413 7040 00) lubricant.

Proceed as follows for assembling.

Secure drive housing in a vise.


▼ **CAUTION : Do not overtighten since housing might be damaged.**

Install overrunning clutch onto armature shaft. Insert **inner** collar onto shaft. Install a new circlip.

▼ **CAUTION : Always install a new circlip when servicing.**

Insert **outer** collar being careful to match protrusions with notches of collars.


Using a pair of pliers on each side of stop collars, squeeze evenly until collars sit over circlip.



1. Install on overrunning clutch
2. Install thrust washer

Slide yoke over armature.

Install brush holder then brushes in their housings. Insert springs as follows : place one end of spring against brush, compress, then push the other end of spring onto its housing. Repeat for remaining springs.




1. This end first
2. Push this end to complete

Secure insulator over brushes and springs. Properly install end frame and tighten screws.

Insert solenoid plunger inside of drive lever fork and secure to drive housing.


Connect starter bare wire to solenoid.

○ **NOTE :** Connect this wire on the **shorter** solenoid stud.



1. Squeeze evenly

Install thrust washer against outer stop collar. Place drive lever onto overrunning clutch then insert into drive housing.



- 1. Shorter stud
- 2. Bare wire


INSTALLATION

Make sure that starter and engine mating surfaces are free of grime. Serious trouble may arise if starter is not properly aligned.

Install starter.

NOTE : Check proper engaging depth of starter pinion teeth to ring gear teeth (see illustration). Install hardened washers (P / N 503 0079 00) between engine and starter supports accordingly.

CAUTION : All starter bracket fasteners must be secured with Loctite 271 (P / N 413 7074 00).



- 1. Screwdriver pulling starter pinion
- 2. Ring gear
- 3. No excessive backlash
- A. 0.5 to 1.5 mm (.020 to .060 in)

Connect the RED battery cable and the red wire to the large terminal of the solenoid. Connect RED / GREEN wire to small terminal of solenoid.

Connect BLACK cable to battery.

WARNING : Always disconnect ground cable first and connect last.

CLEANING AND INSPECTION

CLEANING

CAUTION : Armature starter yoke ass’y and drive unit assembly must not be immersed in cleaning solvent.

Clean brushes and holder with a clean cloth soaked in solvent. Brushes must be dried thoroughly with a clean cloth.

Blow brush holder clean using compressed air.

WARNING : Always wear safety goggles when using compressed air.

Remove dirt, oil or grease from commutator using a clean cloth soaked in suitable solvent. Dry well using a clean, dry cloth.

Clean engine starter gear teeth and drive unit (clutch).

NOTE : Bushings must not be cleaned with grease dissolving agents.

Immerse all metal components in cleaning solution. Dry using a clean, dry cloth.


INSPECTION

Armature

NOTE : An ohmmeter may be used for the following testing procedures, except for the one concerning the shorted windings in the armature.

Check the commutator for roughness, burnt or scored surface. If necessary, turn the commutator on a lathe, enough to remove grime only.


Check the commutator for mica depth. If the depth is less than 0.20 mm (0.008 in), undercut the mica. Be sure that no burrs are left and no copper dust remains between the segments after the undercutting operation is completed.



1. Commutator undercut 0.20 mm (.008 in)

Check the commutator out-of-round condition with V Blocks and an indicator. If the commutator out-of-round is more than 0.40 mm (.016 in), the commutator should be turned on a lathe.


Check commutator outer diameter. If less than specified value, replace.



| MODEL | WEAR LIMIT |
|----------|------------------|
| S-Series | 27 mm (1.063 in) |

Test for Ground Circuit in the Armature :


Use growler test probes. Check between armature core and the commutator bars. If growler lamp turns on, bars are grounded. Replace armature if so.



1. Test probes
2. Commutator bars

Test Armature for Shorted Winding :

When the armature is rotated in the growler with a steel strip (hack-saw blade) held above it, the strip will vibrate over that area of the armature which has short circuit. Replace armature if so.



1. Steel strip (hack-saw blade)
2. Growler


Test the Armature for Open Circuit :

Use growler test probes. Place one test probe on a commutator bar and the other test probe on the neighboring bar. Repeat this operation for all bars, moving one test probe at a time. If the growler lamp does not turn on, the armature circuit between these two bars is opened. The armature should be replaced or repaired; open circuits most often occur at the commutator riser where coils are soldered. (Burnt commutator bars are usually an indication of an open-circuit armature coil.)

Field Windings and Brushes

Test the Field Winding for Open Circuit

Use growler test probes. Place one test probe on the negative brush and the other test probe on the yoke. If growler lamp does not turn on, the field winding has an open-circuit. The yoke has to be repaired or replaced.



1. Test probes

Check the dynamic brake winding for open circuit by placing one test probe on the positive brush and the other probe on the negative brush.

If growler lamp does not turn on, the winding circuit is open-circuit and the yoke has to be repaired or replaced.

Brush Holder

Check the brush holder for insulation using growler test probes. Place one test probe on the insulated brush holder and the other test probe on the brush holder plate. If the growler lamp turns on, the brush holder has to be repaired or replaced.


Brush Length

Measure brush length. If less than the specified value, replace them.

| MODEL | LENGTH | |
|----------|--------------------|-------------------|
| | New | Wear limit |
| S-Series | 10 mm (.400 in) | 6 mm (.236 in) |

Section 05 ELECTRICAL

Sub-Section 06 (ELECTRIC STARTER)



TYPICAL

1. New
2. Wear limit

Overrunning Clutch

The pinion of the overrunning clutch should turn smoothly in the clockwise direction, and should not slip in a counterclockwise direction. If defective, replace.

Check the pinion teeth for wear and damage. If defective, replace.

SOLENOID SWITCH

Inspect connections and clean as necessary. Solenoid switch condition can be checked with an ohmmeter. Install test probes on **large** connectors of solenoid when it is activated (+ on RED / GREEN wire and – on solenoid body).

IMPORTANT : No current must be present on large cables when using ohmmeter, otherwise meter could be damaged.

TESTING PROCEDURE

GENERAL

Two types of ignition systems are found on ROTAX engines covered by this manual ; both are Capacitor Discharge Ignition (CDI) systems. The following chart gives the engine types with their implemented system.

| ENGINE TYPE | IGNITION SYSTEM | CHARGING SYSTEM OUTPUT |
|------------------|--------------------------------|------------------------|
| 277 | ①NIPPONDENSO (CDI) SINGLE COIL | 160 |
| 377, 443 and 503 | ②DUCATI (ADC) | 240 |

CDI System Identification

Nippondenso

The NIPPONDENSO CDI system has a separate ignition coil which is mounted on fan housing.


Ignition module is connected to a single ignition generator coil via a 2-wire connector (BLACK and BLACK / RED wires).

277 Engine

Ignition module stamped P / N : 070000-1960

Ignition coil stamped P / N : 129700-2480

Flywheel stamped P / N : 032700-4380



① NIPPONDENSO CDI SINGLE COIL SYSTEM

1. Separate ignition coil mounted on fan housing
2. Two-wire connector (BLACK and BLACK / RED wires)
3. Single ignition generator coil


Ducati

The DUCATI CDI system has a combined ignition module / ignition coil which are mounted on air silencer, below carburetor(s).

Ignition module is connected to the ignition generator coils via a 4-wire connector (GREEN and WHITE wires).

Section 05 ELECTRICAL

Sub-Section 07 (TESTING PROCEDURE)



② DUCATI CDI SYSTEM

1. Combined ignition module / ignition coil mounted on air silencer below carburetors
2. 4-wire connector

Ignition System Testing Sequence

When dealing with ignition problems, the following items should be verified in this order.

Nippondenso

1. Spark occurrence / spark plug condition.
2. Electrical connections.
3. Engine stop / tether cord switches.
4. Ignition coil output.
5. Ignition module output.
6. Magneto output (ignition generator coil).

▼ **CAUTION :** Whenever replacing a component in ignition system, check ignition timing.

Ducati

1. Spark occurrence / spark plug condition.
2. Electrical connections.
3. Engine stop / tether cord switches.
4. Trigger coil output.
5. Magneto output (ignition generator coil).
6. Ignition coil output.
7. Ignition module.

All Systems

The first 2 items can be checked with known automotive equipment and other items as follows.

Engine Stop / Tether Cut-Out Switches Verification

Engine Stop Switch

Unplug stop switch connector from main harness then using an ohmmeter, connect test probes to BLACK / YELLOW and BLACK wires.

Measure resistance, it must be an open circuit in its operating position and close to 0 ohm when depressed.

Tether Cut-Out Switch


Unplug tether cut-out switch connector from main harness then using an ohmmeter, connect test probes to BLACK / YELLOW and BLACK wires.

Measure resistance, it must be an open circuit when cap is over switch and close to 0 ohm when removed.

Magneto System Verification

System verification can be performed using the Bombardier ignition tester (P / N 419 0033 00), a digital ohmmeter or by substituting parts.

USE OF BOMBARDIER IGNITION TESTER



○ **NOTE :** For more information about operating and maintenance of the tester, refer to its instruction manual.

Test Condition

All tests are performed on the vehicle at cranking speed

Vigorous manual cranking against compression causes the flywheel to snap over, raising the output higher than by cranking without compression, therefore, do not remove spark plug.

Test values listed are taken against compression.

Always crank vigorously as in actual starting.

Always proceed in the following order:

1. Connect tester **P** and **N** clip leads as illustrated for each specific test.
2. Follow test procedure sequence.
3. After every test that lights the indicator lamp, **reset** the indicator circuit by depressing the reset button.

Analysis of Test Results

Indicator Lamp Lights at Specific Setting

Output is as specified. Test results should repeat 3 times. If readings do not repeat, output is erratic and cause should be investigated (loose connections or components etc.).

Indicator Lamp Lights at Lower Setting

This indicates that the output is less than that designed to operate in a satisfactory manner. However, before coming to the conclusion of a faulty condition, be certain that correct engine cranking conditions were met before condemning the tested part.

Indicator Lamp Does Not Light

One component is defective. Proceed as instructed to find defective component.

Intermittent Ignition Problems

In dealing with intermittent problems there is no easy diagnosis. For example, problems that occur only at normal engine operating temperature have to be tested under similar conditions.

In most cases of temperature and / or vibration failure, only parts replacement can solve the problem as most of these failures return to normal when engine is not running.

Multiple Problems

There is always the possibility of more than one faulty part. If after a component has been replaced, the problem still persists, carefully repeat the complete test procedure to find the other faulty part.

NIPPONDENSO CDI SYSTEM TESTING

(Applicable to 277 Engine Type)

NOTE : Ensure ignition cut-out switches are properly working and they are in the ON position prior to performing the following tests.


WARNING : To prevent powerful electric shocks while cranking engine, do not touch neither electronic ignition components (ignition coil, high tension wire, wire harness, etc.) nor tester leads.

IGNITION COIL OUTPUT

A paper clip of approximately 20 mm (3/4 in) will be used as a test adapter for the following test.

1. Clip the test adapter around spark plug cable close to the spark plug.
2. Connect tester wires then set switch and dial as follows :

| Tester wires | Component wires | Tester switch position | Tester dial position |
|--------------|---|------------------------|----------------------|
| N | Tester adapter (paper clip) on spark plug cable | LOW | 45 |
| P | Engine ground | | |



TYPICAL
1. Engine ground
2. MAG side
A. 20 mm (3/4 in)

3. Crank engine and observe indicator.

NOTE : If engine starts, allow it to idle while observing indicator. Then, shut engine off.

4. Push reset button and repeat step 3 twice.

Results :


- a. Indicator lamp lights : Ignition system is OK.
- b. Indicator lamp does not light on one or both cylinder : Proceed to following tests.

IGNITION MODULE OUTPUT

1. Disconnect both connectors at ignition coil.
At installation, secure with new locking ties.
2. Connect an ignition coil (known as being in good condition) to the spark plug.
3. Connect CDI module to replacement ignition coil paying attention to connect the WHITE / BLUE wire to the positive (+) terminal and the BLACK wire to the negative (–) terminal.

Section 05 ELECTRICAL

Sub-Section 07 (TESTING PROCEDURE)




1. Black
2. White / Blue

4. Slip plastic protectors out of coil terminals.
5. Connect tester wires to coil terminals then set switch and dial as follows :

NOTE : If necessary use jumper wires from coil terminals to tester wires.

| Tester wires | Component wires | Tester switch position | Tester dial position |
|--------------|--|------------------------|----------------------|
| N | WHITE / BLUE wire (+) of ignition coil | HIGH | 55 |
| P | BLACK wire (-) of ignition coil | | |



TYPICAL

1. Black
2. White / Blue

6. Crank engine and observe indicator.
7. Push reset button and repeat step 6 twice.

Results :

- a. **Indicator lamp lights** : Ignition module output is up to specifications. The problem is a faulty ignition coil.
- b. **Indicator lamp does not light** : Proceed to following test. If magneto output tests good, the problem is a faulty ignition module.

MAGNETO OUTPUT (Ignition Generator Coil)

1. Disconnect the 2-wire connector between ignition module and magneto harness.
At installation, secure with new locking ties.

Section 05 ELECTRICAL


Sub-Section 07 (TESTING PROCEDURE)

2. Connect tester wires then set switch and dial as follows :

| Tester wires | Component wires | Tester switch position | Tester dial position |
|--------------|-------------------------------------|------------------------|----------------------|
| N | BLACK / RED wire of magneto harness | LOW | 85 |
| P | BLACK wire of magneto harness | | |

2. Connect tester wires then set switch and dial as follows :

| Tester wires | Component wires | Tester switch position | Tester dial position |
|--------------|--|------------------------|----------------------|
| N | YELLOW wire of magneto harness | LOW | 70 |
| P | YELLOW / BLACK wire of magneto harness | | |



- 1. Black / Red
- 2. Black

- 3. Crank engine and observe indicator.
- 4. Push reset button and repeat step 3 twice.


Results :

- a. **Indicator lamp lights** : Ignition generator coil output is up to specifications.
- b. **Indicator lamp does not light** : The problem is a faulty ignition generator coil.

LIGHTING GENERATOR COIL OUTPUT

NOTE : The lighting generator coil is not part of the ignition system. It is a separate system that supplies current to the lighting system and AC-powered devices. However it can be tested with the same tester.

- 1. Disconnect wiring harness junction block at engine (the one with YELLOW and YELLOW / BLACK wires).



- TYPICAL
- 1. Yellow
 - 2. Yellow / Black

- 3. Crank engine and observe indicator.
- 4. Push reset button and repeat step 3 twice.

Results :

- a. **Indicator lamp lights** : Lighting generator coil output is up to specifications.
- b. **Indicator lamp does not light** : Lighting generator coil is faulty.

SUMMARY TABLE

| Test to perform | Tester wires | Component wires | Switch | Dial |
|--|--------------|--|--------|------|
| Ignition coil output | N | Test adapter on MAG spark plug cable | LOW | 45 |
| | P | Engine ground | | |
| Ignition module output | N | WHITE / BLUE wire (+) of ignition coil | HIGH | 55 |
| | P | BLACK wire (-) of ignition coil | | |
| Magneto output (ignition generator coil) | N | BLACK / RED wire of magneto harness | LOW | 85 |
| | P | BLACK wire of magneto harness | | |
| Lighting generator coil output | N | YELLOW wire of magneto harness | LOW | 70 |
| | P | YELLOW wire of magneto harness | | |

RESISTANCE MEASUREMENTS

As an alternate method, magneto system components can be checked with a digital ohmmeter.

NOTE : All resistance measurements must be performed with parts at room temperature (approx. 20°C (68°F)). Temperature greatly affects resistance measurements.

Disconnect connectors at ignition coil and magneto junction. Measure resistance between each terminal. Refer to the following table for values and wire colors.

NOTE : An ignition coil with good resistance measurement can still be faulty. Voltage leak can occur at high voltage level which is not detectable with an ohmmeter.

Section 05 ELECTRICAL

Sub-Section 07 (TESTING PROCEDURE)

| PART NAME | | WIRE COLOR* | RESISTANCE OHM | REMARKS |
|----------------|--|---|--|---|
| MAGNETO | Ignition generator coil | BK with BK / RD | 40 - 76 | |
| | Lighting generator coil | YL with YL / BK | 0.05 - 0.6 | |
| IGNITION COIL | Primary winding | BK with WH / BL | 0.11 - 0.21 (applicable to 277 engine type only) | No display change means open circuit. |
| | | | 0.34 - 0.62 (applicable to 503 Alpine II engine only) | |
| | Secondary winding (spark plug cap removed) | BR with high tension wire (applicable to 277 engine type only) | 4.9 - 7.5 K (4900 - 7500) | Display showing zero (0) means short circuit. |
| | | End of each high tension wire | 9 - 15 K (9000 - 15000) | |
| | Insulation | WH / BL with core | $\infty\Omega$ | |
| | | WH / BL with high tension wire | | |
| SPARK PLUG CAP | Spark plug cap | — | 4.5 - 5.5 K | |

∞ : Infinity (extremely large number)

*

| COLOR CODE | |
|-------------|-------------|
| BK – BLACK | GN – GREEN |
| WH – WHITE | GY – GREY |
| RD – RED | VI – VIOLET |
| BL – BLUE | OR – ORANGE |
| YL – YELLOW | BR – BROWN |

DUCATI CDI SYSTEM TESTING

(Applicable to 377, 443 and 503 Engine Types)

NOTE : Ensure ignition cut-out switches are properly working and they are in the ON position prior to performing the following tests.


WARNING : To prevent powerful electric shocks while cranking engine, do not touch neither electronic ignition components (ignition coil, high tension wire, wire harness, etc.) nor tester leads.

TRIGGER COIL OUTPUT

1. Disconnect the 4-wire connector at ignition module.
2. Connect tester wires then set switch and dial as follows :

| Tester wires | Component wires | Tester switch position | Tester dial position |
|--------------|----------------------------------|------------------------|----------------------|
| N | RED / WHITE wire of trigger coil | LOW | 45 |
| P | Engine ground | | |

3. Crank engine and observe indicator.
4. Push reset button and repeat step 3 twice.



1. Engine ground
2. White / Red


Results :

- a. **Indicator lamp lights :** Trigger coil output is up to specifications.
- b. **Indicator lamp does not light :** The problem is a faulty trigger coil or bad grounding.

MAGNETO OUTPUT (Ignition Generator Coil)

1. Disconnect the 4-wire connector between ignition module and magneto harness.
2. Connect tester wires then set switch and dial as follows :

| Tester wires | Component wires | Tester switch position | Tester dial position |
|--------------|-------------------------------|------------------------|----------------------|
| N | GREEN wire of magneto harness | LOW | 80 |
| P | WHITE wire of magneto harness | | |



1. Green
2. White

3. Crank engine and observe indicator.
4. Push reset button and repeat step 3 twice.

Results :


- a. **Indicator lamp lights :** Ignition generator coil output up to specifications.
- b. **Indicator lamp does not light :** The problem is a faulty ignition generator.

IGNITION COIL OUTPUT

- A paper clip of approximately 20 mm (3/4 in) will be used as a test adapter for the following test.
- Clip the test adapter around spark plug cable close to MAG side spark plug.
 - Connect tester wires then set switch and dial as follows :

| Tester wires | Component wires | Tester switch position | Tester dial position |
|--------------|---|------------------------|----------------------|
| N | Test adapter (paper clip) on spark plug cable | LOW | 70 |
| P | Engine ground | | |

NOTE : Different reading occurs if N tester wire is connected to PTO side spark plug cable.



- Engine ground
- MAG side
- 20 mm (3/4 in)

- Crank engine and observe indicator.

- NOTE : If engine starts, allow it to idle while observing indicator. Then, shut engine off.
- Push reset button and repeat step 3 twice.

Results :

- Indicator lamp lights** : Ignition system is OK.
- Indicator lamp does not light on one or both cylinder** : The problem is a faulty ignition coil / module.

IGNITION MODULE


Ignition module can not be tested with the Bombardier ignition tester. When other components test good, the module is probably faulty. Try a new module.

LIGHTING GENERATOR COIL OUTPUT

NOTE : The lighting generator coil is not part of the ignition system. It is a separate system that supplies current to the lighting system and AC-powered devices. However it can be tested with the same tester.

- Disconnect wiring harness junction block at engine (the one with YELLOW and YELLOW / BLACK wires).
- Connect tester wires then set switch and dial as follows :

| Tester wires | Component wires | Tester switch position | Tester dial position |
|--------------|--|------------------------|----------------------|
| N | YELLOW wire of magneto harness | LOW | 80 |
| P | YELLOW / BLACK wire of magneto harness | | |



- Yellow
- Yellow / Black

- Crank engine and observe indicator.
- Push reset button and repeat step 3 twice.

Results :

- a. **Indicator lamp lights** : Lighting generator coil output is up to specifications.
- b. **Indicator lamp does not light** : Lighting generator coil is faulty.

SUMMARY TABLE

| Test to perform | Tester wires | Component wires | Switch | Dial |
|--|--------------|--|--------|------|
| Trigger coil output | N | RED wire of trigger coil | LOW | 45 |
| | P | Engine ground | | |
| Magneto output (ignition generator coil) | N | GREEN wire of magneto harness | LOW | 80 |
| | P | WHITE wire of magneto harness | | |
| Ignition coil output | N | Test adapter on MAG spark plug cable | LOW | 70 |
| | P | Engine ground | | |
| Lighting generator coil output | N | YELLOW wire of magneto harness | LOW | 80 |
| | P | YELLOW / BLACK wire of magneto harness | | |

Section 05 ELECTRICAL
Sub-Section 07 (TESTING PROCEDURE)

RESISTANCE MEASUREMENTS

As an alternate method, magneto system components can be checked with a digital ohmmeter.

NOTE : All resistance measurements must be performed with parts at room temperature (approx. 20°C (68°F)). Temperature greatly affects resistance measurements.

Disconnect connector at ignition coil and magneto junction. Measure resistance between each terminal. Refer to the following table for values and wire colors.

NOTE : An ignition coil with good resistance measurement can still be faulty. Voltage leak can occur at high voltage level which is not detectable with an ohmmeter.

| PART NAME | | WIRE COLOR* | RESISTANCE OHM | REMARKS |
|----------------|--|-------------------------------|---------------------------|---|
| MAGNETO | Trigger coil | RD with engine ground | 140 - 180 | No display change means open circuit. |
| | Ignition generator coil | WH with GN | 230 - 330 | |
| | Lighting generator coil | YL with YL / BK | 0.23 - 0.28 | |
| IGNITION COIL | Secondary winding ① (spark plug cap removed) | End of each high tension wire | 5.1 - 6.3 K (5100 - 6300) | Display showing zero (0) means short circuit. |
| SPARK PLUG CAP | Spark plug cap | — | 4.5 - 5.5 K | |

① The primary winding of ignition coil can be measured because there is no external connection.

| | |
|--------------|-------------|
| * COLOR CODE | |
| BK – BLACK | GN – GREEN |
| WH – WHITE | GY – GREY |
| RD – RED | VI – VIOLET |
| BL – BLUE | OR – ORANGE |
| YL – YELLOW | BR – BROWN |

VOLTAGE REGULATOR INSPECTION

A faulty voltage regulator is often responsible for frequent burned bulbs.

▼ **CAUTION :** Never run an engine with a faulty or inoperative voltage regulator. This could damage the DUCATI CDI module.

TESTING PROCEDURE

The regulator ground must be checked to ensure the circuit is complete. If necessary, connect a good ground wire from the regulator to the engine.

A) Quick Test Without Voltmeter

▼ **CAUTION :** Do not perform this test on engines that have a DUCATI CDI system.

If a voltmeter is not available, a visual test can be performed with satisfactory results.

Disconnect **all** lights and electric equipment.

While engine is running, disconnect and connect regulator connector several times checking for a spark.

A spark on regulator terminal indicates a good and working regulator.

B) Voltmeter Test

○ **NOTE :** Use a voltmeter able to read alternating current (AC). For accurate reading, use a RMS voltmeter.

Connect a wire of the voltmeter to YELLOW / BLACK wire.

Connect the other wire of the voltmeter to YELLOW wire.

Lift the rear of vehicle and support with a mechanical stand.

Start the engine at an idle without opening the throttle.

◆ **WARNING :** Ensure the track is free of particles which might be thrown out while track is rotating. Keep hands, tools, feet and clothing clear of track. Ensure no-one is standing in close proximity to the vehicle.

Slowly open the throttle and accelerate the engine to increase the RPM.

If the meter reads over 15 volts, the regulator is defective and must be replaced.

▼ **CAUTION :** Do not increase the RPM so the voltage exceeds 15 V as the bulb(s) will burn.

○ **NOTE :** Whatever the voltmeter type used (peak voltage or RMS) the voltage must not exceed 15 V (a defective regulator will allow voltage to exceed 15 V as engine RPM is increased).

Section 05 ELECTRICAL

Sub-Section 07 (TESTING PROCEDURE)

INSPECTION OF AC CIRCUIT ISOLATION

All Electric Start Models

If AC circuit is not isolated from frame, headlamp beam will weaken.

INSPECTION

Disconnect regulator / rectifier.

Connect one digital ohmmeter probe (needle ohmmeter will not offer enough precision) to frame and other probe to YELLOW or YELLOW / BLACK magneto wires.

Measured resistance must be infinite. If such is not the case, it means there is a connection between AC circuit and DC circuit.

Disconnect one accessory at the time to identify the faulty circuit.

INSPECTION OF HEATING ELEMENTS

All measurements must be performed at 21°C (70°F).

Throttle Lever Heating Element

Resistance Measurement

| | | |
|----------------|--|-----------------------|
| HIGH INTENSITY | YELLOW / BLACK wire BROWN wire | 1.96 to 3.64 ohms |
| LOW INTENSITY | YELLOW / BLACK wire BROWN / YELLOW wire | 8.05 to 14.95 ohms |

Current Measurement

| | | |
|----------------|---------------------|----------------------|
| HIGH INTENSITY | BROWN wire | 0.23 Amp. minimum |
| LOW INTENSITY | BROWN / YELLOW wire | 0.13 Amp. minimum |


Handlebar Grip Heating Element

| | | |
|----------------|---|-----------------------|
| HIGH INTENSITY | YELLOW / BLACK wire ORANGE wire | 8.73 to 10.67 ohms |
| LOW INTENSITY | YELLOW / BLACK wire ORANGE / VIOLET wire | 17.7 to 20.7 ohms |

| | |
|---|----------------|
| TORQUE REACTION SUSPENSION | 06-02-1 |
| COMPONENT REMOVAL | 06-02-2 |
| REMOVAL..... | 06-02-2 |
| DISASSEMBLY AND ASSEMBLY | 06-02-2 |
| INSPECTION | 06-02-3 |
| RIDE ADJUSTMENT..... | 06-02-3 |
| LUBRICATION | 06-02-6 |
| SC-10 SPORT AND TOURING SUSPENSION | 06-03-1 |
| COMPONENT REMOVAL AND INSTALLATION | 06-03-2 |
| REMOVAL..... | 06-03-2 |
| DISASSEMBLY AND ASSEMBLY | 06-03-3 |
| INSPECTION | 06-03-4 |
| INSTALLATION | 06-03-5 |
| RIDE ADJUSTMENT..... | 06-03-5 |
| LUBRICATION | 06-03-7 |
| DRIVE AXLE | 06-04-1 |
| REMOVAL..... | 06-04-2 |
| DISASSEMBLY..... | 06-04-2 |
| ASSEMBLY..... | 06-04-2 |
| AXIAL PLAY | 06-04-4 |
| INSTALLATION | 06-04-7 |
| LUBRICATION | 06-04-8 |
| ADJUSTMENT..... | 06-04-8 |
| TRACK | 06-05-1 |
| TRACK TYPE APPLICATION..... | 06-05-1 |
| GENERAL | 06-05-1 |
| INSPECTION | 06-05-1 |
| REMOVAL..... | 06-05-1 |
| INSTALLATION | 06-05-1 |
| TRACK CLEAT | 06-05-4 |

TORQUE REACTION SUSPENSION

Tundra II LT



Section 06 REAR SUSPENSION

Sub-Section 02 (TORQUE REACTION SUSPENSION)

COMPONENT REMOVAL

Lift rear of vehicle and support it off the ground.

5, Rear Arm

Release spring tension. Unfasten shock from rear arm. Remove 3 screws retaining rear arm.

REMOVAL

○ **NOTE** : To prevent cross shaft from turning when unscrewing screws assembled with threadlocker, proceed as follows :

- Loosen one screw then retighten.
- Remove the other screw.
- Remove the first one.

1,2,3,4, Cross Shaft, Idler Wheel, Spacer and Screw

Remove idler wheel ass'y.

Lift rear of vehicle and support it off the ground.


Unscrew 4 screws retaining front arm and rear arm to frame.

Remove suspension.

DISASSEMBLY AND ASSEMBLY

6, Stopper Strap

Inspect strap for wear or cracks, bolt and nut for tightness. If loose, inspect hole for deformation. Replace as required. Make sure it is attached through the 3rd hole from the end. Torque nut to 11 N•m (97 lbf•in).




1. 1st hole
2. 3rd hole
A. 11 N•m (97 lbf•in)

9,10,12, Nut, Slotted Screw and Slider Shoe

To replace a worn shoe, remove the front screw and stop nut, then slide the shoe rearward out of the runner.

○ **NOTE** : Slider shoe minimum thickness : 10 mm (25/64 in).



1. Front screw and nut
A. 10 mm (25/64 in)

▼ **CAUTION** : Slider shoes must always be replaced in pairs.


7,8, Support and Front Arm Support

To remove rivets securing the supports, cut rivet heads off using a cold chisel.

At assembly, position the rivet head toward the outside of the assembly. Support the rivet head against a metal block, as shown, and use a flat head punch to secure the rivet in place.

Section 06 REAR SUSPENSION

Sub-Section 02 (TORQUE REACTION SUSPENSION)



- 1. Flat head punch
- 2. Support
- 3. Runner
- 4. Metal block

NOTE : Rivets can be substituted with 3/16 in x 3/4 in long screws and flanged elastic stop nuts. Always position screw head outside the assembly.

INSPECTION

Shock Absorber

Refer to SUSPENSION AND SKI SYSTEM 07-03 for shock inspection.


INSTALLATION

Release rear spring tension then install assembled suspension into track with front portion first.

Insert rear portion of suspension into track.

Bolt suspension to tunnel.

Pry rear spring end onto cam.



- 1. Spring end


Adjust track tension / alignment. Refer to TRACK 06-05.

RIDE ADJUSTMENT

The front portion of rear suspension is adjustable for surface condition and steering effects.

The stopper strap is adjustable for vehicle weight transfer control.

The rear portion of rear suspension is adjustable for driver's weight.



- 1. Driver's weight
- 2. Stopper strap for weight transfer
- 3. Steering effect/surface condition
- 4. Adjustment cams

Choice of suspension adjustments depends on carrying load, driver's weight, personal preference, riding speed and field condition.


Slight suspension bottoming occurring under the worst riding conditions indicates a good choice of spring preload.

To adjust rear suspension adjustment cams, use special key supplied in vehicle tool box.

Turning adjustment cam moves edges of cam supporting spring rod. The softest adjustment is reached when the supporting edge of cam is the closest to hexagonal portion of cam.

Section 06 REAR SUSPENSION


Sub-Section 02 (TORQUE REACTION SUSPENSION)



SOFFTEST ADJUSTMENT

1. Supporting edge closest to hexagonal
2. Spring


The stiffest adjustment is reached when the supporting edge of cam is the farthest to hexagonal portion of cam.




STIFFEST ADJUSTMENT

1. Supporting edge farthest to hexagonal

▼ **CAUTION :** Always turn the left side adjustment cams in a clockwise direction and the right side cams in a counterclockwise direction. Left and right adjustment cams must always be set at the same position.




RH SIDE



LH SIDE

○ **NOTE :** To quickly change rear cam position without using any tool :

- Lay vehicle on its side.
- Unhook rear spring by hand from lower idler wheel.



- Turn adjustment cam by hand to the desired position.
- Reinstall spring on its support making sure that it sits in the groove of support.

Stopper Strap

The function of the stopper strap is to control the transfer of vehicle weight during acceleration and to control track lead angle.

The longer the belt, the more the weight will be transferred to the track to provide a better traction. The shorter the belt, the lesser the weight transferred to the track, thus maintaining a more positive steering.


The longer the belt, the greater will be the track lead angle. A shorter belt will reduce track lead angle which may help when negotiating a particular snow condition.

Adjusting holes on the stopper strap allow to adjust it according to driver's requirements, field and / or snow conditions.

CAUTION : Whenever stopper strap length is changed, track tension must be readjusted to prevent any possibility of operating vehicle with a too loose or too tight track tension.

For normal use, locate bolt through 3rd hole from strap end.

WARNING : Always torque the nut to 11 N•m (97 lbf•in). Replace strap if worn or torn.



- 1. 1st hole
- 2. 3rd hole
- A. 11 N•m (97 lbf•in)

NOTE : When towing a load, it is suggested to adjust stopper strap to its shortest length, soften front springs of rear suspension and stiffen rear springs. These adjustment will improve steering ability.

Deep Snow Operation

When operating the vehicle in deep snow, it may be necessary to change position of adjustment cams, stopper strap and / or driver's riding position, to change the angle at which the track rides on the snow. Operator's familiarity with the various adjustments as well as snow conditions will dictate the most efficient combination.


Section 06 REAR SUSPENSION

Sub-Section 02 (TORQUE REACTION SUSPENSION)

LUBRICATION


Lubricate front and rear arms at grease fittings using low temperature grease (P / N 413 7061 00).

○ NOTE : There are 4 grease fittings.



SC-10 SPORT AND TOURING SUSPENSION

S-Series



A03F24S

Section 06 REAR SUSPENSION

Sub-Section 03 (SC-10 SPORT AND TOURING SUSPENSION)


COMPONENT REMOVAL AND INSTALLATION

Lift rear of vehicle and support it off the ground.

1, Rear Arm

Release spring tension by unfastening spring support. Unfasten shock from rear arm. Remove 3 screws retaining rear arm.


At installation, rear arm stroke limiter must be behind shackle.



1. Stroke limiter on rear side

18, Spring Support

CAUTION : To avoid track damage, spring supports must be mounted upward.




RIGHT SIDE SHOWN

- 1. Right position : upward
- 2. Wrong position


REMOVAL

19, Cam

Decrease spring preload by turning LH cam clockwise and RH cam counterclockwise.



LH SIDE SHOWN



RH SIDE SHOWN

Lift rear of vehicle and support it off the ground.
Block suspension in place.

2,3,4,5,6,18, Spring, Washer, Idler Wheel, Spacer, Screw and Spring Support

Unbolt spring support from runner while retaining spring end. Move spring end rearward to completely release spring preload. Proceed with the other side.

Unscrew both rear arm screws.


NOTE : To prevent cross shaft from turning when unscrewing screws assembled with threadlocker, proceed as follows :

- Knock on screw head and / or heat to break threadlocker bond.
- Loosen one screw then retighten.
- Remove the opposite screw.
- Remove the first one.

7, Screw

Unscrew center idler wheel axle from tunnel then remove.

Lift rear of vehicle until spacers, idler wheels, washers and springs can be removed.



1. Lift rear of vehicle

6, Screw

Remove both screws retaining front arm to tunnel.


Remove suspension.

DISASSEMBLY AND ASSEMBLY

Inspect track thoroughly before reinstalling suspension. Refer to 06-05 TRACK.

1, Rear Arm

At installation, rear arm stroke limiter must be on rear side.




1. Stroke limiter on rear side

8,9, Pivot Arm and Flat Washer

At installation pivot arm grease fitting must face rearward. Small washer must be against nut. Large washers must be inside rails on both side.

10, Outer Bushing

At installation, hole must face adjustment screw.



11, Axle

Note position of axles at disassembly. Axles with a paint stripe serve as idler wheel axles. These are more precise than those used as pivot axles. Idler wheel axles can be used as pivot axles but the opposite is not true.

Section 06 REAR SUSPENSION

Sub-Section 03 (SC-10 SPORT AND TOURING SUSPENSION)


12,13,14, Front Shock, Spring Stopper and Cap

Use shock spring remover (P / N 529 0271 00) in a vise. Mount shock in it and turn shock so that spring coils matched spring compressor.

Close and lock bar. Adjust handle horizontal by changing position of clevis pin.

Push down on handle until it locks. Remove spring stopper and cap then release handle.


At installation, cap opening must be 180° from spring stopper opening.



1. Spring stopper opening
2. Cap opening

20, Stopper Strap


Inspect strap for wear or cracks, bolt and nut for tightness. If loose, inspect hole for deformation. Replace as required. Make sure it is attached through the 2nd hole from the end. Torque nut to 11 N•m (97 lbf•in).



1. 1st hole
2. 2nd hole
- A. 11 N•m (97 lbf•in)

17, Slider Shoe

Replace slider shoes when it is worn to the line.



1. Wear limit line

CAUTION : Slider shoes must always be replaced in pairs.

INSPECTION

Shock Absorber

Refer to SUSPENSION AND SKI SYSTEM 07-03 then look for **Shock Inspection**.


INSTALLATION

Do not install rear spring yet. Install assembled suspension into track with front portion first.

Insert rear portion of suspension into track.

2,3,4,5,6 Spring, Washer, Idler Wheel, Spacer and Screw

On each side, install rear spring, washer, idler wheel, spacer then bolt that axle to tunnel.




1. Spacer

18, Spring Support

Install spring supports to rails.

CAUTION : To avoid track damage, spring supports must be mounted upward.




RIGHT SIDE SHOWN

1. Right position : upward
2. Wrong position

RIDE ADJUSTMENT

The stopper strap is adjustable for vehicle weight transfer control.

The rear portion of rear suspension is adjustable for driver's weight.



1. Stopper strap for weight transfer
2. Driver's weight

Choice of suspension adjustments depends on carrying load, driver's weight, personal preference, riding speed and field condition.

Rear Suspension Setting Table

| | |
|-------------------|-------------------|
| Cam position | Soft —————▶ Heavy |
| Operator's weight | Light —————▶ High |
| Riding speed | Low —————▶ High |
| Field condition | Flat —————▶ Bumpy |


Slight suspension bottoming occurring under the worst riding conditions indicates a good choice of springs preload.

Section 06 REAR SUSPENSION

Sub-Section 03 (SC-10 SPORT AND TOURING SUSPENSION)

To adjust rear suspension adjustment cams, use multi wrench supplied in vehicle tool box.


Turning adjustment cam moves edges of cam supporting spring rod. The softest adjustment is reached when the supporting edge of cam is the closest to hexagonal portion of cam.



SOFTTEST ADJUSTMENT

1. Supporting edge **closest** to hexagonal
2. Spring


The stiffest adjustment is reached when the supporting edge of cam is the farthest to hexagonal portion of cam.




STIFFEST ADJUSTMENT

1. Supporting edge **farthest** to hexagonal

▼ **CAUTION :** Always turn the left side adjustment cams in a clockwise direction and the right side cams in a counterclockwise direction. Left and right adjustment cams must always be set at the same position.



LH SIDE SHOWN



RH SIDE SHOWN

Stopper Strap

The function of the stopper strap is to control the transfer of vehicle weight during acceleration and to control track lead angle.


The longer the belt, the more the weight will be transferred to the track to provide a better traction. The shorter the belt, the lesser the weight transferred to the track, thus maintaining a more positive steering.

The longer the belt, the greater will be the track lead angle. A shorter belt will reduce track lead angle which may help when negotiating a particular snow condition.

Adjusting holes on the stopper strap allow to adjust it according to driver's requirements, field and / or snow conditions.

CAUTION : Whenever stopper strap length is changed, track tension must be readjusted to prevent any possibility of operating vehicle with a too loose or too tight track tension.

For normal use, locate bolt through 2nd hole from strap end.



- 1. 1st hole
- 2. 2nd hole
- A. 11 N•m (97 lbf•in)

WARNING : Always torque the nut to 11 N•m (97 lbf•in). Replace strap if worn or torn.

NOTE : When towing a load, it is suggested to adjust stopper strap to a shorter length and stiffen rear springs. These adjustment will improve steering ability.


Deep Snow Operation

When operating the vehicle in deep snow, it may be necessary to change position of adjustment cams, stopper strap and / or driver's riding position, to change the angle at which the track rides on the snow. Operator's familiarity with the various adjustments as well as snow conditions will dictate the most efficient combination.

LUBRICATION


Lubricate front and rear arms at grease fittings using low temperature grease (P / N 413 7061 00).

NOTE : There are 4 grease fittings.




DRIVE AXLE

Tundra II LT



S-Series



Section 06 REAR SUSPENSION

Sub-Section 04 (DRIVE AXLE)

REMOVAL

All Models

Drain oil from chaincase or gearbox. Remove chaincase cover and release drive chain tension (if applicable).

Raise and block rear of vehicle off the ground.

Remove suspension. (Refer to REAR SUSPENSION 06).

2,6, End Bearing Housing and Seal

NOTE : If applicable, remove muffler, battery and its support. If vehicle is equipped with a speedometer, remove angle drive unit and coupling cable if necessary.

On all S-Series, remove chaincase cover, chain and sprocket then circlip and bearing on drive axle.

Pry oil seals from chaincase and end bearing housing (if applicable).

Unlock sprocket from drive axle and remove with its spacer (if applicable).

8,9, Drive Axle and Sprocket

Release drive axle sprocket from track and at the same time, pulling the drive axle towards the end bearing housing side.

Remove drive axle from vehicle.

DISASSEMBLY


4, Speedometer Drive Insert

All Models

Remove speedometer drive insert (if applicable).


5,12, Bearing

To remove bearings, use puller assembly, ring and half rings as illustrated.



9,13, Sprocket and Half-Sprocket

To remove press fit sprockets, use a press and a suitable support as illustrated.




1. Support sprocket near hub

NOTE : Two different types of sprocket press fit can be found. Ensure to replace ring reinforced sprockets with the same type.

ASSEMBLY


8,9,13, Drive Axle and Sprocket

To assemble press fit sprockets, use a press and a suitable pipe as illustrated. Sprockets must be assembled according to the following dimensions.



1. Pipe

Tundra II LT




TYPICAL

1. Chaincase side

| APPLICABLE MODEL | A mm (in) | B mm (in) |
|------------------|-----------------|------------------|
| Tundra II LT | 83 (3-17/64) | 242 (9-17/32) |


S-Series



A. 155.4 mm (6-1/8 in)
B. 278.4 mm (10-31/32 in)

All Models

Ensure to align indexing marks of each sprocket when assembling.



TYPICAL


1. Indexing marks aligned

The maximum desynchronization for the sprockets is 1.5 mm (1/16 in).

To check this tolerance, place axle assembly on a plane surface and measure the gap between sprocket tooth and surface.

Section 06 REAR SUSPENSION

Sub-Section 04 (DRIVE AXLE)




1. Plane surface
A. 1.5 mm (1/16 in) MAXIMUM

CAUTION : The same sprocket must not be pressed twice on the axle. If synchronization is found to be defective, use a new sprocket.

6,8, Drive Axle and Seal

When assembling drive axle, always position a new seal on each end of drive axle (chaincase side only on Tundra II LT). Locate seal lip as illustrated.




1. Grease seal type
2. Oil seal type

11, Bearing Protector


At assembly, flat side of bearing protector must be against bearing.

5,12, Bearing

Always push bearing by inner race.



The bearing on the splined side of axle must be pushed until it is seated on shaft shoulder. The end bearing housing bearing must be flush with end of drive axle. Each bearing must have its shield facing the sprocket.



1. Bearing shield on this side
2. Flush with drive axle
3. Seated on shaft shoulder

AXIAL PLAY

S-Series

Ensure there is no deformation of the sheet metal around the end bearing housing. Straighten as required.


Before attempting to adjust the drive axle axial play, check the chaincase perpendicularity as follows :

CHAINCASE PERPENDICULARITY ADJUSTMENT

- Remove driven pulley.
- Slacken bearing collar set screw and working from the driven pulley side, turn bearing collar clockwise.

Section 06 REAR SUSPENSION

Sub-Section 04 (DRIVE AXLE)




TYPICAL

1. Set screw
2. Slacken
3. Tighten

- Extract bearing from its support.

Wrong chaincase perpendicularity will make it difficult to correctly install the bearing in its support due to the countershaft and support misalignment.




TYPICAL

- Add shim(s) (P / N 504 0398 00) between chaincase and frame to obtain easy bearing installation.

▼ **CAUTION :** When installing one shim or more between chaincase and frame, secure with 50 mm long screws.

| SHIM LOCATION | BEARING POSITION | | | |
|---------------|--------------------------------------|-------------------------------------|---------------------------------------|------------------------------------|
| | (A) TOWARD FRONT OF VEHICLE | (B) TOWARD REAR OF VEHICLE | (C) TOWARD BOTTOM OF VEHICLE | (D) TOWARD TOP OF VEHICLE |
| LOWER | | UPPER | UPPER | LOWER |

This chart can be use as a “starting point” to correct the chaincase perpendicularity.




TYPICAL

1. Upper shim location
2. Lower shim location
3. 50 mm long screws when installing one shim or more

- Do not reinstall the driven pulley at this time.

Section 06 REAR SUSPENSION
Sub-Section 04 (DRIVE AXLE)


AXIAL PLAY ADJUSTMENT



TOP VIEW

- 1. Countershaft
- 2. Shim position on end bearing housing side
- 3. Shim position on chaincase side
- 4. Drive axle
- 5. Axial play
- 6. Shim between sprocket and spacer


- Push the drive axle toward chaincase and take note of the distance between the sprocket and tunnel.



TYPICAL

- 1. Distance between sprocket and tunnel
- 2. Drive axle pushed toward chaincase

CAUTION : Be sure drive axle bearing makes full contact all around the shoulder of the bearing bore.



- 1. No gap all around

- Pull drive axle toward the end bearing housing and take note of the measurement between sprocket and tunnel.

The drive axle axial play is the difference between these 2 measurements.

- Repeat this procedure 2 or 3 times to obtain an accurate measurement.

The allowable drive axle axial play is 0 to 1.5 mm (0 to .060 in).

The drive axle axial play, as calculated above, should be within the allowable axial play, add shim(s) accordingly.

- Remove drive axle, install required shim(s) as per the **shim position** chart, reinstall drive axle without the suspension and track.

SHIM POSITION

Shim position is important to maintain proper sprocket alignment.


CAUTION : Install shim(s) following the pattern shown in the chart.

| SHIM(S) REQUIRED | SHIM POSITION AND QUANTITY | |
|---------------------|-----------------------------|-------------------|
| | END BEARING HOUSING SIDE | CHAINCASE SIDE |
| 1 | 1 | |
| 2 | 1 | 1 |
| 3 | 2 | 1 |

When installing shims between the chaincase and the drive axle bearing, there must be same quantity of shims between the drive chain sprocket and spacer.

Section 06 REAR SUSPENSION

Sub-Section 04 (DRIVE AXLE)




1. Chaincase
2. Spacer
3. Same quantity

- Double-check drive axle axial play as described above.
- Modify total shim thickness as required.
- Reinstall track and suspension. Adjust track tension and alignment.

NOTE : Center the track suspension to ensure that the alignment check made in the next step is accurate.

- To center, grasp the track suspension and move it sideways, left and right. Position the track suspension at the midpoint of its sideways movement.
- Check track front alignment by measuring the gap, on each side between guide cleat and the slider shoe, behind the suspension front axle as shown.



1. Distance between guide cleat and slider shoe
2. Suspension front axle

If the difference between each side exceeds 3 mm (1/8 in), redistribute drive axle shims as follows :

| DIFFERENCE BETWEEN EACH SIDE | DRIVE AXLE SHIM REDISTRIBUTION |
|---------------------------------|--|
| 3 to 4.5 mm (1/8 to 3/16 in) | Remove 1 shim from larger gap side. Add 1 shim on smaller gap side. |
| 4.5 to 6 mm (3/16 to 1/4 in) | Remove 2 shims from larger gap side. Add 2 shims on smaller gap side. |


INSTALLATION

4, Speedometer Drive Insert

If the drive axle to be installed is a new part and the vehicle is equipped with a speedometer, a correct size speedometer drive insert must be installed into the axle end. Ensure that insert is flush with end of axle.

Position drive axle assembly into location. Install end bearing housing. Install spacer (if applicable) between bearing and lower chaincase sprocket.

Install chaincase and position seals (if applicable), making sure that a gap of approximately 2 mm (1/16 in) exists between end of bearing housing and each seal.



SIDE VIEW

1. Bearing
2. Seal
3. Housing
4. Seal lip
- A. 2 mm approx.

Section 06 REAR SUSPENSION

Sub-Section 04 (DRIVE AXLE)

3, Retainer Ring

Make sure that welded nuts are toward inside of tunnel.

Lock drive axle sprocket with a circlip.

Reinstall the chaincase cover (if applicable).

Refill with chaincase oil.

Install the suspension. Refer to TRACK 06-05 and adjust track tension and carry out track alignment procedure.

LUBRICATION

15, Grease Fitting

Lubricate end housing bearing with low temperature grease (P / N 413 7061 00).


ADJUSTMENT

Sprocket / Track Alignment

▼ **CAUTION** : Do not temper with sprocket / track alignment if frame or suspension is damaged.

Sprockets might be repositioned to fit track holes (lugs on S-Series) without removing drive axle.

Use drive axle sprocket adjuster kit (P / N 861 7257 00).



A01B2PA

TYPICAL

TRACK

TRACK TYPE APPLICATION

Refer to TECHNICAL DATA 09-03.

GENERAL


This section gives guidelines for track removal. Some components require more detailed disassembly procedures. In these particular cases, refer to the pertaining section in this manual.

INSPECTION

Visually inspect track for :

- cuts and abnormal wear
- broken rods
- broken or missing track cleats

If track is damaged or rods are broken, replace track. For damaged or missing cleats, replace by new ones, using cleat remover (P / N 529 0082 00) for Tundra II LT (P / N 529 0287 00) for all other models. Use large-cleat installer (P / N 529 0288 00) or small-cleat installer (P / N 529 0085 00).

 **WARNING :** Do not operate a snowmobile with a cut, torn or damaged track.

REMOVAL

Tundra II LT

Remove the following items :

- chaincase cover, sprockets, chain
- muffler
- upper center idler ass'y
- suspension
- end bearing housing
- drive axle seal
- drive axle (outwards from end bearing housing)
- track

S-Series


Remove the following items :

- speedometer cable
- muffler
- chaincase cover
- suspension
- drive axle seal
- end bearing housing
- sprockets and chain
- drive axle (toward end bearing housing)
- track

INSTALLATION

All Models

Reverse the removal procedure.

 **NOTE :** When installing the track, respect rotation direction indicated by an arrow on track thread.

Check sprocket / track alignment as described in DRIVE AXLE 06-04.

Track Tension and Alignment

Track tension and alignment are interrelated. Do not adjust one without checking the other. Track tension procedure must be carried out prior to track alignment.


Tension

Lift the rear of vehicle and support with a mechanical stand. Allow the slide to extend normally. Check the gap half-way between front and rear idler wheels. Measure between slider shoe and bottom inside of track.

When using the track tension gauge (P / N 529 0215 00), slide U shape extrusion to proper deflection.


Section 06 REAR SUSPENSION

Sub-Section 05 (TRACK)



1. Example 45 mm
2. Extrusion

Insert pre-settled gauge between slider shoe and track. Allow gauge to settle by forcing track up and down. Track tension is as specified when edge of gauge reaches line.




TYPICAL

1. Line

NOTE : Lightly oil track tension gauge center pin to avoid sticking.

Tundra II LT


35 to 45 mm (1-3/8 to 1-25/32 in) when exerting a downward pull of 7.3 kg (16 lb).



A. 35 to 45 mm (1-3/8 to 1-25/32 in)

S-Series

40 to 55 mm (1-9/16 to 2-5/32 in) when exerting a downward pull of 7.3 kg (16 lb).



TYPICAL

1. 40 to 55 mm (1-9/16 to 2-5/32 in) with 7.3 kg (16 lb)


Section 06 REAR SUSPENSION

Sub-Section 05 (TRACK)

All Models

▼ **CAUTION** : Too much tension will result in power loss and excessive stress on suspension components. If too loose, the track will have a tendency to thump.

To adjust, loosen the rear idler wheel retaining screws (one side only on Tundra II LT and S-Series) and the adjuster bolt lock nut ; then loosen or tighten the adjuster bolts located on the inner side of the rear idler wheels.



TYPICAL

1. Adjuster bolt
2. Lock nut (except S-Series)
3. Retaining screw


Alignment

◆ **WARNING** : Before checking track tension, ensure that the track is free of all particles which could be thrown out while it is rotating. Keep hands, tools, feet and clothing clear of track. Ensure no one is standing in close proximity to the vehicle.

All Models

With rear of vehicle supported off the ground, start engine and allow the track to rotate **slowly**.


Check that the track is well centered ; equal distance on both sides between edges of track guides and slider shoes.



1. Guides
2. Slider shoes
3. Equal distance

◆ **WARNING** : Before checking track alignment, ensure that the track is free of all particles which could be thrown out while track is rotating. Keep hands, tools, feet and clothing clear of track.

To correct, stop engine then loosen the lock nuts and tighten the adjuster bolt on side where guides are farthest to slide. Tighten lock nuts and recheck alignment.




1. Guides
2. Slider shoes
3. Tighten on this side

Tighten lock nuts and the idler wheel retaining screws.

Section 06 REAR SUSPENSION

Sub-Section 05 (TRACK)



TYPICAL

1. Retighten (except S-Series)
2. Retighten

Restart engine, rotate track **slowly** and recheck alignment.

TRACK CLEAT


Removal

- Raise rear of vehicle off the ground and lift snow guard then rotate track to expose a cleat to be replaced.
- Using track cleat remover (P / N 529 0082 00) for Tundra II LT. Use (P / N 529 0087 00) for all other models.

Installation

○ **NOTE :** Keep the same pitch between guide cleats.

- Place new cleat in position and using small track cleat installer (P / N 529 0085 00) or large cleat installer (P / N 529 0288 00) bend cleat then push tabs into rubber.



TYPICAL

1. First step
2. Second step (to push tabs into rubber)

Section 07 STEERING / FRONT SUSPENSION

Sub-Section 01 (TABLE OF CONTENTS)

| | |
|----------------------------------|----------------|
| STEERING SYSTEM | 07-02-1 |
| INSPECTION | 07-02-3 |
| DISASSEMBLY AND ASSEMBLY | 07-02-3 |
| INSPECTION | 07-02-3 |
| ADJUSTABLE HANDLEBAR | 07-02-5 |
| STEERING ADJUSTMENT (SKIS) | 07-02-5 |
| LUBRICATION | 07-02-9 |

| | |
|--|----------------|
| SUSPENSION AND SKI SYSTEM | 07-03-1 |
| ON-VEHICLE COMPONENT REMOVAL..... | 07-03-2 |
| DISASSEMBLY | 07-03-2 |
| INSPECTION | 07-03-3 |
| INSTALLATION | 07-03-3 |
| DISASSEMBLY | 07-03-6 |
| INSPECTION | 07-03-7 |
| INSTALLATION | 07-03-7 |


Tundra II LT



Section 07 STEERING / FRONT SUSPENSION

Sub-Section 02 (STEERING SYSTEM)

S-Series



A06G01S

INSPECTION

Check skis and runner shoes for wear, replace as necessary (see section 08-03).

17,36, Steering Arm and Ski Leg

Make sure steering arm and ski leg splines interlock (if applicable).

◆ **WARNING : All parts having worn splines have to be changed by new ones.**

Check general condition of steering system.

Check general condition of steering system components for wear and replace if necessary.

DISASSEMBLY AND ASSEMBLY

8, Grip

Grips can be removed and installed without any damage by injecting compressed air into the handlebar or by heating them with a heat gun.


1, Steering Column

Remove steering pad then handlebar ass'y.

Detach short tie rod from steering column working under engine. On S-Series remove air intake silencer and carburetor(s) to gain access.

17, Steering Arm

To maintain correct steering geometry when reassembling, punch mark the steering arm and ski leg before removal.




TYPICAL

1. Punch marks

31, Heating Grip Element

On vehicle equipped with heating grips, grips might be unremovable as explained earlier, in this case, carefully proceed as follows to prevent damaging heating elements.

Locate the grip heater wires inside handlebar ; look through end of grip. Start cutting grip exactly opposite heater wires and immediately peel open to locate gap in heating element, as shown.



1. Gap in heating element opposite wires

Continue cutting along gap and remove grip. If required, slowly peel heating element from handlebar and remove.

To install, stick heating element to handlebar making sure wires do not interfere with operation of accelerator or brake handle.

◆ **WARNING : Never use lubricants (e.g. soap, grease, etc.) to install handlebar grip, use instead a mix of soap and water. Mix 40 parts of water with one part of dish washing soap (recommended: Ultra Joy, Sunlight or Palmolive).**

Insert new grip with a rubber mallet. Heat grip with a heater gun or a spot light to facilitate installation.

INSPECTION


To verify heating elements refer to TESTING PROCEDURE 05-07.

10,16, Ball Joint (Left Hand and Right Hand Treads)

Inspect ball joint ends for wear or looseness, if excessive, replace.

Section 07 STEERING / FRONT SUSPENSION
Sub-Section 02 (STEERING SYSTEM)


Screw threaded end of ball joint into tie rod. The maximum external threaded length not engaged in tie rod must not exceed the value L in the following chart :



TYPICAL

| MODEL | L | |
|------------|----|---------|
| | mm | (in) |
| All models | 20 | (25/32) |

The cut-off section of the tie rod end must run parallel with the horizontal line of the steering arm when assembled on vehicle. The ball joint should be restrained when tightening tie rod end lock nut. For torque specifications see specific exploded view.




TYPICAL

- 1. Steering arm
- 2. Parallel with steering arm

WARNING : The cut off section of the ball joint must run parallel with the steering arm. When tightening lock nuts, restrain ball joint with appropriate size wrench. Ensure not too many threads are kept outside of the tie rod according to the thread length chart.

21, Hardened Washer

Install a hardened washer on each side.




TYPICAL

- 1. Hardened washers

17,36, Steering Arm

The steering arm angles should be equal on both sides when skis are parallel with vehicle.

Steering arm must run parallel to ski.



- 1. Parallel

9,13,15, Ball Joint Nut and Jam Nut

Tighten ball joint jam nuts to specified torque (see illustration).

11,12, Steering Arm Nut and Bolt

Tighten steering arm nuts to specified torque (see illustration).

ADJUSTABLE HANDLEBAR

1,3, Steering Column and Handlebar

If applicable, remove the steering clamp and nuts holding the handlebar to the steering column. Tighten nuts to the specified torque (see illustration).

2,4,5,6, Handlebar Support, Steering Clamp, Bolt and Nut


Install the four handlebar support, steering clamp, the four screws and nuts to the column, as illustrated.

See applicable exploded view for each model.

Adjust the steering handle to the desired position.

Lock the handle in place by tightening the four nuts to 26 N•m (19 lbf•ft).

CAUTION : Tighten the nuts equally in a criss-cross sequence and ensure there is an equal gap on each side of the clamps.



TYPICAL

1. Torque 26 N•m (19 lbf•ft)
2. Equal gap all around

WARNING : Avoid contact between the brake handle and the windshield by **NOT** adjusting the handlebar too high.

WARNING : Make sure that the steering pad and all controls are properly fixed to their normal location on the handlebar.


CAUTION : Plastic alloy components such as fuel tank, windshield, controls, etc. can be cleaned using mild detergents or isopropyl alcohol and a soft clean cloth. Never clean plastic parts with strong detergent, degreasing agent, paint thinner, acetone, etc. Do not apply isopropyl alcohol directly on decals.

7,23,24,25, Steering Pad, Bolt, Nut and Rubber Attachment

CAUTION : Prior to installation, perform handlebar adjustment.

Properly fit the steering pad to the handlebar. Assemble using the two rubber attachments, nuts and bolts.

WARNING : Make sure that the steering pad and all controls are properly fixed to their normal location on the handlebar.




1. Rubber attachment
2. Nut and bolt

STEERING ADJUSTMENT (SKIS)

Definitions

TOE-OUT:

A difference in measurement between front edge A and rear edge B of skis as viewed from top side of suspension system. It is adjustable.



Section 07 STEERING / FRONT SUSPENSION

Sub-Section 02 (STEERING SYSTEM)

CAMBER:

A specific inward or outward tilt angle of ski leg compared to a vertical line when viewing vehicle from front. This angle is not adjustable on these models.

Adjustments

TOE-OUT

Tundra II LT


Adjustments should be performed following this sequence:

- Pivot arm centering/horizontal handlebar.
- Set toe-out.

PIVOT ARM CENTERING/HORIZONTAL HANDLEBAR


Turn handlebar until pivot arm is well centered in slot of its bracket.

Check if handlebar is horizontal. To adjust, loosen lock nuts of short tie rod and turn it accordingly.




1. Pivot arm centered in slot
2. Slot
3. Turn to adjust

◆ **WARNING :** Maximum ball joint external threaded length not engaged in the tie rod end must not exceed 15 mm (19/32 in). Torque lock nut to 20 N•m (15 lbf•ft).



A. 15 mm (19/32 in) max.

Restrain tie rod while firmly retighten nuts so that ball joint sockets run parallel with steering arm and pivot arm.




LONG TIE ROD SHOWN

1. Restrain tie rod to tighten lock nuts

◆ **WARNING :** Ball joint sockets must run parallel with steering arm and pivot arm. Tie rod must be restrained when tightening lock nuts.

Section 07 STEERING / FRONT SUSPENSION

Sub-Section 02 (STEERING SYSTEM)



LONG TIE ROD SHOWN

1. Ball joint parallel with arm


Ensure that pivot arm is still centered and check ski toe-out.

TOE-OUT

Loosen lock nuts of long tie rods and turn each tie rod so that skis are in a straight ahead position. To adjust toe-out, slightly turn both tie rods exactly the same amount.


Check external threaded length not engaged and firmly retighten nuts as specified above.

NOTE : To make sure skis are in straight-ahead position, place a straight edge against pre-adjusted track and measure distance between front and rear of skis and straight edge. Distances should be equal. After ski toe-out adjustment, distance at front of ski must be 3.0 mm (1/8 in) more than at rear on both sides for a total toe-out of 6 mm (1/4 in).



TYPICAL

1. 3.0 mm (1/8 in) more at front than at rear
2. Straight edge



1. Turn to adjust

DSA S-Series

Adjustments should be performed following this sequence :

- Pivot arm centering.
- Check for horizontal handlebar.
- Set toe-out.

DSA System

PIVOT ARM CENTERING

◆ **WARNING :** Do not attempt to adjust skis straight ahead position by turning ball joint on tie rod no. 14.


13,14,22, Jam Nut, Tie Rod and Pivot Arm

With handlebar in straight position, center of pivot arm must be in line with end of bolt. Loosen jam nuts on tie rod **no. 14** (LH threads on steering column end) and turn tie rod accordingly. Tighten jam nuts to 18 N•m (159 lbf•in).

◆ **WARNING :** Never lengthen tie rod so that threaded portion of ball joint exceeds 20 mm (25/32 in).

Section 07 STEERING / FRONT SUSPENSION

Sub-Section 02 (STEERING SYSTEM)




DSA

1. Tie rod no. 14
2. Center of pivot arm in line with bolt and

HANDLEBAR AND SKI TOE-OUT

Check that handlebar is horizontal when skis are in straight ahead position by measuring from the extremities of the grips to the rear most edge of the tunnel, as shown.

NOTE : The reference point must be the same relative to each side.



TYPICAL

1. Equal distance A on each side
2. Same reference point (rivet)

Adjustment is performed by adjusting length of left and right tie rods no. 20.

WARNING : Do not attempt to adjust skis straight ahead position by turning ball joint on tie rod no. 14.

Procedure :

- Loosen jam nuts no. 13 and no. 15 of both tie rods no. 20.
- Turn the tie rod on one side to shorten its length.
- Lengthen the other one by turning it exactly the same amount, so that toe-out is not changed.

WARNING : Never lengthen tie rod so that threaded portion of ball joint exceeds 20 mm (25/32 in).


- Close front of skis manually to take all slack from steering mechanism.

NOTE : A rubber cord must be hooked in front of skis to keep them closed.

Toe-out is 0 mm (0 in) when skis are in a straight-ahead position and the front of vehicle is lifted off the ground.

NOTE : To make sure skis are in a straight-ahead position, place a straight edge against pre-adjusted track and measure the distance between front and rear of skis and straight edge. Distances should be equal. After the ski toe-out adjustment, distance must be equal.

To reduce tolerance when measuring, set one ski to proper toe-out then measure from that ski to the opposite ski.



TYPICAL

1. Straight edge
2. Measure here

LUBRICATION

◆ **WARNING :** Do not lubricate throttle and/or brake cable, housing and spring coupler bolts.

Grease Fitting and Ski Leg

Use low temperature grease only (P/N 413 7061 00).


Tundra II LT

Lubricate front suspension posts and pivot arm at grease fittings. Pump five strokes of grease gun on each post.

○ **NOTE :** There are three grease fittings.


Oil ball joints and steering column bushings.

○ **NOTE :** There are 8 lubrication points.



Other grease fittings require low temperature grease (P/N 413 7061 00) injected with a grease gun.

The following symbols will be used to show what type of lubricant should be used at the suitable locations.



1. Low temperature grease
2. Chain lube or WD-40


Lubricate :

S-Series

- Steering column.
- Upper and lower control arms drop link and tie rod ends.
- Grease ski legs, ski pivots and idler arm.
- Coat stabilizer sliders with grease, and oil their ball joints if so equipped.


Section 07 STEERING / FRONT SUSPENSION
Sub-Section 02 (STEERING SYSTEM)

S-Series



SUSPENSION AND SKI SYSTEM

Tundra II LT



A05G0JS

Section 07 STEERING / FRONT SUSPENSION


Sub-Section 03 (SUSPENSION AND SKI SYSTEM)

ON-VEHICLE COMPONENT REMOVAL

8, Shock


Lift front of vehicle and support off the ground.

Unscrew shock piston pin nut then remove washer. Unscrew 3 Allen screws retaining cover **no. 3**, then remove stopper **no. 5**, washers **no. 6**, washer **no. 7**.



1. Allen screws

NOTE : These washers and stopper can be wedged in cover.



1. Washers and stopper wedged in cover
2. Spring

Pull out spring then check shock as described below in **inspection**.

Suspension Free Operation

Remove cover and check for free movement of ski leg by lifting end of ski.

DISASSEMBLY


Lift front of vehicle and support off the ground.

1,2,3,5,6,7,9,11,12, Bolt, Lock Washer, Cover, Stopper, Bushing and Nut

Remove ski bolt, nut, bushings and ski.

Unscrew shock piston pin nut then remove washer. Shock with spring will fall off the ski leg.

Unscrew 3 Allen screws retaining cover, then remove stopper and washers.




1. Allen screws

NOTE : These washers and stopper can be wedged in cover.

4,13,14,16,17, O-ring, Ski Leg, Bushing and Seal

Pull up ski leg. Steering arm will not interfere.



1. Pull up ski leg
2. Steering arm in place

Remove seal and O-rings. Drive out bushing if worn out.

INSPECTION

13, Ski Leg

Check straightness of ski leg. Check for scored or scratched surface. Replace as required.

5, Stopper

Check condition of stopper. Replace it when deteriorated.

Grease Fitting

Ensure that grease fittings are not clogged.

10, Stopper


Check stopper for crack or deterioration. Replace as required.

13, Ski Leg

Check that splines on ski leg and steering arm interlock properly with no excessive free play. Renew as necessary.

8, Shock Absorber

Secure the shock body end in a vise.



1. Clamp

CAUTION : Do not clamp directly on shock body.

Examine each shock for leaks. Extend and compress the piston several times over its entire stroke checking that it moves smoothly and with uniform resistance.

Pay attention to the following conditions that will denote a defective shock :

- A skip or a hang back when reversing stroke at mid travel.
- Seizing or binding condition except at extreme end of either stroke.
- Oil leakage.
- A gurgling noise, after completing one full compression and extension stroke.

Renew if any faults are present.

INSTALLATION

For assembly, reverse the disassembly procedure. However, pay attention to the following.


Apply low temperature grease (P / N 413 7061 00) as illustrated in exploded view above.

Tighten nuts and screws to proper torque as mentioned in exploded view.

Section 07 STEERING / FRONT SUSPENSION

Sub-Section 03 (SUSPENSION AND SKI SYSTEM)

Steering arm notch must face outside of vehicle.



1. Recess facing outside


16,17, Seal

Install seal before reinstalling ski leg.

Sub-Section 03 (SUSPENSION AND SKI SYSTEM)

Sub-Section 03 (SUSPENSION AND SKI SYSTEM)

S-Series



Section 07 STEERING / FRONT SUSPENSION


Sub-Section 03 (SUSPENSION AND SKI SYSTEM)

DISASSEMBLY

5, Shock

Lift front of vehicle and support it off the ground.

On models so equipped reduce spring preload by turning adjusting ring accordingly with special key in vehicle tool box.



1. Shock cam
2. Special key


Remove lower bolt then upper bolt of shock.

For shock spring disassembly, use shock spring remover (P / N 529 0271 00) in a vise. Mount shock in it and turn shock so that spring coils matched spring compressor.

Close and lock bar. Adjust handle horizontal by changing position of clevis pin.

Push down on handle until it locks. Remove spring stopper and cap then release handle.

At installation, cap opening must be 180° from spring stopper opening.



1. Spring stopper opening
2. Cap opening

1, Swing Arm

Lift front of vehicle and support it off the ground.

Unbolt ski.


Remove cap, circlip then slacken steering arm bolt and pull up steering arm. Note shim positions. Ski leg may fall off from swing arm.

Unbolt lower end of shock from swing arm.

Unbolt half arms and tie rods.

Unbolt rear of swing arm from frame.

Pull swing arm off the vehicle. Stabilizer bar will disengage ball joint at swing arm inside rails.



1. Cap no. 4
2. Circlip no. 3
3. Shims no. 2
4. Bolt retaining lower end of shock no. 6

INSPECTION

Check all rubber cushions for crack and wear. Replace as required.

Check straightness of splines and proper interlocking with steering arm. Replace as required.

Check for straightness of swing arm. Replace as required.

Check if grease fittings are not clogged.

Check proper action of sliding blocks in swing arm.

Check skis and runners for wear, replace as necessary.

Check condition of ski stopper. Replace it when deteriorated.

To check condition of shock on all S-Series models except Touring SLE, refer to Tundra shock inspection.

On Touring SLE gas bag shock can be inspected as follows :

Because of gas pressure, strong resistance is felt when compressing shock. When released, the shock will extend unassisted. Renew as required.

If suspecting an internal gas leak between oil chamber and gas chamber, check shock as follows :

Install shock in a vise clamping on its bottom eyelet with its rod upward.

Let it stand for 5 minutes.

Completely push down the shock rod then release.

Rod must come out at a steady speed. If speed suddenly increases particularly at end of extension, replace shock.

If suspecting a frozen gas shock proceed as follows :

Place shock in a freezer (temperature below 0°C (32°F)) for 4 hours.

Push down on rod and note its resistance, compare to a new shock. If shock is frozen it will be more difficult to compress than for the new one.

INSTALLATION

For assembly, reverse the disassembly procedure. However, pay attention to the following.

Apply low temperature grease (P / N 413 7061 00) to ski leg components.


Tighten nuts and screws to proper torque as mentioned in exploded view.

7,8, Upper Half Arm and Tie Rod

Position half arms and tie rods horizontally before tightening nuts.

9,10,11, Bolt, Nut and Link Plate

Attach link plate to frame with additional nuts and bolts, if applicable.



SOME MODELS

1. Nuts and bolts

| | |
|--|----------------|
| BODY | 08-02-1 |
| INSTALLATION AND ADJUSTMENT | 08-02-1 |
| HEADLAMP BEAM AIMING | 08-02-1 |
| BULB REPLACEMENT | 08-02-1 |
| DECAL | 08-02-2 |
| WINDSHIELD INSTALLATION | 08-02-2 |
| BELT GUARD | 08-02-2 |
| WIRING HARNESS | 08-02-2 |
| CABLES | 08-02-2 |
| PIPING | 08-02-2 |
| PLASTIC MAINTENANCE AND REPAIR | 08-02-3 |
| MAINTENANCE | 08-02-3 |
| REPAIR | 08-02-3 |
| MATERIAL REPAIR PROCEDURE | 08-02-4 |
| REPAIR PROCEDURE FOR R.I.M. POLYURETHANE | 08-02-4 |

| | |
|-----------------------------------|----------------|
| FRAME | 08-03-1 |
| FRAME CLEANING | 08-03-1 |
| FRAME WELDING | 08-03-1 |
| FRAME COMPONENT REPLACEMENT | 08-03-1 |


BODY

INSTALLATION AND ADJUSTMENT


HEADLAMP BEAM AIMING

Beam aiming is correct when center of high beam is 25 mm (1 in) below the headlamp horizontal center line, scribed on a test surface, 381 cm (12 ft 6 in) away.

Measure headlamp center distance from ground. Scribe a line at this height on test surface (wall or screen). Light beam center should be 25 mm (1 in) below scribed line.



- 1. Headlamp center line
- A. 381 cm (12 ft 6 in)
- B. 25 mm (1 in) below headlamp center



- 1. Headlamp horizontal center line
- 2. Light beam (high beam) (projected on the wall)
- 3. Light beam center
- A. 25 mm (1 in)

Required Conditions


Place the vehicle on a flat surface perpendicular to test surface (wall or screen) and 381 cm (12 ft 6 in) away from it.

Rider or equivalent weight must be on the vehicle.

Select **high beam**.

BULB REPLACEMENT

If headlamp bulb is burnt, tilt cab and unplug the connector from the headlamp. Remove the rubber boot and unfasten the bulb retainer clips or locking ring.



TYPICAL

- 1. Locking ring

Detach the bulb and replace. If the taillight bulb is burnt, expose the bulb by removing red plastic lens. To remove, unscrew the 2 retaining screws. Verify all lights after replacement.

CAUTION : Never touch glass portion of an halogen bulb with bare fingers, as it shortens its operating life. If by mistake glass is touched, clean it with isopropyl alcohol which will not leave a film on the bulb.

Section 08 BODY / FRAME

Sub-Section 02 (BODY)

DECAL

To remove a decal ; heat old decal with a heat gun and peel off slowly.

Using isopropyl alcohol, clean the surface and dry thoroughly.

Apply liquid soap to new decal and carefully position the decal. Using a sponge or a squeegee, remove the air bubbles and surplus water working from the center toward the edges. Allow to air dry.


▼ **CAUTION :** Do not apply isopropyl alcohol or solvant directly on decals.

WINDSHIELD INSTALLATION

When peeling off the protective film some polyethylene particles may remain on the windshield. A soft clean cloth moistened with naphtha (camping equipment fuel) will easily remove the remaining particles.

◆ **WARNING :** Naphtha is flammable and explosive under certain conditions. Always manipulate in a well ventilated area. Do not smoke or allow open flames or sparks in the vicinity.

Position the windshield on the hood then push it down until the tabs are fully inserted into the hood slots. Lock the windshield tabs in position using latches as shown.



S-SERIES

1. Latch
2. Temporary remove headlamp molding for windshield installation

BELT GUARD

Disassembly and Assembly

○ **NOTE :** For additional information (ex. : exploded view) refer to the correspondent parts catalog.

◆ **WARNING :** Engine should be running only with belt guard and / or pulley guard well secured in place.

Inspection

Check belt guard mounting bosses, clips and retainers for wear.

○ **NOTE :** Belt guards are purposely made slightly oversize to maintain tension on their clips and retainers preventing undue noise and vibration. It is important that this tension be maintained when reassembling.

WIRING HARNESS

◆ **WARNING :** Ensure all terminals are properly crimped on the wires and that all connector housings are properly fastened. Keep wires away from any rotating, moving, heating and vibrating parts. Use proper fastening devices as required.

CABLES

◆ **WARNING :** Before installation, ensure that all cables are in perfect condition. Properly install the cable ends and secure them in place. Pay attention to route them properly, away from any rotating, moving, heating, or vibrating parts.

PIPING

◆ **WARNING :** Always ensure that the fuel, vent, primer, impulse, injection oil and rotary valve oil lines are properly fixed to their connectors, that they are not perforated or kinked and that they are properly routed away from any rotating, moving, heating or vibrating parts. Also check for leaks. Replace if required.

○ **NOTE :** Refer to proper *Parts Catalog* to find suitable clip part numbers.

PLASTIC MAINTENANCE AND REPAIR

MAINTENANCE

Clean the vehicle thoroughly, removing all dirt and grease accumulation.

To clean use a soft clean cloth and either soapy water or isopropyl alcohol.

To remove grease, oil or glue use isopropyl alcohol.

▼ **CAUTION :** Do not apply isopropyl alcohol or acetone directly on decals.

▼ **CAUTION :** The following products **must not** be used to clean or wax any of the plastic components used on the vehicles :

- gasoline
- brake fluid
- kerosene
- diesel fuel
- lighter fluid
- varsol
- naphtha
- acetone
- strong detergents
- abrasive cleaners

- waxes containing an abrasive or a cleaning agent in their formula

▼ **CAUTION :** Clean R.I.M. Metton® with isopropyl alcohol **only**. **Never** use cleaners or products containing **chlorine**.

Apply wax on glossy finish only. Protect the vehicle with a cover to prevent dust accumulation during storage.



▼ **CAUTION :** If for some reason the snowmobile has to be stored outside it is preferable to cover it with an opaque tarpaulin. This will prevent the sun rays from affecting the plastic components and the vehicle finish.

REPAIR

The very first step before repairing plastic materials is to find out exactly which type of material is involved. Refer to following chart.

▼ **CAUTION :** Consult chart and repair kit instructions carefully, some repair products are not compatible with certain plastics.

◆ **WARNING :** Polycarbonate windshields must **never** be repaired by welding or otherwise.

| PART | MODEL | REPAIRABLE | IRREPARABLE |
|--|--------------|---------------------|--------------|
| | | R.I.M. POLYURETHANE | POLYETHYLENE |
| HOOD  <small>A03H0ZJ</small> | Tundra II LT | | |
| | S-Series | | |
| BOTTOM PAN  <small>A06H1AJ</small> | Tundra II LT | | |
| | S-Series | | |

Section 08 BODY / FRAME

Sub-Section 02 (BODY)

MATERIAL REPAIR PROCEDURE

R.I.M. polyurethane is light colored (tan) on the inside with a smooth surface.

◆ **WARNING :** Material should be repaired and repainted in a well ventilated area only.

▼ **CAUTION :** Clean R.I.M. with isopropyl alcohol or Crest Hi-Solv product. **Never** use cleaners or products that contain **chlorine**.

▼ **CAUTION :** R.I.M. should never be exposed to temperatures exceeding 93°C (200°F).

○ **NOTE :** When working on a R.I.M. surface, never use a grinder or a high revolution tool such as an air or electric buffer. Use of such tools could overheat material and liberate agents in it thus causing a bad adhesion.

REPAIR PROCEDURE FOR R.I.M. POLYURETHANE

Small Scratches

- Sand and scuff area.
- Feather out edges.
- Paint with a matching acrylic auto touch-up paint.

Deep Scratches

- Sand and scuff area.
- Make a V groove using a knife or a rough round file.
- Clean surface with isopropyl alcohol or Crest Hi-Solv stock no. AH-S product.
- Cover with TP-E epoxy mixed in equal quantities.
- Heat the surface with a heater lamp placed at 38 cm (15 in) for a period of 15 minutes.
- Sand the repair using a smooth dry sand paper.
- Use the same product if a final finish is required.
- Clean surface with Crest Hi-Solv product.
- Apply a flexible primer such as Crest Prima Flex stock no. AP-F.
- Wait 10 minutes.
- Repaint (air dry during 72 hours (approximately)).

Large Crack

- Sand and scuff outside and inside area by exceeding it 31.7 mm (1-1/4 in) on each side and 12.7 mm (1/2 in) at each end.
- Make a V groove (appr. 90°) on both sides of hood using a knife or a rough round file.
- Enlarge the crack to 2.4 mm (3/32 in) – 3.2 mm (1/8 in) using a sharp knife.
- Clean outside and inside surface with isopropyl alcohol or Crest Hi-Solv product.
- Repair inside surface first.
- Cover inside area with Crest TP-E epoxy.
- Apply a 50 mm × 30 mm (2 in × 1-1/4 in) patch. If no room for the patch, use tape.
- Cover exterior surface with same product. Damaged area should be slightly higher.
- Heat surface with a heater lamp placed at 38 mm (15 in) for a period of 15 minutes.
- Sand outside repair using a smooth dry sand paper.
- Use same product if a final finish is required.
- Apply a flexible primer.
- Wait 10 minutes.
- Repaint (air dry during 72 hours approximately).

○ **NOTE :** R.I.M. material is high static plastics, painting must be done in a dust free area such as a paint booth.

CREST MAIN OFFICE AND MANUFACTURING PLANT**CREST INDUSTRIES, INC.**

3841 13th Street
Wyandotte, Michigan
48192

Phone : 313-283-4100
Toll Free : 1-800-822-4100
Fax : 1-800-344-4461
Fax : 313-283-4461

Crest products used in R.I.M. repair procedure are available from following locations :

DISTRIBUTOR WAREHOUSE LOCATIONS

| UNITED STATES | | CANADA |
|--|--|--|
| CREST EAST COAST, INC. P.O. Box 550 1109 Industrial Parkway Brick, New Jersey 08723 Phone : 908-458-9000 Fax : 908-458-5753 CREST PRODUCTS, INC. <i>Shipping Address :</i> 125 Production Drive Yorktown, Virginia 23693 Phone : 804-599-6572 Virginia : 1-800-572-5025 Outstate : 1-800-368-5033 Fax : 804-599-6630 <i>Mailing Address :</i> P.O. Box 2018 Grafton, Virginia 23692 CREST INDUSTRIES SOUTHEAST, INC. <i>Shipping Address :</i> 4300 Glen Haven Drive Decatur, Georgia 30035 Phone : 404-288-4658 Toll Free : 1-800-552-0876 Fax : 404-288-4658 <i>Mailing Address :</i> P.O. Box 254 Decatur, Georgia 30031 | CREST INDUSTRIES, INC. (CREST MID-WEST) 231 Larkin Williams Ind. Court St. Louis, Missouri 63026 Phone : 314-349-4800 Toll Free : 1-800-733-2737 Fax : 314-349-4888 Toll Free Fax : 1-800-776-2737 CREST MID WEST Regional Branch Warehouses CREST INDUSTRIES, INC. P.O. Box 635 Mountain Home, Arkansas 72653 Phone : 501-491-5583 Toll Free : 1-800-733-2737 CREST INDUSTRIES, INC. 4200 Jackson Street, Unit 9 Denver, Colorado 80216 Phone : 303-320-3900 Toll Free : 1-800-733-2737 Fax : 303-320-6509 REM-CO DISTRIBUTING, INC. 5625 S. Adams Tacoma, Washington 98409 Phone : 206-474-5414 Toll Free : 1-800-735-7224 Fax : 206-474-7339 | J2 PRODUCTS A Division of Sawill Ltd. 54 Audia Court, Unit 2A Concord, Ontario, L4K 3N4 <i>Phone :</i> Toronto : 416-665-1404 Concord : 905-669-9410 Montréal : 514-655-6505 <i>Fax :</i> Concord : 905-669-9419 Montréal : 514-655-6505 WHEEL-IN AUTOMOTIVE SUPPLY <i>Shipping Address :</i> # 1, 3911A Brandon St. S.E. Calgary, Alberta, T2G 4A7 Office : 403-287-0775 <i>Mailing Address :</i> P.O. Box 40036 929-42nd Avenue S.E. Calgary, Alberta, T2G 5G5 |

FRAME

FRAME CLEANING

NOTE : For aluminum frames use only aluminum cleaner and follow instructions on container. (Dursol cleaner or equivalent).

Clean frame and tunnel with appropriate cleaners and rinse with high pressure hose.

Touch up all metal spots where paint has been scratched off. Spray all bare metal parts of vehicle with metal protector.

Seat Cleaning

For all models, it is recommend to clean the seat with a solution of **warm soapy water**, using a soft clean cloth.

CAUTION : Avoid use of harsh detergents such as strong soaps, degreasing solvents, abrasive cleaners, paint thinners, etc. that may cause damage to the seat cover.

FRAME WELDING


Steel Frame :

- electric welding
- amperage : 70-110 A
- voltage : 20-24 V
- rod : E-7014 (3/32 in)

Aluminum Frame : (refer to specialized welding shop)

- argon-oxygen / acetylene welding
- rod : ER-4043 (3/32 in)

CAUTION : Before performing electrical welding anywhere on the vehicle, unplug the multiple connector at the electronic box. On models equipped with a battery, also unplug the negative cable. This will protect the electronic box and battery against damage caused by flowing current when welding.



TYPICAL

1. Unplug before electrical welding

CAUTION : If welding is to be done near plastic material, it is recommended to either remove the part from the area or to protect it with aluminum foil to prevent damage.

FRAME COMPONENT REPLACEMENT

S-series

Drilling Procedure

When drilling self-piercing rivets, use Supertanium™ drill bit (P / N 529 0318 00), available in a 5 mm (3/16 in) size and shipped in packs of 2.

For proper drilling instructions and to prevent premature wear, follow the procedure below.

Always use a variable speed electric drill.

It is not necessary to center punch the rivet head, simply center the drill bit on the rivet and drill.

Maintain a slow to medium speed at all times when drilling. The proper speed is attained when a constant chip is ejected.

NOTE : To increase bit life, use Bombardier synthetic chaincase oil (P / N 413 8033 00) as a cutting oil.

CAUTION : High speed drilling will cause excessive heat which may destroy the cutting edge of the bit, therefore avoid using pneumatic drills.


Section 08 BODY / FRAME

Sub-Section 03 (FRAME)

Grinding Procedure

Rear Cap

Grind rivet heads from top of rear cap and underneath for side retaining rivets.



1. Rivets heads ground
2. Rivets to be ground from underneath

To remove rivet, strike with a punch from rivet head side.

Make a chamfer from underneath on all 4 corner holes.

TECHNICAL DATA

SI* METRIC INFORMATION GUIDE

| BASE UNITS | | | |
|---------------------|---------|--------------------------|-----------------|
| DESCRIPTION | | UNIT | SYMBOL |
| length | | meter | m |
| mass | | kilogram | kg |
| force | | newton | N |
| liquid | | liter | L |
| temperature | | Celsius | °C |
| pressure | | kilopascal | kPa |
| torque | | newton•meter | N•m |
| speed | | kilometer per hour | km/h |
| PREFIXES | | | |
| PREFIX | SYMBOL | MEANING | VALUE |
| kilo | k | one thousand | 1 000 |
| centi | c | one hundredth | 0.01 |
| milli | m | one thousandth | 0.001 |
| micro | μ | one millionth | 0.000001 |
| CONVERSION FACTORS | | | |
| TO CONVERT | | TO † | MULTIPLY BY |
| in | | mm | 25.4 |
| in | | cm | 2.54 |
| in² | | cm² | 6.45 |
| in³ | | cm³ | 16.39 |
| ft | | m | 0.3 |
| oz | | g | 28.35 |
| lb | | kg | 0.45 |
| lbf | | N | 4.4 |
| lbf•in | | N•m | 0.11 |
| lbf•ft | | N•m | 1.36 |
| lbf•ft | | lbf•in | 12 |
| PSI (lbf/in²) | | kPa | 6.89 |
| imp. oz | | U.S. oz | 0.96 |
| imp. oz | | mL | 28.41 |
| imp. gal | | U.S. gal | 1.2 |
| imp. gal | | L | 4.55 |
| U.S. oz | | mL | 29.57 |
| U.S. gal | | L | 3.79 |
| MPH | | km/h | 1.61 |
| Fahrenheit | | Celsius | (°F – 32) ÷ 1.8 |
| Celsius | | Fahrenheit | (°C × 1.8) + 32 |

*The international system of units abbreviates SI in all languages.







†To obtain the inverse sequence, divide by the given factor. To convert "mm" to "in", divide by 25.4.



NOTE : Conversion factors are rounded off to 2 decimals for easier use.






Section 09 TECHNICAL DATA

Sub-Section 02 (ENGINES)

|  | VEHICLE MODEL | | TUNDRA II LT | TOURING E, TOURING E LT, SKANDIC 380, FORMULA S | TOURING LE | TOURING SLE, SKANDIC 500, FORMULA SL |
|---|---------------------------------------|---|---|--|----------------------|--|
| | ENGINE TYPE | | 277 | 377 | 443 | 503 |
|  | Number of Cylinders | | 1 | 2 | 2 | 2 |
| | Bore | mm (in) | 72.00 (2.835) | 62.00 (2.441) | 67.5 (2.66) | 72.00 (2.835) |
| | Stroke | mm (in) | 66.00 (2.598) | 61.00 (2.402) | 61.00 (2.402) | 61.00 (2.402) |
| | Displacement | cm ³ (in ³) | 268.70 (16.40) | 368.30 (22.48) | 436.6 (26.64) | 496.70 (30.31) |
| | Compression Ratio (corrected) | | 6.70 | 6.80 | 6.4 | 6.20 |
| | Maximum Power Engine Speed ① | | ± 100 RPM 6900 | 6900 | 7000 | 7100 |
| | Piston Ring Type | | 1 st / 2 nd ST / R | ST / R | ST / R | ST / R |
| | Ring End Gap | (new) | mm (in) | 0.2 (.008) | 0.2 (.008) | 0.2 (.008) |
| | | (wear limit) | mm (in) | 1.0 (.039) | 1.0 (.039) | 1.0 (.039) |
| | Ring / Piston Groove Clearance | (new) | mm (in) | 0.04 (.0016) | 0.04 (.0016) | 0.04 (.0016) |
| | | (wear limit) | mm (in) | 0.2 (.008) | 0.2 (.008) | 0.2 (.008) |
| | Piston / Cylinder Wall Clearance | (new) | mm (in) | 0.070 (.0028) | 0.060 (.0024) | 0.060 (.0024) |
| | | (wear limit) | mm (in) | 0.2 (.008) | 0.2 (.008) | 0.2 (.008) |
| | Connecting Rod Big End Axial Play | (new) | mm (in) | 0.20 (.0079) | 0.20 (.0079) | 0.2 (.0079) |
| | | (wear limit) | mm (in) | 1.0 (.0394) | 1.0 (.0394) | 1.0 (.0394) |
| | Maximum Crankshaft End-play ⑤ | | mm (in) | 0.3 (.0118) | 0.3 (.0118) | 0.3 (.0118) |
| | Maximum Crankshaft Deflection | | mm (in) | 0.08 (.0031) | 0.08 (.0031) | 0.08 (.0031) |
| | Rotary Valve Timing ② | | Opening Closing | N.A. | N.A. | N.A. |
|  | Magneto Generator Output | | W | 160 | 240 | 240 |
| | Ignition Type | | | CDI | CDI | CDI |
| | Spark Plug Make and Type | | | NGK BR9ES | NGK BR9ES | NGK BR9ES |
| | Spark Plug Gap | | mm (in) | 0.45 (.018) | 0.45 (.018) | 0.45 (.018) |
| | Ignition Timing BTDC ③ | | mm (in) | 2.52 (.099) | 1.68 (.066) | 1.68 (.066) |
| | Generating Coil ⑦ | Low Speed : Ω | | 40 – 76 | N.A. | N.A. |
| | | High Speed : Ω | | N.A. | 230 – 330 | 230 – 330 |
| | Lighting Coil ⑦ | | Ω | 0.05 – 0.6 | 0.23 – 0.28 | 0.23 – 0.28 |
| | High Tension Coil ⑦ | Primary | Ω | 0.11 – 0.21 | N.A. | N.A. |
| | | Secondary | kΩ | 4.9 – 7.5 | 5.1 – 6.3 | 5.1 – 6.3 |
|  | Carburetor Type | | PTO / MAG | VM 34-443 | 2 x VM 30-190 | 2 x VM 34-467 |
| | Main Jet | | PTO / MAG | 190 | 140 / 140 | 180 / 180 |
| | Needle Jet | | | 159 D-8 | 159 P-0 | 159 P-1 |
| | Pilot Jet | | | 40 | 40 | 40 |
| | Needle Identification – Clip Position | | | 6DH4-2 | 6DP9-3 | 6DH2-3 |
| | Slide Cut-away | | | 2.5 | 2.5 | 2.5 |
| | Float Adjustment | | ± 1 mm (± 0.40 in) | 23.9 (.94) | 23.9 (.94) | 23.9 (.94) |
| | Air Screw Adjustment | | ± 1/16 turn | 1 | 1-1/4 | 1-1/4 |
| | Idle Speed RPM | | ± 200 RPM | 1200 | 1650 | 1650 |
| | Gas Type / Pump Octane number | | | Unleaded / 87 | Unleaded / 87 | Unleaded / 87 |
|  | Gas / Oil Ratio | | | Injection | Injection | Injection |
| | Type | | | Radial Fan | Axial Fan | Axial Fan |
| | Axial Fan Belt Adjustment | Deflection | mm in | N.A. | 8 – 9 (.31 – .35) | 8 – 9 (.31 – .35) |
| | | Force ④ | kg (lbf) | N.A. | 5 (11) | 5 (11) |
| | Thermostat Opening Temperature | | °C (°F) | N.A. | N.A. | N.A. |
|  | Radiator Cap Opening Pressure | | kPa (PSI) | N.A. | N.A. | N.A. |
| | ENGINE COLD N·m (lb-ft) | Drive Pulley Retaining Screw ⑥ | | 95 (70) | 95 (70) | 95 (70) |
| | | Exhaust Manifold Nuts or Bolts | | 25 (18) | 22 (16) | 22 (16) |
| | | Magneto Ring Nut | | 90 (66) | 105 (77) | 105 (77) |
| | | Crankcase Nuts or Screws | M6 | — | 10 (7) | — |
| | | | M8 | 22 (16) | 22 (16) | 22 (16) |
| | | Crankcase / Engine Support Nuts or Screws | | 21 (15) | 38 (28) | 38 (28) |
| | | Cylinder Head Nuts | | 26 (19) | 22 (16) | 22 (16) |
| | | Crankcase / Cylinder Nuts or Screws | | N.A. | N.A. | N.A. |
| | Axial Fan Shaft Nut | | | N.A. | 50 (37) | 50 (37) |






Section 09 TECHNICAL DATA

Sub-Section 03 (VEHICLES)

|  | VEHICLE MODEL | | TUNDRA II LT | TOURING E, FORMULA S | TOURING E LT |
|---|---------------------------------|---|---------------------------------|------------------------------------|--|
| | ENGINE TYPE | | 277 | 377 | 377 |
|  | Chain Drive Ratio | | 14/25 | 21/44 | 21/44 |
| | Chain | Pitch | in | 1/2 | 3/8 |
| | | Type / Links Qty / Plates Qty | Single / 62 | Silent / 72 / 11 | Silent / 72 / 11 |
| | Drive Pulley | Type of Drive Pulley | Bombardier Lite | Bombardier Lite | Bombardier Lite |
| | | Ramp Identification | N.A. | N.A. | N.A. |
| | | Calibration Screw Position or Calibration Disc Quantity ⑥ | 2C | 1W | 1W |
| | | Spring Color | Turquoise | Red / Blue | Yellow / Green |
| | | Spring Length | ± 1.5 mm (± 0.060 in) | 102 (4.02) | 82 (3.23) |
| | | Clutch Engagement | ± 200 RPM | 3100 | 2900 |
| | Driven Pulley Spring Preload | | ± 0.7 kg (± 1.5 lb) | 4.8 (10.6) | 4.8 (10.6) |
| | Cam Angle | | 37.8° | 44° | 44° |
| | Pulley Distance Z | | (+0, -1) mm ((+0, -1/32) in) | 25.5 (1) | 25.5 (1) |
| | Offset | X | ± 0.4 mm (± 1/64 in) | 33.4 (1-5/16) | 33.4 (1-5/16) |
| | | Y - X | MIN. MAX. | + 0.5 (+ 0.020) + 1.5 (+ 0.059) | + 0.5 (+ 0.020) + 1.5 (+ 0.059) |
| | Drive Belt Part Number (P / N) | | 414 8276 00 | 415 0606 00 | 415 0606 00 |
| | Drive Belt Width (new) ① | | 33.3 (1-5/16) | 34.7 (1-3/8) | 34.7 (1-3/8) |
| | Drive Belt Adjustment | Deflection | ± 5 mm (± 13/64 in) | 32 (1-1/4) | 32 (1-1/4) |
| | | Force ② | kg (lbf) | 11.3 (25) | 11.3 (25) |
| | Track | Width | cm (in) | 38.1 (15) | 38.1 (15) |
| | | Length | cm (in) | 354 (139) | 345 (136) |
| | | Adjustment | Deflection | mm (in) | 40 - 55 (1-9/16 - 2-5/32) |
| | | | Force ③ | kg (lbf) | 7.3 (16) |
| | Suspension Type | Track | Torque Reaction Slide | Slide | Slide |
| | | Ski | Telescopic Strut | DSA | DSA |
|  | Length | | cm (in) | 284.5 (112) | 292 (115) |
| | Width | | cm (in) | 95.3 (37.5) | 115.6 (45.5) |
| | Height | | cm (in) | 114 (44.9) | Touring : 122 (48.0) Formula : 112 (44.1) |
| | Ski Stance | | cm (in) | 81.3 (32.0) | 101.6 (40) |
| | Mass (dry) | | kg (lb) | 171 (377) | Touring : 204 (449) Formula : 195 (430) |
| | Ground Contact Area | | cm² (in²) | 7864 (1219) | 6503 (1008) |
| | Ground Contact Pressure | | kPa (PSI) | 2.13 (.309) | Touring : 3.08 (.447) Formula : 2.94 (.426) |
| | Frame Material | | Steel | Aluminum | Aluminum |
| | Bottom Pan Material | | Polyethylene High Density | Polyethylene | Polyethylene |
| | Cab Material | | Polyethylene High Density | RRIM Polyurethane | RRIM Polyurethane |
|  | Battery | | V (A•h) | N.A. | Touring : 12 (22) Formula : N.A. |
| | Headlight | | W | H4 60/55 | H4 60/55 |
| | Taillight and Stoplight | | W | 8/27 | 8/27 |
| | Tachometer and Speedometer Bulb | | W | N.A. | 5 |
| | Fuel and Temperature Gauge Bulb | | W | N.A. | N.A. |
| | Fuse | Starter Solenoid | A | N.A. | Touring : 30 Formula : N.A. |
| | | Tachometer | A | N.A. | N.A. |
|  | Fuel Tank | | L (U.S. gal) | 26 (6.9) | 40 (10.6) |
| | Chaincase / Gearbox | | mL (U.S. oz) | 250 (8.5) | 250 (8.5) |
| | Cooling System | | L (U.S. oz) | N.A. | N.A. |
| | Injection Oil Reservoir | | L (U.S. oz) | 1.9 (64) | 2.55 (86) |
| | | | | | |

Section 09 TECHNICAL DATA

Sub-Section 03 (VEHICLES)

|  | VEHICLE MODEL | | TOURING LE | SKANDIC 380 | TOURING SLE, SKANDIC 500 | FORMULA SL |
|--|--|---|--------------------------------|------------------------------------|--|--------------------------------|
| | ENGINE TYPE | | 443 | 377 | 503 | 503 |
|  | Chain Drive Ratio | | 21/44 | 21/44 | 21/44 | 22/44 |
| | Chain | Pitch | in 3/8 | 3/8 | 3/8 | 3/8 |
| | | Type / Links Qty / Plates Qty | Silent / 72 / 11 | Silent / 72 / 11 | Silent / 72 / 11 | Silent / 72 / 11 |
| | Drive Pulley | Type of Drive Pulley | TRA | Bombardier Lite | TRAC | TRAC |
| | | Ramp Identification | 227 ④ | N.A. | 284 ④ | 284 ④ |
| | | Calibration Screw Position or Calibration Disc Quantity ⑤ | 4 | 1W | 4 | 3 |
| | | Spring Color | Yellow / Violet | Yellow / Green | Red / Yellow | Blue / Yellow |
| | | Spring Length ± 1.5 mm (± 0.060 in) | 88.4 (3.48) | 82 (3.23) | 87.9 (3.46) | 115.1 (4.53) |
| | | Clutch Engagement ± 200 RPM | 3100 | 2900 | 3000 | 3600 |
| | Driven Pulley Spring Preload Cam Angle | | ± 0.7 kg (± 1.5 lb) 44° | 4.8 (10.6) 44° | 4.8 (10.6) 44° | 4.8 (10.6) 44° |
| | Pulley Distance Z (+0, -1) mm (+0, -1/32) in | | 16.5 (21/32) | 25.5 (1) | 16.5 (21/32) | 16.5 (21/32) |
| | Offset | X ± 0.4 mm (± 1/64 in) | 35.0 (1-3/8) | 33.4 (1-5/16) | 35.0 (1-3/8) | 35.0 (1-3/8) |
| | | Y - X MIN. MAX. | + 1 (+ 0.039) + 2 (+ 0.079) | + 0.5 (+ 0.020) + 1.5 (+ 0.059) | + 1 (+ 0.039) + 2 (+ 0.079) | + 1 (+ 0.039) + 2 (+ 0.079) |
| | Drive Belt Part Number (P / N) | | 415 0606 00 | 415 0606 00 | 415 0606 00 | 415 0606 00 |
| | Drive Belt Width (new) ① | | mm 34.7 (in) (1-3/8) | 34.7 (1-3/8) | 34.7 (1-3/8) | 34.7 (1-3/8) |
| | Drive Belt Adjustment | Deflection ± 5 mm (± 13/64 in) | 32 (1-1/4) | 32 (1-1/4) | 32 (1-1/4) | 32 (1-1/4) |
| | | Force ② kg (lbf) | 11.3 (25) | 11.3 (25) | 11.3 (25) | 11.3 (25) |
| | Track | Width | cm 38.1 (in) (15) | 38.1 (15) | 38.1 (15) | 38.1 (15) |
| | | | cm 345 (in) (136) | 345 (136) | 345 (136) | 307 (121) |
| | | Adjustment | Deflection mm (in) | 40 - 55 (1-9/16 - 2-5/32) | 40 - 55 (1-9/16 - 2-5/32) | 40 - 55 (1-9/16 - 2-5/32) |
| | | | Force ③ kg (lbf) | 7.3 (16) | 7.3 (16) | 7.3 (16) |
| | Suspension Type | Track | Slide | Slide | Slide | Slide |
| | | Ski | DSA | DSA | DSA | DSA |
|  | Length | | cm (in) 292 (115) | 294 (115.7) | Touring : 292 (115) Skandic : 294 (115.7) | 272.5 (107.3) |
| | Width | | cm (in) 115.6 (45.5) | 108 (42.5) | Touring : 120.7 (47.5) Skandic : 108 (42.5) | 120.7 (47.5) |
| | Height | | cm (in) 122 (48.0) | 122 (48.0) | 122 (48.0) | 112 (44.1) |
| | Ski Stance | | cm (in) 101.6 (40) | 94 (37) | Touring : 106.7 (42) Skandic : 94 (37) | 106.7 (42) |
| | Mass (dry) | | kg (lb) 208 (457) | 214 (471) | Touring : 224 (493) Skandic : 221 (486) | 202 (445) |
| | Ground Contact Area | | cm² (in²) 7227 (1120) | 7227 (1120) | 7227 (1120) | 6503 (1008) |
| | Ground Contact Pressure | | kPa (PSI) 2.82 (.409) | 2.90 (.421) | Touring : 3.04 (.441) Skandic : 3.06 (.435) | 3.05 (.442) |
| | Frame Material | | Aluminum | Aluminum | Aluminum | Aluminum |
| | Bottom Pan Material | | Polyethylene | Polyethylene | Polyethylene | Polyethylene |
| | Cab Material | | RRIM Polyurethane | RRIM Polyurethane | RRIM Polyurethane | RRIM Polyurethane |
|  | Battery | | V (A•h) 12 (22) | N.A. | Touring : 12 (22) Skandic : N.A. | N.A. |
| | Headlight | | W H4 60/55 | H4 60/55 | H4 60/55 | H4 60/55 |
| | Taillight and Stoplight | | W 8/27 | 8/27 | 8/27 | 8/27 |
| | Tachometer and Speedometer Bulb | | W 2 x 3 | 2 x 3 | 2 x 3 | 2 x 3 |
| | Fuel and Temperature Gauge Bulb | | W N.A. | N.A. | N.A. | N.A. |
| | Fuse | Starter Solenoid | A 30 | N.A. | Touring : 30 Skandic : N.A. | N.A. |
| | | Tachometer | A N.A. | N.A. | N.A. | N.A. |
|  | Fuel Tank | | L (U.S. gal) 40 (10.6) | 40 (10.6) | 40 (10.6) | 40 (10.6) |
| | Chaincase / Gearbox | | mL (U.S. oz) 250 (8.5) | 250 (8.5) | 250 (8.5) | 250 (8.5) |
| | Cooling System | | L (U.S. oz) N.A. | N.A. | N.A. | N.A. |
| | Injection Oil Reservoir | | L (U.S. oz) 2.55 (86) | 2.55 (86) | 2.55 (86) | 2.55 (86) |

ENGINE TECHNICAL DATA LEGEND

BP : Breaker Points
BTDC : Before Top Dead Center
CDI : Capacitor Discharge Ignition
CTR : Center
K : Kilo (x 1000)
MAG : Magneto Side
N.A. : Not Applicable
PTO : Power Take Off Side
R : Rectangular
ST : Semi-trapez
 μ : Micro (\div 1 000 000)

- ① The maximum horsepower RPM is applicable on the vehicle. It may be different under certain circumstances and BOMBARDIER INC. reserves the right to modify it without obligation.
- ② Rotary valve to crankcase clearance : 0.27 – 0.48 mm (.011 – .019 in).
- ③ At 6000 RPM (engine cold) with headlamp turned on.
- ④ Force applied midway between pulleys to obtain specified deflection.
- ⑤ Crankshaft end-play is not adjustable on these models except Tundra II LT. Specification is given for verification purposes only.
- ⑥ Drive pulley retaining screw : torque to 90 to 100 N•m (66 to 74 lbf•ft), install drive belt, accelerate the vehicle at low speed (maximum 30 km/h (20 MPH)) and apply the brake ; repeat 5 times. Recheck the torque of 90 to 100 N•m (66 to 74 lbf•ft).
- ⑦ All resistance measurements must be performed with parts at room temperature (approx. 20°C (68°F)). Temperature greatly affects resistance measurements.

VEHICLE TECHNICAL DATA LEGEND

DSA : Direct Shock Action
RRIM : Reinforced Reaction Injection Molding
TRA : Total Range Adjustable drive pulley
N.A. : Not Applicable

- ① Minimum allowable width may not be less than 3.0 mm (1/8 in) of new drive belt.
- ② Force applied midway between pulleys to obtain specified deflection.
- ③ Force or downward pull applied to track to obtain specified tension deflection.
- ④ Lever with roller pin P/N 417 0043 03 (Hollow).
- ⑤ 2C : 2 Caps
1W : 1 Washer



Bombardier SERVICE PUBLICATIONS REPORT

Publication title and year _____ Page _____

Machine _____ Report of error ☐ Suggestion ☐

Name _____

Address _____

City and State/Prov. _____ Date _____

Zip code/Postal code _____

Bombardier SERVICE PUBLICATIONS REPORT

Publication title and year _____ Page _____

Machine _____ Report of error ☐ Suggestion ☐

Name _____

Address _____

City and State/Prov. _____ Date _____

Zip code/Postal code _____

Bombardier SERVICE PUBLICATIONS REPORT

Publication title and year _____ Page _____

Machine _____ Report of error ☐ Suggestion ☐

Name _____

Address _____

City and State/Prov. _____ Date _____

Zip code/Postal code _____

We would be pleased if you could communicate to Bombardier any suggestions you may have concerning our publications.





AFFIX
PROPER
POSTAGE



Bombardier Inc.

Technical Publications
After Sales Service
Valcourt, (Quebec)
Canada, J0E 2L0

AFFIX
PROPER
POSTAGE



Bombardier Inc.

Technical Publications
After Sales Service
Valcourt, (Quebec)
Canada, J0E 2L0

AFFIX
PROPER
POSTAGE



Bombardier Inc.

Technical Publications
After Sales Service
Valcourt, (Quebec)
Canada, J0E 2L0

ANNEX 1 TUNDRA II LT

The diagram illustrates the electrical system of a motorcycle. Key components include:

- SPARK PLUG**: Connected to the primary winding of the **IGNITION COIL**.
- GENERATING COIL**: Part of the engine's electrical output.
- LIGHTING COIL**: Provides power for the lighting system.
- IGNITION MODULE**: Controls the ignition coil.
- REGULATOR**: Maintains voltage levels for the battery and lights.
- BULB 8/27 W**: A small auxiliary bulb connected to the taillight assembly.
- TAILLIGHT**: The rear light assembly.
- BRAKELIGHT SWITCH**: Activates the brakelights when the brake lever is pulled.
- HEADLIGHT 55-60 W HALOGEN**: The main front illumination source.

Connectors are labeled as follows:

- C-1, C-2, C-3**: Located on the engine, right side.
- C-4**: Located on the ignition switch.
- C-5**: Located in the console, left side.
- C-6, C-7, C-15**: Located near the steering column.
- C-8, C-9, C-11**: Located in the hood, near the instrument location.

Wire colors and combinations are indicated throughout the diagram, such as BK/YL, YL/BK, WH/BL, and GY/VL/GY.


C-1,C-2,C-3: ON ENGINE, RIGHT SIDE
C-4: ON IGNITION SWITCH
C-5: IN CONSOLE, LEFT SIDE
C-6,C-7,C-15: NEAR STEERING COLUMN
C-8,C-9,C-14: IN HOOD, NEAR INSTRUMENT LOCATION
C-10: NEAR DRIVEN PULLEY
C-11: BETWEEN SEAT AND FUEL TANK
C-12: ON TAILLIGHT
C-13: NEAR REGULATOR



WARNING :

ENSURE ALL TERMINALS ARE PROPERLY CRIMPED ON THE WIRES AND ALL CONNECTOR HOUSINGS ARE PROPERLY FASTENED.


IGNITION SWITCH



ANNEX 2

FORMULA S / SL
SKANDIC 380 / 500


FORMULA S '97
FORMULA SL
SKANDIC 380
SKANDIC 500



- = WELDED JOINT

WARNING:


ENSURE ALL TERMINALS ARE PROPERLY CRIMPED ON THE WIRES AND ALL CONNECTOR HOUSINGS ARE PROPERLY FASTENED.



ANNEX 3

TOURING E / E LT
TOURING LE / SLE

TOURING E '97
TOURING ELT
TOURING LE
TOURING SLE



EMPLACEMENT DES RACCORDS

- C-2, C-3, PRES DU MOTEUR
- C-4 : PRES DU REGULATEUR SOUS LE MOTEUR
- C-5, C-5A, ENTRE LE SIEGE ET LE RESERVOIR DE CARBURANT
- C-6 : SUR LE FEU ARRIERE
- C-7 : SOUS LE RESERVOIR D'HUILE A INJECTION
- C-8 : JOINT ENTRE LE CAPOT ET LE CHASSIS
- C-9 @ C-14 : SOUS LE CAPOT, PRES DES INSTRUMENTS
- C-15 @ C-21 : PRES DE LA COLONNE DE DIR. SOUS TABLEAU-BORD
- C-22 : AU DESSUS DU CARTER DE CHAINE
- C-23 : SUR L'INTERRUPTEUR D'ALLUMAGE

■ = JOINT SOUDE

S'ASSURER QUE TOUS LES RACCORDS ELECTRIQUES SONT BIEN SERTIS AU BOUT DES FILS ET QUE TOUS LES LOGEMENTS DE RACCORDS SONT CORRECTEMENT FIXES.



® * TRADEMARKS OF BOMBARDIER INC.
ALL RIGHTS RESERVED © BOMBARDIER INC. 1996
LITHO'D IN CANADA

VERSION FRANÇAISE ÉGALEMENT DISPONIBLE

