

# TABLE OF CONTENTS

<b>SAFETY NOTICE</b> .....	X
<b>INTRODUCTION</b> .....	XI
GENERAL .....	XI
HOW TO IDENTIFY YOUR VEHICLE .....	XII
SNOWMOBILE LIFTING .....	XII
ENGINE EMISSIONS INFORMATION .....	XIII
TIGHTENING TORQUE .....	XIV
SELF-LOCKING FASTENERS PROCEDURE .....	XV
LOCTITE APPLICATION PROCEDURE .....	XV
MANUAL INFORMATION .....	XVIII
<b>01 MAINTENANCE</b>	
<b>01 – MAINTENANCE CHART</b> .....	1
<b>02 – STORAGE PROCEDURE</b> .....	3
GENERAL .....	3
PROCEDURES .....	3
ENGINE MANAGEMENT SYSTEM .....	3
FUEL SYSTEM .....	3
ENGINE .....	3
ELECTRICAL SYSTEM .....	5
DRIVE/BRAKE SYSTEM .....	5
CHASSIS .....	5
VEHICLE .....	6
<b>03 – PRESEASON PREPARATION</b> .....	7
GENERAL .....	7
PROCEDURES .....	7
ENGINE .....	7
FUEL SYSTEM .....	7
ELECTRICAL SYSTEM .....	8
DRIVE/BRAKE SYSTEM .....	8
<b>02 ENGINE</b>	
<b>01 – ENGINE REMOVAL AND INSTALLATION</b> .....	9
GENERAL .....	12
PROCEDURES .....	12
ENGINE .....	12
ENGINE STOPPER .....	23
ENGINE SUPPORT .....	24
ENGINE RUBBER MOUNT .....	25
<b>02 – ENGINE LEAK TEST</b> .....	27
TROUBLESHOOTING .....	28
PROCEDURES .....	29
ENGINE .....	29
PUMP SHAFT OIL GEAR RESERVOIR .....	30
<b>03 – ENGINE MEASUREMENT</b> .....	33
PROCEDURES .....	33
CYLINDER HEAD WARPAGE .....	33
CYLINDER TAPER .....	33
CYLINDER OUT OF ROUND .....	33
CYLINDER/PISTON CLEARANCE .....	34
RING/PISTON GROOVE CLEARANCE .....	35
RING END GAP .....	36
CRANKSHAFT DEFLECTION .....	36
CONNECTING ROD BIG END AXIAL PLAY .....	37

# TABLE OF CONTENTS

<b>02 ENGINE</b> (cont'd)	
<b>03 – ENGINE MEASUREMENT</b> (cont'd)	
PROCEDURES (cont'd)	
CRANKSHAFT ALIGNMENT .....	37
COMBUSTION CHAMBER VOLUME MEASUREMENT .....	38
<b>04 – AIR INTAKE SYSTEM</b> .....	41
GENERAL .....	43
PROCEDURES .....	43
AIR FILTER .....	43
PRIMARY AIR INTAKE SILENCER .....	44
SECONDARY AIR INTAKE SILENCER .....	44
<b>05 – EXHAUST SYSTEM</b> .....	49
GENERAL .....	51
PROCEDURES .....	51
MUFFLER .....	51
EXHAUST GAS TEMPERATURE SENSOR (EGTS) .....	51
TUNED PIPE .....	51
MANIFOLD .....	52
<b>06 – REWIND STARTER</b> .....	53
INSPECTION .....	55
PROCEDURES .....	55
REWIND STARTER HANDLE .....	55
REWIND STARTER .....	55
<b>07 – LUBRICATION SYSTEM</b> .....	61
GENERAL .....	65
SYSTEM DESCRIPTION .....	65
RECOMMENDED OIL .....	66
INSPECTION .....	66
OIL SYSTEM LEAK TEST .....	66
TROUBLESHOOTING .....	68
PROCEDURES .....	68
OIL INJECTION PUMP (500SS/600/800R) .....	68
OIL PUMP (600 HO E-TEC) .....	71
OIL TANK .....	75
OIL LEVEL SENSOR .....	77
OIL FILTER (500SS/600/800R) .....	78
INJECTION NOZZLE .....	78
<b>08 – COOLING SYSTEM</b> .....	81
GENERAL .....	83
MAINTENANCE .....	83
COOLANT REPLACEMENT .....	83
INSPECTION .....	85
COOLING SYSTEM LEAK TEST .....	85
ENGINE COOLING SYSTEM LEAK TEST (800R) .....	85
PROCEDURES .....	86
THERMOSTAT .....	86
RADIATOR CAP .....	87
FRONT RADIATOR .....	87
REAR RADIATOR .....	88
COOLANT RESERVOIR .....	89
WATER PUMP .....	89
COOLANT TEMPERATURE SENSOR (CTS) .....	89
<b>09 – MAGNETO SYSTEM</b> .....	93
GENERAL .....	96

<b>02 ENGINE</b> (cont'd)	
<b>09 – MAGNETO SYSTEM</b> (cont'd)	
PROCEDURES.....	96
MAGNETO FLYWHEEL .....	96
STATOR (500SS/600/800R) .....	98
STATOR (600 HO E-TEC).....	100
CRANKSHAFT POSITION SENSOR (600 HO E-TEC) .....	103
TRIGGER COILS (500SS/600).....	103
TRIGGER COILS (800R).....	103
MAGNETO HOUSING (800R).....	104
<b>10 – RAVE (593)</b> .....	107
GENERAL .....	109
SYSTEM DESCRIPTION .....	109
PROCEDURES.....	109
RAVE VALVES .....	109
<b>11 – RAVE (593 E-TEC)</b> .....	113
GENERAL .....	115
SYSTEM DESCRIPTION .....	115
INSPECTION.....	116
3D RAVE VALVES POSITION VALIDATION .....	116
TROUBLESHOOTING .....	116
DIAGNOSTIC TIPS .....	116
PROCEDURES.....	117
3D RAVE VALVES .....	117
ACTUATOR CHECK VALVES .....	123
LUBRICATION CHECK VALVES .....	123
SOLENOID.....	124
3D RAVE VALVES POSITION SENSOR .....	126
<b>12 – RAVE (797)</b> .....	129
GENERAL .....	131
SYSTEM DESCRIPTION .....	131
TROUBLESHOOTING .....	136
DIAGNOSTIC FLOW CHART.....	136
TROUBLESHOOTING TIPS .....	137
PROCEDURES.....	137
3D RAVE VALVE.....	137
CHECK VALVES .....	142
SOLENOIDS .....	143
<b>13 – TOP END (593)</b> .....	147
GENERAL .....	150
PROCEDURES.....	150
REED VALVES.....	150
CYLINDER HEAD COVER (500SS/600) .....	151
CYLINDER HEAD (500SS/600).....	151
CYLINDER HEAD (600 HO E-TEC).....	152
CYLINDERS.....	152
PISTONS.....	154
<b>14 – TOP END (797)</b> .....	157
GENERAL .....	159
PROCEDURES.....	159
REED VALVES.....	159
CYLINDER HEAD .....	159
PISTONS.....	160
CYLINDER BLOCK.....	162

# TABLE OF CONTENTS

<b>02 ENGINE (cont'd)</b>	
<b>15 – BOTTOM END (593)</b> .....	165
GENERAL .....	168
PROCEDURES.....	168
WATER PUMP .....	168
WATER PUMP SHAFT .....	169
CRANKCASE.....	172
CRANKSHAFT.....	174
<b>16 – BOTTOM END (797)</b> .....	181
GENERAL .....	183
PROCEDURES.....	183
WATER PUMP .....	183
WATER/OIL PUMP SHAFT.....	184
CRANKCASE.....	187
CRANKSHAFT.....	190
<b>03 ENGINE MANAGEMENT SYSTEM</b>	
<b>01 – OVERVIEW (500SS/600)</b> .....	197
GENERAL .....	197
SYSTEM DESCRIPTION .....	197
<b>02 – OVERVIEW (600 HO E-TEC)</b> .....	199
GENERAL .....	199
SYSTEM DESCRIPTION .....	199
POWER DISTRIBUTION .....	201
<b>03 – OVERVIEW (800R)</b> .....	203
GENERAL .....	204
SYSTEM DESCRIPTION .....	204
<b>04 – COMMUNICATION TOOLS AND B.U.D.S. SOFTWARE</b> .....	207
GENERAL .....	207
TROUBLESHOOTING .....	207
COMMUNICATION PROBLEMS.....	207
PROCEDURES.....	208
MULTI-PURPOSE INTERFACE-2 (MPI-2).....	208
B.U.D.S. SOFTWARE .....	211
<b>05 – MONITORING SYSTEM AND FAULT CODES</b> .....	213
GENERAL .....	213
MONITORING SYSTEM .....	213
FAULT CODES .....	216
SPECIFIC FAULT CODES .....	217
FAULT CODE TABLES .....	218
<b>04 FUEL SYSTEM</b>	
<b>01 – FUEL TANK AND FUEL PUMP</b> .....	225
GENERAL .....	228
SYSTEM DESCRIPTION (500SS/600/800R).....	228
SYSTEM DESCRIPTION (600 HO E-TEC).....	229
INSPECTION.....	231
FUEL SYSTEM PRESSURIZATION.....	231
FUEL PUMP PRESSURE TEST (600 HO E-TEC).....	232
PROCEDURES.....	234
FUEL TANK .....	234
DIAPHRAGM FUEL PUMP (500SS/600/800R).....	239
ELECTRIC FUEL PUMP (600 HO E-TEC) .....	240
FUEL PRESSURE REGULATOR (600 HO E-TEC) .....	242
IN-LINE FUEL FILTER (600 HO E-TEC) .....	243

---

# TABLE OF CONTENTS

---

<b>04 FUEL SYSTEM (cont'd)</b>	
<b>01 – FUEL TANK AND FUEL PUMP (cont'd)</b>	
PROCEDURES (cont'd)	
FUEL LEVEL SENSOR .....	244
OETIKER CLAMPS.....	247
<b>02 – TM CARBURETORS.....</b>	249
PROCEDURES.....	251
CARBURETORS.....	251
THROTTLE POSITION SENSOR (TPS).....	257
THROTTLE CABLE.....	261
CHOKE CABLE.....	264
<b>03 – DPM SYSTEM (800R).....</b>	265
GENERAL .....	267
SYSTEM DESCRIPTION .....	267
PROCEDURES.....	267
AIR TEMPERATURE SENSOR (ATS).....	267
AIR PRESSURE SENSOR (APS) .....	269
DPM SOLENOID.....	270
DPM MANIFOLD .....	271
<b>04 – E-TEC DIRECT FUEL INJECTION .....</b>	273
GENERAL .....	273
SYSTEM DESCRIPTION .....	274
ADJUSTMENT .....	276
IDLE SPEED .....	276
CLOSED THROTTLE RESET (TPS).....	276
TROUBLESHOOTING .....	277
DIAGNOSTIC TIPS .....	277
PROCEDURES.....	278
FUEL HOSES AND OETIKER CLAMPS.....	278
THROTTLE CABLE.....	279
FUEL INJECTOR.....	281
ENGINE CONTROL MODULE (ECM).....	294
THROTTLE BODY.....	304
THROTTLE POSITION SENSOR (TPS).....	305
CRANKSHAFT POSITION SENSOR (CPS) .....	309
AIR TEMPERATURE SENSOR (ATS).....	310
COOLANT TEMPERATURE SENSOR (CTS) .....	312
AIR PRESSURE SENSOR (APS) .....	314
EXHAUST GAS TEMPERATURE SENSOR (EGTS).....	315
KNOCK SENSOR (KS).....	316
<b>05 ELECTRICAL SYSTEM</b>	
<b>01 – IGNITION SYSTEM .....</b>	319
GENERAL .....	319
SYSTEM DESCRIPTION (500SS/600/800R).....	319
SYSTEM DESCRIPTION (600 HO E-TEC).....	319
ADJUSTMENT .....	321
IGNITION TIMING .....	321
TROUBLESHOOTING .....	327
IGNITION SYSTEM TESTING SEQUENCE.....	327
PROCEDURES.....	328
SPARK PLUGS .....	328
SPARK PLUG CABLES (500SS/600/800R) .....	330
SPARK PLUG CABLES (600 HO E-TEC) .....	331
ENGINE STOP SWITCH .....	331

# TABLE OF CONTENTS

<b>05 ELECTRICAL SYSTEM (cont'd)</b>	
<b>01 – IGNITION SYSTEM (cont'd)</b>	
PROCEDURES (cont'd)	
IGNITION COIL (500SS/600/800R).....	335
IGNITION COILS (600 HO E-TEC) .....	337
TRIGGER COILS (500SS/600/800R) .....	341
KNOCK SENSOR (800R) .....	342
ENGINE CONTROL MODULE (500SS/600/800R) .....	343
<b>02 – CHARGING SYSTEM</b> .....	349
GENERAL .....	349
SYSTEM DESCRIPTION .....	349
TROUBLESHOOTING .....	349
TROUBLESHOOTING GUIDELINES (500SS/600/800R) .....	350
TROUBLESHOOTING GUIDELINES (600 HO E-TEC).....	350
PROCEDURES.....	350
CHARGING FUSE.....	350
CHARGING RELAY (R2).....	351
VOLTAGE REGULATOR/RECTIFIER (500SS/600/800R).....	351
VOLTAGE REGULATOR/RECTIFIER (600 HO E-TEC) .....	354
DC-DC CONVERTER (600 HO E-TEC) .....	356
CAPACITOR (600 HO E-TEC) .....	358
BATTERY (YTX20L-BS).....	362
<b>03 – STARTING SYSTEM</b> .....	367
GENERAL .....	369
BASIC STARTING SYSTEM OPERATION .....	369
TROUBLESHOOTING .....	369
TROUBLESHOOTING TIPS .....	369
STARTING SYSTEM TESTING SEQUENCE.....	369
PROCEDURES.....	369
START/RER FUSE.....	369
ELECTRIC STARTER .....	370
STARTER SOLENOID .....	375
START/RER SWITCH (500SS/600/800R) .....	377
START/RER SWITCH 600 HO E-TEC .....	380
<b>04 – DIGITALLY ENCODED SECURITY SYSTEM (D.E.S.S.)</b> .....	385
GENERAL .....	385
SYSTEM DESCRIPTION .....	385
PROCEDURES.....	385
D.E.S.S. KEY .....	385
D.E.S.S. POST .....	386
BEEPER.....	389
<b>05 – ROTAX ELECTRONIC REVERSE</b> .....	391
GENERAL .....	391
TROUBLESHOOTING .....	391
DIAGNOSTIC TIPS .....	391
PROCEDURES.....	392
RER FUSE (600 HO E-TEC) .....	392
RER SWITCH (500SS/600/800R).....	392
RER SWITCH (600 HO E-TEC) .....	394
BEEPER (REVERSE ALARM) .....	397
<b>06 – LIGHTS, GAUGE AND ACCESSORIES</b> .....	399
GENERAL .....	399
TROUBLESHOOTING .....	399
LIGHTING AND ACCESSORIES SYSTEM TESTING .....	399
ACCESSORY CIRCUIT TEST WITH B.U.D.S. ....	400

# TABLE OF CONTENTS

<b>05 ELECTRICAL SYSTEM (cont'd)</b>	
<b>06 – LIGHTS, GAUGE AND ACCESSORIES (cont'd)</b>	
PROCEDURES.....	400
FUSES .....	400
RELAY R1 (LIGHTS AND ACCESSORIES) .....	402
HEADLIGHTS .....	403
TAILLIGHT .....	406
GAUGE.....	406
REMOTE MODE AND SET BUTTON .....	412
SPEED SENSOR .....	413
FUEL LEVEL SENSOR .....	414
HEATED THROTTLE LEVER .....	415
HEATED HANDLEBAR GRIPS .....	416
12-VOLT POWER OUTLET.....	424
VISOR OUTLET .....	424
<b>06 DRIVE SYSTEM AND BRAKE</b>	
<b>01 – DRIVE BELT .....</b>	<b>425</b>
GENERAL .....	425
APPLICATION CHART .....	425
PROCEDURES.....	425
DRIVE BELT GUARD.....	425
DRIVE BELT GUARD SUPPORT .....	426
DRIVE BELT.....	426
<b>02 – DRIVE PULLEY.....</b>	<b>433</b>
GENERAL .....	436
PROCEDURES.....	436
DRIVE PULLEY.....	436
<b>03 – DRIVEN PULLEY AND COUNTERSHAFT .....</b>	<b>449</b>
GENERAL .....	452
PROCEDURES.....	452
DRIVEN PULLEY.....	452
COUNTERSHAFT .....	458
COUNTERSHAFT BEARING .....	458
COUNTERSHAFT BEARING SUPPORT.....	459
<b>04 – BRAKE .....</b>	<b>461</b>
GENERAL .....	463
MAINTENANCE.....	463
BRAKE FLUID.....	463
PROCEDURES.....	464
BRAKE PADS .....	464
CALIPER .....	466
BRAKE DISC.....	469
MASTER CYLINDER.....	469
BRAKE LIGHT SWITCH.....	470
<b>05 – CHAINCASE .....</b>	<b>473</b>
GENERAL .....	475
ADJUSTMENT .....	475
DRIVE CHAIN .....	475
MAINTENANCE.....	475
CHAINCASE OIL .....	475
PROCEDURES.....	476
CHAINCASE COVER.....	476
CHAINCASE.....	477
CHAINCASE BEARING .....	480

# TABLE OF CONTENTS

<b>06 DRIVE SYSTEM AND BRAKE (cont'd)</b>	
<b>05 - CHAINCASE (cont'd)</b>	
PROCEDURES (cont'd)	
CHAIN TENSIONER.....	482
<b>06 - DRIVE AXLE.....</b>	483
GENERAL .....	485
PROCEDURES.....	485
DRIVE AXLE .....	485
MAGNETIC CAPS.....	486
<b>07 - TRACK .....</b>	489
PROCEDURES.....	489
TRACK .....	489
TRACTION ENHANCING PRODUCTS (STUDS) .....	491
<b>07 CHASSIS</b>	
<b>01 - FRONT SUSPENSION .....</b>	495
GENERAL .....	497
ADJUSTMENT .....	497
SUSPENSION SPRING.....	497
SHOCK ABSORBER .....	498
PROCEDURES.....	498
SHOCK ABSORBER .....	498
UPPER SUSPENSION ARM .....	500
UPPER BALL JOINT .....	501
LOWER SUSPENSION ARM .....	502
LOWER BALL JOINT .....	503
SKI LEG .....	504
STABILIZER BAR.....	504
<b>02 - REAR SUSPENSION .....</b>	507
GENERAL .....	517
PROCEDURES.....	517
SUSPENSION ASSEMBLY.....	517
REAR AXLE .....	518
SHOCK ABSORBERS .....	520
REAR SPRINGS.....	535
SLIDER SHOES.....	538
FRONT ARM.....	539
REAR ARM.....	541
PIVOT ARM.....	543
COUPLING BLOCKS.....	543
IDLER WHEELS.....	544
IDLER WHEEL SUPPORT.....	544
STOPPER STRAP .....	544
<b>03 - STEERING SYSTEM .....</b>	547
GENERAL .....	551
ADJUSTMENT .....	551
STEERING ALIGNMENT .....	551
PROCEDURES.....	552
SKI RUNNER.....	552
SKI .....	552
SKI HANDLE .....	553
SKI LEG .....	554
HANDLEBAR GRIP .....	554
HANDLEBAR.....	556
HANDLEBAR EXTENSION.....	557



# TABLE OF CONTENTS

<b>07 CHASSIS</b> (cont'd)	
<b>03 - STEERING SYSTEM</b> (cont'd)	
<b>PROCEDURES</b> (cont'd)	
TIE-ROD.....	558
STEERING COLUMN .....	559
<b>04 - BODY</b> .....	561
<b>GENERAL</b> .....	561
CLEANING .....	561
BODY PARTS REPAIR .....	561
<b>PROCEDURES</b> .....	562
DECAL .....	562
SIDE PANEL .....	562
REWIND STARTER HANDLE HOUSING.....	562
HOOD.....	563
BOTTOM PAN COVER.....	564
FRONT BUMPER .....	565
FRONT BOTTOM PAN.....	566
WINDSHIELD .....	568
GAUGE SUPPORT .....	568
CONSOLE.....	570
REAR RACK (GTX SPORT/LE) .....	572
<b>05 - FRAME</b> .....	575
<b>GENERAL</b> .....	577
RIVET DRILLING PROCEDURE.....	577
<b>PROCEDURES</b> .....	578
FRAME.....	578
REAR BUMPER.....	578
REAR FRAME MEMBER .....	578
FRONT FRAME MEMBER.....	579
FRONT CROSS MEMBER .....	580
ENGINE MEMBER.....	582
<b>08 TECHNICAL SPECIFICATIONS</b>	
<b>01 - 500SS MODELS</b> .....	585
<b>02 - 600 MODELS</b> .....	591
<b>03 - 600 HO E-TEC MODELS</b> .....	595
<b>04 - 800R MODELS</b> .....	615
<b>09 WIRING DIAGRAM</b>	
<b>01 - WIRING DIAGRAM INFORMATION</b> .....	625
<b>GENERAL</b> .....	625
WIRING DIAGRAM LOCATION.....	625
WIRING DIAGRAM CODES.....	625
SUMITOMO CONNECTOR INFORMATION .....	626
DEUTSCH CONNECTOR INFORMATION .....	627
PACKARD CONNECTOR INFORMATION.....	627
AMP MULTILOCK CONNECTOR INFORMATION .....	629
AMP CONNECTOR (8-CIRCUIT) INFORMATION .....	631
AMP CONNECTOR INFORMATION (ECM OF 600 HO E-TEC).....	631
BATTERY CABLE TERMINAL INFORMATION.....	633

# INTRODUCTION

## GENERAL

This shop manual covers the following BRP made 2009 REV-XP and REV-XR (2-stroke) models:

MODEL	ENGINE TYPE	CHASSIS	MODEL NUMBER
GTX LE 600 HO E-TEC	593	REV-XR (2-stroke)	ES9A
GSX Limited 600 HO E-TEC	593	REV-XP	DD9A
GSX Sport 500SS	593	REV-XP	DC9A
GTX Sport 500SS	593	REV-XP	ED9A
MXZ 50TH 600 HO E-TEC	593	REV-XP	MP9A, MP9B
MXZ Adrenaline 600 HO E-TEC	593	REV-XP	BL9A, BL9B, BL9C, BL9D
MXZ Adrenaline 800R Power TEK	797	REV-XP	BD9A, BD9B, BD9C, BD9D
MXZ Renegade 600 HO E-TEC	593	REV-XP	BX9A, BX9B, BX9C, BX9D, BX9E
MXZ Renegade 800R Power TEK	797	REV-XP	BU9A, BU9B, BU9C, BU9D
MXZ Renegade X 600 HO E-TEC	593	REV-XP	BW9A, BW9B, BW9C, BW9D, BW9E
MXZ Renegade X 800R Power TEK	797	REV-XP	BS9A, BS9B, BS9C, BS9D, BS9E
MXZ Trail 500SS	593	REV-XP	BH9A, BH9B
MXZ TNT 500SS	593	REV-XP	MF9A, MF9B, MF9C
MXZ TNT 600 HO E-TEC	593	REV-XP	MJ9A, MJ9B, MJ9C
MXZ X 600 HO E-TEC	593	REV-XP	BK9A, BK9B, BK9C, BK9D, BK9E
MXZ X 800R Power TEK	797	REV-XP	BB9A, BB9B, BB9C, BB9D, BB9E
Summit 50TH 800R Power TEK	797	REV-XP	CZ9A
Summit Everest 600	593	REV-XP	CY9A, CY9B
Summit Everest 600 HO E-TEC	593	REV-XP	CX9A, CX9B, CX9C
Summit Everest (146) 800R Power TEK	797	REV-XP	CU9A, CU9B
Summit Everest (154) 800R Power TEK	797	REV-XP	CT9A, CT9B
Summit Everest (163) 800R Power TEK	797	REV-XP	CW9A, CW9B
Summit Hill Climb (154) 800R Power TEK	797	REV-XP	CF9A
Summit X 600 HO E-TEC	593	REV-XP	CV9A, CV9B

# INTRODUCTION

MODEL	ENGINE TYPE	CHASSIS	MODEL NUMBER
Summit X (146) 800R Power TEK	797	REV-XP	CH9A, CH9B, CH9C, CH9D
Summit X (154) 800R Power TEK	797	REV-XP	CG9A, CG9B, CG9C, CG9D, CG9E
Summit X (163) 800R Power TEK	797	REV-XP	CP9A, CP9B, CP9C, CP9D

The information and component/system descriptions contained in this manual are correct at time of publication. BRP however, maintains a policy of continuous improvement of its products without imposing upon itself any obligation to install them on products previously manufactured.

Due to late changes, it may have some differences between the manufactured product and the description or specifications in this document.


BRP reserves the right at any time to discontinue or change specifications, designs, features, models or equipment without incurring obligation.

This manual uses technical terms which may be slightly different from the ones used in the *PARTS CATALOG*.

When ordering parts always refer to the specific model *PARTS CATALOG*.


## HOW TO IDENTIFY YOUR VEHICLE

### VEHICLE IDENTIFICATION NUMBER LOCATION



TYPICAL  
1. Vehicle identification number


## IDENTIFICATION NUMBER MEANING



## ENGINE SERIAL NUMBER LOCATION



TYPICAL — 500SS AND 600 HO SDI ENGINES  
1. Engine serial number



TYPICAL — 800R ENGINE  
1. Engine serial number

## SNOWMOBILE LIFTING

To lift a REV-XP or a REV-XR (2-stroke) securely, it is important to use the reinforced footrest holes.



1. Reinforced holes in footrest

Install lifting tool hooks in holes as shown.



1. Hook of lifting tool

**NOTICE** Do not use footrest opening or steering column to lift the snowmobile. Frame or steering system could be seriously damaged.

## ENGINE EMISSIONS INFORMATION

### MANUFACTURER'S RESPONSIBILITY

Manufacturers of engines must determine the exhaust emission levels for each engine horsepower family and certify these engines with the United States of America *ENVIRONMENTAL PROTECTION AGENCY (EPA)*. An emissions control information label, showing emission levels and engine specifications, must be placed on each vehicle at the time of manufacture.

### DEALER RESPONSIBILITY

When performing service on snowmobiles that carry an emissions control information label, adjustments must be kept within published factory specifications.

Replacement or repair of any emission related component must be executed in a manner that maintains emission levels within the prescribed certification standards.

Dealers are not to modify the engine in any manner that would alter the horsepower or allow emission levels to exceed their predetermined factory specifications.

Exceptions include manufacturer's prescribed changes, such as altitude adjustments for example.

## OWNER RESPONSIBILITY

The owner/operator is required to have engine maintenance performed to maintain emission levels within prescribed certification standards.

The owner/operator is not to, and should not allow anyone to modify the engine in any manner that would alter the horsepower or allow emissions levels to exceed their predetermined factory specifications.

## EPA EMISSION REGULATIONS

Some Ski-Doo snowmobiles manufactured by BRP are certified to the EPA as conforming to the requirements of the regulations for the control of air pollution from new snowmobiles engines. This certification is contingent on certain adjustments being set to factory standards. For this reason, the factory procedure for servicing the product must be strictly followed and, whenever practicable, returned to the original intent of the design.

The responsibilities listed above are general and in no way a complete listing of the rules and regulations pertaining to the EPA requirements on exhaust emissions for snowmobiles products. For more detailed information on this subject, you may contact the following locations:

#### FOR ALL COURIER SERVICES:

U.S. Environmental Protection Agency  
Office of Transportation and Air Quality  
1310 L Street NW  
Washington D.C. 20005

#### REGULAR US POSTAL MAIL:

1200 Pennsylvania Ave. NW  
Mail Code 6403J  
Washington D.C. 20460

INTERNET: <http://www.epa.gov/otaq/>

E-MAIL: [otaqpublicweb@epa.gov](mailto:otaqpublicweb@epa.gov)

# INTRODUCTION

## TIGHTENING TORQUE

Tighten fasteners to torque mentioned in exploded views and/or text, When they are not specified, refer to following table.

### ⚠ WARNING

Torque wrench tightening specifications must strictly be adhered to. Locking devices (e.g.: locking tabs, elastic stop nuts, self-locking fasteners, etc.) must be installed or replaced with new ones, where specified. If the efficiency of a locking device is impaired, it must be renewed.

In order to avoid a poor assembling, tighten screws, bolts or nuts in accordance with the following procedure:

1. Manually screw all screws, bolts and/or nuts.
2. Apply the half of the recommended torque value.

**NOTICE** Be sure to use proper tightening torque for the proper strength grade.

**NOTE:** When possible, always apply torque on the nut.


3. Torque at the recommended torque value.

**NOTE:** Always torque screws, bolts and/or nuts in a criss-cross sequence.

Property class and head markings				
Property class and nut markings				

FASTENER SIZE	FASTENER GRADE/TORQUE			
	5.8 Grade	8.8 Grade	10.9 Grade	12.9 Grade
M4	1.5 – 2 N•m (13 – 18 lbf•in)	2.5 – 3 N•m (22 – 27 lbf•in)	3.5 – 4 N•m (31 – 35 lbf•in)	4 – 5 N•m (35 – 44 lbf•in)
M5	3 – 3.5 N•m (27 – 31 lbf•in)	4.5 – 5.5 N•m (40 – 47 lbf•in)	7 – 8.5 N•m (62 – 75 lbf•in)	8 – 10 N•m (71 – 89 lbf•in)
M6	6.5 – 8.5 N•m (58 – 75 lbf•in)	8 – 12 N•m (71 – 106 lbf•in)	10.5 – 15 N•m (93 – 133 lbf•in)	16 N•m (142 lbf•in)
M8	15 N•m (133 lbf•in)	24.5 N•m (18 lbf•ft)	31.5 N•m (23 lbf•ft)	40 N•m (30 lbf•ft)
M10	29 N•m (21 lbf•ft)	48 N•m (35 lbf•ft)	61 N•m (45 lbf•ft)	72.5 N•m (53 lbf•ft)
M12	52 N•m (38 lbf•ft)	85 N•m (63 lbf•ft)	105 N•m (77 lbf•ft)	127.5 N•m (94 lbf•ft)
M14	85 N•m (63 lbf•ft)	135 N•m (100 lbf•ft)	170 N•m (125 lbf•ft)	200 N•m (148 lbf•ft)

## SELF-LOCKING FASTENERS PROCEDURE



TYPICAL — SELF-LOCKING FASTENER

The following describes the most common application procedures when working with self-locking fasteners.

Use a metal brush or a tap to clean the hole properly then use a solvent, let act during 30 minutes and wipe off. The solvent utilization is to ensure the adhesive works properly.


## LOCTITE APPLICATION PROCEDURE

The following describes the most common application procedures when working with Loctite products.

**NOTE:** Always use proper strength Loctite product as recommended in this shop manual.

### THREADLOCKER

#### Uncovered Holes (bolts and nuts)




1. Apply here
2. Do not apply

1. Clean threads (bolt and nut) with solvent.
2. Apply LOCTITE PRIMER N (P/N 293 800 041) on threads and allow to dry.
3. Choose proper strength Loctite threadlocker.

4. Fit bolt in the hole.
5. Apply a few drops of threadlocker at proposed tightened nut engagement area.
6. Position nut and tighten as required.


#### Blind Holes



1. On threads
2. On threads and at the bottom of hole

1. Clean threads (bolt and hole) with solvent.
2. Apply LOCTITE PRIMER N (P/N 293 800 041) on threads (bolt and nut) and allow to dry for 30 seconds.
3. Choose proper strength Loctite threadlocker.
4. Apply several drops along the threaded hole and at the bottom of the hole.
5. Apply several drops on bolt threads.
6. Tighten as required.

#### Stud in Blind Holes



1. On threads
2. On threads and in the hole
3. Onto nut threads

1. Clean threads (stud and hole) with solvent.
2. Apply LOCTITE PRIMER N (P/N 293 800 041) on threads and allow to dry.


## INTRODUCTION

- Put 2 or 3 drops of proper strength Loctite threadlocker on female threads and in hole.

**NOTE:** To avoid a hydro lock situation, do not apply too much Loctite.

- Apply several drops of proper strength Loctite on stud threads.
- Install stud.
- Install cover, etc.
- Apply drops of proper strength Loctite on uncovered threads.
- Tighten nuts as required.

### Pre-assembled Parts




- Apply here
- Do not apply

- Clean bolts and nuts with solvent.
- Assemble components.
- Tighten nuts.
- Apply drops of proper strength Loctite on bolt/nut contact surfaces.
- Avoid touching metal with tip of flask.

**NOTE:** For preventive maintenance on existing equipment, retighten nuts and apply proper strength Loctite on bolt/nut contact surfaces.

### Adjusting Screw




- Apply here
- Plunger

- Adjust screw to proper setting.
- Apply drops of proper strength Loctite threadlocker on screw/body contact surfaces.
- Avoid touching metal with tip of flask.

**NOTE:** If it is difficult to readjust, heat screw with a soldering iron (232°C (450°F)).

### STRIPPED THREAD REPAIR



- Release agent
- Stripped threads
- Form-A-Thread
- Tapes
- Cleaned bolt
- Plate
- New threads
- Threadlocker

### Standard Thread Repair

Follow instructions on Loctite FORM-A-THREAD 81668 package.

If a plate is used to align bolt:

- Apply release agent on mating surfaces.
- Put waxed paper or similar film on the surfaces.

- Twist bolt when inserting it to improve thread conformation.

**NOTE:** NOT intended for engine stud repairs.

## Repair of Small Holes/Fine Threads


**Option 1:** Enlarge damaged hole, then follow *STANDARD THREAD REPAIR* procedure.

**Option 2:** Apply *FORM-A-THREAD* on the screw and insert in damaged hole.

## Permanent Stud Installation (light duty)

- Use a stud or thread on desired length.
- DO NOT apply release agent on stud.
- Do a *STANDARD THREAD REPAIR*.
- Allow to cure for 30 minutes.
- Assemble.

## GASKET COMPOUND



- Proper strength Loctite
- Loctite Primer N (P/N 293 800 041) and Gasket Eliminator 518 (P/N 293 800 038) on both sides of gasket
- Loctite Primer N only

- Remove old gasket and other contaminants with *LOCTITE CHISEL REMOVER* (P/N 413 708 500). Use a mechanical mean if necessary.

**NOTE:** Avoid grinding.

- Clean both mating surfaces with solvent.
- Spray Loctite Primer N on both mating surfaces and on both sides of gasket. Allow to dry 1 or 2 minutes.

- Apply *GASKET ELIMINATOR 518* (P/N 293 800 038) on both sides of gasket, using a clean applicator.

- Place gasket on mating surfaces and assemble immediately.


**NOTE:** If the cover is bolted to blind holes (above), apply proper strength Loctite in the hole and on threads. Tighten.

If holes are sunken, apply proper strength Loctite on bolt threads.

- Tighten as usual.

## MOUNTING ON SHAFT

### Mounting with a Press



- Bearing
- Proper strength Loctite
- Shaft

- Clean shaft external part and element internal part.

- Apply a strip of proper strength Loctite on shaft circumference at insert or engagement point.

**NOTE:** Retaining compound is always forced out when applied on shaft.

- DO NOT use antiseize Loctite or any similar product.

- No curing period is required.

### Mounting in Tandem

- Apply retaining compound on internal element bore.


- Continue to assemble as shown above.



# INTRODUCTION

## CASE-IN COMPONENTS

### Metallic Gaskets



1. Proper strength Loctite

1. Clean inner housing diameter and outer gasket diameter.
2. Spray housing and gasket with LOCTITE PRIMER N (P/N 293 800 041).
3. Apply a strip of proper strength Loctite on leading edge of outer metallic gasket diameter.

**NOTE:** Any Loctite product can be used here. A low strength liquid is recommended as normal strength and gap are required.

4. Install according to standard procedure.
5. Wipe off surplus.
6. Allow it to cure for 30 minutes.

**NOTE:** Normally used on worn-out housings to prevent leaking or sliding.

It is generally not necessary to remove gasket compound applied on outer gasket diameter.

## MANUAL INFORMATION

The manual is divided into many major sections as you can see in the main table of contents at the beginning of the manual.

Each section is divided in various subsections, and again, each subsection has one or more division.


Illustrations and photos show the typical construction of the different assemblies and, in all cases, may not reproduce the full detail or exact shape of the parts shown. However, they represent parts which have the same or a similar function.

**NOTICE** Most components of those vehicles are built with parts dimensioned in the metric system. Most fasteners are metric and must not be replaced by customary fasteners or vice-versa. Mismatched or incorrect fasteners could cause damage to the vehicle or possible personal injury.

As many of the procedures in this manual are interrelated, we suggest, that before undertaking any task, you read and thoroughly understand the entire section or subsection in which the procedure is contained.


A number of procedures throughout the book require the use of special tools. Before commencing any procedure, be sure that you have on hand all the tools required, or approved equivalents.

The use of RIGHT and LEFT indications in the text, always refers to driving position (when sitting on vehicle).



TYPICAL  
1. Left  
2. Right

## TYPICAL PAGE



Specific torque applicable to this installation.

**CAUTION:** Pay attention to torque specifications.  
Some of these are in lbf•in instead of lbf•ft.  
Use appropriate torque wrench.

## TYPICAL PAGE

Title in bold indicates category of information to be carried out.

Reference to a specific section or subsection.

Indicates component procedures apply to.

Indicates specific procedure to be carried out.

### **GENERAL**

**NOTE:** The following procedures can be done without removing the engine.

During assembly/installation, use the torque values and service products as in the exploded views.

Clean threads before applying a threadlocker. Refer to **SELF-LOCKING FASTENERS** and **LOCTITE APPLICATION** sections at the beginning of this manual for complete procedure.

#### **WARNING**

Torque wrench tightening specifications must be strictly adhered to. Locking devices (e.g.: locking tabs, elastic stop nuts, self-locking fasteners, etc.) must be replaced with new ones.

### **PROCEDURES**

#### **MAGNETO FLYWHEEL**

##### **Magneto Flywheel Cleaning**

Clean all metal components in a non-ferrous metal cleaner.

**CAUTION:** Clean magneto flywheel using only a clean cloth.

##### **Magneto Flywheel Removal**

Remove muffler, refer to the **EXHAUST SYSTEM** section.

Remove acoustic panel.

Remove rewind starter.

Remove starting pulley no. 2



TYPICAL

"TYPICAL" indicates a general view which may not represent exact details.

**NOTE:** To remove starting pulley bolts, hold magneto flywheel with a socket as shown.



TYPICAL

Call-outs pertaining to above illustration.

Illustration always follows text to which it applies.

#### **Models**

Remove the connecting flange retaining the rewind starter to the engine housing.

Italic bold face type-setting indicates a procedure applicable to a specific model(s).

111112000001

57

Bold face number following part name refers to exploded view at beginning of subsection.

# MAINTENANCE CHART

	*10-HOUR OR 500 km (300 mi)					
	Weekly or every 240 km (150 mi)					
	Monthly or every 800 km (500 mi)					
	Every year or 3200 km (2000 mi)					
	Every 2 years or 6000 km (3700 mi)					
	*Storage					
	*Preseason					
PART/TASK						LEGEND
<b>ENGINE</b>						
Rewind starter					LC	I
Engine motor mounts	I		I		I	
Exhaust system	I		I		I	
Exhaust manifold screws <sup>(1)</sup>	I					I
Engine lubrication					L	
Cooling system	I		I			I
Coolant	I			R		(1) Retighten to specified torque.
Crankshaft PTO seal						I
RAVE valves			C			
RAVE valves solenoid (E-TEC and 800R)			I			
Injection oil filter				R		
Oil injection pump (500SS and 800R)	A		A			A
Engine stopper			A			
<b>ENGINE MANAGEMENT SYSTEM</b>						
EMS fault codes	I					I
<b>FUEL SYSTEM</b>						
Fuel stabilizer					(2)	
Fuel filter				R		
Fuel lines, fuel rail and connections	I					I
Carburetor Venturi					C	
Throttle body (E-TEC)					C	
Throttle cable	I		I			I
Air silencer filter			I			I
Fuel injection system (visual inspection)			I			I

# Section 01 MAINTENANCE

## Subsection 01 (MAINTENANCE CHART)

PART/TASK	*10-HOUR OR 500 km (300 mi)							LEGEND
	Weekly or every 240 km (150 mi)							
Monthly or every 800 km (500 mi)							*Storage	
Every year or 3200 km (2000 mi)								
Every 2 years or 6000 km (3700 mi)							*Preseason	
<b>DRIVE SYSTEM</b>								
Drive belt <sup>(3)</sup>	I	I					I	(3) Adjust drive belt height and check the tension at every belt removal.
Drive pulley <sup>(4)</sup>	I		I	C			I	
Driven pulley	I		I	C			I	(4) Tightening torque of drive pulley must be checked at the 10-hour inspection and every year or 3200 km (2000 mi) thereafter.
Brake fluid	I	I				R	I	
Brake hose, pads and disk	I	I					I	(5) Check track condition before each ride.
Drive chain	A		A				A	
Chaincase oil							R	(6) Adjust track tension and alignment as required.
Track <sup>(5)</sup>	A							
<b>STEERING</b>								
Steering mechanism	I		I				I	
<b>FRONT SUSPENSION</b>								
Front suspension mechanism <sup>(7)</sup>	I,L		I,L				I,L	(7) Lubricate whenever the vehicle is used in wet conditions (wet snow, rain, puddles).
Skis and runners	I	I					I	
<b>REAR SUSPENSION</b>								
Rear suspension <sup>(7)</sup>	I		I,L				I,L	(7) Lubricate whenever the vehicle is used in wet conditions (wet snow, rain, puddles).
Suspension stopper strap				I			I	
<b>ELECTRICAL SYSTEM</b>								
Spark plugs (500SS and 800R)	I		I				R	(8) Spark plugs must be inspected or replaced every 3 years or 10 000 km (6200 mi).
Spark plugs (E-TEC)								
Battery (if so equipped)	I		I				I	
Wiring harnesses, cables and lines	I		I				I	
Lighting system (HI/LO beam, brake light, etc.). Engine stop switch and tether cord cap (DESS)	I	I					I	
<b>CHASSIS/BODY</b>								
Headlights beam aiming				A			A	
Engine compartment	C		C				C	
Vehicle cleaning and protection	C		C				C	

A: ADJUST  
C: CLEAN  
I: INSPECT  
L: LUBRICATE  
R: REPLACE

\*: TO BE PERFORMED BY AN AUTHORIZED SKI-DOO DEALER

\*10-HOUR OR 500 km (300 mi)

Weekly or every 240 km (150 mi)

Monthly or every 800 km (500 mi)

Every year or 3200 km (2000 mi)

Every 2 years or 6000 km (3700 mi)

\*Storage

\*Preseason

PART/TASK

LEGEND

### DRIVE SYSTEM

Drive belt <sup>(3)</sup>	I	I					I	(3) Adjust drive belt height and check the tension at every belt removal.
Drive pulley <sup>(4)</sup>	I		I	C			I	
Driven pulley	I		I	C			I	(4) Tightening torque of drive pulley must be checked at the 10-hour inspection and every year or 3200 km (2000 mi) thereafter.
Brake fluid	I	I				R	I	
Brake hose, pads and disk	I	I					I	(5) Check track condition before each ride.
Drive chain	A		A				A	
Chaincase oil							R	(6) Adjust track tension and alignment as required.
Track <sup>(5)</sup>	A							

### STEERING

Steering mechanism	I		I				I
--------------------	---	--	---	--	--	--	---

### FRONT SUSPENSION

Front suspension mechanism <sup>(7)</sup>	I,L		I,L				I,L	(7) Lubricate whenever the vehicle is used in wet conditions (wet snow, rain, puddles).
Skis and runners	I	I					I	

### REAR SUSPENSION

Rear suspension <sup>(7)</sup>	I		I,L				I,L	(7) Lubricate whenever the vehicle is used in wet conditions (wet snow, rain, puddles).
Suspension stopper strap				I			I	

### ELECTRICAL SYSTEM

Spark plugs (500SS and 800R)	I		I				R	(8) Spark plugs must be inspected or replaced every 3 years or 10 000 km (6200 mi).
Spark plugs (E-TEC)								
Battery (if so equipped)	I		I				I	
Wiring harnesses, cables and lines	I		I				I	
Lighting system (HI/LO beam, brake light, etc.). Engine stop switch and tether cord cap (DESS)	I	I					I	

### CHASSIS/BODY

Headlights beam aiming				A			A
Engine compartment	C		C				C
Vehicle cleaning and protection	C		C				C

# STORAGE PROCEDURE

## SERVICE PRODUCTS

Description	Part Number	Page
BRP PLASTIC & VINYL CLEANER .....	413 711 200 .....	6
FUEL STABILIZER .....	413 408 600 .....	3
SCRATCH REMOVER KIT .....	861 774 800 .....	6
STORAGE OIL (CANADA) .....	413 711 600 .....	4
STORAGE OIL (USA) .....	413 711 900 .....	4
SUSPENSION GREASE .....	293 550 033 .....	5
XP-S LUBE .....	293 600 016 .....	5

## GENERAL

Proper snowmobile storage is a necessity during the summer months or when a vehicle is not being used for certain period of time.

If vehicle is not intended to be used within one month, add fuel stabilizer in fuel tank to prevent fuel deterioration. Refer to *FUEL SYSTEM* further in this section.

If vehicle is not intended to be used within three months, refer to storage column from *MAINTENANCE CHART* jointly with the present storage procedures in order to cover each and every aspect of the snowmobile storage procedure. Any worn, broken or damaged parts must be replaced.

### WARNING

Unless otherwise specified, engine should be turned off for storage procedure.

To facilitate the inspection and ensure adequate lubrication of components, it is recommended to clean the entire vehicle.

## PROCEDURES

### ENGINE MANAGEMENT SYSTEM

#### Fault Codes

1. Using B.U.D.S., verify fault codes state. Refer to *ENGINE MANAGEMENT SYSTEM* section.

## FUEL SYSTEM

### Fuel System Protection

With the new fuel additives, it is critical to use the FUEL STABILIZER (P/N 413 408 600) or an equivalent to prevent fuel deterioration, gum formation and fuel system gumming. Follow manufacturer's instructions for proper use.

**NOTICE** Fuel stabilizer should be added prior to engine lubrication to ensure fuel system components protection against varnish deposits.

1. Pour fuel stabilizer in fuel tank.
2. Fill up fuel tank completely.
3. Ensure there is no water inside fuel tank.

**NOTICE** Should any water be trapped inside fuel tank, severe internal damage will occur to the fuel injection system (600 HO E-TEC).

Do not drain fuel system.

## ENGINE

### Rewind Starter

For inspection, cleaning and lubrication, refer to *REWIND STARTER* section.

### Engine Motor Mounts

1. Check if engine supports are cracked or damaged. Replace if necessary.
2. Check rubber mount on engine supports. Replace them if brittle, cracked or damaged.

### Exhaust System

Check and replace if necessary:

- Tuned pipe shields and deflectors for damages
- Tuned pipe ends for cracks or damages
- Manifold for cracks or damages.

## Section 01 MAINTENANCE

### Subsection 02 (STORAGE PROCEDURE)

#### Engine Lubrication (500SS/600/800R)

**NOTICE** Fuel stabilizer should be added prior to engine lubrication to ensure carburetor protection against varnish deposit.

Engine internal parts must be lubricated to protect them from possible rust formation during the storage period.


Proceed as follows:

1. Place the vehicle in a well ventilated area and start the engine.
2. Start the engine and let it run at idle speed until it reached its operating temperature.
3. Stop the engine.
4. Remove the primary air intake silencer. Refer to *AIR INTAKE SYSTEM* for the removal procedure.
5. Restart engine and run at idle speed.
6. Inject storage oil into each carburetor/throttle body until the engine stalls or until a sufficient quantity of oil has entered the engine (approximately half a can).
7. With the engine stopped, remove the spark plugs and spray STORAGE OIL (CANADA) (P/N 413 711 600) or STORAGE OIL (USA) (P/N 413 711 900) into each cylinder.
8. Crank slowly 2 or 3 revolutions to lubricate cylinders.
9. Reinstall the spark plugs and primary air intake silencer.

#### Engine Lubrication (600 HO E-TEC)

##### Engine Lubrication Using B.U.D.S. Software

1. Place the vehicle in a well ventilated area.
2. Connect B.U.D.S. Refer to *COMMUNICATION TOOLS/B.U.D.S. SOFTWARE* section.
3. Start the engine and let engine run at idle speed until it reached its operating temperature.
4. In B.U.D.S., select **Read Data**.
5. Select **Activation** folder.
6. Go to the **ECM** page.
7. Press on **Storage** button and follow instructions.



1. Activation folder
2. ECM page
3. Storage button


The engine lubrication procedure takes approximately 1 minute. During this time the engine RPM will increase slightly.

At the end of engine lubrication procedure, the ECM will turn the engine off.

8. Remove tether cord to avoid starting the vehicle during storage period.

##### Engine Lubrication Using Multifunction Gauge

1. Place the vehicle in a well ventilated area.
2. Start the engine and let it run at idle speed until it reached its operating temperature.
3. Push the SET (S) button to select odometer (Km/Mi) mode.



**NOTE:** The storage mode does not function in other modes (trip A, trip B and hr trip).


4. Quickly depress the HI/LOW beam switch rapidly and simultaneously press and hold the SET (S) button.
5. Release switch and button when PUSH "S" appears in the display.

## Section 01 MAINTENANCE

### Subsection 02 (STORAGE PROCEDURE)



6. Press and hold the SET (S) button 2 - 3 seconds.
7. When OIL appears in display, release the button and wait the end of the procedure.



The engine lubrication procedure takes approximately 1 minute. During this time the engine RPM will increase slightly.

At the end of engine lubrication procedure, the ECM will turn the engine off.

8. Remove tether cord to avoid starting the vehicle during storage period.

## ELECTRICAL SYSTEM

### Battery (if so equipped)

1. Remove battery, clean its tray and surrounding area with water and baking soda.
2. Inspect, clean and charge battery as explained in *CHARGING SYSTEM* section.

### Wiring Harnesses, Cables and Connectors

1. Inspect for wear, deterioration or damage, replace defective parts if necessary.

## DRIVE/BRAKE SYSTEM

### Drive and Driven Pulleys

1. Remove drive belt.
2. Inspect and clean pulleys.

3. Spray XP-S LUBE (P/N 293 600 016) on sheaves to protect them from rust.
4. Do not reinstall drive belt.

### Drive Axle End Bearing (Brake Side)

1. Remove the disc brake protector cover and make a visual inspection of the bearing seal to ensure it is not damaged. Replace bearing if damaged. Refer to *DRIVE AXLE* section.

## Track

**NOTE:** Do not release track tension.

1. Visually inspect track for:
  - Cuts and abnormal wear
  - Broken rods
  - Broken or missing track cleats.

If track is damaged or rods are broken, replace track, refer to *TRACK* section.

For damaged or missing cleats, refer to *TRACK* section for procedure.

## Chaincase

### Chaincase Oil

1. Replace chaincase oil, refer to *CHAINCASE* section.

### Drive Chain

1. Check drive chain tension and adjust if necessary, refer to *CHAINCASE* section.

## CHASSIS

### Front Suspension

1. Inspect the front suspension arms for wear or damages, replace if necessary. Refer to *FRONT SUSPENSION* section.

### Rear Suspension

1. Inspect rear suspension components for wear, deterioration or damage, replace defective parts if necessary.
2. Inspect strap(s) for wear or cracks.
3. Check bolt and nut securing strap(s) for tightness. If loose, inspect strap holes for deformation. Replace strap if necessary.
4. Lubricate rear arm at grease fittings using *SUSPENSION GREASE* (P/N 293 550 033).

### Steering Mechanism

1. Lubricate the steering mechanism if needed. **Inspect all components for tightness.**



---

## Section 01 MAINTENANCE

### Subsection 02 (STORAGE PROCEDURE)

---

#### Skis and Runners

1. Inspect skis and runners for wear, deterioration or damage, replace if necessary.

## VEHICLE

### Vehicle Cleaning

Keep engine compartment clean of grass, twigs, cloth, etc. These are combustible under certain conditions.

To clean the vehicle, do not use high pressure washers (like the ones found in car washes) as it may damage certain parts of the vehicle.

To clean the vehicle, proceed as follows:

1. Rinse the vehicle thoroughly with water to remove loose dirt.
2. Using a soft clean cloth, wash the vehicle with water mixed with a mild detergent, such as soap specially formulated for motorcycles or automobiles.
3. While washing the vehicle, check for grease or oil. If necessary, use BRP PLASTIC & VINYL CLEANER (P/N 413 711 200) or a mild automotive degreaser. Follow thoroughly the manufacturer's instructions.

**NOTICE** Do not use heavy duty cleaner on decals or vinyl.

4. Dry the vehicle with a chamois or a soft towel.

#### WARNING

Do not apply a vinyl or plastic protector on the seat as the surface will become slippery and the operator or the passenger may slip off the vehicle.

### Windshield Polishing

Windshield can be polished using SCRATCH REMOVER KIT (P/N 861 774 800) or a plastic cleaner specially formulated for these special surfaces.

**NOTICE** Do not clean the windshield with alkaline or acid cleaner, gasoline or solvent to avoid windshield damage.

### Vehicle Waxing

Apply only nonabrasive wax safe for clearcoats paints on glossy finishes.

Avoid applying wax on mat surfaces.

### Vehicle Protection

1. Block air intake and muffler with clean rags.

2. Touch up all metal spots where paint has been scratched off.
3. Cover the vehicle with a permeable material. Avoid using plastic or similar non-breathing, coated materials that restrict air flow and allow heat and moisture to accumulate.
4. Store vehicle in a dry unheated area, away from sunlight, with a small amount of daily temperature variation.
5. Lift rear of vehicle until track is clear of the ground. Install on a snowmobile mechanical stand.

# PRESEASON PREPARATION

## SERVICE PRODUCTS

Description	Part Number	Page
PULLEY FLANGE CLEANER .....	413 711 809 .....	8

## GENERAL

Proper vehicle preparation is necessary after the summer months or when a vehicle has not been used for more than three months.

Refer to preseason preparation column from *MAINTENANCE CHART* jointly with the present preseason preparation procedures in order to cover each and every aspect of the snowmobile preseason preparation procedure.

Any worn, broken or damaged parts found during the storage procedure should have been replaced. If not, proceed with the replacement.

### **WARNING**

Unless otherwise specified, engine should be turned off for preparation procedure.

## PROCEDURES

### ENGINE

#### Exhaust Manifold

Check exhaust manifold screws for looseness. Retorque if necessary.

#### Muffler

Remove rags that were installed during storage preparation.

#### Cooling System

Inspect cooling system for leaks, to perform a cooling system leak test, refer to *COOLING SYSTEM* section.

Check coolant level in coolant reservoir. Add coolant if necessary.

If engine is cold, refill up to 15 mm (5/8 in) over COLD level line.

If engine is hot, refill up to 25 mm (1 in) over COLD level line. Use caution when opening pressurized coolant reservoir cap. Place a rag over cap and turn it slowly to release pressure.

#### Crankshaft PTO Seal

Make sure there is no grease coming out from crankshaft PTO seal, if so replace seal. Refer to *BOTTOM END* section.

#### Air Intake Silencer Prefilter

Ensure that air intake silencer prefilter is properly installed and in good condition.

Rinse prefilter with fresh water to clean or replace if damaged.

#### Oil Injection Pump

##### *500SS/600/800R*

Make sure oil injection pump is properly adjusted, refer to *LUBRICATION SYSTEM* section.

#### RAVE Valves (600 HO E-TEC)

**NOTE:** This action must be performed only when the vehicle preparation is completed.

1. Remove LH side panel.
2. Remove tool kit support located on drive belt guard.
3. Remove 3D RAVE valves cover.
4. Start engine and let it run 1 minute at idle.
5. Disconnect 3D RAVE vacuum/pressure hose on PTO side.
6. Press on the link bar and check the 3D RAVE valves operation.

If the RAVE valves move freely, reinstall removed parts.

If not, clean the RAVE valves. Refer to *RAVE VALVE (E-TEC/800R)*.

## FUEL SYSTEM

Inspect fuel system for leaks. Perform a fuel system leak test, refer to *FUEL TANK AND FUEL PUMP* section.

---

## Section 01 MAINTENANCE

### Subsection 03 (PRESEASON PREPARATION)

---

#### Carburetors

##### *500SS/600/800R*

Disassemble carburetors in order to clean all internal parts. Do not hesitate to replace any jets having gum or varnish on their surfaces.

**NOTE:** Cleaning is not required if vehicle was prepared as per storage procedures.

Make sure carburetors are properly adjusted, refer to *FUEL SYSTEM*.

#### Throttle Body

##### *600 HO E-TEC*

Using the PULLEY FLANGE CLEANER (P/N 413 711 809), clean the throttle plates and throttle body bores.

**NOTE:** To ease cleaning, throttle body should be partially pulled from engine, without disconnecting throttle cable or coolant hose.

**NOTICE** Ensure the cleaner does not enter engine intake.

#### Throttle Lever

Make sure that throttle lever operates freely, adjust and lubricate throttle cable as required, refer to *FUEL SYSTEM*.

#### Choke

##### *500SS/600/800R*

Make sure choke lever operates freely, adjust and lubricate choke cable as required. Refer to *FUEL SYSTEM*.

## ELECTRICAL SYSTEM

#### Spark Plugs

##### *500SS/600/800R*

Once preseason preparation is done, start engine with the old spark plugs to burn excess storage oil. Then, install new spark plugs.

**NOTE:** Ensure to replace with recommended spark plugs.

#### Battery (if so equipped)

Verify that battery is fully charged, if not, refer to the appropriate charging procedure in *CHARGING SYSTEM*.

#### Lighting System

Check if the lighting system works well.

#### Engine Cut-Out Switch

Check engine cut-out switch operation.

#### Accessories

Check the operation of all accessories.

## DRIVE/BRAKE SYSTEM

#### Drive and Driven Pulley

Clean drive and driven pulleys sheaves with PULLEY FLANGE CLEANER (P/N 413 711 809).

#### Drive Belt

Inspect belt for cracks, fraying or abnormal wear. Replace if necessary.

Make sure to install the proper belt with arrow printed on belt pointing front of vehicle.

#### Brake

##### Brake Fluid

Check brake fluid in reservoir for proper level. Add fluid (DOT 4) as required.

**NOTICE** Use only DOT 4 brake fluid from a sealed container. An opened container may be contaminated or may have absorbed moisture from the air.

##### Brake Hose, Pads and Disk

Inspect brake hose for wear, deterioration or damage, replace if necessary.

Inspect brake pads for proper thickness. Refer to *BRAKE* section.

Remove any rust built-up on braking surfaces. Clean brake disk braking surfaces with PULLEY FLANGE CLEANER (P/N 413 711 809).

#### Track

Verify track tension and alignment, refer to *TRACK* section.

**NOTE:** Track tension and alignment are interrelated. Do not adjust one without checking the other. Track tension procedure must be carried out prior to track alignment.

# ENGINE REMOVAL AND INSTALLATION


## SERVICE TOOLS

<b>Description</b>	<b>Part Number</b>	<b>Page</b>
ENGINE REMOVAL HOOK.....	529 035 829 .....	15, 20, 24-26
LIFTING TOOL.....	529 036 131 .....	20, 24, 26
SMALL HOSE PINCHER .....	295 000 076 .....	14, 16, 21
SPARK PLUG LIFT RING .....	529 035 830 .....	15, 24, 26


## Section 02 ENGINE

### Subsection 01 (ENGINE REMOVAL AND INSTALLATION)

500SS/600/800R



600 HO E-TEC



## Section 02 ENGINE

### Subsection 01 (ENGINE REMOVAL AND INSTALLATION)

## GENERAL

During assembly/installation, use the torque values and service products as in the exploded view.

Clean threads before applying a threadlocker. Refer to *SELF-LOCKING FASTENERS* and *LOCTITE APPLICATION* at the beginning of this manual for complete procedure.

### ⚠ WARNING

Torque wrench tightening specifications must be strictly adhered to.

Locking devices (e.g.: locking tabs, elastic stop nuts, cotter pin, etc.) must be replaced with new ones.

Hoses or cables removed or disconnected must be installed and routed at the same place.

**NOTICE** Locking ties removed during a procedure must be replaced and installed at the same location.

## PROCEDURES

### ENGINE

#### Engine Removal


##### 500SS/600/800R

1. Place vehicle at workstation that will have access to an engine-lifting hoist.
2. Refer to *BODY* section and remove the following:
  - LH and RH side panels
  - Hood
  - Front bottom pan cover.
3. On vehicle with electric starter, remove the negative cable (-) from battery.




1. Negative cable

4. Remove muffler and tuned pipe. Refer to *EXHAUST SYSTEM* section.
5. Remove the driven pulley. Refer to *DRIVEN PULLEY AND COUNTERSHAFT* section.
6. On vehicle with electric starter, remove starter cable from starter.




1. Starter cable  
2. Starter

7. Disconnect water pump hose to drain engine.



1. Water pump cover  
2. Remove this hose

8. Remove the acoustic panel on the RH side of vehicle.




1. Acoustic panel screws

9. Remove rewind starter cover screws and place rewind starter housing aside.




1. Rewind starter cover

10. Cut locking ties securing coolant hose and wiring harness to RAVE solenoid support.



1. Locking ties to remove

11. Detach hoses from support.  
 12. On 800R models, unplug RAVE solenoid connector.  
 13. Unplug trigger coil and magneto connectors.




**CONNECTORS LOCATED BEHIND CHAINCASE**  
 1. Trigger coil connector  
 2. Magneto connector

14. Remove YELLOW wires from the magneto connector.  
 15. Remove and discard screws securing MAG engine supports to front and rear rubber mounts.



**FRONT MAG SUPPORT**  
 1. Front engine support screw



**REAR MAG SUPPORT**  
 1. Rear engine support screw  
 2. Intake adapter  
 3. Thermostat housing

16. Remove nuts securing the bottom of countershaft bearing support.



1. Nuts to remove  
 2. Countershaft bearing support

17. Remove bolt retaining the top of countershaft bearing support.



## Section 02 ENGINE

### Subsection 01 (ENGINE REMOVAL AND INSTALLATION)



1. Countershaft bearing support
2. Upper bolt

18. Loosen lower nut located behind support.




1. Loosen this nut

19. Remove the countershaft bearing support.


20. Remove the primary air intake silencer. Refer to *AIR INTAKE SYSTEM* section.

21. Install a SMALL HOSE PINCHER (P/N 295 000 076) on heater hose.



1. Hose pincher
2. Heater hose
3. Heater valve

22. Disconnect heater hose from heater valve.



1. Heater hose
2. Heater valve

23. Unscrew clamps securing carburetors to intake adapters.

24. Move and attach carburetors aside.

25. Unplug the coolant temperature sensor (CTS) connector.



1. CTS connector

26. On 800R models, remove the knock sensor.

## Section 02 ENGINE

### Subsection 01 (ENGINE REMOVAL AND INSTALLATION)



1. Knock sensor screw


27. Remove both spark plugs.



1. Spark plugs

28. Remove the elbow on cylinder head cover.

29. Install the SPARK PLUG LIFT RING (P/N 529 035 830) in spark plug hole (PTO side).



1. Spark plug lift ring


30. On models equipped with a high windshield, remove it to avoid scratches during engine removal.

31. Install the ENGINE REMOVAL HOOK (P/N 529 035 829).



1. Engine removal hook

32. Remove and discard screws securing PTO engine supports to front and rear rubber mounts.




1. Front engine support screw  
2. Rear engine support screw

33. Remove the engine stopper. Discard screws.

## Section 02 ENGINE


### Subsection 01 (ENGINE REMOVAL AND INSTALLATION)



1. Engine stopper
2. Crankshaft


34. Lift the engine a little.

35. Remove pulse line from fuel pump.




1. Pulse line
2. Fuel pump

36. Detach oil pump cable from oil pump.





1. Oil pump cable
2. Oil pump

37. Unplug oil injection inlet hose (hose with a spring) and plug it with an extension (1/4" drive).



1. Inlet hose
2. Extension


38. Install a SMALL HOSE PINCHER (P/N 295 000 076) on oil injection outlet hose.



1. Outlet hose
2. Hose pincher

39. Disconnect the outlet hose.

40. Remove PTO rubber mounts.




1. Front rubber mount
2. Rear rubber mount

41. Lift and slide out engine

## Engine Removal


### 600 HO E-TEC

- Place vehicle at workstation that will have access to an engine-lifting hoist.
- Refer to *BODY* section and remove the following:
  - LH and RH side panels
  - Hood
  - Front bottom pan cover.
- Remove the secondary air intake silencer. Refer to *AIR INTAKE SYSTEM* section.
- Remove fuel pressure using B.U.D.S. software. Refer to *FUEL TANK AND FUEL PUMP* section.
- Remove muffler and tuned pipe. Refer to *EX-HAUST SYSTEM* section.
- Remove the drive belt guard support. Refer to *DRIVE BELT* section.
- Remove the drive pulley. Refer to *DRIVE PULLEY* section.
- Remove the driven pulley. Refer to *DRIVEN PULLEY AND COUNTERSHAFT* section.
- Place a drain pan under engine compartment.
- Disconnect water pump hose to drain engine coolant.



- Water pump cover
- Remove this hose

- Remove the acoustic panel on the RH side of vehicle.




- Acoustic panel screws

- Remove rewind starter cover screws and place rewind starter housing aside.



- Rewind starter cover

- Cut locking ties securing coolant hoses and wiring harness to 3D RAVE solenoid support.



- Locking ties to remove

- Detach hoses from support.
- Unplug 3D RAVE solenoid connector.

## Section 02 ENGINE

### Subsection 01 (ENGINE REMOVAL AND INSTALLATION)



mm2009-008-003\_a

1. 3D RAVE solenoid connector

16. Unplug trigger coil and magneto connectors.



mm2009-008-004\_a

1. Trigger coil connector  
2. Magneto connector

17. Remove and discard screw securing front MAG engine support to front rubber mount.




mm2008-008-007\_a

1. Front engine support screw

18. Remove the primary air intake silencer. Refer to *AIR INTAKE SYSTEM* section.


19. Remove nuts securing the bottom of countershaft bearing support.



mm2009-008-005\_a

1. Nuts to remove  
2. Countershaft bearing support

20. Remove bolt retaining the top of countershaft bearing support.



mm2009-008-006\_a

1. Countershaft bearing support  
2. Upper bolt

21. Loosen lower nut located behind support.



mm2009-008-007\_a

1. Loosen this nut


22. Remove the countershaft bearing support.

23. Remove the throttle body heater hose from the cylinder head.



1. Heater hose


24. Unscrew clamps securing throttle body to intake adapters.



1. Throttle body clamps

25. Move and attach throttle body aside.

26. Unplug spark plug cables.



1. PTO spark plug cable  
2. MAG spark plug

27. Unplug the coolant temperature sensor (CTS) connector.



1. CTS connector  
2. MAG spark plug

28. Remove and discard screw securing rear MAG engine support to rear rubber mount.

29. Disconnect coolant hose from cylinder head.



1. Coolant hose

30. Unplug fuel injector connectors.



1. Fuel injector connectors

31. Remove screws that attach fuel injector hose retainers to fuel injectors.

## Section 02 ENGINE

### Subsection 01 (ENGINE REMOVAL AND INSTALLATION)



1. Fuel injector hose retainers

32. Place a rag at the bottom of fuel injectors and unplug fuel hoses from fuel injectors.

33. Disconnect the coolant hose on the top of cylinder head.




1. Small coolant hose from coolant reservoir

34. Remove knock sensor from cylinder head.



1. Knock sensor

35. Cut locking tie securing 3D RAVE connector to LH front frame member.



1. 3D RAVE connector  
2. LH front frame member

36. Disconnect oil hoses from 3D RAVE valves.



1. 3D RAVE valve oil hoses

37. Install the LIFTING TOOL (P/N 529 036 131) instead of knock sensor.



**NOTE:** Use knock sensor screw to secure lifting tool on cylinder head.

38. Place the ENGINE REMOVAL HOOK (P/N 529 035 829) into lifting tool rings.


## Section 02 ENGINE

### Subsection 01 (ENGINE REMOVAL AND INSTALLATION)




1. Lifting tool
2. Engine removal hook

39. Remove the engine stopper. Discard screws.



1. Engine stopper
2. Crankshaft

40. Remove and discard screws securing PTO engine supports to front and rear rubber mounts.



1. Front engine support screw
2. Rear engine support screw


41. Lift the engine a little.

42. Remove the PTO rear rubber mount.



1. Rubber mount screws

43. Install a SMALL HOSE PINCHER (P/N 295 000 076) on the oil return hose.



1. Oil return hose

44. Disconnect oil inlet hoses from crankcase. Discard the Oetiker clamps.



## Section 02 ENGINE

### Subsection 01 (ENGINE REMOVAL AND INSTALLATION)



1. Inlet hoses

45. Lift engine and slide it out of vehicle. During this operation pay attention to the following:
46. Do not crush fuel hoses or break fuel hoses adaptors.
47. Do not hit spark plugs against the side frame member.


### Engine Installation

To install the engine, reverse the removal procedure. However, pay attention to the following.

- Install **NEW** self-locking screws where required, refer to exploded view at the beginning of this section.
- Install **NEW** Oetiker clamps when installing oil inlet hoses.
- Install and tighten engine support bolts. Refer to *ENGINE SUPPORT INSTALLATION* in this section.
- Install and adjust the engine stopper. Refer to *ENGINE STOPPER ADJUSTMENT* in this section.
- Oil hoses must be routed correctly to avoid lubrication problems. To route hoses correctly, refer to *OIL HOSES IDENTIFICATION*.
- When engine installation is completed, bleed oil system. Refer to *LUBRICATION SYSTEM* section for proper procedure.
- If a new engine is installed or the engine was repaired, premix the fuel with oil (500SS/600/800R) or restart the break-in procedure in B.U.D.S. for the 600 HO E-TEC.


### Oil Hoses Identification

#### 500SS/600




1. Oil injection inlet hose
2. Oil injection pump cable
3. Magneto harness
4. Crankcase vent hose

#### 600 HO E-TEC




- REAR OF ENGINE**
1. Oil inlet hose (PTO side)
  2. Oil inlet hose (MAG side)
  3. Oil return hose




- RH SIDE OF VEHICLE**
1. Oil pump
  2. Oil inlet hose towards PTO fitting
  3. Oil inlet hose towards MAG fitting

**800R**




1. Oil injection inlet hose
2. Oil injection pump cable
3. Magneto harness
4. Crankcase vent hose




1. Oil injection inlet hose
2. Oil injection pump cable
3. Magneto harness
4. Crankcase vent hose

**Oil Hoses Identification (3D RAVE Valves)**

**600 HO E-TEC**



- RH SIDE OF VEHICLE**
1. Oil pump
  2. Towards PTO 3D RAVE valve
  3. Towards MAG 3D RAVE valve
  4. Thermostat housing




- FRONT OF ENGINE**
1. Magneto and CPS harnesses
  2. MAG 3D RAVE valve
  3. PTO 3D RAVE valve

**ENGINE STOPPER**

**Engine Stopper Adjustment**

The engine stopper is located on the LH front engine support, in front of the drive pulley.

1. Remove DESS key from post.
2. Remove the LH side panel, refer to *BODY* section.
3. Remove drive belt guard, refer to *DRIVE BELT GUARD REMOVAL* in this section.
4. Loosen the three bolts retaining the engine stopper to the engine support without removing them.



1. Engine stopper
2. Engine stopper screws
3. Drive pulley

5. Apply a downward pressure on the engine stopper with your fingers while tightening the screws just enough to obtain contact between the screw heads and the surface of the stopper.

## Section 02 ENGINE

### Subsection 01 (ENGINE REMOVAL AND INSTALLATION)

6. Torque screws to 10 N•m (89 lbf•in).

**NOTICE** Serious pulley damage can occur if the engine stopper and its screws are not properly installed.

## ENGINE SUPPORT

### Engine Support Inspection

Check if engine supports are cracked, bent or damaged. Replace if necessary.


### PTO Side Engine Support Removal (Engine not Removed)

**NOTE:** On vehicle with electric starter, remove the electric starter. Refer to *STARTING SYSTEM* section.

Remove drive and driven pulleys. Refer to *DRIVE PULLEY* and *DRIVEN PULLEY AND COUNTER-SHAFT* sections.

Remove the tuned pipe. Refer to *EXHAUST SYSTEM* section.

Remove and discard screws securing PTO engine supports to front and rear rubber mount adapters.



1. Front engine support screw  
2. Rear engine support screw

Insert a pry bar over the LH frame member and gently raise the engine just enough to remove engine weight from support.

Remove and discard screws retaining engine support to engine.

Remove engine support.

### MAG Side Engine Support Removal (Engine not Removed)

Remove muffler and tuned pipe. Refer to *EXHAUST SYSTEM* section.

Remove driven pulley. Refer to *DRIVEN PULLEY AND COUNTERSHAFT* section.

Remove the primary air intake silencer. Refer to *AIR INTAKE SYSTEM* section.

Unscrew clamps retaining throttle body or carburetors to intake adapters.

Move and attach throttle body or carburetors aside.

### 500SS/600/800R

Remove spark plugs.

Install the SPARK PLUG LIFT RING (P/N 529 035 830) in spark plug hole (PTO side).



Install the ENGINE REMOVAL HOOK (P/N 529 035 829).



Remove and discard screws securing engine supports to rubber mount adapters.

Lift engine.

Remove and discard screws retaining engine support to engine.

Remove engine support.

### 600 HO E-TEC

Remove the knock sensor.

Install the LIFTING TOOL (P/N 529 036 131) instead of knock sensor.



**NOTE:** Use knock sensor screw to secure lifting tool on cylinder head.

Place the ENGINE REMOVAL HOOK (P/N 529 035 829) into lifting tool rings.



Remove and discard screws securing engine supports to rubber mount adapters.

Lift engine.

Remove and discard screws retaining engine support to engine.


Remove engine support.

### Engine Support Installation

The installation is the reverse of the removal procedure, however pay attention to the following.

**NOTE:** Do not forget the adjustment of the engine stopper.

1. Front engine supports (PTO and MAG sides) are secured using a conical washer and a flat washer.




**FRONT ENGINE MOUNT (PTO SIDE)**

1. Conical washer
2. Flat washer

2. Torque engine supports hexagonal bolts to 25 N•m (18 lbf•ft) using the following sequence.

- 2.1 Rear engine support (PTO side)
- 2.2 Rear engine support (MAG side)
- 2.3 Front engine support (PTO side)

- 2.4 Front engine support (MAG side).



**TYPICAL — PTO SIDE**

- Step 1: Rear engine support (PTO side)
- Step 3: Front engine support (PTO side)



**TYPICAL — MAG SIDE**

- Step 2: Rear engine support (MAG side)
- Step 4: Front engine support (MAG side)

## ENGINE RUBBER MOUNT

### Engine Rubber Mount Inspection

Check rubber mounts. Replace them if brittle, cracked or damaged.

### Engine Rubber Mount Removal

Remove muffler and tuned pipe. Refer to *EXHAUST SYSTEM* section.

Remove driven pulley. Refer to *DRIVEN PULLEY AND COUNTERSHAFT* section.

Remove the primary air intake silencer. Refer to *AIR INTAKE SYSTEM* section.

Unscrew clamps retaining throttle body or carburetors to intake adapters.

Move and attach throttle body or carburetors aside.

### **500SS/600/800R**

Remove spark plugs.

## Section 02 ENGINE

### Subsection 01 (ENGINE REMOVAL AND INSTALLATION)

Install the SPARK PLUG LIFT RING (P/N 529 035 830) in spark plug hole (PTO side).



Install the ENGINE REMOVAL HOOK (P/N 529 035 829).



Remove and discard screws securing engine supports to rubber mount adapters.

Lift engine.

Unscrew bolts or nuts securing engine rubber mounts to frame.

#### **600 HO E-TEC**

Remove the knock sensor.

Install the LIFTING TOOL (P/N 529 036 131) instead of knock sensor.



**NOTE:** Use knock sensor screw to secure lifting tool on cylinder head.

Place the ENGINE REMOVAL HOOK (P/N 529 035 829) into lifting tool rings.



Remove and discard screws securing engine supports to rubber mount adapters.

Lift engine.

Unscrew bolts or nuts securing engine rubber mounts to frame.

#### **Engine Rubber Mount Installation**

The installation is the reverse of the removal procedure.

# ENGINE LEAK TEST

## SERVICE TOOLS


<b>Description</b>	<b>Part Number</b>	<b>Page</b>
INTAKE PLUG .....	529 036 128 .....	29
MANIFOLD PLUG .....	529 035 961 .....	29
SMALL HOSE PINCHER .....	295 000 076 .....	29
VACUUM/PRESSURE PUMP .....	529 021 800 .....	29

## Section 02 ENGINE

### Subsection 02 (ENGINE LEAK TEST)

## TROUBLESHOOTING

NOTE: This flow chart must be used as a visual reference during the engine leak test procedure.




## PROCEDURES

### ENGINE

Prior to take apart an engine, it is important to proceed with a leak test to diagnose engine problems. Whenever the engine is disassembled, a leak test should be performed after reassembly.

1. Remove engine. Do not remove the exhaust manifold. Refer to *ENGINE REMOVAL AND INSTALLATION* section.
2. Install MANIFOLD PLUG (P/N 529 035 961) over exhaust manifold and secure with a clamp.




TYPICAL

3. Insert an INTAKE PLUG (P/N 529 036 128) in each intake adaptors. Tighten with existing clamps.



1. Intake plug

4. Using a SMALL HOSE PINCHER (P/N 295 000 076), block each impulse hose as applicable.



1. Small hose pinchers

**NOTICE** Pay attention not to squeeze hose nipples.

5. Install VACUUM/PRESSURE PUMP (P/N 529 021 800) on manifold plug.



TYPICAL

6. Activate pump and pressurize engine to 34 kPa (5 PSI). Do not exceed this pressure.
7. Engine must stand this pressure during 3 minutes. If pressure drops before 3 minutes, spray a soapy solution on tester kit (manifold and intake plugs, vacuum/pressure pump and its hose).
  - 7.1 If tester kit (manifold and intake plugs, hoses and pump) is leaking, bubbles will indicate where leak comes from.
  - 7.2 If tester kit is not leaking, check engine, see *ENGINE COMPONENTS TO BE VERIFIED*.

### Engine Components to be Verified

Leak indicator hole below coolant pump housing.



## Section 02 ENGINE

### Subsection 02 (ENGINE LEAK TEST)

All jointed surfaces and screw or stud threads of engine:

- Spark plug base, insulator
- Cylinder head
- RAVE valve bellows, piston and housing
- Cylinder
- Crankcase halves (joint)
- Crankshaft outer seals (PTO and MAG)
- Coolant pump housing.

#### 500SS/600/800R

- O-ring of oil injection pump mounting flange
- Coolant bleed screws/plugs.


Verify also the small injection oil lines coming from oil pump.

#### 600 HO E-TEC

- Coolant bleed nipples on cylinder head
- Fuel injector gaskets.


### Troubleshooting Tips

Air bubbles or oil column going toward pump may indicate a defective check valve in injection nozzle.



#### 800R ENGINE SHOWN

1. Injection nipples
2. Small injection oil lines




#### 600 HO E-TEC ENGINE

1. Injection nipples

Air bubbles in cooling system indicate a defective cylinder head O-ring or cylinder base gasket.

If there is a leak from the leak indicator hole, it indicates a defective oil seal from pump shaft (oil seal behind coolant ceramic seal).




1. Leak indicator hole

### PUMP SHAFT OIL GEAR RESERVOIR


Install air pump on reservoir fitting and pressurize engine to 34 kPa (5 PSI). Do not exceed this pressure.

**Section 02 ENGINE**  
Subsection 02 (ENGINE LEAK TEST)




**TYPICAL**  
1. Air pump hose on fitting

If pressure drops, it indicates a defective crankshaft inner seal or a defective oil seal either on water pump side or oil pump side.



**TYPICAL — CRANKCASE INSIDE VIEW**  
1. Leakage through water pump seal (reservoir side)  
2. Leakage on oil pump side (seal or O-ring)



**TYPICAL — CRANKCASE INSIDE VIEW**  
1. Leakage through inner seal on PTO side  
2. Leakage through inner seal on MAG side

# ENGINE MEASUREMENT

## SERVICE TOOLS


Description	Part Number	Page
DEGREE WHEEL.....	529 035 607 .....	37-38
DIAL INDICATOR.....	414 104 700 .....	37-38
DIAL INDICATOR ADAPTER KIT.....	529 036 132 .....	39

## PROCEDURES

**NOTE:** This subsection explains the procedures to correctly measure engine components. For the engine technical specifications, refer to *INSPECTION* in the appropriate *ENGINE* subsection.

### CYLINDER HEAD WARPAGE

1. Check gasket mating surface of the cylinder head with a straight edge and a feeler gauge. Make sure part is within the given specification.
2. If cylinder head is out of specification, replace it.
3. Verify combustion chamber volume to use the correct cylinder base gasket with the new part.




1. Straight edge
2. Feeler gauge

### CYLINDER TAPER

1. Measure cylinder diameter in the following locations:
  - Above exhaust port
  - Below intake port.
2. Compare cylinder diameters.

3. If the difference exceeds the specified dimension, the cylinder should be rebored and honed or should be replaced. Nikasil cylinder can be honed using diamond hone but can not be rebored.

**NOTE:** Be sure to restore the chamfer around all cylinder sleeve port openings.



1. Below the intake port
- A. Above exhaust port


### CYLINDER OUT OF ROUND

1. Measuring above exhaust port with a cylinder gauge, check if the cylinder out of round is more than the specified dimension.
2. If larger, cylinder should be rebored and honed or should be replaced. Nikasil cylinder can be honed using diamond hone but cannot be rebored.

**NOTE:** Be sure to restore the chamfer around all cylinder sleeve port openings.

## Section 02 ENGINE


### Subsection 03 (ENGINE MEASUREMENT)



1. Piston pin position
2. Measures to be compared
- A. Above exhaust port


## CYLINDER/PISTON CLEARANCE

1. Using a micrometer, measure piston at "A" perpendicularly (90°) to piston pin.




- TYPICAL**
1. Measuring perpendicularly (90°) to piston pin axis
  - A. 15 mm (.591 in)

2. The measured dimension must not be less than 0.15 mm (.006 in) of the one scribed on piston dome. Otherwise, install a new piston.



- TYPICAL**
1. Piston dome
  2. Piston measurement

3. If piston is within tolerance, adjust and lock a micrometer to the piston dimension.



1. Micrometer set to the piston dimension
4. Refer to *PROCEDURE CONTINUATION WITH A NEW OR USED PISTON* further.
5. With the micrometer set to the piston dimension, adjust a cylinder bore gauge to the micrometer dimension and set the indicator to 0.




1. Use the micrometer to set the cylinder bore gauge
2. Dial bore gauge



1. Indicator set to 0 (zero)

**NOTE:** Make sure the cylinder bore gauge indicator is set exactly at the same position as with the micrometer, otherwise the reading will be false.

6. Position the dial bore gauge above the exhaust port.
7. **IMPORTANT:** Always remove cylinder-block from crankcase before measuring.



1. Measuring perpendicularly (90°) to piston pin axis
- A. Above exhaust port

8. Read the measurement on the cylinder bore gauge. The result is the exact piston/cylinder wall clearance. If clearance exceeds specified tolerance, replace cylinder and piston.

**NOTE:** Oversize pistons are available for the 593 engine only.

### RING/PISTON GROOVE CLEARANCE

1. Using a feeler gauge check clearance between rectangular ring and groove.
2. Replace piston if clearance exceeds specified tolerance.



## Section 02 ENGINE


### Subsection 03 (ENGINE MEASUREMENT)

#### RING END GAP

1. Position ring halfway between transfer ports and intake port.

**NOTE:** In order to correctly position the ring in the cylinder, use piston as a pusher.

2. Using a feeler gauge, check ring end gap. Replace ring if gap exceeds specified tolerance.




**TYPICAL**  
1. Transfer port  
2. Intake port


#### CRANKSHAFT DEFLECTION

##### Measuring in Crankcase

1. Using a dial indicator, check deflection with crankshaft in crankcase.



**TYPICAL — PTO SIDE**  
1. Measure deflection 3 mm (1/8 in) from crankshaft end




**TYPICAL — MAG SIDE**  
1. Measure deflection at mid point between key and groove  
2. Key  
3. Groove


2. If deflection exceeds the specified tolerance, recheck deflection using V-shaped blocks to determine the defective part(s). See *MEASURING ON BENCH*.

##### Measuring on Bench

1. Once engine is disassembled, check crankshaft deflection on V-shaped blocks.



**TYPICAL — V-SHAPED BLOCKS POSITION WITH BEARINGS**  
1. Measure deflection 3 mm (1/8 in) from crankshaft end  
2. Measure deflection at mid point between key and groove



**TYPICAL — V-SHAPED BLOCKS POSITION WITHOUT BEARINGS**


1. Measure deflection 3 mm (1/8 in) from crankshaft end
2. Measure deflection at mid point between key and groove

**NOTE:** Crankshaft deflection cannot be correctly measured between centers of a lathe.

2. If deflection exceeds the specified tolerance, it can be worn bearings or a bent crankshaft.
3. Remove crankshaft bearings and check deflection again on V-shaped blocks to determine the defective part(s).
4. If the deflection exceeds the specified tolerance, crankshaft should be repaired or replaced.

### CONNECTING ROD BIG END AXIAL PLAY

1. Using a feeler gauge, measure distance between thrust washer and crankshaft counterweight.
2. If the distance exceeds specified tolerance, repair or replace the crankshaft.




**TYPICAL**


### CRANKSHAFT ALIGNMENT

*All Engines except 593 HO E-TEC*

1. Remove both spark plugs.
2. Install the DIAL INDICATOR (P/N 414 104 700) in spark plug hole on MAG side.



3. Bring MAG piston at top dead center.
4. Scribe a mark on crankcase.
5. Install DEGREE WHEEL (P/N 529 035 607) on crankshaft end so that 360° mark aligns with the mark on crankcase. Do not rotate crankshaft.



6. Remove dial indicator and install it in spark plug hole on PTO side.
7. Bring PTO piston to top dead center. Degree wheel must rotate with crankshaft.



## Section 02 ENGINE

### Subsection 03 (ENGINE MEASUREMENT)

- Interval between cylinders must be  $180^\circ \pm 0.5$ .
- Any other reading indicates a misaligned (twisted) crankshaft.

#### 593 HO E-TEC Engines


- Remove injectors. Refer to *E-TEC DIRECT FUEL INJECTION* section.
- Bring MAG piston at top dead center. Refer to *IGNITION SYSTEM* section.
- Scribe a mark on crankcase.
- Install the DEGREE WHEEL (P/N 529 035 607) on crankshaft end so that  $360^\circ$  mark aligns with the mark on crankcase. Do not rotate crankshaft.



- Remove dial indicator and install it in spark plug hole on PTO side.
- Bring PTO piston to top dead center. Degree wheel must rotate with crankshaft.
- Interval between cylinders must be  $180^\circ \pm 0.5$ .
- Any other reading indicates a misaligned (twisted) crankshaft.

## COMBUSTION CHAMBER VOLUME MEASUREMENT

The combustion chamber volume is the region in the cylinder head above the piston at Top Dead Center (TDC). It is measured with the cylinder head installed on the engine.



TYPICAL

1. Combustion chamber

**NOTE:** When checking the combustion chamber volume, engine must be cold, piston must be free of carbon deposits and cylinder head must be leveled.

## Engine Preparation

### 593 and 797 Engines

- Remove both spark plugs and bring one piston to Top Dead Center using the DIAL INDICATOR (P/N 414 104 700).





1. Bring piston to TDC

2. Remove cylinder head cover. Refer to *TOP END* section.
3. Apply on piston ring end gap a dab of grease to seal it (piston to TDC). Wipe all excess with your finger.
4. Reinstall cylinder head cover.


#### 593 HO E-TEC Engines

1. Remove fuel injectors. Refer to *E-TEC DIRECT FUEL INJECTION* section.
2. Install the DIAL INDICATOR ADAPTER KIT (P/N 529 036 132) on cylinder head and bring the piston to TDC. Refer to *IGNITION SYSTEM* section for complete procedure.
3. Remove cylinder head. Refer to *TOP END* section.
4. Apply on piston ring end gap a dab of grease to seal it. Wipe all excess with your finger.
5. Reinstall cylinder head.
6. Make sure spark plugs are installed and tightened.

### Measurement


**NOTE:** When measuring, remember that 1 ml = 1 cc.

1. Obtain a graduated burette (capacity 0 - 50 ml) and fill with mineral injection oil.



1. Graduated burette (0 - 50 ml)

2. Open burette valve to fill its tip then close valve.
3. Let oil settle in bureette then add oil until level reaches 0 ml.
4. Inject the burette content in combustion chamber then close burette valve.
  - 4.1 On **593 and 797 engines**, add burette content until oil touches the top spark plug hole then close burette valve.



1. Top of spark plug hole

- 4.2 On **593 HO E-TEC engines**, add burette content until oil touches the bottom of the injector hole (smaller diameter).

## Section 02 ENGINE

### Subsection 03 (ENGINE MEASUREMENT)




1. Injector hole

**NOTE:** The oil level in cylinder must not drop for a few seconds after filling. If so, there is a leak between piston and cylinder. The recorded volume would be false. Repair engine then repeat procedure.

5. Let burette stand upward for about 10 minutes, until oil level is stabilized.
6. Read the burette scale to obtain the quantity of oil injected in the combustion chamber.

**NOTE:** On 593 and 797 engines, deduct 2.25 ml from the value obtained on the burette, this amount corresponds to the cylinder head spark plug well.




TYPICAL  
A. Spark plug well

7. Repeat the complete procedure for the other cylinder.
8. When completed, compare cylinders measurement with specified tolerances.
9. If necessary, install a thicker or thinner gasket between cylinder and crankcase in order to obtain the specified combustion chamber volume.
10. Repeat procedure until specified tolerances are obtained.

# AIR INTAKE SYSTEM


500SS, 600 and 800R



## Section 02 ENGINE

### Subsection 04 (AIR INTAKE SYSTEM)

600 HO E-TEC



## GENERAL

During assembly/installation, use the torque values and service products as in the exploded views.

Clean threads before applying a threadlocker. Refer to *SELF-LOCKING FASTENERS* and *LOCTITE APPLICATION* at the beginning of this manual for complete procedure.

### **⚠ WARNING**

Torque wrench tightening specifications must be strictly adhered to. Locking devices (e.g.: locking tabs, elastic stop nuts, cotter pins, etc.) must be replaced with a new ones.

Hoses or cables removed or disconnected must be installed and routed at the same place.

**NOTICE** Locking ties removed during a procedure must be replaced and installed at the same location.


## PROCEDURES

### AIR FILTER


#### Air Filter Removal

*All Models except GTX LE and SUMMIT*

- The air filter is located on left hand side of secondary air intake silencer.
- Refer to *BODY* and remove:
  - Hood
  - Bottom pan cover
  - LH side panel.
- Remove left upper console screw.
- Pull off both front secondary air intake silencer Velcro straps.



- Gently pull upper section of bottom pan and lift front of secondary air intake silencer.
- Unlatch all 5 air filter retaining tabs.




- Step 1: Pull upper section of bottom pan  
Step 2: Lift front of secondary air intake silencer  
Step 3: Unlatch retaining tabs

- Pull air filter out of secondary air intake silencer.

#### *GTX LE*

- The air filter is located on left hand side of secondary air intake silencer.
- Refer to *BODY* and remove:
  - Hood
  - Bottom pan cover
  - LH side panel.
- Pull off secondary air intake silencer Velcro strap.
- Gently pull upper section of bottom pan and lift front of secondary air intake silencer.
- Pull the air filter to release retaining pins.



1. Retaining pins

#### *SUMMIT*

- Remove hood. Refer to *BODY* section.
- Pull the filter out of its housing.

## Section 02 ENGINE

### Subsection 04 (AIR INTAKE SYSTEM)



1. Air filter with its jacket
2. Secondary air intake silencer

### Air Filter Cleaning

Clean with fresh water and mild soap.

Replace air filter as required.

**NOTE:** If the filter is very dirty, clean the interior of secondary air intake silencer at the same time.


### Air Filter Installation

The installation is the reverse of the removal procedure.

## PRIMARY AIR INTAKE SILENCER


### Primary Air Intake Silencer Removal

1. Remove LH side panel.
2. Remove drive belt guard, refer to *DRIVE BELT* section.
3. Unlock connector tube as follows:
  - 3.1 Lift tab on rear section of connector tube.
  - 3.2 Twist tube counter clockwise and pull slightly forward.



- Step 1: Lift tab  
Step 2: Twist tube  
Step 3: Pull forward

4. Push securing tab of primary air intake silencer and pull silencer out of adapter plate.



1. Primary air intake silencer
2. Securing tab

### Primary Air Intake Silencer Installation

The installation is the reverse of the removal procedure. However, pay attention to guide the primary air intake silencer into the adapter plate's groove. Also make sure that the primary air silencer is pushed to the end of adapter plate and that the securing tab is fully engaged.


## SECONDARY AIR INTAKE SILENCER

### Secondary Air Intake Silencer Removal

*All Models except GTX LE*

1. Remove multifunction gauge, refer to *LIGHTS, GAUGE AND ACCESSORIES* section.
2. Refer to *BODY* section and remove:
  - Hood
  - LH and RH side panels
  - Bottom pan cover
  - Gauge support and headlights as a unit.
3. Slightly move console aside without disconnecting cables.
4. Unplug APS hose located on RH top of secondary air intake silencer (600 HO E-TEC only).

**Section 02 ENGINE**  
Subsection 04 (AIR INTAKE SYSTEM)



1. APS hose

5. Unplug vent hose (500SS, 600 and 800R).




6. Disconnect air temperature sensor (ATS) located on top of connector tube (600 HO E-TEC and 800R).

7. Unlock connector tube as described in *PRIMARY AIR INTAKE SILENCER REMOVAL*.

8. Pull off all 4 Velcro straps located on the lower portion of the secondary air intake silencer.



TYPICAL — REAR VELCRO STRAP



FRONT VELCRO STRAPS

9. Remove secondary air intake silencer.


**GTX LE**

1. Refer to *BODY* section and remove the following parts:

- Hood
- Bottom pan cover
- Windshield
- Console.

2. Remove the multifunction gauge. Refer to *LIGHTS, GAUGE AND ACCESSORIES* section.

3. Unplug headlight connectors.




1. Headlight connectors


4. Remove screws securing the gauge support.

## Section 02 ENGINE


### Subsection 04 (AIR INTAKE SYSTEM)



**RH SIDE SHOWN**  
1. Retaining screw  
2. Gauge support




1. Velcro Strap  
2. Secondary air intake silencer  
3. Tuned pipe




1. Front retaining screws

5. Unplug the DESS post, the visor outlet and the 12-volt power outlet.




1. DESS post  
2. Visor outlet  
3. 12-volt power outlet

6. Unlock connector tube as described in *PRIMARY AIR INTAKE SILENCER REMOVAL*.
7. Disconnect air temperature sensor (ATS) located on top of connector tube.
8. Pull off the Velcro strap located on the front lower portion of the secondary air intake silencer.



**LH SIDE SHOWN**  
1. Press this tab



**RH SIDE SHOWN**  
1. Press this tab


11. Slide the gauge support then lift its rear portion to separate the gauge support and the secondary air intake silencer.



## Secondary Air Intake Silencer Installation

The installation is the reverse of the removal procedure. However, pay attention to the following. Make sure to route Velcro straps correctly.

*All Models except GTX LE*



FRONT VELCRO STRAPS ROUTING



TYPICAL — REAR VELCRO STRAP ROUTING

*GTX LE*



*All Models*

Make sure to reconnect the APS, the ATS and the vent hose where applicable.

# EXHAUST SYSTEM

## SERVICE TOOLS


<b>Description</b>	<b>Part Number</b>	<b>Page</b>
SPRING REMOVAL TOOL.....	529 035 983 .....	51-52

## SERVICE TOOLS – OTHER SUPPLIER

<b>Description</b>	<b>Part Number</b>	<b>Page</b>
SNAP-ON 5 MM ALLEN SPHERICAL SOCKET .....	FABLM5E .....	52

## Section 02 ENGINE

### Subsection 05 (EXHAUST SYSTEM)



500SS

**NEW**




600 HO E-TEC

**NEW**



800R

**NEW**



## GENERAL

### **⚠ WARNING**

To avoid potential burns, never touch exhaust system components immediately after the engine has been running because these components are very hot. Let engine and exhaust system cool down before performing any servicing.

During assembly/installation, use the torque value and service products as in the exploded view.

### **⚠ WARNING**

Torque wrench tightening specifications must be strictly adhered to. Locking devices (e.g.: locking tabs, elastic stop nuts, self-locking fasteners, cotter pins, etc.) must be replaced with new ones.


**NOTE:** On applicable models, it is good practice to check for fault codes using B.U.D.S. software as a first troubleshooting step. Refer to *EMS DIAGNOSTIC AND COMMUNICATION TOOLS*.

## PROCEDURES

### MUFFLER

#### Muffler Removal

1. Remove right hand side panel.
2. Disconnect the EGTS (Exhaust Gas Temperature Sensor) on 600 HO E-TEC models.
3. Remove springs retaining the muffler. Use SPRING REMOVAL TOOL (P/N 529 035 983).



4. Remove the muffler.

#### Muffler Inspection

Check the muffler for cracks or other damages.

#### Muffler Installation

For installation, reverse the removal procedure.


### EXHAUST GAS TEMPERATURE SENSOR (EGTS)

Refer to *ELECTRONIC FUEL INJECTION (EFI)* section to verify or change the EGTS.

### TUNED PIPE

#### Tuned Pipe Removal

1. Refer to *BODY* and remove:
  - Right hand side panel
  - Hood
  - Bottom pan cover.
2. Remove exhaust springs. Use SPRING REMOVAL TOOL (P/N 529 035 983).



3. Remove muffler (except 800R models). See procedure in this section.
4. Remove tuned pipe.
5. Remove doughnut shaped exhaust gaskets.

#### Tuned Pipe Inspection


1. Check tuned pipe and shields for:
  - Damages
  - Cracks.
2. Also inspect gaskets condition. Replace as required.

#### Tuned Pipe Installation

1. Install doughnut shaped exhaust gasket with both of its notches aligned with Y-manifold protrusions.

## Section 02 ENGINE

### Subsection 05 (EXHAUST SYSTEM)



1. Align notches

2. Install all exhaust springs using SPRING REMOVAL TOOL (P/N 529 035 983).

## MANIFOLD

### Manifold Removal

1. Remove tuned pipe. See procedure in this section.
2. Remove and discard manifold screws using a SNAP-ON 5 MM ALLEN SPHERICAL SOCKET (P/N FABLM5E).



**NOTE:** Take note of the respective position of the socket screws and the hexagonal screws for proper installation.

**NOTICE** Heat screws for 30 seconds before loosening to prevent screw breakage.


3. Remove manifold.
4. Remove gaskets.

### Manifold Inspection

Check if the manifold is cracked or damaged. Replace if necessary.

### Manifold Installation


1. Install the manifold with new gaskets.
2. Install **NEW** manifold screws. On **500SS** and **600 HO E-TEC**, install hexagonal screws at these locations.



600 HO E-TEC SHOWN

1. Hexagonal screws

3. Torque manifold screws to specification using the following pattern.



ENGINE	TORQUE
593	22 N•m (16 lbf•ft)
593 HO E-TEC	11 N•m (97 lbf•in)
797	17 N•m (150 lbf•in)

4. Install tuned pipe.
5. Install muffler.

# REWIND STARTER

## SERVICE TOOLS

<b>Description</b>	<b>Part Number</b>	<b>Page</b>
SMALL HOSE PINCHER .....	295 000 076 .....	55


## SERVICE PRODUCTS

<b>Description</b>	<b>Part Number</b>	<b>Page</b>
MOLYKOTE PG 54 .....	420 899 763 .....	57-58

## Section 02 ENGINE

### Subsection 06 (REWIND STARTER)

All Engines Except 600 HO E-TEC with Electric Start



## INSPECTION

Due to dust accumulation, rewind starter must be periodically cleaned, inspected and lubricated. Refer to *MAINTENANCE CHART*.

**NOTICE** It is of the utmost importance that the rewind starter spring be lubricated periodically using specific lubricant. Otherwise, rewind starter component life will be shortened and/or rewind starter will not operate properly under very cold temperatures.

Check if rope no. 6 is fraying, replace if so.

When pulling starter grip, mechanism must engage within 30 cm (1 ft) of rope pulled. If not, disassemble rewind starter, clean and check for damaged plastic parts. Replace as required, lubricate, reassemble and recheck.

When releasing starter grip, it must return to its stopper and stay against it. If not, check for proper spring preload or damage. Readjust or replace as required.


When pulling starter grip 10 times in a row, it must return freely. If not, check for damaged parts or lack of lubrication. Replace parts or lubricate accordingly.

## PROCEDURES

### REWIND STARTER HANDLE

#### Rewind Starter Handle Removal


Pull rope for 50 cm (20 in) approximately. Using a SMALL HOSE PINCHER (P/N 295 000 076), lock rope near rewind starter.



Using a small screwdriver, extract rope knot from stater handle no. 3. Cut rope close to knot.

#### Rewind Starter Handle Installation

Before installing starter handle on the rope, it is necessary to fuse the rope end with a lit match. Pass rope through starter handle and tie a knot on the rope end, see picture.



A.  $30 \pm 5 \text{ mm}$  ( $1 \pm 1/4 \text{ in}$ )

Fuse the knot with a lit match then insert rope end down and pull the starter handle over the knot.



### REWIND STARTER

#### Rewind Starter Removal

Remove the following parts:

- RH side panel
- Muffler
- Acoustic panel.

Remove starter handle no. 3.



## Section 02 ENGINE


### Subsection 06 (REWIND STARTER)

Remove screws **no.2** securing rewind starter **no. 1** to engine then remove rewind starter.

#### Rewind Starter Rope Replacement


Remove rewind starter.

Completely pull out rope. Hold rewind starter in a vise. Slide rope and untie the knot. Pull out the rope completely.




1. Knot to be untied

To install rope **no. 6**, insert rope into sheave **no. 5** orifice and lock it by making a knot, leaving behind a free portion of about 25 mm (1 in) in length.



FREE PORTION

Fuse rope end with a lit match and insert it into sheave.



FREE PORTION INSERTED INTO SHEAVE


**NOTE:** When rope is completely pulled out, spring preload is 4-1/2 turns.

#### Rewind Starter Disassembly

Remove the hose pincher previously installed on rope at rewind starter removal. Let sheave get free to release spring preload.


Cut push nut and discard.

Remove lock lever, O-ring **no. 11**, collar sleeve, pawl lock and pawl.



1. Push nut  
2. Lock lever  
3. Collar sleeve  
4. Pawl lock  
5. Pawl


Remove sheave **no. 5** from starter housing **no. 1**. Hold spring with a screwdriver.



Take out the knot and then rope no. 6.

### Rewind Starter Assembly

Lubricate spring contact area and spring guide inside housing with MOLYKOTE PG 54 (P/N 420 899 763).



1. Molykote PG 54

At assembly, position spring no. 4 outer end into spring guide notch then wind the spring counter-clockwise into guide.

### **⚠ WARNING**


Since the spring is tightly wound inside the guide it may fly out when rewind is handled. Always handle with care.



### TYPICAL

1. Outer end into guide notch

Lubricate spring assembly and 1 cm (1/2 in) wide on bottom of housing with MOLYKOTE PG 54 (P/N 420 899 763).




1. Molykote PG 54 applied 1 cm (1/2 in) wide on bottom of housing  
2. Molykote PG 54 on spring

**NOTICE** It is of the utmost importance that the rewind starter spring be lubricated periodically using MOLYKOTE PG 54 (P/N 420 899 763). The use of standard multipurpose grease could result in rewind starter malfunction under very cold temperatures and components life will be shortened.

Lubricate housing post with MOLYKOTE PG 54 (P/N 420 899 763). Install sheave.

## Section 02 ENGINE

### Subsection 06 (REWIND STARTER)




1. Molykote PG 54

To adjust spring tension:


Wind rope on sheave and place rope sheave into starter housing making sure that the sheave hub notch engages in the rewind spring hook.

Rotate the sheave counterclockwise until rope end is accessible through rope exit hole. This will give 1/2 turn of preload.

Pull the rope out of the starter housing and temporarily make a knot to hold it.




Lubricate pawl no.8 with MOLYKOTE PG 54 (P/N 420 899 763) then install over rope sheave.



Lubricate pawl lock no.9 with MOLYKOTE PG 54 (P/N 420 899 763). Install over pawl.



Install collar sleeve no. 10 with its collar first. Lubricate a new O-ring no. 11 and lock lever no. 12 with MOLYKOTE PG 54 (P/N 420 899 763). Install over pawl lock.



- 1. Collar sleeve
- 2. O-ring
- 3. Lock lever

Secure lock lever with a new push nut **no. 13**.

### Rewind Starter Installation

Thread starter rope **no. 6** through console.

Install handle, refer to *STARTER HANDLE INSTALLATION*.

Reinstall rewind starter assembly on engine.

# LUBRICATION SYSTEM

## SERVICE TOOLS

<b>Description</b>	<b>Part Number</b>	<b>Page</b>
ENGINE REMOVAL HOOK.....	529 035 829 .....	69
FLUKE 115 MULTIMETER .....	529 035 868 .....	77
LEAK TESTING KIT.....	529 033 100 .....	66
OIL PUMP CABLE ADJUSTER .....	529 036 045 .....	70
SMALL HOSE PINCHER .....	295 000 076 .....	66
SPARK PLUG LIFT RING .....	529 035 830 .....	68
THROTTLE FREE PLAY WEDGE TOOL.....	529 036 042 .....	69
VACUUM/PRESSURE PUMP .....	529 021 800 .....	67, 78


## SERVICE PRODUCTS

<b>Description</b>	<b>Part Number</b>	<b>Page</b>
LOCTITE 243 (BLUE).....	293 800 060 .....	69
LOCTITE 648 (GREEN).....	413 711 400 .....	79
PULLEY FLANGE CLEANER .....	413 711 809 .....	79
XP-S SYNTHETIC BLEND 2-STROKE OIL.....	293 600 100 .....	66

## Section 02 ENGINE



### Subsection 07 (LUBRICATION SYSTEM)

#### OIL INJECTION TANK



## OIL INJECTION PUMP


500SS/600/800R



## Section 02 ENGINE

### Subsection 07 (LUBRICATION SYSTEM)

600 HO E-TEC





## GENERAL

During assembly/installation, use the torque values and service products as in the exploded view. Clean threads before applying a threadlocker. Refer to *SELF-LOCKING FASTENERS* and *LOCTITE APPLICATION* at the beginning of this manual for complete procedure.

### **⚠ WARNING**

Torque wrench tightening specifications must be strictly adhered to. Locking devices (e.g.: locking tabs, elastic stop nuts, self-locking fasteners, etc.) must be replaced with new ones.

Hoses or cables removed or disconnected must be installed and routed at the same place.

**NOTICE** Locking ties removed during a procedure must be replaced and installed at the same location.

### **⚠ WARNING**

Wipe off any oil spills. Oil is highly flammable.

**NOTICE** Do not use a hose pincher on outlet hose. This would damage the spring inside hose.

## SYSTEM DESCRIPTION

### *500SS/600/800R*

These engines employ a variable-rate plunger-type oil injection pump.

This variable-rate mechanical oil injection pump is directly driven by the crankshaft.

This pump delivers the right amount of oil at all engine RPM and at all throttle opening positions.


The pump stroke is variable and controlled by a cam, connected to the pump lever and cable (linked to the throttle cable). The wider the throttle is opened, the pump stroke increases and more oil is delivered.

This pump requires no or little maintenance.

### *600 HO E-TEC*

An electronic oil injection pump with a mechanical positive displacement type is used. An electronic pump is more accurate and injection rate can be changed according to engine requirements. This results in a greatly reduced oil consumption.

The electronic oil injection pump is directly attached under oil injection tank.



1. Oil injection tank  
2. Electronic oil injection pump

The E-TEC pump features a total of 4 outlets:

- 2 large outlets to the crankcase to lubricate engine internal parts.
- 2 small outlets to the 3D RAVE valves to lubricate valves to prevent carbon deposits.

The 4 plungers in the pump work synchronized. They pump all at the same time.



The ECM controls the pump to inject a variable amount of oil through the entire engine operating range and conditions.

Here are some highlights of the pump.

- For the first 6 hours of engine break-in period, oil delivery is increased.
- Oil/fuel ratio can go up to approximately 70:1 after the break-in period.
- At idle, pump works at approximately less than 1 pulse per minute. A very low quantity of oil is injected to reduce engine smoke and to reduce engine emissions.
- As engine speed increases, oil delivery increases but not proportionally. It varies according to the specific engine requirements.

## Section 02 ENGINE

### Subsection 07 (LUBRICATION SYSTEM)

- At 8000 RPM, pump works at approximately 120 pulses per minute.
- When operating vehicle in high altitude area, oil delivery is reduced proportionally as altitude increases.
- When engine temperature is low, more electrical power is sent to pump to warm it up to improve oil flow.

### Automated Engine Oil Fogging

An automated engine oil fogging has been implemented to automatically inject the required oil to protect the engine during vehicle storage. Engine speed will be increased to approximately 2000 RPM and excess oil will be injected for approximately 30 seconds then, the engine will automatically be stopped.

The storage mode can be activated either by using B.U.D.S. or the multifunction gauge on the vehicle. Refer to *STORAGE* section for the procedures.

### RECOMMENDED OIL

ENGINES	RECOMMENDED INJECTION OIL
All	XP-S synthetic blend 2-stroke oil <sup>(1)</sup>

**NOTICE** <sup>(1)</sup> These engines were specifically developed and tested with XP-S SYNTHETIC BLEND 2-STROKE OIL (P/N 293 600 100). The use of any other 2-stroke engine oils may cause severe engine damage and may void the limited warranty. Use only XP-S synthetic blend oil.

The XP-S synthetic blend provides superior lubrication, reduced engine component wear and oil deposit, thus maintaining maximum-level performance and antifriction properties. The synthetic blend injection oil meets the latest ASTM and JASO standards by ensuring high biodegradability and low exhaust smoke.



## INSPECTION

### OIL SYSTEM LEAK TEST


Install on oil tank test cap from the LEAK TESTING KIT (P/N 529 033 100).



TYPICAL  
1. Test cap on tank

Install a SMALL HOSE PINCHER (P/N 295 000 076) on check valve outlet hose.

**Section 02 ENGINE**  
Subsection 07 (LUBRICATION SYSTEM)



### Check Valve Test

Check valve allows air to get into the tank.

To verify this one-way check valve, cut locking tie then remove it along with the hose. Make sure that it holds pressure and that it does not let air go through.

**NOTE:** Remember hose position.

**NOTICE** If check valve does not allow air to enter, serious engine damage will occur.

When replacing/installing check valve, insert its black side into vent line.



**TYPICAL**  
1. Check valve outlet hose  
2. Oil tank

Connect the VACUUM/PRESSURE PUMP (P/N 529 021 800) to test cap.




Pressurize oil system as follows.

PRESSURE	TIME TO HOLD PRESSURE
18 kPa (2.6 PSI)	3 minutes

If pressure drops, locate leak(s) and repair or replace leaking component(s).

- If no external leak can be found, check the engine pump shaft and the injector nozzles (except 600 HO E-TEC).

If pressure does not drop, this validate the system for leakage (except for the oil pump hoses on 600 HO E-TEC).




**TYPICAL**  
1. Black side here

## Section 02 ENGINE

### Subsection 07 (LUBRICATION SYSTEM)

## TROUBLESHOOTING

### 600 HO E-TEC

ELECTRONIC OIL INJECTION PUMP		
SYMPTOM	CAUSE	ACTION
	Damaged or disconnected oil pump.	Check oil pump wires and connectors on oil pump.
	Circuit wires, connectors or ECM output pins.	Check WHITE/RED wire on oil pump connector for 55 volts.
		Check system circuit J1B-23.
		Repair or replace defective part(s).
Engine seizure (PTO or MAG side)	Damaged, kinked or obstructed inlet hose.	Repair or replace hose and test oil pump (oil outflow).
	Damaged oil pump inner piston.	Replace oil pump.
	Mechanical engine problem.	Repair or replace engine defective part(s).
Engine misfires (carbon on 3D RAVE valve(s))	Damaged, kinked or obstructed inlet hose.	Repair or replace hose and test oil pump (oil outflow).
	Damaged oil pump inner piston.	Replace oil pump.
	Defective 3D RAVE valve.	Clean or replace 3D RAVE valve.

## PROCEDURES

### OIL INJECTION PUMP (500SS/600/800R)

#### Oil Injection Pump Verification

NOTE: Since pump is a piston type, it works when engine rotates in both forward and reverse.


1. Remove oil pump from engine. Refer to *OIL INJECTION PUMP REMOVAL* in this section.
2. Connect a hose filled with injection oil to main line fitting. Insert other hoses end in an injection oil container. Using a clockwise rotating

drill, rotate pump shaft. Oil must drip from hoses while holding lever in a fully open position. If not replace pump.


#### Oil Injection Pump Removal

To gain access to oil pump, perform the following.

1. Remove the muffler. Refer to *EXHAUST SYSTEM* section.
2. Remove the engine stopper support.
3. Remove the primary air intake silencer. Refer to *AIR INTAKE SYSTEM* section.
4. Remove the driven pulley. Refer to *DRIVEN PULLEY AND COUNTERSHAFT* section.
5. Detach carburetors from engine. Refer to *TM CARBURETORS* section.
6. Unscrew bolts retaining fuel pump to frames.
7. Unscrew bolts retaining engine supports to rubber mounts.




TYPICAL — PTO SIDE  
1. Remove hexagonal bolts



MAG SIDE  
1. Remove hexagonal bolts

8. Remove spark plugs and install the SPARK PLUG LIFT RING (P/N 529 035 830) at the farthest spark plug hole.



1. Spark plug lift ring

9. Install the ENGINE REMOVAL HOOK (P/N 529 035 829).



10. Lift engine enough to gain access to oil pump.  
 11. Remove screws retaining oil pump to engine.  
 12. Unplug hoses connected to oil pump.

**NOTE:** Mark hose locations for installation.

13. Disconnect oil pump cable.

### Oil Injection Pump Cleaning

Clean all metal components in a non-ferrous metal cleaner.

### Oil Injection Pump Installation

For installation, reverse the removal procedure. However, pay attention to the following.

1. During installation, always check for spring clip tightness on pump inlet hose.
2. Apply LOCTITE 243 (BLUE) (P/N 293 800 060) on threads of screws and torque them to 6 N•m (53 lbf•in).
3. Make sure cable barrel is well seated in oil pump lever.
4. Secure barrel with plastic washer and circlip.
5. Install cable lock washer on left side of support.
6. Bleed oil pump. See procedure further.

**NOTICE** Always bleed oil pump when the system has been opened.


7. Torque fuel pump screw to 5 N•m (44 lbf•in).
8. Install and tighten engine support bolts. Refer to *ENGINE SUPPORT INSTALLATION* in *ENGINE REMOVAL AND INSTALLATION* section.
9. Adjust oil pump cable. See procedure further.

### Oil Injection Pump Adjustment

1. Slightly press on throttle lever to eliminate throttle cable free play.
2. Insert the THROTTLE FREE PLAY WEDGE TOOL (P/N 529 036 042), between throttle lever and housing as shown.
  - 2.1 Slide tool up and down until all free-play is recovered. Stop recovering free-play before throttle cam just begins to move at carburetors.

## Section 02 ENGINE

### Subsection 07 (LUBRICATION SYSTEM)




mmv2009-070-003\_a

TYPICAL

**NOTICE** Throttle slides must not move and remain in idle position.

3. Move adjuster boot away and stretch oil pump cable at adjuster.



mmv2008-070-016\_a

TYPICAL

1. Oil pump cable adjuster




mmv2006-070-004

TYPICAL

4. Insert cable in the appropriate slot of the OIL PUMP CABLE ADJUSTER (P/N 529 036 045).

MODEL	ADJUSTMENT SPECIFICATION
500SS 600 800R	16.5 mm (.65 in)




mmv2006-070-005

**NOTE:** If tool cannot be inserted, turn cable adjuster to "shorten" cable.

5. Pull cable with a force of 34 N (7.6 lbf) to recover all play in cable.

6. While still pulling, check if there is a gap as shown.




mmv2006-070-006\_a

A. Pull 34 N (7.6 lbf)

B. Remove gap here

7. Turn cable adjuster to recover that gap.




mmv2006-070-006\_a

**FINAL ADJUSTMENT WITHOUT GAP**

A. Pull 34 N (7.6 lbf)

B. No gap

8. Secure adjustment in place with lock nut.



1. Cable adjuster  
2. Lock nut

9. Remove the throttle free play wedge tool, push back cable in adjuster and slide adjuster boot in place.

### Oil Injection Pump Bleeding

Bleed main oil line (between tank and pump) by loosening the bleeder screw until air has escaped from the line. Add injection oil as required.



TYPICAL  
1. Bleeder screw  
2. Oil pump lever

Ensure there are no air bubbles in small oil lines between pump and engine. If so, inject oil using a syringe into lines before connecting them to engine.

### OIL PUMP (600 HO E-TEC)

#### Oil Pump Identification

Every pump is bench tested. Its electrical and flow characteristics are registered throughout all its operating range and are associated to a compensation number.

When a pump is replaced, the compensation number must be entered in B.U.D.S. so that the ECM properly controls the pump according to its optimized characteristics.


The compensation number is located on a label on the pump as shown.



Oil pump bleeding is done with B.U.D.S. Refer to *OIL PUMP BLEEDING* further in this section.

#### Oil Pump Test with B.U.D.S.

1. Connect B.U.D.S. Refer to *COMMUNICATION TOOLS AND B.U.D.S.* section.
2. In B.U.D.S., press **Read Data**.
3. Select **Activation** folder then the **ECM** page.
4. Press on the oil pump.



1. Press here to activate oil pump

5. Listen if the oil pump is activated.
6. If the test fails, check wires and connector.

#### Oil Pump Removal

1. Remove the RH side panel. Refer to *BODY* section.
2. Using B.U.D.S. software, release fuel pressure. Refer to *COMMUNICATION TOOLS AND B.U.D.S.* section.
3. Remove the 30 A fuse.


## Section 02 ENGINE

### Subsection 07 (LUBRICATION SYSTEM)




1. 30 A fuse location

4. Empty oil tank completely by siphoning injection oil.
5. Detach the battery relay jumper from the oil tank (rewind starter equipped models).
6. Detach fuse holders from the oil tank.




1. Battery relay jumper  
2. Fuse holder

7. Cut locking tie retaining wires against oil tank.




1. Oil level sensor  
2. Fuse holder  
3. Cut this locking tie

8. Move harness aside and cut the locking tie at the bottom of oil tank.



1. Harness  
2. Cut this locking tie


9. Detach the diagnostic connector housing from oil tank.



1. Diagnostic connector housing

10. Remove the muffler. Refer to *EXHAUST SYSTEM* section.

11. Remove the acoustic panel by removing the retaining screws.



1. Acoustic panel screws

12. Remove the driven pulley. Refer to *DRIVEN PULLEY AND COUNTERSHAFT* section.

13. Unplug the quick disconnect fitting of the fuel inlet hose at ECM.





**CAUTION**

Only developed and tested with  
 1 2 stroke oil (293 600 101)  
 2 stroke engine oils may cause  
 damage and may void the limited  
 3 Synthetic Blend 2 stroke oil

mmv2009-057-006\_a


1. Fuel inlet hose fitting
2. Press here to disengage the fitting.

**NOTE:** Place a container under the connector to recover residual fuel remaining in the system.

**WARNING**


Use the B.U.D.S. software to release fuel pressure prior to removing a hose. Cover the fuel line connection with an absorbent shop rag. Slowly disconnect the fuel hose to minimize spilling. Do not allow fuel to spill on hot engine parts and/or on electrical connectors. Wipe off any fuel spillage in the engine compartment. Fuel is flammable and explosive under certain conditions. Always disconnect battery prior to working on the fuel system.

14. Detach the ECM support from oil tank by pressing the upper tab and sliding the support outwards.



1. Upper tab
2. ECM support


15. Remove and discard the Oetiker clamps securing oil hoses to oil pump fittings.
16. Disconnect the 4 hoses from oil pump by using a small screwdriver.



1. Oil hoses


**NOTICE** Do not pull on the oil hoses to avoid breaking oil pump fittings.

17. Unplug oil pump connector.



1. Oil pump
2. Oil pump connector
3. Chaincase
4. Diagnostic connector

18. Remove screws securing the oil pump support.




1. Oil pump support
2. Support screws

19. Remove the oil pump support.
20. Turn oil pump toward engine until oil injection pump is unlocked from oil injection tank.

## Section 02 ENGINE

### Subsection 07 (LUBRICATION SYSTEM)



1. Oil injection tank tab
2. Oil injection pump

21. Place a rag under oil pump to catch oil spillage.
22. Lower oil pump to remove it from oil tank.

### Oil Pump Inspection

1. Check the strainer on the top of oil pump. Replace oil pump if the strainer is damaged.




1. Oil pump strainer

### Oil Pump Installation

The installation is the reverse of the removal procedure. However, pay attention to the following.

1. Install pump.
2. Install oil injection pump support and tighten screws to 1 N•m (9 lbf•in).
3. Use the following illustration to route oil hoses correctly.



1. Towards PTO fitting
2. Towards PTO 3D RAVE valve
3. Towards MAG fitting
4. Towards MAG 3D RAVE valve

4. Install all other removed parts.
5. Fill up oil tank using recommended synthetic blend oil. See *RECOMMENDED OIL* at the beginning of this section.
6. Bleed oil injection system. Refer to *OIL PUMP BLEEDING* for proper procedure.

### ⚠ WARNING

Make sure the quick disconnect fitting of the fuel inlet hose at ECM is not leaking.

### Oil Pump Bleeding

1. Connect B.U.D.S. Refer to *COMMUNICATION TOOLS AND B.U.D.S.* section.
2. Start vehicle.
3. In B.U.D.S., press **Read Data**.
4. Select **Setting** folder then the ECM page.
5. Verify for same codes in B.U.D.S. and on oil pump sticker.



1. B.U.D.S. oil pump code



BACK OF OIL PUMP

1. Oil pump code (0 to 9)

6. Correct the oil pump code if required.
7. Select **Activation** folder then the **ECM** page.
8. Press the **Oil System Bleeding** button. Wait until engine returns to idle RPM.
9. Check for air into hoses. If so, the bleeding procedure must be repeated once more.

## OIL TANK

### Oil Tank Removal

1. Remove the primary air intake silencer. Refer to *AIR INTAKE SYSTEM* section.
2. Refer to *BODY* section to remove the following parts:
  - Both side panels
  - Console.
3. Empty oil tank completely by siphoning injection oil.

### Rewind Starter Equipped Models

4. Remove the muffler. Refer to *EXHAUST SYSTEM* section.
5. Remove the acoustic panel.



600 HO E-TEC SHOWN

1. Acoustic panel screws

6. Remove rewind starter handle. Refer to *REWIND STARTER* section.
7. Remove rewind starter handle housing. Refer to *BODY* section.

### 500SS/600/800R

8. Detach the ECM from oil tank.



TYPICAL

1. ECM

2. Push on tab to release

### 600 HO E-TEC

9. Remove the battery relay jumper from oil tank.



1. Battery relay jumper

2. Fuse holder

10. Remove the 30 A fuse.




1. 30 A fuse location

## Section 02 ENGINE

### Subsection 07 (LUBRICATION SYSTEM)

- Using B.U.D.S. software, release fuel pressure. Refer to *COMMUNICATION TOOLS AND B.U.D.S.* section.
- Unplug the quick disconnect fitting of the fuel inlet hose at ECM.




- Fuel inlet hose fitting
- Press here to disengage the fitting

**NOTE:** Place a container under the connector to recover residual fuel remaining in the system.

#### **⚠ WARNING**

Use the B.U.D.S. software to release fuel pressure prior to removing a hose. Cover the fuel line connection with an absorbent shop rag. Slowly disconnect the fuel hose to minimize spilling. Do not allow fuel to spill on hot engine parts and/or on electrical connectors. Wipe off any fuel spillage in the engine compartment. Fuel is flammable and explosive under certain conditions. Always disconnect battery prior to working on the fuel system.

- Detach the ECM support from oil tank by pressing the upper tab and sliding the support outwards.




- Upper tab
- ECM support

- Remove the oil pump from the oil tank. Refer to *OIL PUMP (600 HO E-TEC)* in this section.


#### **All Models**

- Disconnect the crankcase vent hose from oil tank.
- Cut locking tie securing wiring harness to oil tank.



- Vent hose
- Cut this locking tie

- Detach fuse holders from oil tank.
- Disconnect the oil level sensor.
- Detach the diagnostic connector housing from oil tank.



- Diagnostic connector housing

- Remove the RH side frame member.

*600 HO E-TEC*

**⚠ WARNING**

Make sure the quick disconnect fitting of the fuel inlet hose at ECM is not leaking.

## OIL LEVEL SENSOR

### Oil Level Sensor Test

Measure resistance of the oil level sensor using a FLUKE 115 MULTIMETER (P/N 529 035 868).

SENSOR POSITION	RESISTANCE
Sensor exposed to air	High value or infinite (OL)
Sensor soaked in oil	0.2 $\Omega$ (closed)

If resistance test fails, replace sensor.


### Oil Level Sensor Removal

1. Remove rewind starter handle housing. Refer to *BODY* section.
2. Unplug oil level sensor connector.



1. Connector

3. Using a small screwdriver, push and hold tab to release then pull on sensor to remove.



BEHIND THE TOP OF CHAINCASE  
1. Side frame member lower bolt

21. Remove holder retaining oil tank to side frame member brace.



1. Side frame member brace  
2. Oil tank holder

22. Remove screws securing oil tank to chaincase.



1. Oil tank screws


23. Remove tank from vehicle.

## Oil Tank Installation

The installation is the reverse of the removal procedure.

## Section 02 ENGINE

### Subsection 07 (LUBRICATION SYSTEM)



1. Tie  
2. Sensor

### Oil Level Sensor Installation

For installation, reverse the removal procedure. However, pay attention to the following.

Ensure sensor wire is secured with a locking tie. Ensure wire does not apply any tension on sensor. Wire must have a loop.



TYPICAL  
1. Sensor

### OIL FILTER (500SS/600/800R)

#### Oil Filter Removal

Remove oil tank. Refer to *OIL TANK REMOVAL* in this section.

To remove oil filter from tank, turn clockwise and pull.

#### Oil Filter Installation

For installation, reverse the removal procedure. However, pay attention to the following.

Bleed oil pump. See procedure further.

## INJECTION NOZZLE

### Injection Nozzle Inspection

#### 500SS/600/800R

Carry out the *OIL SYSTEM LEAK TEST* as described in this section.

If test is successful, repeat leak test but this time at 20.7 kPa (3 PSI).

- If the injector nozzle opens normally, it is in good condition.
- If the test is not successful, repeat test at injector nozzle as described in this topic.

#### All Engines

Lift engine to access the injector nozzles.

Use the VACUUM/PRESSURE PUMP (P/N 529 021 800).



529 021 800

Test check valve of injection nozzle as follows.

PUMP SETTING	Set to VACUUM	Set to PRESSURE
TO DO	Activate pump several times	Slowly activate pump and listen to check valve
RESULT	Air must not flow through check valve	You should hear it release pressure at approximately 20.7 kPa (3 PSI)
ACTION	Success: Perform next test	Success: Check valve is good
	Failed: Replace injection nozzle	Failed: Replace injection nozzle


## Injection Nozzle Removal

**NOTICE** Do not remove injection nozzle needlessly. It is likely to be damaged.

1. To gain access to the injector nozzles, engine must be lifted. Refer to *ENGINE REMOVAL AND INSTALLATION* for the procedure.
2. Clean injection nozzle area to remove oil or dirt.
3. Heat injection nozzle then pull it out of crankcase.

## Injection Nozzle Installation

1. Prior to coating it with Loctite, make sure check valve body is clean and dry. Clean from dirt or oil, if any, with PULLEY FLANGE CLEANER (P/N 413 711 809).
2. Apply LOCTITE 648 (GREEN) (P/N 413 711 400) on the outer diameter of the check valve (machined section). Take care that Loctite is **ONLY** in this area.




A32C59A

**TYPICAL**  
A. PTO side  $45^{\circ} \pm 5^{\circ}$  from cylinder axis to the top  
B. MAG side  $20^{\circ} \pm 5^{\circ}$  from cylinder axis to the bottom

### All Models

4. Punch in the injection nozzle carefully with a plastic hammer.
5. Clean the crankcase from surplus of Loctite 648 with a rag.
6. Reinstall engine into vehicle. Refer to *ENGINE* section.



A32C57A

APPLY LOCTITE ON THIS AREA ONLY

### 500SS/600/800R

3. Install the check valve in the correct position as described on next photos into the crankcase lower side.

# COOLING SYSTEM

## SERVICE TOOLS

<b>Description</b>	<b>Part Number</b>	<b>Page</b>
LARGE HOSE PINCHER.....	529 032 500 .....	85-86
SMALL HOSE PINCHER.....	295 000 076 .....	86
SUPERTANIUM™ BIT .....	529 031 800 .....	87
TEST CAP.....	529 035 991 .....	85
VACUUM/PRESSURE PUMP .....	529 021 800 .....	85-86

## SERVICE PRODUCTS


<b>Description</b>	<b>Part Number</b>	<b>Page</b>
BRP PREMIXED COOLANT .....	219 700 362 .....	83
LOCTITE 380 (BLACK MAX) .....	413 408 300 .....	88



## Section 02 ENGINE

### Subsection 08 (COOLING SYSTEM)

600 HO E-TEC Engine Shown



## GENERAL

**NOTE:** On applicable models, it is a good practice to check for fault codes using B.U.D.S. software as a first troubleshooting step. Refer to the *MONITORING SYSTEM/FAULT CODES* section.

During assembly/installation, use torque values and service products as in the exploded views.

Clean threads before applying a threadlocker. Refer to *SELF-LOCKING FASTENERS* and *LOCTITE APPLICATION* at the beginning of this manual for complete procedure.

### **⚠ WARNING**

Torque wrench tightening specifications must be strictly adhered to. Locking devices (e.g.: locking tabs, elastic stop nuts, self-locking fasteners, cotter pins, etc.) must be replaced with new ones.

## MAINTENANCE

### COOLANT REPLACEMENT

#### Recommended Coolant

Use BRP PREMIXED COOLANT (P/N 219 700 362) or a blend of 50% antifreeze with 50% distilled water.

To prevent antifreeze deterioration, always use the same brand. Never mix different brands unless cooling system is completely flushed and refilled.

**NOTICE** To prevent rust formation or freezing condition, always replenish the system with the BRP premixed coolant or with 50% antifreeze and 50% water. Do not use tap water, straight antifreeze or straight water in the system. Tap water contains minerals and impurities which build up in the system. During cold weather, straight water causes the system to freeze while straight antifreeze thickens (like slush ice) and does not have the same efficiency. Always use ethylene glycol antifreeze containing corrosion inhibitors specifically recommended for aluminum engines.

#### Cooling System Draining

### **⚠ WARNING**


Never drain or refill the cooling system when engine is hot.

Remove RH side panel and hood. Refer to *BODY*.

Remove muffler and tuned pipe. Refer to *EX-HAUST SYSTEM*.

Place a large drain pan under the vehicle bottom pan.

Unplug the coolant hose at water pump to drain coolant.



**WATER PUMP**  
1. Unscrew clamp

When the coolant level is low enough, lift the rear of vehicle to drain the radiators.



**TYPICAL VIEW**


#### Cooling System Refill and Bleeding

Apply parking brake.

Lift front of vehicle as shown and support it safely.

## Section 02 ENGINE


### Subsection 08 (COOLING SYSTEM)



TYPICAL VIEW

A. At least 60 cm (24 in)

With engine cold, refill coolant reservoir up to COLD LEVEL line.



TYPICAL

1. Coolant reservoir
2. COLD LEVEL line

Start engine.

Refill up to line while engine is idling until rear radiators are warm to the touch (about 4 to 5 minutes).

**NOTE:** Always monitor coolant level while filling reservoir to avoid emptying and thus allowing air to enter the system.

Install pressure cap.

Lower vehicle back on the ground.



Lift rear of vehicle and support it safely.



TYPICAL VIEW

### ⚠ WARNING

Before revving engine, ensure that the track is free of particles which could be thrown out while track is rotating. Keep hands, tools, feet and clothing clear of track. Always lift the snowmobile on a wide-base stand with a rear deflector panel. Ensure no one is standing in close proximity to the snowmobile, especially at the rear of the track. Centrifugal force could cause debris, damaged or loose studs, pieces of torn track, or an entire track to be violently thrown backwards out of the frame with tremendous force, possibly resulting in the loss of a leg or other serious injury.

Remove parking brake.

Activate throttle lever 3 - 4 times to bring engine speed to 7000 RPM.

Apply the brake.

Lower vehicle back on ground.


Stop engine.



Add coolant up to 15 mm (1/2 in) above the COLD LEVEL line.

## Section 02 ENGINE

### Subsection 08 (COOLING SYSTEM)



#### TYPICAL

1. Coolant reservoir
2. Coolant 15 mm (1/2 in) above COLD LEVEL line

When engine has completely cooled down, recheck coolant level in coolant reservoir and refill up to line if needed.

Check for coolant mixture freezing point.

#### COOLANT MIXTURE RECOMMENDED FREEZING POINT

-37°C (-35°F)

Adjust mixture as necessary.

Reinstall removed parts.

## INSPECTION

### COOLING SYSTEM LEAK TEST


**NOTE:** This test confirms if there is a leak in the cooling system, including the engine.

#### **⚠ WARNING**

To prevent potential burns, do not remove the radiator cap if the engine is hot.

Remove hood.

Install the TEST CAP (P/N 529 035 991) on coolant reservoir.



Connect the VACUUM/PRESSURE PUMP (P/N 529 021 800) to the test cap nipple.

Pressurize system through coolant reservoir.

#### TEST PRESSURE

100 kPa (15 PSI)



If pressure drops, check all hoses and engine for coolant leaks. Spray a soap/water solution and look for air bubbles.

If no external leak is found and pressure drops, carry out the *ENGINE LEAK TEST* to find the engine internal leak.


### ENGINE COOLING SYSTEM LEAK TEST (800R)

**NOTE:** An engine leak test should be performed prior to installing engine in vehicle each time the engine is disassembled.

On the water pump side, install a suitable hose on the water pump housing and block it with a LARGE HOSE PINCHER (P/N 529 032 500).

## Section 02 ENGINE


### Subsection 08 (COOLING SYSTEM)



Install a hose on the straight fitting on cylinder head and secure it with a clamp. Install a SMALL HOSE PINCHER (P/N 295 000 076) to block the hose.

Install a hose on the water outlet housing and secure it with a clamp. Install a LARGE HOSE PINCHER (P/N 529 032 500) to block this hose.

Install the VACUUM/PRESSURE PUMP (P/N 529 021 800) on the small elbow fitting.



1. Hose blocked on water outlet housing
2. Small elbow fitting
3. Hose blocked on straight fitting

Pressurize the engine.

#### TEST PRESSURE

100 kPa (15 PSI)


If pressure drops, spray a soap/water solution onto engine jointed surfaces and look for air bubbles.

## PROCEDURES

### THERMOSTAT

#### Thermostat Removal

For removal of thermostat, block all four thermostat hoses with hose pinchers or drain the cooling system (see above).



1. Thermostat

Remove LH and RH panels. Refer to *BODY*.

Remove pulley guard. Refer to *DRIVE SYSTEM/ BRAKE*.

Remove primary air intake silencer. Refer to *AIR INTAKE SYSTEM*.

Remove muffler. Refer to the *EXHAUST SYSTEM* section.

Remove acoustic panel.

Cut Oetiker clamps, unplug hoses and remove thermostat housing.



THERMOSTAT HOUSING

## Thermostat Test

To check thermostat, put in water and heat water. Thermostat should start to open when water temperature reaches the following degree.

ENGINE	TEMPERATURE
All	37°C (99°F)

It will be almost fully open at 55°C (131°F).

## Thermostat Installation

For installation, reverse the removal procedure. Refill cooling system as described in this section.

## RADIATOR CAP

Using a pressure cap tester, check the relief pressure of radiator cap.

If the test failed, install a new 90 kPa (13 PSI) cap. Do not exceed this pressure.

## FRONT RADIATOR

### Front Radiator Cleaning and Inspection

Remove all debris between radiator fins. A clean radiator is more efficient than a dirty one.

Check if the radiator fins are damaged. Replace the front radiator if necessary.

**NOTE:** A radiator with many broken fins does not work properly.

### Front Radiator Removal

Drain cooling system.

Remove LH panel. Refer to *BODY*.


Remove pulley guard. Refer to *DRIVE SYSTEM/ BRAKE*.

Remove primary air intake silencer. Refer to *AIR INTAKE SYSTEM*.

Remove carburetors or throttle body according to vehicle. Refer to the *TM CARBURETORS* or *E-TEC-DIRECT FUEL INJECTION*.


Use a SUPERTANIUM™ BIT (P/N 529 031 800).

From underneath frame, drill the lower rivets of front radiator or grind them with a grinding disk.




1. Front radiator  
2. Rivets

From engine compartment, grind the 3 rivets retaining the radiator protector.



1. Radiator protector (in front of track)




**SOME PARTS HAVE BEEN REMOVED FOR CLARITY PURPOSE ONLY**

1. Radiator protector rivets (in engine compartment)

Remove the upper rivets retaining the front radiator to the frame (a zip gun may be used).

## Section 02 ENGINE

### Subsection 08 (COOLING SYSTEM)



SOME PARTS HAVE BEEN REMOVED FOR CLARITY PURPOSE ONLY

1. Upper rivets of front radiator

Remove the rear RH engine mount nuts.



ENGINE MOUNT SHOWN WITHOUT COUNTERSHAFT FOR MORE CLARITY

Remove the Oetiker clamps securing coolant hoses.


Disconnect hoses and remove radiator.

### Front Radiator Installation

For installation, reverse the removal procedure. However, pay attention to the following.


To avoid removing the track, the rivets of the radiator protector will be installed from the engine compartment. Proceed as follows:

1. Lift and secure rear of vehicle.
2. Use 3 washers (P/N 517 124 300).
3. Glue washers in protector bores using LOCTITE 380 (BLACK MAX) (P/N 413 408 300).



1. Glue washers here

4. From underneath frame, position protector.



1. Radiator protector (in front of track)

5. From engine compartment, secure protector with the rivets. Ensure to insert the rivet ends in washers.

Reinstall remaining removed parts.

Refill cooling system as described in this section.

## REAR RADIATOR

### Rear Radiator Cleaning and Inspection

Remove all debris between radiator fins. A clean radiator is more efficient than a dirty one.

Check if the radiator fins are damaged. Replace the rear radiator if necessary.

**NOTE:** A radiator with many broken fins does not work properly.

### Rear Radiator Removal

Drain cooling system, see *COOLING SYSTEM DRAINING* in this section.


Remove rear suspension. Refer to the *REAR SUSPENSION* section.

Remove fuel tank. Refer to *FUEL TANK/FUEL PUMP*.

Remove luggage rack as necessary according to vehicle.

Remove snow guard.

Using a grinding disk, grind all rivet rows retaining rear radiator to frame. Work from top of frame.



1. Grind all rivet rows

**NOTE:** When pushing the grinded rivets out, support the frame around the rivet with a socket on the opposite side to avoid warpage.

Unplug coolant hoses from rear radiator then remove radiator from vehicle.

## Rear Radiator Installation

The installation is the reverse of the removal procedure.

**NOTE:** If traction enhancing products (studs) are used on vehicle, install the appropriate radiator protector. Refer to *TRACK* to choose the proper protectors kit.

Refill cooling system as described in this section.

## COOLANT RESERVOIR

### Coolant Reservoir Removal

Remove hood.

Remove RH side panel.

Siphon coolant reservoir and block the three lower hoses with pinchers.

Cut Oetiker clamps and remove all hoses from coolant reservoir.

Remove retaining screws to disengage coolant reservoir from frame.

### Coolant Reservoir Inspection

Check if the reservoir is cracked or melted. Replace if necessary.

### Coolant Reservoir Installation

For installation, reverse the removal procedure.

Refill cooling system as described in this section.

## WATER PUMP

Refer to *BOTTOM END* section of the appropriate engine.

## COOLANT TEMPERATURE SENSOR (CTS)

*500SS/600/800R*

**NOTE:** For the 600 HO E-TEC models, Refer to the *E-TEC-DIRECT FUEL INJECTION* section.

### General

When measuring the resistance with an ohmmeter, value is given for a temperature of 20°C (68°F). The value of a resistor varies with the temperature. The value for common resistor **increases** as the temperature increases. However, our temperature sensors are NTC types (Negative Temperature Coefficient) and work the opposite which means that the value **decreases** as the temperature increases. Use the table for sensor resistive values at given temperature.

The resistive value of a temperature sensor may test good at a certain temperature but it might be defective at other temperatures. If in doubt, try a new sensor.

Also remember this validates the operation of the sensor at room temperature. It does not validate the over temperature functionality.

To test it, the sensor could be removed and heated with a heat gun (ensure not to heat excessively) while it is still connected to the harness to see if the ECM will detect the high temperature condition and generate a fault code.

A good test would be to put sensor in a container filled with ice and water and measure resistance. Then, boil water and read resistance again. According to the table *CTS SENSOR TEMPERATURE*, the value would be approximately as follows.



## Section 02 ENGINE


### Subsection 08 (COOLING SYSTEM)

TEMPERATURE CONDITION	RESISTANCE
Sensor in ice/water (0°C (32°F))	5705 $\Omega$
Sensor in boiling water (100°C (212°F))	182.1 $\Omega$

#### CTS Dynamic Test

Use B.U.D.S. software.

Look engine temperature in **Monitoring** tab of B.U.D.S. It should show the coolant temperature. Otherwise, perform the following test.



#### CTS Resistance Test

Remove RH side panel. Refer to *BODY*.

Remove pulley guard. Refer to *DRIVE SYSTEM/ BRAKE*.

Disconnect CTS sensor connector.



Use a multimeter and set it to  $\Omega$ .

Measure resistance between sensor terminals.

CTS		RESISTANCE
Pin 1	Pin 2	Refer to <i>CTS SENSOR TEMPERATURE TABLE</i>



CTS SENSOR TEMPERATURE TABLE		
Unit		Resistance ( $\Omega$ )
°C	°F	CTS
- 40	- 40	43610
- 30	- 22	25090
- 20	- 4	14900
- 10	14	9102
0	32	5705
10	50	3680
20	68	2436
25	77	2000
30	86	1651

CTS SENSOR TEMPERATURE TABLE		
Unit		Resistance ( $\Omega$ )
$^{\circ}\text{C}$	$^{\circ}\text{F}$	CTS
40	104	1144
50	122	807.6
60	140	580.3
70	158	424.4
80	176	315.5
90	194	238
100	212	182.1
110	230	141.1
120	248	110.6
130	266	87.8
140	284	70.4
150	302	57.1
160	320	46.7
170	338	38.5
180	356	32
190	374	26.8
200	392	22.7


If resistance is out of specifications, replace sensor.

If resistance tests good, reconnect the CTS.

Disconnect the ECM connector.

Measure resistance as follows.

ECM CONNECTOR		RESISTANCE
Pin 1	Pin 21	Refer to <i>CTS SENSOR TEMPERATURE TABLE</i>



If resistance value is correct, sensor and wiring/connectors are good.

If resistance value is incorrect, repair/replace wiring/connectors between ECM and CTS.

### CTS Replacement

Remove RH side panel. Refer to *BODY*.

Remove pulley guard. Refer to *DRIVE SYSTEM/ BRAKE*.

Remove primary air intake silencer. Refer to *AIR INTAKE SYSTEM*.

Remove driven pulley. Refer to *DRIVE SYSTEM/ BRAKE*.

Lift rear of vehicle to reduce coolant spillage.

Disconnect CTS connector.

Remove CTS.

Install the new CTS and torque to 12 N•m (106 lbf•in).

Reinstall removed parts.

Refill engine coolant. If an important quantity of coolant is spilled, bleed cooling system. Refer to *COOLING SYSTEM REFILL AND BLEEDING* in this section.

# MAGNETO SYSTEM

## SERVICE TOOLS

<b>Description</b>	<b>Part Number</b>	<b>Page</b>
CRANKSHAFT PROTECTOR .....	420 876 557 .....	97
MAGNETO PULLER .....	529 035 547 .....	98
PULLER RING .....	420 876 081 .....	96


## SERVICE PRODUCTS

<b>Description</b>	<b>Part Number</b>	<b>Page</b>
LOCTITE 243 .....	293 800 060 .....	98
LOCTITE 243 (BLUE) .....	293 800 060 .....	98, 100, 102
LOCTITE 5910 .....	293 800 081 .....	104


## Section 02 ENGINE

### Subsection 09 (MAGNETO SYSTEM)

500SS/600/800R



600 HO E-TEC



## Section 02 ENGINE

### Subsection 09 (MAGNETO SYSTEM)

## GENERAL

**NOTE:** The following procedures can be carried out without removing the engine.

During assembly/installation, use the torque values and service products as in the exploded views.

Clean threads before applying a threadlocker. Refer to the *SELF-LOCKING FASTENERS* and *LOC-TITE APPLICATION* sections at the beginning of this manual for complete procedure.

### **⚠ WARNING**

Torque wrench tightening specifications must be strictly adhered to. Locking devices (e.g.: locking tabs, elastic stop nuts, self-locking fasteners, etc.) must be replaced with new ones.


## PROCEDURES

### MAGNETO FLYWHEEL

#### Magneto Flywheel Removal


**⚠ CAUTION** Ensure tether cord is removed from DESS post and engine shut-off switch is in the OFF position.

1. Remove muffler, refer to the *EXHAUST SYSTEM* section.
2. Remove acoustic panel.
3. Remove the rewind starter assembly (or magneto housing cover for 600 HO E-TEC electric start models).
4. Remove starting pulley.




TYPICAL - STARTING PULLEY

**NOTE:** To remove starting pulley screws, hold magneto flywheel with a socket as shown as you remove the pulley retaining screws.



TYPICAL - STARTING PULLEY SCREWS

5. Remove the connecting flange retaining the rewind starter to the engine housing (except 800R models).



TYPICAL - REWIND STARTER CONNECTING FLANGE

6. Install the PULLER RING (P/N 420 876 081) on magneto flywheel (or counterweight on 800R engine).


**Section 02 ENGINE**  
**Subsection 09 (MAGNETO SYSTEM)**



**PULLER RING (P/N 420 876 081)**

**NOTICE** Use only the following screw lengths to fasten puller ring to magneto flywheel. If other screw lengths are used, the stator behind the magneto flywheel may be damaged.

ENGINE	SCREW LENGTH
500SS/600/800R	M8 x 20 mm
600 HO E-TEC	M8 x 25 mm



**TYPICAL - 800R**


1. Tab in magneto housing opening
2. M8 screws of appropriate length



**TYPICAL - 500SS/600/600 HO E-TEC**

1. Tab in magneto housing opening
2. M8 screws of appropriate length

7. Remove magneto flywheel retaining nut, using a 30 mm socket with the outside diameter machined to 40 mm (1.580 in) by 16 mm (5/8 in) long.
8. To correctly remove a threadlocked fastener, first tap on the fastener to break threadlocker bond. This will prevent the thread from breaking.



**TYPICAL**

1. Machined 30 mm socket

9. Install the CRANKSHAFT PROTECTOR (P/N 420 876 557) on crankshaft end.

**NOTE:** Applying a small amount of grease to the end of the crankshaft will hold the protector in place and allow you to easily install the magneto puller.

## Section 02 ENGINE

### Subsection 09 (MAGNETO SYSTEM)



10. Screw the MAGNETO PULLER (P/N 529 035 547) into the puller ring.



MAGNETO PULLER (P/N 529 035 547)

11. Tighten puller bolt, while at the same time, tapping on on the puller bolt head with a hammer to release the magneto flywheel from the taper on the crankshaft.



TYPICAL

### Magneto Flywheel Cleaning

**NOTICE** Clean magneto flywheel using only a clean cloth.

### Magneto Flywheel Inspection

Inspect magneto flywheel for abnormal coloration (brown or blue) that would indicate overheating condition.

If overheating condition is suspected, carry out the following:

- Check flywheel magnetic field using a piece of metal. If magnetic field is not felt or weak, replace flywheel.
- Inspect flywheel for cracks, pay particular attention to the inside circumference (magnets), and the tapered center portion.
- Check if magneto housing ventilation holes are clean.
- Check stator for signs of overheating.
- Test stator, see procedures further in this section.

### Magneto Flywheel Installation

1. Clean crankshaft extension (taper) and apply LOCTITE 243 (P/N 293 800 060) on tapered surface.
2. Position Woodruff key, magneto flywheel and lock washer on crankshaft.
3. Clean the threads in the magneto flywheel nut and apply LOCTITE 243 (BLUE) (P/N 293 800 060).
4. Install nut on crankshaft and tighten to specified torque, see following table.

ENGINE	TORQUE
500SS/600/600 HO E-TEC	125 N•m (92 lbf•ft)
800R	95 N•m (70 lbf•ft)


**NOTICE** Do not apply silicone dielectric grease or any other product on Deutsch waterproof housings as housing seal may be damaged.

### STATOR (500SS/600/800R)

#### Stator Continuity Test

1. Remove RH side panel.
2. Remove muffler.
3. Remove acoustic panel.
4. Disconnect connector from voltage regulator.






**TYPICAL**  
1. Voltage regulator  
2. Regulator connector

5. Set multimeter to  $\Omega$ .
6. Read the resistance between wires as follows.

<b>STATOR CONTINUITY TEST</b>		
TEST PROBES		RESISTANCE @ 20°C (69°F)
Any YELLOW wire	To another YELLOW wire	0 - 0.5 $\Omega$



**VOLTAGE REGULATOR CONNECTOR, YELLOW WIRES**

7. Repeat test for every pair of YELLOW wires.
8. If resistance is out of specification, replace stator.
9. Install the connector and other parts in the reverse order of removal. Refer to appropriate sections for details.

### Stator Insulation Test

1. Refer to the applicable *STATOR CONTINUITY TEST* for instructions on how to access stator connector on voltage regulator.


2. Set multimeter to  $\Omega$ .
3. Read resistance as follows.

<b>STATOR INSULATION TEST</b>		
TEST PROBES		RESISTANCE @ 20°C (69°F)
Any YELLOW wire	Engine ground	OL (open circuit)

If results are out of specification, the stator and/or the wiring need to be repaired/replaced.

### Stator AC Voltage Output Test

1. Remove RH side panel.
2. Remove muffler.
3. Remove acoustic panel.
4. Disconnect the voltage regulator connector.




**TYPICAL**  
1. Voltage regulator  
2. Regulator connector

5. Set multimeter to Vac scale.
6. Manually crank engine and read the voltage as follows. Repeat the test 3 times for each pair of YELLOW wires.

<b>STATOR AC VOLTAGE OUTPUT TEST</b>		
TEST PROBES		VOLTAGE
Any YELLOW wire	Any other YELLOW wire	3.5 - 7.5 Vac

## Section 02 ENGINE

### Subsection 09 (MAGNETO SYSTEM)



VOLTAGE REGULATOR CONNECTOR, YELLOW WIRES

If voltage is lower than specification, replace stator.

Install all removed parts.

### Stator Removal

1. Remove magneto flywheel.
2. Remove all Allen socket screws retaining stator to magneto housing.
3. Disconnect the voltage regulator connector.
4. Remove the three yellow stator wires from the voltage regulator connector using the appropriate contact removal tool.
5. Tie a string of adequate length to the stator wires and secure the loose end so that it cannot be pulled through the harness and grommet.
6. Cut the locking tie securing wires at grommet near crankcase opening.
7. Carefully pull wires through crankcase opening as you remove the stator.
8. Untie the string from the stator wires, it will be used to pull the wires back through the grommet on installation.

### Stator Cleaning


**NOTICE** Clean stator using only a clean cloth.

### Stator Installation

1. Insert the stator wires through the crankcase grommet and pull them up to the voltage regulator connector.

**NOTE:** Use the string and a piece of tape to secure the ends of the wires to ease pulling them through the crankcase, grommet and flexible conduit.

2. Position stator so that its wire protectors are positioned over the recessed area in the crankcase.



1. Crankcase recessed area
2. Wire protectors


**NOTE:** During installation, ensure the stator harness is located on the left side.

3. Apply LOCTITE 243 (BLUE) (P/N 293 800 060) on threads of stator screws then torque them to 9 N•m (80 lbf•in).
4. Install a new locking tie near the crankcase grommet as prior to stator removal.
5. Insert the yellow stator wires into the voltage regulator connector. Pull on the wires with enough force to ensure they are properly locked in.
6. Reinstall all other removed parts.

## STATOR (600 HO E-TEC)

### Stator Continuity Test


1. Remove LH side panel.
2. Remove tool kit.
3. Remove drive belt guard.
4. Disconnect magneto stator connector.



**MAGNETO STATOR CONNECTOR**

5. Set multimeter to  $\Omega$ .
6. Measure the resistance of each stator coil at stator connector as follows.

STATOR CONTINUITY TEST		
TEST PROBES		RESISTANCE @ 20°C (69°F)
Pin 1	Pin 6	$0.63 \pm 0.03 \Omega$
Pin 2	Pin 5	
Pin 3	Pin 4	



**STATOR CONNECTOR PIN-OUT**

**NOTE:** The stator resistance values mentioned in the table are manufacturers specifications under ideal conditions. If stator coil resistance is less than  $1 \Omega$ , consider stator to be in good working condition.

If resistance is out of specification, replace stator.


7. Install stator connector and other parts in the reverse order of removal.

### Stator Insulation Test

Refer to the *STATOR CONTINUITY TEST* for instructions on how to access and disconnect stator connector.

1. Set multimeter to  $\Omega$ .
2. Read resistance at stator connector as follows.

STATOR INSULATION TEST		
TEST PROBES		RESISTANCE @ 20°C (69°F)
Pin 1	Engine ground	OL (open circuit)
Pin 2		
Pin 3		
Pin 1	Pin 4	
Pin 1	Pin 5	
Pin 2	Pin 4	



**STATOR CONNECTOR PIN-OUT**

If results are out of specification, the stator and/or the wiring need to be repaired/replaced.

### Stator Voltage Output Test

Refer to the *STATOR CONTINUITY TEST* for instructions on how to access and disconnect stator connector.


1. Set multimeter to Vac and manually set a scale capable of reading at least 20 Vac.
2. Manually crank engine and read the voltage from each winding as follows. Repeat the test 3 times for each winding.

## Section 02 ENGINE

### Subsection 09 (MAGNETO SYSTEM)

#### STATOR OUTPUT VOLTAGE TEST

TEST PROBES		VOLTAGE
Pin 1	Pin 6	Approximately 15 - 20 Vac
Pin 2	Pin 5	
Pin 3	Pin 4	



STATOR CONNECTOR PIN-OUT

3. If voltage is lower than specification, remove and inspect magneto flywheel and stator. Refer to *MAGNETO FLYWHEEL*.
4. Replace magneto flywheel and/or stator as applicable.
5. Install all removed parts.

#### Stator Removal

1. Remove *MAGNETO FLYWHEEL*, see procedure in this section.
2. Remove all Allen socket screws retaining stator to magneto housing.
3. Remove grommet from crankcase where CPS sensor and stator wires exit magneto housing.
4. Disconnect the crankshaft position sensor (CPS) connector, see procedure in this section.
5. Disconnect the stator connector located on the capacitor support, see illustration.



TYPICAL  
1. Stator connector

**NOTE:** To ease harness routing at installation, tie a string on each connector and let the strings follow through as you pull on the harnesses. Pass the CPS sensor connector through the grommet first.

6. Remove the stator and carefully pull the wires through the grommet.

**NOTE:** It will be necessary to break the silicone sealant behind the left side of the stator. Proceed carefully to avoid wire damage.

#### Stator Cleaning

**NOTICE** Clean stator using only a clean cloth.

#### Stator Inspection

Refer to *MAGNETO FLYWHEEL INSPECTION*.

#### Stator Installation

**NOTE:** It is important to remove the old silicon sealant behind the LH side of the stator, and apply new silicon at stator installation.

1. Insert the stator connector through the crankcase and grommet, followed by the CPS sensor connector.
2. Install the grommet on crankcase.

**NOTE:** During installation, ensure the stator harness is located on the left side.

Apply LOCTITE 243 (BLUE) (P/N 293 800 060) on threads of stator screws then torque them to 9 N•m (80 lbf•in).

3. Tie the strings on the connectors used during removal of the stator and CPS sensor connectors, then pull on them to route the harnesses up to their original locations.
4. Reinstall all other removed parts.

## CRANKSHAFT POSITION SENSOR (600 HO E-TEC)

### CPS Sensor Test

Refer to *E-TEC DIRECT INJECTION* section.

### CPS Sensor Removal

**⚠ CAUTION** Ensure tether cord is removed from DESS post and engine shut-off switch is in the OFF position.

1. Remove magneto flywheel, refer to *MAGNETO FLYWHEEL REMOVAL* in this section.
2. Remove CPS sensor retaining screws.
3. Remove grommet from crankcase where CPS sensor harness exits magneto housing.
4. Disconnect CPS sensor connector located on the capacitor support, see illustration.



1. CPS sensor connector

**NOTE:** To ease harness routing at installation, tie a string to the CPS sensor connector and guide it through as you pull on the CPS sensor harness.

5. Remove CPS sensor and carefully pull harness through from crankcase.

### CPS sensor Installation

1. Tie the rope used during removal on the CPS sensor connector, then pull on it to route the harness to its original location.
2. Complete the installation in the reverse order of the removal procedure.

**NOTE:** It is important to remove the old silicon at CPS sensor location then apply new silicon. Screw CPS sensor then stick the CPS sensor harness in silicon.

## TRIGGER COILS (500SS/600)

### Trigger Coil Inspection

For trigger coil testing, refer to the *IGNITION SYSTEM* section.

### Trigger Coil Removal

**⚠ CAUTION** Ensure tether cord is removed from DESS post and engine shut-off switch is in the OFF position.

1. Remove magneto flywheel, refer to *MAGNETO FLYWHEEL REMOVAL* in this section.

**NOTE:** The trigger coil connector is located behind the oil filter (below oil reservoir).

2. Remove grommet from crankcase where trigger coil wire(s) exit(s) magneto housing.
3. Remove trigger coil(s) retaining screws.
4. Remove trigger coil(s) and carefully pull wires through crankcase.

### Trigger Coil Installation

For installation, reverse the removal procedure.

**NOTE:** It is important to remove the old silicon at trigger coil location then apply new silicon. Screw trigger coil then stick the trigger coil wires in the silicon.

## TRIGGER COILS (800R)

### Trigger Coil Inspection

For trigger coil testing, refer to the *IGNITION SYSTEM* section.

### Trigger Coil Removal

Remove the magneto housing. See procedure in this section.

Separate trigger coils from silicone sealer on magneto housing.

## Section 02 ENGINE


### Subsection 09 (MAGNETO SYSTEM)



TRIGGER COILS SEALED TO MAGNETO HOUSING WITH SILICONE

### Trigger Coil Installation

Apply new silicone sealer LOCTITE 5910 (P/N 293 800 081) between trigger coils and magneto housing as prior to removal. Then, stick the trigger coil wires in the silicone.



NEW SILICONE SEALER APPLICATION

Install the magneto housing.

### MAGNETO HOUSING (800R)


#### Magneto Housing Inspection

Inspect housing for cracks or other apparent damage. Replace as necessary.

### Magneto Housing Removal

**CAUTION** Ensure tether cord is removed from DESS post and engine shut-off switch is in the OFF position.

1. Remove magneto flywheel, refer to *MAGNETO FLYWHEEL REMOVAL* in this section.
2. Remove magneto housing retaining screws.




MAGNETO HOUSING RETAINING SCREWS

3. Remove trigger coil retaining screws.




TRIGGER COIL RETAINING SCREWS

4. Remove magneto harness grommet from crankcase.



TYPICAL - GROMMET

5. Slightly pull magneto housing and cut silicone sealer from between trigger coils and crankcase.



TYPICAL

6. Remove magneto housing with trigger coils.

### Magneto Housing Installation

For installation, reverse the removal procedure. However, pay attention to the following.

Reinstall magneto housing and trigger coils on crankcase.

Torque trigger coil screws as specified in exploded view.

Torque magneto housing screws to 9 N•m (80 lbf•in).

# RAVE (593)

## SERVICE PRODUCTS

Description	Part Number	Page
DREI BOND SEALING COMPOUND .....	420 297 906 .....	111
LOCTITE CHISEL.....	413 708 500 .....	111






## Section 02 ENGINE

### Subsection 10 (RAVE (593))

500SS/600



## GENERAL

During assembly/installation, use torque values and service products as in the exploded view.

Clean threads before applying a threadlocker. Refer to *SELF-LOCKING FASTENERS* and *LOCTITE APPLICATION* at the beginning of this manual for complete procedure.

### **⚠ WARNING**

Torque wrench tightening specifications must be strictly adhered to. Locking devices (e.g.: locking tabs, elastic stop nuts, self-locking fasteners, cotter pins, etc.) must be replaced with new ones.

## SYSTEM DESCRIPTION

**NOTE:** RAVE stands for Rotax Adjustable Variable Exhaust.

The RAVE valves change the height of the exhaust port to enhance the engine powerband and torque according to the engine RPM and throttle position.

Exhaust pressure is used to inflate the bellows and open the RAVE valves at the proper engine RPM.


## PROCEDURES

### RAVE VALVES

#### Rave Valves Removal and Disassembly

1. Remove LH side cover.
2. Remove tool kit support located on drive pulley guard.
3. Remove RAVE valve cover by removing screws.


**⚠ CAUTION** Firmly hold cover to valve base. The compression spring inside the valve applies pressure against the cover.



TYPICAL

1. Cover
2. Retaining screws

4. Remove the compression spring.




TYPICAL

5. Unscrew the Allen socket screw then remove the RAVE valve base.


## Section 02 ENGINE

### Subsection 10 (RAVE (593))




**TYPICAL**  
1. Allen socket screws  
2. RAVE valve base

6. Unscrew and remove the guillotine from the valve piston than remove the gasket.




**TYPICAL**  
1. Guillotine  
2. Gasket  
3. Valve piston

7. Remove spring retaining bellows to valve piston.




**TYPICAL**  
1. Spring  
2. Valve piston  
3. Bellows

8. Remove valve piston.




**TYPICAL**

9. Remove the small spring retaining bellows to valve base.



**TYPICAL**  
1. Bellows  
2. Small spring  
3. Valve base

10. Remove bellows from valve base.



**TYPICAL**

### Rave Valves Cleaning

Discard all gaskets and O-rings. Use LOCTITE CHISEL (P/N 413 708 500) to clean mating surfaces.

Clean all metal components in a non-ferrous metal cleaner.

### Rave Valves Inspection

**NOTE:** If there is oil in the valve base, replace seal.


There are no wear parts anywhere in the system and there are no adjustments to be periodically checked. The only possible maintenance required would be cleaning of carbon deposits from the

guillotine slide. Cleaning intervals would depend upon the user's riding style and the quality of the oil used.

BRP suggests annual cleaning of the valve. If a customer uses lower quality oil, than recommended, more frequent cleaning may be required.

No special solvents or cleaners are required when cleaning the valve.

Check valve rod housing and cylinder for clogged passages.



1. Draining hole  
2. Passages

**NOTE:** Oil dripping from draining hole indicates a loosen spring or damaged bellows.

Check for cracked, dried or perforated bellows.

In its stock configuration, the RAVE valve guillotine has a minimum of 0.5 mm (.020 in) clearance to the cylinder bore measured at the center line of the cylinder. This is the minimum production clearance.

### Rave Valves Assembly and Installation

Assembly and intallation are the reverse of the removal, however, pay attention to the following.

Apply DREI BOND SEALING COMPOUND (P/N 420 297 906) on the bellow lower rib and in the valve piston groove.

## Section 02 ENGINE

### Subsection 10 (RAVE (593))



1. Apply Drei Bond here



1. Apply Drei Bond here

Install RAVE valve with its mention TOP as illustrated in the following photo.



# RAVE (593 E-TEC)

## SERVICE TOOLS

Description	Part Number	Page
T-HARNESS .....	529 035 869 .....	124
VACUUM/PRESSURE PUMP .....	529 021 800 .....	117


## SERVICE PRODUCTS

Description	Part Number	Page
DREI BOND SEALING COMPOUND .....	420 297 906 .....	120–121
LOCTITE 243 .....	293 800 060 .....	122, 127
MOLYKOTE G-N .....	420 297 433 .....	120

## Section 02 ENGINE

### Subsection 11 (RAVE (593 E-TEC))

600 HO E-TEC



## GENERAL

During assembly/installation, use torque values and service products as in the exploded view.

Clean threads before applying a threadlocker. Refer to *SELF-LOCKING FASTENERS PROCEDURE* and *LOCTITE APPLICATION PROCEDURE* at the beginning of this manual for complete procedure.


### **⚠ WARNING**

Torque wrench tightening specifications must be strictly adhered to. Locking devices (e.g.: locking tabs, elastic stop nuts, self-locking fasteners, cotter pins, etc.) must be replaced with new ones.

## SYSTEM DESCRIPTION


The E-TEC basically uses the same mechanisms as on the 800R engine except for the following:

- RAVE valves are lubricated by the electronic oil injection pump.
- RAVE valve position feedback to ECM. A hall-effect position sensor is used (RPS; RAVE position sensor).
- Only one solenoid is used to activate the RAVE valves.
- RAVE valves movement is synchronized and monitored with a link bar.



1. Linked RAVE valves
2. RAVE solenoid
3. Pressure hoses to RAVE valves
4. Electronic oil injection pump
5. Oil lines to RAVE valves


A link bar is used to keep RAVE valves opening and closing synchronized one with each other. This provides a more consistent engine operation.



If link bar is removed, a particular adjustment is required at the assembly. Also, B.U.D.S. needs to be used to set the RAVE mid-position.

The RAVE position sensor (RPS) provides the ECM its actual position. Either closed, mid-position or open. This informs the ECM that the RAVE valves are really at the expected position so that the proper amount of fuel is injected as well as other required operating parameters are applied.

The 3D RAVE arrangement uses only one solenoid to move the RAVE valves to the desired position.




**CRANKCASE HOSES, CHECK VALVES AND Y-CONNECTORS ARRANGEMENT TO SOLENOID**



## Section 02 ENGINE

### Subsection 11 (RAVE (593 E-TEC))



SOLENOID VACUUM/PRESSURE SEPARATION

The ECM controls the solenoid as follows.

RAVE VALVES POSITION	SOLENOID STATE	SOLENOID VALVE OPERATION
FULLY OPENED	ON	Pressure
MIDDLE	Switched between ON and OFF repeatedly by the ECM (pulse width modulation with a variable DC) (duty cycle from 10 to near 50%).	Near atmospheric pressure (floating position). A constant switching between pressure and vacuum to keep the RAVE in the mid position as set in the ECM.
CLOSED	OFF	Vacuum

## INSPECTION

### 3D RAVE VALVES POSITION VALIDATION

- Lift rear of vehicle to clear track from the ground. Support it with a wide base stand.
- Connect B.U.D.S. Refer to *COMMUNICATION TOOLS AND B.U.D.S.* section.
- In B.U.D.S., select the **Setting** tab, then the **ECM** tab. The actual 3D RAVE valves position is displayed in the **Rave Mid-Position** area.
- Start engine.

## WARNING

Make sure that the track is free of any particles which could be thrown out while track is rotating. Keep hands, tools, feet and clothing clear of track. Ensure no one is standing in close proximity to the vehicle.

- Monitor the actual 3D RAVE valves position at different engine speeds. Refer to the following table.

3D RAVE VALVES POSITION REFERENCE TABLE	
ENGINE SPEED	VALVE POSITION
Idle or low RPM	0.5 to 0.7 (closed)
6600 to 7700	Approximately 2.5 (mid)
From 7700	4.5 to 4.7 (open)

If the 3D RAVE valves positions do not correspond with the reference table, verify the following in this order.

- Fault codes. Correct as required
- RAVE valves cleanliness
- RAVE valves leak test
- Actuator check valves operation
- Solenoid operation.

## TROUBLESHOOTING

### DIAGNOSTIC TIPS

#### Engine Vibration or Misfiring

##### Spark Plugs

Improper spark plug indexing may lead to engine misfiring. Check if BRP spark plugs are installed or if spark plugs are properly indexed. Refer to *IGNITION SYSTEM* in *ELECTRICAL SYSTEM* section.

##### 3D RAVE Valves

Check RAVE valves cleanliness. Dirty valves may cause engine misfiring or erratic operation of RER. Refer to *3D RAVE VALVE CLEANING* in this section.

Check RAVE valve operation. Improper RAVE valves position may cause engine to vibrate or misfire. Refer to *3D RAVE VALVES POSITION VALIDATION*.

## PROCEDURES

### 3D RAVE VALVES


#### 3D RAVE Valve Leak Test

NOTE: Test each RAVE individually.

Use the VACUUM/PRESSURE PUMP (P/N 529 021 800).




1. Remove 3D RAVE valves cover and link bar, see *3D RAVE VALVES REMOVAL*.
2. Unplug the RAVE inlet hose.
3. Install test pump on nipple and apply pressure. Piston should fully rise. Otherwise or if it lowers rather quickly, check bellow and seals inside RAVE valve.



TYPICAL

4. Apply vacuum. Piston should fully lower. Otherwise or if it rises rather quickly, check bellow and seals inside RAVE valve.



TYPICAL


For check valves and solenoid leak tests, refer to *3D SOLENOID AND CHECK VALVES* in this section.

5. Install link bar and cover.

NOTE: It is very important to perform *3D RAVE VALVES SYNCHRONIZATION* whenever link bar is removed. See procedure below.

#### 3D RAVE Valves Removal

1. Remove LH side panel.
2. Remove tool kit support located on drive belt guard.
3. Remove 3D RAVE valves cover.
4. Remove 3D RAVE valves link bar. Hold RAVE pistons with a wrench and remove the retaining nuts.




1. Link bar
2. Hold piston here
3. Retaining nut

5. Remove 3D RAVE valves position sensor.


## Section 02 ENGINE

### Subsection 11 (RAVE (593 E-TEC))



1. Position sensor

6. Disconnect 3D RAVE valve oil lines and vacuum/ pressure hoses.
7. Remove screws retaining the 3D RAVE valve housing no. 5 to the cylinder.
8. Pull valve assembly out.



**NOTE:** Be careful not to loose springs underneath housing.

#### 3D RAVE Valve Disassembly


1. Carefully remove spring no. 3 retaining bellow no. 2 to valve piston no. 1.



TYPICAL

2. Free bellow from valve piston.
3. Carefully unscrew valve piston then remove compression spring.

**CAUTION** Firmly hold valve piston. The compression spring inside the valve applies pressure against the piston.




TYPICAL

4. Carefully remove bellow no. 2 from valve housing no. 5.

**NOTE:** If oil is found in housing area, replace seals.

5. Extract RAVE valve from housing.
6. Take note of seals orientation and carefully pry them out.



mmv2007-019-022\_a

TYPICAL

### 3D RAVE Valve Cleaning

The 3D RAVE valves should be cleaned every 3 years or 10 000 km (6000 mi) whichever comes first. Clean carbon deposits as required.

Thoroughly clean all 3D RAVE VALVES components and cylinder slots.

No special solvents or cleaners are required when cleaning the valve.

### Valves Frequently Gummed


If the valves are getting gummed more frequently than usual, do the following:

- Check if XP-S synthetic blend injection oil is used.
- Check lubrication hoses for restriction.
- Check lubrication hoses for presence of air. Bleed system if needed.
- Check lubrication check valves as explained in this section.

### 3D RAVE Valve Inspection

Check valves **no. 6** for breakage.

Check valves for wear at sliding points and straightness.



mmv2007-016-009\_a

SIGNS OF WEAR

Check spring condition and straightness.


**NOTE:** Oil dripping from draining hole indicates a defective seal and a loosen retaining spring or damaged bellows.

Check for cracked, dried or perforated bellows **no. 2**.

**NOTE:** Make sure hoses are not leaking, kinked or damaged.

### 3D RAVE Valve Assembly

Position parts as per illustrations.



mmv2007-019-001\_a

1. Oil seal
2. Gasket ring

Use an appropriate pusher to reinstall seals.

## Section 02 ENGINE

### Subsection 11 (RAVE (593 E-TEC))



TYPICAL


1. Assemble together the main and side valves.



4. Apply MOLYKOTE G-N (P/N 420 297 433) to valve shaft and on seals in housing.
5. Install housing and carefully align springs on stud ends of housing.



2. Insert valves together in cylinder. Install gasket.



TYPICAL

6. Install lower spring no. 4 on bellow.
7. Apply DREI BOND SEALING COMPOUND (P/N 420 297 906) on the bellow's lower rib, then install bellow and spring.



TYPICAL

3. Align springs on stud ends of valves.



1. Apply Drei Bond here

8. Install compression spring then tighten valve piston.
9. Apply DREI BOND SEALING COMPOUND (P/N 420 297 906) on valve piston groove.




1. Apply Drei Bond here

10. Position bellow on valve piston then secure top retaining spring no. 3 as follows.
11. Attach a locking tie to spring.



12. Block valve piston in the open position with a suitable socket.



13. Position joint of spring under your thumb.
14. Hold spring with your thumb while sliding spring on the other side using the locking tie.



1. Joint of spring under thumb

15. Continue sliding locking tie all around the edge of valve piston.

## Section 02 ENGINE

### Subsection 11 (RAVE (593 E-TEC))




**NOTE:** Take care there is no strain in the bellow that could apply some bending force or torsion to the 3D RAVE valve. That may contribute to a RAVE valve jam.

Push and pull valve piston to make sure it moves freely.



16. When installing valve assembly in its housing, center valve horizontally and longitudinally then hand tighten screws.



17. Tighten screws and check valve for free movement again. If some friction is felt, slightly loosen screws and readjust housing then retighten screws.

Repeat the process until a free movement is obtained.

18. Install position sensor.

19. Position link bar on valve pistons and install nuts, with LOCTITE 243 (P/N 293 800 060) on piston threads but do not tighten yet.

20. Install lubrication and vacuum/pressure hoses.

21. Perform *3D RAVE VALVE SYNCHRONIZATION* procedure below to complete link bar installation. This step is very important.

22. Bleed oil lines. Refer to *OIL PUMP (600 HO E-TEC)* in the *LUBRICATION SYSTEM* section.

### 3D RAVE Valve Synchronization

1. With retaining nuts loose, push the center of the link bar downwards in order to seat both valves on their fully closed position and hold.
2. Prevent pistons from turning and tighten both nuts while holding the link bar down. Do not overtighten.

**NOTICE** To prevent piston breakage, proceed with care and make sure piston does not turn.

3. Verify valve synchronization.

3.1 Push and pull link bar to force valves to pass through their 3 positions.

3.2 Pay attention when valves cross the mid position (partially open). When crossing that point, a step will be felt.

**NOTE:** Valves are properly synchronized, only if one step is felt at mid position. Valve synchronization is critical for proper engine performance.

4. If valves are not perfectly synchronized, loosen nuts and repeat synchronization procedure.
5. Start engine and recheck 3D RAVE valves operation.


**NOTE:** Pistons should move freely. If not, look for excessive friction due to torsion force applied on the piston rods during installation.

6. Install cover.
7. Perform the *3D RAVE VALVES MID POSITION SETTING*, refer to *3D RAVE VALVES POSITION SENSOR*, this step is very important.

## ACTUATOR CHECK VALVES

### Check Valve Leak Test

1. Disconnect check valve.
  2. Install test pump as shown.
  3. Pressurize check valve to 34 kPa (5 PSI).
- Valve should stand pressure.



4. Install test pump in the opposite side.
  5. Pressurize check valve.
- Air should flow freely.



Replace valve if any test failed.

### Check Valve Installation

Ensure to reinstall all check valves in the proper direction.



CHECK VALVE ORIENTATION

## LUBRICATION CHECK VALVES

### Check Valve Test

1. Disconnect check valve.
2. Install test pump as shown.



## Section 02 ENGINE

### Subsection 11 (RAVE (593 E-TEC))



TYPICAL

3. Pressurize check valve to 10 kPa (1.5 PSI).


Valve should stand pressure.

4. Install test pump in the opposite side.

Air should start to flow between 14 kPa and 24 kPa (2 PSI and 3 PSI).

Replace valve if any test failed.

## SOLENOID




1. RAVE solenoid

**NOTE:** First ensure the problem is not related with tubes connection and RAVE valves themselves.

### Solenoid Test with B.U.D.S.

Refer to *COMMUNICATION TOOLS/B.U.D.S. SOFTWARE* section for proper connection to vehicle.

Using B.U.D.S. software (E-TEC version), energize RAVE solenoid from **Activation** tab.




1. Activate here


This will validate the RAVE solenoid mechanical and electrical operation.

If the solenoid does not work or works only when T-HARNESS (P/N 529 035 869) is connected, proceed with *SOLENOID INPUT VOLTAGE TEST* in this section.

### Solenoid Leak Test



SOLENOID OPERATION (OFF)



SOLENOID OPERATION (ON)


**NOTE:** Test each solenoid individually.

1. Unplug supply hose from solenoid.
2. Install test pump on solenoid nipple.

3. Supply 12 Vdc to solenoid terminals. Ensure to respect polarity.

**NOTE:** B.U.D.S. may be used to activate solenoid when performing this test but the activation lasts less than one second.

4. Pressurize solenoid.




**TEST PRESSURE**

69 - 103 kPa (10 - 15 PSI)

Wait for some time to see if pressure drops:


- If pressure does not build up or drops, replace solenoid.
- If pressure is maintained, continue testing.

Disconnect solenoid. Pressure should evacuate through upper nipple.



5. Unplug outlet hose from solenoid.

6. Install test pump on solenoid nipple. Pressurize to the same pressure as before.




Wait some time to see if pressure drops:

- If pressure does not build up or drops, replace solenoid.
- If pressure is maintained, continue testing.

7. Supply 12 Vdc to solenoid terminals. Ensure to respect polarity.

8. Pressure should evacuate through upper nipple.




If any test failed, replace solenoid.

**Solenoid Input Voltage Test**

1. Remove muffler. Refer to *EXHAUST SYSTEM* section.
2. Remove the acoustic panel.
3. Disconnect the connector from the solenoid.

## Section 02 ENGINE

### Subsection 11 (RAVE (593 E-TEC))



1. Solenoid connector

4. Install a suitable jumper wire on pin 2 (harness side) taking care not to damage terminal.
5. Reinstall muffler.

**NOTICE** Make sure there is no contact between muffler and jumper wire.

6. Start engine and measure voltage on jumper wire as follows.

TEST PROBE		MEASUREMENT
Pin 2 (extended with jumper wire)	Engine ground	Battery voltage


If reading is not as per specification repair/replace wiring/connector.

If solenoid does not work but the voltage supply is good, perform *SOLENOID CIRCUIT TEST*.

#### Solenoid Circuit Test

1. Disconnect ECM connector.
2. Measure wiring resistance between solenoid connector and ECM connector as follows.

SOLENOID CONNECTOR PIN	ECM CONNECTOR PIN	RESISTANCE
1	Connector J1B pin 22	Close to 0 $\Omega$



ECM JB1 CONNECTOR PIN OUT

If the solenoid circuit test failed, repair/replace wiring/connector.

#### Solenoid Replacement

1. Remove muffler. Refer to *EXHAUST SYSTEM* section.
  2. Remove the acoustic panel.
- NOTE:** Mark hose locations of RAVE solenoid for reinstallation.
3. Disconnect solenoid.
  4. Cut the locking ties retaining the coolant hoses to the plastic bracket.
  5. Remove solenoid screws.
  6. Cut the small Oetiker clamps securing the hoses to the solenoid.

For installation, reverse the removal procedure.

#### 3D RAVE VALVES POSITION SENSOR

##### 3D RAVE Valves Mid Position Resetting

1. Disconnect the RAVE valves vacuum/pressure hoses.
2. Connect vehicle to B.U.D.S., Refer to *COMMUNICATION TOOLS/B.U.D.S. SOFTWARE* section.
3. In the **Setting** tab, select **Set Mid** in the RAVE Mid Position box.

##### 3D RAVE Valves Position Sensor Diagnostic with B.U.D.S.

Whenever ECM detects a problem affecting the following, it will register a fault code.

- Defective position sensor


- Defective position sensor wiring
- Valves not reaching the desired position.

Refer to *COMMUNICATION TOOLS/B.U.D.S. SOFTWARE* for proper connection to vehicle.

For fault codes reading procedure and definition, refer to *MONITORING SYSTEM/FAULT CODES*.

### 3D Rave Valves Position Sensor Removal

1. Disconnect position sensor connector.
2. Remove 3D RAVE valves cover and link bar, see *3D RAVE VALVES REMOVAL* in this section.
3. Remove 3D RAVE valves position sensor.



1. Position sensor

**NOTE:** It is very important to perform *3D RAVE VALVES SYNCHRONIZATION* whenever link bar is removed. See procedure in this section.

### 3D Rave Valves Position Sensor Installation

1. Apply LOCTITE 243 (P/N 293 800 060) on screws threads and install position sensor with wiring upwards.
2. Install connector.
3. Position link bar on valve pistons and install nuts on piston threads but do not tighten yet.
4. Perform *3D RAVE VALVE SYNCHRONIZATION* procedure in this section to complete link bar installation. This step is very important.

# RAVE (797)

## SERVICE TOOLS

Description	Part Number	Page
VACUUM/PRESSURE PUMP .....	529 021 800 .....	137


## SERVICE PRODUCTS

Description	Part Number	Page
DREI BOND SEALING COMPOUND .....	420 297 906 .....	141
MOLYKOTE G-N .....	420 297 433 .....	140

## Section 02 ENGINE

### Subsection 12 (RAVE (797))

800R



## GENERAL

During assembly/installation, use torque values and service products as in the exploded view.

Clean threads before applying a threadlocker. Refer to *SELF-LOCKING FASTENERS PROCEDURE* and *LOCTITE APPLICATION PROCEDURE* at the beginning of this manual for complete procedure.

### **⚠ WARNING**

Torque wrench tightening specifications must be strictly adhered to.  
Locking devices (e.g.: locking tabs, elastic stop nuts, self-locking fasteners, cotter pins, etc.) must be replaced with new ones.

Hoses or cables removed or disconnected must be installed and routed at the same place.

**NOTICE** Locking ties removed during a procedure must be replaced and installed at the same location.

## SYSTEM DESCRIPTION

### 3D RAVE Basic Operation

3-step RAVE valves are used. Their positions vary according to engine operating condition.

The RAVE valve steps are:


- Fully closed
- Partially opened
- Fully opened.

RAVE valves are activated by 2 solenoids that are controlled by the ECM through mappings.

Many different mappings are used by the ECM to control the 3D RAVE valves. The mappings are based on current engine RPM, crankshaft rate of acceleration or deceleration and the following inputs: intake temperature, TPS, knock sensor, engine coolant temperature and APS.


**NOTE:** 3D RAVE valves may go through all 3 positions or skip the partially open position and go directly to either the fully open or closed positions depending how quickly the throttle is depressed and the engine load.

Solenoids use crankcase pulses (pressure and vacuum) to open or close the valves.



1. Vacuum solenoid
2. Pressure solenoid

An arrangement of check valves and Y-fittings allows to separate the crankcase vacuum pulses from the pressure pulses.





### **CHECK VALVE ORIENTATION**

1. Arrows on check valves
2. Arrows on Y-fittings

## Section 02 ENGINE



### Subsection 12 (RAVE (797))

#### 3D RAVE Position According to Engine Operation

ENGINE OPERATION	RAVE VALVE POSITION MEASURED FROM TOP OF GREEN BELLOW TO EDGE OF RAVE HOUSING	
Engine stopped	Partially open	 <p data-bbox="546 864 720 884">mbs2007-015-002_a</p> <p data-bbox="720 884 1186 914">A: Approximately 1 mm (1/32 in) down</p>
Idle to approximately 6200 RPM	Fully closed	 <p data-bbox="546 1455 720 1475">mbs2007-015-001_a</p> <p data-bbox="720 1475 1186 1504">A: Approximately 6 mm (1/4 in) down</p>



**Section 02 ENGINE**  
Subsection 12 (RAVE (797))

ENGINE OPERATION	RAVE VALVE POSITION MEASURED FROM TOP OF GREEN BELLOWS TO EDGE OF RAVE HOUSING	
Approximately 6200 to 7900 RPM (typical trail riding)	Partially opened	<p data-bbox="539 318 1028 350">NOTE: Same as engine stopped position.</p>  <p data-bbox="539 913 711 933">mbs2007-015-002_a</p> <p data-bbox="718 935 1182 965">A: Approximately 1 mm (1/32 in) down</p>
Approximately 7900 RPM to top RPM	Fully opened	 <p data-bbox="539 1548 711 1568">mbs2007-015-003_a</p> <p data-bbox="732 1570 1168 1600">A: Approximately 8 mm (5/16 in) up</p>

## Section 02 ENGINE

### Subsection 12 (RAVE (797))

#### Solenoid State According to Engine Operation

ENGINE OPERATION	VACUUM SOLENOID	PRESSURE SOLENOID	DIAGRAM
Engine stopped	OFF	OFF	<p>The diagram illustrates the state of the vacuum and pressure solenoids when the engine is stopped. Both solenoids are in the OFF position. The vacuum solenoid is closed, and the pressure solenoid is closed. The vacuum check valve is closed, and the pressure check valve is closed. The PTO RAVE and MAG RAVE lines are connected to the solenoids. The engine is shown with 'No pulse (PTO)' and 'No pulse (MAG)'.</p>
Idle to approximately 6200 RPM	ON	OFF	<p>The diagram illustrates the state of the vacuum and pressure solenoids when the engine is idle to approximately 6200 RPM. The vacuum solenoid is in the ON position, and the pressure solenoid is in the OFF position. The vacuum solenoid is open, and the pressure solenoid is closed. The vacuum check valve is open, and the pressure check valve is closed. The PTO RAVE and MAG RAVE lines are connected to the solenoids. The engine is shown with 'Pulse (PTO)' and 'Pulse (MAG)'.</p>

**Section 02 ENGINE**  
 Subsection 12 (RAVE (797))


ENGINE OPERATION	VACUUM SOLENOID	PRESSURE SOLENOID	DIAGRAM
Approximately 6200 to 7900 RPM (typical trail riding)	OFF	OFF	<p>The diagram illustrates the state of the vacuum and pressure solenoid systems when both are OFF. The vacuum solenoid is in the OFF position, allowing atmospheric air to flow through it. The pressure solenoid is also in the OFF position, allowing pressure to flow through it. The engine provides pulses to the PTO and MAG solenoids. Check valves are present on the vacuum and pressure lines.</p> <p><small>mmr2008-018-010_a</small></p>
Approximately 7900 RPM to top RPM	ON	ON	<p>The diagram illustrates the state of the vacuum and pressure solenoid systems when both are ON. The vacuum solenoid is in the ON position, blocking atmospheric air. The pressure solenoid is also in the ON position, blocking pressure. The engine provides pulses to the PTO and MAG solenoids. Check valves are present on the vacuum and pressure lines.</p> <p><small>mmr2008-018-011_a</small></p>

## Section 02 ENGINE

Subsection 12 (RAVE (797))

# TROUBLESHOOTING

## DIAGNOSTIC FLOW CHART



## TROUBLESHOOTING TIPS

### Intermittent Engine Performance Problem

If engine does not always reach maximum RPM:

- Make sure problem is not related with transmission (belt, drive and driven pulleys).
- Check 3D RAVE valves operation. Refer to *DIAGNOSTIC FLOW CHART* in this section.

**NOTE:** Make sure there are no fault codes (active or occurred).

### Solenoid Troubleshooting

Refer to the following table for engine behavior related to solenoid malfunction.

ENGINE RPM	VACUUM SOLENOID	PRESSURE SOLENOID	RAVE POSITION	ENGINE BEHAVIOR
Idle to approximately 6200 RPM	Defective	Defective	Partially open	Poor acceleration
	Defective	Functional	Partially open	Poor acceleration
	Functional	Defective	Fully closed	Normal operation
Approximately 6200 to 7900 RPM	Defective	Defective	Partially open	Normal operation
	Defective	Functional	Partially open	Normal operation
	Functional	Defective	Partially open	Normal operation
Approximately 7900 RPM to top RPM	Defective	Defective	Partially open	Cannot reach top RPM
	Defective	Functional	Fully open	Normal operation
	Functional	Defective	Fully closed	Cannot reach top RPM

## PROCEDURES

### 3D RAVE VALVE

#### 3D RAVE Valve Adjustment

There are no adjustments to be periodically checked.


#### 3D RAVE Valve Leak Test

**NOTE:** Test each RAVE individually.


1. Use the VACUUM/PRESSURE PUMP (P/N 529 021 800).



2. Unplug the RAVE inlet hose.
3. Install test pump on nipple and apply pressure. Piston should fully rise. Otherwise or if it lowers rather quickly, check bellow and seals inside RAVE valve.



4. Then, apply vacuum. Piston should fully lower. Otherwise or if it rises rather quickly, check bellow and seals inside RAVE valve.




## Section 02 ENGINE

### Subsection 12 (RAVE (797))


5. For check valves and solenoids leak tests, refer to *3D SOLENOIDS AND CHECK VALVES* in this section.

#### 3D RAVE Valves Removal

1. Remove LH side panel.
2. Remove *DRIVE BELT GUARD*. Refer to *DRIVE BELT* section.
3. Remove 3D RAVE valve cover by removing screws.



4. Remove screws securing the RAVE valve housing to cylinder block.
5. Pull valve assembly out.



**NOTE:** Be careful not to loose springs underneath housing.

#### 3D RAVE Valve Disassembly

1. Carefully remove spring retaining bellow to valve piston.




TYPICAL

2. Free bellow from valve piston.
3. Carefully unscrew valve piston then remove compression spring.


#### **⚠ WARNING**

Firmly hold valve piston. The compression spring inside the valve applies pressure against the piston.



TYPICAL

4. Carefully remove bellows from valve housing.  
**NOTE:** If oil is found in housing area, replace seals.
5. Extract RAVE valve from housing.
6. To remove seals, carefully pry them out.



### 3D RAVE Valve Cleaning

Clean carbon deposits. Cleaning intervals depend upon the user's riding style and the quality of the oil used.

BRP suggests annual cleaning of the valve. If a customer uses lower quality oil than recommended, more frequent cleaning may be required.

No special solvents or cleaners are required when cleaning the valve.

### 3D RAVE Valve Inspection

1. Check valves for breakage.

2. Check valves for wear at sliding points and straightness.




SIGNS OF WEAR

3. Check spring condition and straightness.  
**NOTE:** Oil dripping from draining hole indicates a loosen spring or damaged bellows.
4. Check for cracked, dried or perforated bellows.  
**NOTE:** Make sure hoses are not leaking, kinked or damaged.

### 3D RAVE Valve Assembly

1. Position parts as per illustrations.



1. Oil seal  
2. Gasket ring


## Section 02 ENGINE

### Subsection 12 (RAVE (797))




1. Lettering of oil seal on top


2. Use an appropriate pusher to reinstall seals.



5. Align springs on stud ends of valves.



3. Assemble together the main and side valves.




6. Apply MOLYKOTE G-N (P/N 420 297 433) to valve shaft and on seals in housing.

7. Install housing and carefully align springs on stud ends of housing.



4. Insert valves together in cylinder. Install gasket.





8. Install lower spring on bellow.
9. Apply DREI BOND SEALING COMPOUND (P/N 420 297 906) on the bellow's lower rib, then install bellow and spring.




1. Apply Drei Bond here
10. Install compression spring then tighten valve piston.
11. Apply DREI BOND SEALING COMPOUND (P/N 420 297 906) on valve piston groove.



1. Apply Drei Bond here
12. Position bellow on valve piston then secure top spring as follows.
  - 12.1 Attach a locking tie to spring.



- 12.2 Block valve piston with a suitable socket.



- 12.3 Position joint of spring under your thumb.
- 12.4 Hold spring with your thumb while sliding spring on the other side using the locking tie.

## Section 02 ENGINE

### Subsection 12 (RAVE (797))



1. Joint of spring under thumb

12.5 Continue sliding locking tie all around the edge of valve piston.




**NOTE:** Take care there is no strain in the bellow that could apply some bending force or torsion to the 3D RAVE valve. That may contribute to a RAVE valve jam.

13. Push and pull valve piston to make sure it moves freely.



14. When installing valve assembly in its housing, center valve horizontally and longitudinally then hand tighten screws.



15. Tighten screws and check valve for free movement again. If some friction is felt, slightly loosen screws and readjust housing then retighten screws.

16. Repeat the process until a free movement is obtained.

17. Start engine and recheck RAVE system operation.

18. Reinstall remaining parts.


## CHECK VALVES

### Check Valve Leak Test

1. Disconnect check valve.
2. Install test pump as shown.
3. Pressurize check valve to 34 kPa (5 PSI).
4. Valve should stand pressure.




5. Install test pump in the opposite side.
6. Pressurize check valve.
7. Air should flow freely.



8. Replace valve if any test failed.


### Check Valve Installation

Ensure to reinstall all check valves in the proper direction.



- CHECK VALVE ORIENTATION**
1. Arrows on check valves
  2. Arrows on Y-fittings

### SOLENOIDS



- TYPICAL**
1. RAVE solenoids


**NOTE:** First ensure the problem is not related with tubes connection and RAVE valves themselves.

### Solenoid Test with B.U.D.S.

1. Refer to *COMMUNICATION TOOLS AND B.U.D.S. SOFTWARE* section for proper connection to vehicle.
2. Using B.U.D.S. software, energize RAVE solenoids from Activation tab.

## Section 02 ENGINE

### Subsection 12 (RAVE (797))




#### TYPICAL


1. Activate here

3. This will validate the RAVE solenoid mechanical and electrical operation.
4. If the solenoid does not work, proceed with the voltage test.

### Solenoid Leak Test




SOLENOID OPERATION (OFF)



SOLENOID OPERATION (ON)

NOTE: Test each solenoid individually.


1. Unplug supply hose from solenoid.
2. Install test pump on solenoid nipple.
3. Supply 12 Vdc to solenoid terminals. Ensure to respect polarity.
4. Pressurize solenoid.



#### TEST PRESSURE

69 kPa to 103 kPa (10 PSI to 15 PSI)


5. Wait some time to see if pressure drops:
  - 5.1 If pressure does not build up or drops, replace solenoid.
  - 5.2 If pressure is maintained, continue testing.
6. Disconnect solenoid. Pressure should evacuate through upper nipple.



7. Unplug outlet hose from solenoid.
8. Install test pump on solenoid nipple. Pressurize to the same pressure as before.




9. Wait some time to see if pressure drops:
  - 9.1 If pressure does not build up or drops, replace solenoid.
  - 9.2 If pressure is maintained, continue testing.
10. Supply 12 Vdc to solenoid terminals. Ensure to respect polarity.
11. Pressure should evacuate through upper nipple.



12. If any test failed, replace solenoid.

### Solenoid Input Voltage Test

1. Remove muffler. Refer to *EXHAUST SYSTEM*.
2. Remove the acoustic panel.



3. Disconnect the connector from the solenoid.




4. Measure voltage on connector as follows.

## Section 02 ENGINE

### Subsection 12 (RAVE (797))

TEST PROBE		MEASUREMENT
Pin 2 (solenoid connector)	Engine ground	Battery voltage




5. If reading is not as per specification, perform the *SOLENOID CIRCUIT TEST*.

#### Solenoid Circuit Test

1. Disconnect ECM connector.
2. Measure wiring resistance as follows.

SOLENOID	SOLENOID CONNECTOR PIN	ECM CONNECTOR PIN	RESISTANCE
VACUUM	1	DA-13	Close to 0 $\Omega$
PRESSURE	1	DA-30	Close to 0 $\Omega$



3. If the solenoid circuit test failed, repair or replace wiring and connectors.

#### Solenoid Replacement

1. Remove muffler. Refer to *EXHAUST SYSTEM*.

2. Remove the acoustic panel.



3. Mark hose locations of RAVE solenoid then unplug them.
4. Disconnect solenoid.
5. Remove solenoid screws and solenoid.
6. For installation, reverse the removal procedure.

# TOP END (593)

## SERVICE TOOLS

<b>Description</b>	<b>Part Number</b>	<b>Page</b>
PISTON CIRCLIP INSTALLER.....	529 035 686 .....	154
RUBBER PAD .....	529 023 400 .....	154


## SERVICE PRODUCTS

<b>Description</b>	<b>Part Number</b>	<b>Page</b>
LOCTITE 243 (BLUE).....	293 800 060 .....	151
LOCTITE CHISEL (GASKET REMOVER) .....	413 708 500 .....	150

## Section 02 ENGINE


### Subsection 13 (TOP END (593))

500SS/600





**600 HO E-TEC**



## Section 02 ENGINE

### Subsection 13 (TOP END (593))

## GENERAL

Before completely disassembling the engine, check airtightness. Refer to *ENGINE LEAK TEST* subsection.

To measure internal parts, refer to *ENGINE MEASUREMENT* subsection.

During assembly/installation, use torque values and service products as in the exploded view.

Discard all gaskets and O-rings. Use LOCTITE CHISEL (GASKET REMOVER) (P/N 413 708 500) to clean mating surfaces.

Clean all metal components in a non-ferrous metal cleaner.

Clean threads before applying a threadlocker. Refer to *SELF-LOCKING FASTENERS* and *LOCTITE APPLICATION* at the beginning of this manual for complete procedure.

### ⚠ WARNING

Torque wrench tightening specifications must be strictly adhered to.


Locking devices (e.g.: locking tabs, elastic stop nuts, self-locking fasteners, cotter pins, etc.) must be replaced with new ones.

### 600 HO E-TEC Engine

After a repair involving major parts replacement, the break-in period must be restarted using B.U.D.S.

Use the latest B.U.D.S. software specific to the E-TEC engine. Refer to *COMMUNICATION TOOLS/B.U.D.S. SOFTWARE* for proper connection.

Select the **Setting** tab and click on the **Restart** button in the **Restart Break-in** box.



1. Click on **Restart**

### ⚠ WARNING

Always disconnect the magneto connector prior to:

- Disconnecting any fuel hose.
  - Removing a fuel injector.
  - Removing a spark plug cable or spark plug.
- Otherwise, if the engine is cranked, fuel vapors may ignite in presence of a spark creating a fire hazard.

## PROCEDURES

### REED VALVES

#### Reed Valve Removal

1. Remove carburetors or throttle bodies, refer to *FUEL SYSTEM* section.
2. Remove intake adapters, then reed valves.


#### Reed Valve Inspection

Check reed valve for proper tightness. There must not be any play between blade and valve body when exerting finger pressure on blade at blade stopper location.

If there is play, turn blade upside down and recheck. If there is still a play, replace blade and/or valve body.

**NOTE:** Blades have a curved shape. Install with their curve facing reed block.

Check distance from blade stopper's outer edge and distance from center of reed valve block.



#### TYPICAL

- A. 500SS engine: 14.75 - 0, + 0.75 mm (.580 - 0, + .030 in)  
600 HO E-TEC engine: 17.5 - 0, + 0.75 mm (.689 - 0, + .030 in)

Bend the blade stopper as required to obtain the proper distance.

### Reed Valve Installation

The installation is the reverse of the removal procedure.

**NOTE:** Blade stoppers may slightly interfere with cylinder during installation. Adjusted distance will be reduced automatically upon installation.

### CYLINDER HEAD COVER (500SS/600)

#### Cylinder Head Cover Removal


1. Remove LH side cover.
2. Remove tool kit support and drive belt guard.
3. Drain coolant, refer to *COOLING SYSTEM*.
4. Disconnect spark plugs cables and remove spark plugs.
5. Unplug coolant hoses from upper coolant socket.
6. Unscrew all cylinder head cover screws and the rear upper coolant socket screw, then remove cylinder head cover.

#### Cylinder Head Cover Inspection

Check cylinder head cover for cracks, warping or other damages. Replace if necessary.

#### Cylinder Head Cover Installation

1. Torque screws to 29N•m (21 lbf•ft) in the following illustrated sequence.



TYPICAL

2. Apply LOCTITE 243 (BLUE) (P/N 293 800 060) on the upper socket screw threads. Position the longer screw outwards (rear of engine).



TYPICAL  
 1. Longer screw

3. Install other removed components.
4. Refill cooling system, refer to *COOLING SYSTEM* section.

### CYLINDER HEAD (500SS/600)

#### Cylinder Head Removal

1. Remove the cylinder head cover as explained above.
2. Disconnect the temperature sensor connector.
3. Disconnect the carburetor or throttle body heater inlet hose at cylinder head.
4. Remove the cylinder head.

#### Cylinder Head Inspection

Check cylinder head for cracks, warp or other damages. Replace if necessary.

Refer to tables below to find cylinder head specifications. For dimension measurement procedures, refer to the *ENGINE MEASUREMENT* subsection.

#### Combustion Chamber volume

ENGINE	VOLUME
500SS/600	27.5 to 28.4 cc

#### Cylinder Head Warpage

ENGINE	MAXIMUM
500SS/600	0.5 mm (.02 in) for total length of cylinder head

## Section 02 ENGINE

### Subsection 13 (TOP END (593))

#### Cylinder Head Cleaning

Scrape off any carbon deposits from cylinder head.

#### Cylinder Head Installation

1. Install new rubber ring and round O-rings on each cylinder.
2. Replace O-rings around spark plug holes and on cylinder head border.
3. Install cylinder head cover as described above.

### CYLINDER HEAD (600 HO E-TEC)

#### Cylinder Head Removal

1. Remove LH side cover.
2. Remove tool kit support and drive belt guard.
3. Drain coolant, refer to *COOLING SYSTEM* section.
4. Refer to *FUEL SYSTEM* section and:
  - Release fuel pressure
  - Disconnect fuel lines.
5. Disconnect injectors electrical connectors.
6. Disconnect spark plugs cables.
7. Remove the knock sensor.
8. Disconnect the temperature sensor connector.
9. Unplug coolant hoses.
10. Disconnect the throttle body heater inlet hose at cylinder head.
11. Unscrew all cylinder head screws, then remove cylinder head.

#### Cylinder Head Inspection

Check cylinder head for cracks, warp or other damages. Replace if necessary.

Refer to tables below to find cylinder head specifications. For dimension measurement procedures, refer to the *ENGINE MEASUREMENT* subsection.

#### Combustion Chamber volume

ENGINE	VOLUME
600 HO E-TEC	25.3 to 27.6 cc

#### Cylinder Head Warpage

ENGINE	MAXIMUM
600 HO E-TEC	0.5 mm (.02 in) for total length of cylinder head


#### Cylinder Head Cleaning

Scrape off any carbon deposits from cylinder head.

#### Cylinder Head Installation

1. Install new rubber ring and round O-rings on each cylinder.
2. Torque cylinder head screws following the illustrated sequence.

CYLINDER HEAD SCREWS TORQUE	
FIRST STEP	15 N•m (133 lb•in)
SECOND STEP	29 N•m (21 lb•ft)



mmr209617-001\_a  
CYLINDER HEAD TORQUE SEQUENCE

3. Install other removed components.
4. Refill cooling system, refer to *COOLING SYSTEM* section.


### CYLINDERS

#### Cylinder Removal

1. Remove cylinder head as explained above.
2. Remove muffler, tune pipe and exhaust manifold. Refer to the *EXHAUST SYSTEM* subsection.
3. Remove acoustic panel.
4. Remove driven pulley and the countershaft bearing support, refer to the *DRIVEN PULLEY AND COUNTERSHAFT* subsection.
5. Disconnect carburetors or throttle bodies from intake adapters and set aside.

#### 600 HO E-TEC

6. Remove RAVE valves cover.
7. Remove RAVE valves link bar. Hold RAVE pistons with a wrench and remove the retaining nuts.



1. Valve link bar
2. Hold piston here
3. Retaining nut

8. Disconnect RAVE valves oil lines and vacuum/pressure hoses.

#### All Models

9. Unscrew cylinder screws and then remove the cylinder(s).

### Cylinder Inspection

Check cylinders for cracks and scoring on the top and bottom of cylinders. Replace if necessary.

Refer to tables below to find cylinder specifications. For dimension measurement procedures, refer to *ENGINE MEASUREMENT*.

#### Cylinder Taper

ENGINE	MAXIMUM
All 593	0.10 mm (.004 in)

#### Cylinder Out of Round

ENGINE	MAXIMUM
All 593	0.08 mm (.003 in)


### Cylinder Cleaning

Scrape off any carbon deposits from cylinder exhaust port.

### Cylinder Installation

Install new base gasket of the same thickness as the old one.

Identify gasket thickness using the identification holes on the gasket surface.



TYPICAL  
1. Identification holes

**NOTE:** The general procedure is to install a new gasket of the same thickness. However if you do not know the thickness of the gasket that was on the engine or if a crankcase and/or crankshaft repair was involved, measure the combustion chamber volume to choose the right gasket. Refer to the *ENGINE MEASUREMENT* subsection for procedure and *CYLINDER HEAD INSPECTION* in this subsection for specification.

**NOTICE** Always install a gasket of the proper thickness. Failure to do so may cause detonation and severe engine damage.

1. Lubricate cylinder wall with new injection oil or equivalent.
2. Install cylinders. Do not tighten.
3. Install new rubber ring and round O-rings on each cylinder.

**NOTE:** Carefully clean screws before reinstallation, specifically under screw head.

4. Install exhaust manifold with gaskets. Tighten screws just enough to obtain a snug contact between the cylinders and the manifold. Do not torque screws yet.
5. Torque cylinder screws in a crosswise sequence as per the following table.

M8	29 N•m (21 lbf•ft)
M10	40 N•m (30 lbf•ft)

6. Torque exhaust manifold screws to specification, refer to *EXHAUST SYSTEM* subsection.
7. On 593 E-TEC engines, refer to the *3D RAVE* subsection and install 3D RAVE link bar. The procedure must be strictly adhered to.
8. Install all other removed parts.


## Section 02 ENGINE

### Subsection 13 (TOP END (593))

## PISTONS

### Piston Removal

1. Remove cylinders, as explained above.
2. Place a clean cloth or RUBBER PAD (P/N 529 023 400) over crankcase. Then with a pointed tool inserted in piston notch, remove both circlips from piston.



TYPICAL

3. Push piston pin out of piston.
4. Remove piston.
5. Remove bearing.

### Piston Inspection

Inspect piston for scoring, cracking or other damage.


Refer to table below to find piston specifications. For dimension measurement procedures, refer to *ENGINE MEASUREMENT*.

MEASUREMENT		MAXIMUM
Ring/piston groove clearance	All 593	0.20 mm (.0079 in)
Ring end gap	All 593	1.0 mm (.039 in)
Piston/cylinder clearance	500SS/600	0.18 mm (.0071 in)
	600 HO E-TEC	0.20 mm (.008 in)

### Piston Cleaning

Scrape off any carbon deposits from piston dome.


**NOTE:** The arrow on the piston dome must be visible after cleaning.



Clean the piston ring groove with a groove cleaner tool or with a piece of broken ring.

### Piston Installation

1. Lubricate needle bearing with injection oil.
2. Insert bearing into connecting rod.
3. Place the piston over the connecting rod with the letters "AUS" (over an arrow on the piston dome) facing down to the exhaust port.



1. Exhaust

4. Push piston pin trough piston.

**NOTICE** Always install new circlips.

5. Use appropriate piston circlip installer to install mono-hook circlips.

ENGINE	TOOL
All 593	PISTON CIRCLIP INSTALLER (P/N 529 035 686)

6. Insert circlip into support so that, when installed in piston groove, the gap will be below the tab (see piston picture below).



7. With round end of pusher, position circlip perpendicular to the support axis.



8. With the other end of the pusher, push circlip into the support groove.




1. Groove



*CIRCLIP READY TO BE INSTALLED ON PISTON*

9. Using a plastic hammer, tap pusher to put circlip in place.

**NOTE:** Make sure to install new circlips with the gap below the tab exactly as shown on the following photo.



*GAP BELOW THE TAB*

## Section 02 ENGINE

### Subsection 13 (TOP END (593))

**NOTICE** Always install new mono-hook circlips. If circlip installation fails at the first attempt, always retry with a new one because, on a second attempt, the circlip will lose its normal retaining capabilities.

**NOTICE** Circlips must not move freely after installation; if so, replace them.

10. Install all other removed parts.




Diagram showing the installation of a circlip onto a shaft.




Diagram showing the installation of a circlip onto a shaft.



Diagram showing the installation of a circlip onto a shaft.






# TOP END (797)

## SERVICE TOOLS

Description	Part Number	Page
PISTON CIRCLIP INSTALLER.....	529 036 138 .....	161
RUBBER PAD .....	529 023 400 .....	160

## SERVICE PRODUCTS


Description	Part Number	Page
LOCTITE CHISEL (GASKET REMOVER) .....	413 708 500 .....	159



## Section 02 ENGINE

### Subsection 14 (TOP END (797))

800R



## GENERAL

Before completely disassembling the engine, check airtightness. Refer to *ENGINE LEAK TEST* section.

Discard all gaskets and O-rings. Use LOCTITE CHISEL (GASKET REMOVER) (P/N 413 708 500) to clean mating surfaces.

Clean all metal components in a non-ferrous metal cleaner.

To measure internal parts, refer to *ENGINE MEASUREMENT* section.

During assembly or installation:

- Hoses, cables and locking tie removed must be reinstalled at the same place.
- Use torque values and service products as in the exploded view.
- Clean threads before applying a threadlocker. Refer to the *INTRODUCTION* at the beginning of this manual for complete procedure.

### **⚠ WARNING**

Torque wrench tightening specifications must be strictly adhered to. Locking devices (e.g.: locking tabs, elastic stop nuts, self-locking fasteners, cotter pins, etc.) must be replaced with new ones.

After a repair involving major parts replacement, a break-in period must be observed.

To assure additional protection during the engine break-in, 500 ml (17 U.S. oz) of recommended injection oil should be added to a full fuel tank.

**NOTICE** Always observe a break-in period as described in the *OPERATOR'S GUIDE*.

## PROCEDURES

### REED VALVES

#### Reed Valve Removal

1. Remove carburetors, refer to *FUEL SYSTEM* section.
2. Unscrew screws retaining intake adapters then remove reed valves.

#### Reed Valve Inspection

1. Check reed valve for proper tightness. There must not be any play between blade and valve body when exerting a finger pressure on blade at blade stopper location.


2. In case of a play, turn blade upside down and recheck. If there is still a play, replace blade and/or valve body.

**NOTE:** Blades have a curved shape. Install with their curve facing reed block.


#### Reed Valve Installation

The installation is the reverse of the removal procedure. Pay attention to the following.

1. Ensure to position reed valves so that they rest flat in intake opening.



2. Ensure to position intake adapter as shown.



## CYLINDER HEAD

### Cylinder Head Removal

1. Remove *DRIVE BELT GUARD*. Refer to *DRIVE BELT* section.

## Section 02 ENGINE

### Subsection 14 (TOP END (797))

2. Drain coolant, refer to *COOLING SYSTEM* section.
3. Remove spark plugs.
4. Remove the knock sensor.
5. Disconnect the temperature sensor connector.
6. Unplug coolant hoses from upper coolant socket.
7. Unplug carburetor heater inlet hose from cylinder head.
8. Unscrew all cylinder head screws.
9. Remove the cylinder head.

### Cylinder Head Inspection

Check cylinder head for cracks or other damages. Replace if necessary.

### Cylinder Head Warpage

**NOTE:** Refer to *ENGINE MEASUREMENT* for the measurement procedures.


ENGINE	MAXIMUM
797	0.05 mm (.002 in) per 50 mm (2 in) of surface
	0.5 mm (.02 in) for total length of cylinder head

### Cylinder Head Cleaning

Scrape off carbon formation from cylinder head.

### Cylinder Head Installation

1. Install **NEW** rubber ring and round O-rings on each cylinder.
2. Install and tighten cylinder head screws.
  - 2.1 As a first step, torque screws following the illustrated sequence to 15 N•m (133 lbf•in).
  - 2.2 Then, torque screws following the same sequence to 29 N•m (21 lbf•ft).




3. Reinstall knock sensor. Refer to *IGNITION SYSTEM* section.
4. Reinstall all other removed parts.


## PISTONS

### Piston Removal

1. Remove *CYLINDER BLOCK*, as explained below.
2. Place a clean cloth or the RUBBER PAD (P/N 529 023 400) over crankcase.



3. Using a pointed tool inserted in piston notch, remove one circlip from piston. Discard circlip.



TYPICAL

4. Push piston pin out of piston.
5. Remove piston.
6. Remove bearing.

### Piston Inspection

For dimension measurement procedures, refer to *ENGINE MEASUREMENT* section.

### Piston Cleaning

1. Scrape off carbon formation from piston dome.

**NOTE:** The arrow on the piston dome must be visible after cleaning.



2. Clean the piston ring groove with a groove cleaner tool or with a piece of broken ring.

### Piston Installation

1. Lubricate needle bearing with injection oil.
2. Insert bearing into connecting rod.
3. At assembly, place the pistons over the connecting rods with the arrow on the piston dome facing towards the exhaust port.



EXHAUST DIRECTION INDICATION

4. Install piston pin in piston.
5. Install a **NEW** circlip (two with a new piston) using the PISTON CIRCLIP INSTALLER (P/N 529 036 138).

**NOTICE** Always install **NEW** mono-hook circlip(s). If circlip installation fails at the first attempt, always retry with a new one.

6. Use the following procedure to use the piston circlip installer correctly.
  - 6.1 Insert circlip into support so that, when installed in piston groove, the gap will be below the tab (see piston picture below).

## Section 02 ENGINE

### Subsection 14 (TOP END (797))



- 6.2 With round end of pusher, position circlip perpendicularly to the support axis.



- 6.3 With the other end of the pusher, push circlip into the support groove.




1. Groove



CIRCLIP READY TO BE INSTALLED ON PISTON

- 6.4 Using a plastic hammer, tap pusher to put the new circlip in place.

**NOTE:** Make sure to install new circlip(s) with the gap below the tab exactly as shown on the following photo.



TAB TOWARD TOP

**NOTICE** Circlips must not move freely after installation; if so, replace them.

7. Install all other removed parts.

## CYLINDER BLOCK

### Cylinder Block Removal

1. Remove *CYLINDER HEAD* as explained above.
2. Remove muffler, tune pipe and exhaust manifold, refer to *EXHAUST SYSTEM* section.
3. Remove acoustic panel.
4. Remove driven pulley and the counter-shaft bearing support, refer to *DRIVE SYSTEM/BRAKE*.

5. Disconnect carburetors from intake adapters and set aside.
6. Remove the clamp that supports the RAVE valve hose to the intake adapter on MAG side.
7. Unplug RAVE valve hose from pressure solenoid.
8. Unscrew cylinder screws then remove the cylinder block.

### Cylinder Block Inspection

1. Remove RAVE valves, refer to *3D RAVE VALVES REMOVAL* in this section.
2. Remove reed valves, refer to *REED VALVES REMOVAL* in this section.
3. Check cylinders for cracks and scoring on the top and bottom of cylinders. Replace if necessary.

**NOTE:** Refer to *ENGINE MEASUREMENT* for the measurement procedures.

### Cylinder Taper

CYLINDER TAPER	
SERVICE LIMIT	0.1 mm (.004 in)

### Cylinder Out of Round

CYLINDER OUT OF ROUND	
SERVICE LIMIT	0.08 mm (.003 in)

### Cylinder Block Cleaning

Scrape off carbon formation from exhaust ports.


### Cylinder Block Installation

1. Install dowel pins in crankcase holes.



2. Install a **NEW** base gasket of the same thickness as the old one.

3. Identify gasket thickness by the identification holes on the gasket surface.



### TYPICAL

1. Identification holes

**NOTE:** The general procedure is to install a new gasket of the same thickness. However if you do not know the thickness of the gasket that was on the engine or if a crankcase and/or crankshaft repair was involved, measure the combustion chamber volume to choose the right gasket, refer to *ENGINE MEASUREMENT*.


**NOTICE** Always install a gasket of the proper thickness. Failure to do so may cause detonation and severe engine damage.

4. Before inserting piston in cylinder, lubricate the cylinder with new injection oil or equivalent.
5. Carefully slide cylinder block down while squeezing piston rings to allow cylinder insertion. Proceed one piston at a time, the help of an assistant may be required. Do not tighten cylinder block yet.
6. Carefully clean screws before reinstallation, specifically under screw head.
7. Install and tighten cylinder block screws.
  - 7.1 As a first step, torque screws following the illustrated sequence to 25 N•m (18 lbf•ft).
  - 7.2 Then, torque screws following the same sequence to 50 N•m (37 lbf•ft).

**NOTE:** When a torquing sequence is done, re-torque the middle screws.

## Section 02 ENGINE

### Subsection 14 (TOP END (797))



8. Install all other removed parts.

1. Inspect the cylinder head for any damage and repair as needed.

2. Remove the intake and exhaust valves from the cylinder head and inspect the valves for any damage and repair as needed.

3. Install the intake and exhaust valves into the cylinder head and torque the valves to the specified torque.

4. Install the intake and exhaust manifolds onto the cylinder head and torque the manifolds to the specified torque.

Cylinder Block Inspection

1. Remove the cylinder block and inspect the block for any damage and repair as needed.

2. Inspect the cylinder walls for any scoring or wear and measure the cylinder diameter at the top and bottom of the cylinder.

3. Check the piston rings for any damage and inspect the rings for any wear.

4. Check the cylinder head for any damage and inspect the head for any wear.

5. Check the timing belt for any damage and inspect the belt for any wear.

NOTE: Always inspect a group of the timing belt. Failure to do so may result in poor timing and engine damage.

Cylinder Head

CYLINDER HEAD	
INLET VALVE	OUTLET VALVE

CYLINDER OUT OF BLOCK	
INLET VALVE	OUTLET VALVE

Cylinder Head Cleaning

Scrub the crown surface for exhaust side.

Cylinder Block Installation

1. Check the block for any damage and inspect the block for any wear.



2. Check the timing belt for any damage and inspect the belt for any wear.



## BOTTOM END (593)

### SERVICE TOOLS

Description	Part Number	Page
BEARING HEATER .....	529 035 969 .....	176
BEARING INSTALLER .....	259 035 980 .....	177
	259 035 990 .....	177
BEARING PULLER .....	420 877 635 .....	175
CERAMIC SEAL INSTALLER.....	529 036 014 .....	171-172
CRANKSHAFT PROTECTOR.....	420 876 552 .....	175
	420 876 557 .....	175
DISTANCE GAUGE.....	529 035 966 .....	177
	529 035 968 .....	177
HALF RINGS.....	420 977 479 .....	174
INDICATOR STICK.....	529 035 970 .....	176
OIL SEAL PROTECTOR.....	529 035 822 .....	172
OIL SEAL PUSHER.....	529 035 757 .....	171
PULLER RING .....	420 977 494 .....	174
SCREWS.....	420 840 681 .....	175
SUPPORT PLATE.....	529 035 976 .....	177

### SERVICE TOOLS – OTHER SUPPLIER

Description	Part Number	Page
SNAP-ON BEARING SEPARATOR.....	CJ 951 .....	175
SNAP-ON MANUAL IMPACT DRIVER .....	PIT120 .....	173
SPX/OTC BEARING SEPARATOR.....	1124 .....	175


### SERVICE PRODUCTS

Description	Part Number	Page
ISOFLEX GREASE .....	293 550 021 .....	178
LOCTITE 5910 .....	293 800 081 .....	173
LOCTITE 767 (ANTISEIZE LUBRICANT) .....	293 800 070 .....	176
LOCTITE CHISEL.....	413 708 500 .....	173
PULLEY FLANGE CLEANER .....	413 711 809 .....	176
XP-S LUBE.....	293 600 016 .....	175


## Section 02 ENGINE

### Subsection 15 (BOTTOM END (593))

500SS/600



600 HO E-TEC



m/m2000-064-002\_a

## Section 02 ENGINE

### Subsection 15 (BOTTOM END (593))

## GENERAL

Before completely disassembling the engine, check airtightness. Refer to *ENGINE LEAK TEST*.

All oil seals and gaskets must be discarded and replaced with new ones when crankcase is split.

During assembly/installation, use torque values and service products as in the exploded view.

Clean threads before applying a threadlocker. Refer to *SELF-LOCKING FASTENERS* and *LOCTITE APPLICATION* at the beginning of this manual for complete procedure.

### **⚠ WARNING**

Torque wrench tightening specifications must be strictly adhered to.

Locking devices (e.g.: locking tabs, elastic stop nuts, self-locking fasteners, cotter pins, etc.) must be replaced with new ones.

### *500SS/600*

After a repair involving major parts replacement, a break-in period must be observed.

To assure additional protection during the engine break-in, 500 ml (17 U.S. oz) of recommended injection oil should be added to a full fuel tank.


**NOTICE** Always observe a break-in period as described in the *OPERATOR'S GUIDE*.

### *600 HO E-TEC*

After a repair involving major parts replacement, a break-in period must be observed.

Use the latest B.U.D.S. software available on BOSSWeb and restart the break-in period. Refer to *COMMUNICATION TOOLS/B.U.D.S. SOFTWARE* for proper connections.

Select the **Setting** tab and click on the **Restart** button in the **Restart Break-in** box.



1. Click on **Restart**

**NOTICE** Always observe a break-in period as described in the *OPERATOR'S GUIDE*.

## PROCEDURES

### WATER PUMP

#### Water Pump Impeller Removal

##### Engine In Vehicle

Remove hood, bottom pan cover and RH panel refer to the *BODY* section.

Remove tune pipe and muffler. Refer to *EXHAUST SYSTEM*.

Remove acoustic panel.

Put a large drain pan under vehicle bottom pan.

Remove starter as necessary. Refer to the *STARTING SYSTEM* section.

Refer to *ENGINE OUT OF VEHICLE* to complete procedure.

##### Engine Out of Vehicle


Remove pump housing no. 5.



TYPICAL

Remove impeller no. 6 by turning it counterclockwise.

**NOTICE** Be careful not to damage impeller fins.



TYPICAL

Clean gasket surfaces of pump housing and crankcase.

### Water Pump Impeller Installation

Install a new gasket.

Reverse removal procedure.

### Ceramic Seal Replacement

The water pump shaft must be removed to replace the ceramic seal. Refer to *WATER PUMP SHAFT*.

## WATER PUMP SHAFT

### Water Pump Shaft Removal


**NOTE:** It is not necessary to split crankcase to pull out shaft.

Remove engine from vehicle. Refer to *ENGINE REMOVAL AND INSTALLATION* section.

Remove oil injection pump (500SS/600) or cover plate (600 HO E-TEC).

Remove water pump housing and impeller. Refer to *WATER PUMP*.


Remove bearing housing screws no. 7.



TYPICAL

1. Screws

From the opposite side of water pump housing, push shaft out while turning shaft to release it from worm gear.




1. Push out shaft here

Then, extract shaft.

## Section 02 ENGINE

### Subsection 15 (BOTTOM END (593))




TYPICAL

### Water Pump Shaft Disassembly

**NOTICE** Pay attention not to damage the bearing housing no.8 during disassembly. Marks or other damages will lead to coolant and/or oil leaking.

**NOTE:** For disassembly/assembly procedure a press is required.

Protect the threads of shaft with a suitable M8 nut. Properly support bearing housing and push shaft out.



1. M8 nut
2. Shaft

**NOTICE** When removing water pump shaft, always replace ceramic seal no.9 and oil seal no.10. Ceramic seal cannot be removed without damage.

Pry inner part of ceramic seal no.9 out.



Push out bearing no. 11 from the bearing housing using an appropriate pusher.



Push oil seal no. 10 out.



Carefully press the outer part of ceramic seal out.  
**NOTE:** Use a mandrel with a diameter of approximately 16 mm (.63 in).

### Water Pump Shaft Assembly


Reverse disassembly procedure and pay attention to the following.

**NOTE:** Never put oil in the press fit area of the oil seal and ceramic seal.


Push the new oil seal no. 10 in bearing housing using the OIL SEAL PUSHER (P/N 529 035 757).



1. 16 mm (.63 in) mandrel



Press bearing no. 11 into bearing housing no. 8.



1. Outer part of ceramic seal

Remove sealant from bearing housing with sand paper no. 180.



Push the new ceramic seal no. 9 in bearing housing no. 8 using the CERAMIC SEAL INSTALLER (P/N 529 036 014).



1. Remove sealant

To extract bearing no. 12 either use a hammer puller or an appropriate pusher.


## Section 02 ENGINE

### Subsection 15 (BOTTOM END (593))



**NOTICE** Never use a hammer for the ceramic seal installation. Only use a press to avoid damaging the ceramic component.

Put OIL SEAL PROTECTOR (P/N 529 035 822) on water pump shaft no. 13.




1. Water pump shaft
2. Oil seal protector

Press water pump shaft no. 13 into the bearing housing no. 8 with appropriate force.

**NOTICE** Inadequate force will damage the oil seal no. 10 and bearing no. 11.

**NOTE:** During installation support the ceramic seal using the CERAMIC SEAL INSTALLER (P/N 529 036 014) as shown on the following illustration.



1. Water pump shaft
2. Bearing housing
3. Ceramic seal installer

Remove oil seal protector from water pump shaft.

### Water Pump Shaft Installation

Clean gasket surfaces of pump housing and crankcase.

Pour 50 ml (1.7 U.S. oz) of injection oil in the cavity under worm gear to lubricate pump gearing.

Install water pump shaft assembly in crankcase while turning shaft to mesh gears.

Torque bearing housing screws no. 7.

After impeller installation, ensure shaft turns properly.

Install a new pump housing gasket.

Torque water pump housing screws in a criss-cross sequence.

Reinstall oil injection pump (500SS/600) or cover plate (600 HO E-TEC).

## CRANKCASE

### Crankcase Disassembly

Remove engine from vehicle. Refer to *ENGINE REMOVAL AND INSTALLATION*.

Remove cylinder head and cylinders. Refer to *TOP END (593)*.

Remove rewind starter. Refer to *REWIND STARTER*.




Remove trigger coils (500SS/600) or crankshaft position sensor (600 HO E-TEC), magneto flywheel and stator. Refer to *MAGNETO SYSTEM*.

Remove front engine supports.

Remove drive pulley. Refer to *DRIVE SYSTEM AND BRAKE*.

Remove PTO oil seal cover no. 1.

**NOTE:** Tap screw heads to break the Loctite bond or use a SNAP-ON MANUAL IMPACT DRIVER (P/N PIT120).



TYPICAL

Remove all screws that retain crankcase halves together.

Split crankcase and remove crankshaft.

Clean all metal components in a non-ferrous metal cleaner. Use LOCTITE CHISEL (P/N 413 708 500) accordingly.

**NOTICE** Never use a sharp object to scrape away old sealant as score marks incurred are harmful to crankcase sealing.

### Crankcase Inspection

Check crankcase for cracks or other damages. Replace if necessary.

### Crankcase Assembly



Install crankshaft in lower crankcase. See *CRANKSHAFT* for procedure.

Apply LOCTITE 5910 (P/N 293 800 081) on crankcase halves. Proceed as follows.

**IMPORTANT:** The total assembly sequence, including sealing compound application and crankcase torquing, must be performed within 10 minutes.

Use a plexiglass plate and apply some sealant on it. Use a 50 - 75 mm (2 - 3 in) soft rubber roller and spread the sealant to get a thin uniform coat on the plate (spread as necessary).

When ready, apply the sealant on crankcase mating surfaces.




**NOTE:** If you do not use the roller method, you may use your finger to uniformly distribute the sealant.

Assemble both crankcase halves.

As a first step, torque screws to 18N•m (159 lbf•in) as per following illustrated sequence.


## Section 02 ENGINE

### Subsection 15 (BOTTOM END (593))



Repeat torquing sequence and this time torque screws to 29 N•m (21 lbf•ft).

Finish by torquing the following crankcase screws to 9 N•m (80 lbf•in).



Install PTO oil seal cover (600 HO E-TEC engine).

## CRANKSHAFT

### Crankshaft Removal

To remove crankshaft, use crankcase disassembly procedure.

### Crankshaft Inspection

Check crankshaft bearings. They must turn smoothly and without noise. Replace as required.

Refer to table below to find crankshaft dimension specifications. For dimension measurement procedures, refer to *ENGINE MEASUREMENT*.

ENGINE MEASUREMENT	TOLERANCES		
	NEW PARTS (min.) (max.)		WEAR LIMIT
Crankshaft deflection on PTO side	N.A.	0.06 mm (.002 in)	N.A.
Crankshaft deflection on MAG side	N.A.	0.05 mm (.002 in)	N.A.
Crankshaft deflection in center of crankshaft	N.A.	0.08 mm (.003 in)	N.A.
Connecting rod big end axial play	500SS/600		
	0.35 mm (.014 in)	0.74 mm (.029 in)	1.20 mm (.047 in)
	600 HO E-TEC		
	0.28 mm (.011 in)	0.68 mm (.027 in)	1.20 mm (.047 in)
Crankshaft end-play	0.10 mm (.004 in)	0.30 mm (.012 in)	N.A.

### Crankshaft Bearing Removal

**NOTE:** Normally it takes approximately 10 minutes to heat up a bearing so in the event of replacing bearing, it's recommended to start the bearing heating process prior to removal operation. See procedure further.

To remove bearings no. 2 and no. 3 from crankshaft no. 4, install HALF RINGS (P/N 420 977 479) and PULLER RING (P/N 420 977 494) on the outer bearing.



1. Half ring
2. Puller ring

**NOTE:** Apply some grease on crankshaft end to hold in place the CRANKSHAFT PROTECTOR (P/N 420 876 552) on PTO side and CRANKSHAFT PROTECTOR (P/N 420 876 557) on MAG side.

Using SCREWS (P/N 420 840 681), install BEARING PULLER (P/N 420 877 635) on the half rings.

Secure the bearing puller in a vise by one of its rib.




**BEARING PULLER SECURED IN THE VISE**

**NOTICE** Never use any air impact tool for tightening the puller bolt. Lubricate the bolt with XP-S LUBE (P/N 293 600 016) to avoid damaging the threads.

Screw in the puller bolt until the bearing comes out.

Follow the same procedure for the inner bearing.

**NOTE:** In the case of damaged bearing or less clearance between crankshaft counterbalance and the bearing or on the MAG side bearing, use SNAP-ON BEARING SEPARATOR (P/N CJ 951) or SPX/OTC BEARING SEPARATOR (P/N 1124) to facilitate the removal.



1. Bearing separator

### Crankshaft Bearing Installation


Inspect crankshaft ends for damage.

Clean crankshaft ends with sand paper no. 180 to remove possible seal marks and debris.




## Section 02 ENGINE

### Subsection 15 (BOTTOM END (593))



Remove all residue using PULLEY FLANGE CLEANER (P/N 413 711 809).

Smear LOCTITE 767 (ANTISEIZE LUBRICANT) (P/N 293 800 070) on crankshaft bearing mounting area.



#### Bearing Heating

Heat up the bearing(s) using BEARING HEATER (P/N 529 035 969). This will expand bearings and ease installation. If required, put a suitable plate or shim to avoid the direct contact between integrated seal with the heating surface.



**NOTICE** Bearing(s) should not be heated to more than 80°C (176°F). Do not heat bearing(s) with direct flame, or with a heat gun or soaked in a heated oil bath. Inappropriate bearing(s) heating may result in inner seals or cage failure.

For even heat distribution, turn bearing several times during heating process.

**NOTE:** Two bearings can be heated at the same time on one bearing heater.



1. Bearings

Probe the side of the inner race of the bearing with the temperature INDICATOR STICK (P/N 529 035 970). Stick will liquefy when the bearing reach the proper temperature.



A32CB9A

**WARNING**

Do not touch heated bearing with bare hands. Always wear heat resisting gloves before handling the heated bearing(s).

**NOTICE** Never reinstall a bearing that has been removed.

**PTO Side Bearings**

Slide in the inner PTO bearing with the integrated seal facing crankshaft. Push bearing to end position.




A32CAVA

**NOTE:** Heated bearing should slide easily onto the crankshaft. If required, push with a BEARING INSTALLER (P/N 259 035 990) on the inner ring of the bearing. Pay special attention to correct positioning of the locating pins and/or retaining discs.

Install retaining discs.

Install SUPPORT PLATE (P/N 529 035 976) with appropriate distance gauge; refer to following table.

TOOL	ENGINE
DISTANCE GAUGE (P/N 529 035 966)	500SS/600
DISTANCE GAUGE (P/N 529 035 968)	600 HO E-TEC



A32CBCA

- 1. Support plate
- 2. Distance gauge

Install bearing locator tool.



A32CAVA

Slide the heated outer PTO bearing onto the crankshaft until it contacts the distance gauge.

**MAG Side Bearings**

Slide the first MAG bearing with the integrated seal facing crankshaft until it bottoms on crankshaft shoulder.

**NOTE:** Heated bearing should slide easily onto the crankshaft. If required, push with a BEARING INSTALLER (P/N 259 035 980) on the inner ring of the bearing.

## Section 02 ENGINE

### Subsection 15 (BOTTOM END (593))




Slide-in the second bearing until it contacts the first one.



### Crankshaft Installation


At crankshaft installation, position locating pins as illustrated.



#### TYPICAL

1. Position pins

Pour 50 ml (1.7 U.S. oz) of injection oil in the pan under worm gear to lubricate worm gear as per photo.



1. Oil bath

Apply ISOFLEX GREASE (P/N 293 550 021) as per following procedure:

**NOTICE** Use only the recommended grease. Make sure not to push grease between the outside bearing race and the crankcase half.

Put the following quantity of grease in a syringe.

ENGINE	QUANTITY OF GREASE
500SS/600	42 ± 5 ml (1.4 U.S. oz)
600 HO E-TEC	30 ± 5 ml (1 U.S. oz)

**NOTE:** The 50 g tube corresponds to 50 ml of grease.

**NOTICE** Do not exceed the recommended amount of grease.


Fill inner side of PTO side bearing with grease (about 10 ml (.3 U.S. oz))



A33C15A

*PTO SIDE BEARING FILLED WITH GREASE*

With the syringe, fill the outer ball bearing and inner side of outer seal with the remaining of grease.



A33C17A

*TYPICAL — FILL WITH GREASE AND SET IN PLACE*

Apply 6 ml (.2 U.S. oz) of grease to MAG side outer bearing.

**NOTE:** If replaced with new bearing, do not apply grease as new bearings come with grease already applied.

Proceed with crankcase assembly. Refer to *CRANKCASE*.



A33C16A

*BALLS COATED WITH A SEAM OF GREASE*

## BOTTOM END (797)

### SERVICE TOOLS

Description	Part Number	Page
BEARING HEATER .....	529 035 969 .....	192
BEARING PULLER .....	529 036 004 .....	191
CERAMIC SEAL INSTALLER.....	529 036 014 .....	186
DISTANCE GAUGE.....	529 036 060 .....	194
INDICATOR STICK.....	529 035 970 .....	193
OIL SEAL PROTECTOR.....	529 035 822 .....	186
OIL SEAL PUSHER.....	529 035 757 .....	185
SCREWS.....	420 840 681 .....	191

### SERVICE TOOLS – OTHER SUPPLIER

Description	Part Number	Page
SNAP-ON BEARING SEPARATOR.....	CJ 951 .....	191
SNAP-ON MANUAL IMPACT DRIVER .....	PIT120 .....	187
SPX/OTC BEARING SEPARATOR.....	1124 .....	191

### SERVICE PRODUCTS


Description	Part Number	Page
ISOFLEX GREASE .....	293 550 021 .....	195
LOCTITE 5910 .....	293 800 081 .....	188
LOCTITE 767 (ANTISEIZE LUBRICANT) .....	293 800 070 .....	192
LOCTITE CHISEL.....	413 708 500 .....	188
PULLEY FLANGE CLEANER .....	413 711 809 .....	192
XP-S LUBE.....	293 600 016 .....	191



## Section 02 ENGINE

### Subsection 16 (BOTTOM END (797))

800R



## GENERAL

Before completely disassembling the engine, check airtightness. Refer to *ENGINE LEAK TEST*.

All oil seals and gaskets must be discarded and replaced with new ones when crankcase is split.

During assembly/installation, use torque values and service products as in the exploded view.

Clean threads before applying a threadlocker. Refer to *SELF-LOCKING FASTENERS* and *LOCTITE APPLICATION* at the beginning of this manual for complete procedure.

### **WARNING**

Torque wrench tightening specifications must be strictly adhered to.

Locking devices (e.g.: locking tabs, elastic stop nuts, self-locking fasteners, cotter pins, etc.) must be replaced with new ones.

After a repair involving major parts replacement, a break-in period must be observed.

To assure additional protection during the engine break-in, 500 ml (17 U.S. oz) of recommended injection oil should be added to a full fuel tank.

**NOTICE** Always observe a break-in period as described in the *OPERATOR'S GUIDE*.

## PROCEDURES

### WATER PUMP

#### Water Pump Impeller Removal

##### Engine In Vehicle

Remove hood, bottom pan cover and RH panel. Refer to the *BODY* section.

Remove tune pipe and muffler. Refer to *EXHAUST SYSTEM*.

Remove acoustic panel.


Put a large drain pan under vehicle bottom pan.

Remove starter, refer to the *STARTING SYSTEM* section.

Refer to *ENGINE OUT OF VEHICLE* to complete procedure.

##### Engine Out of Vehicle


Remove pump housing no. 5.



TYPICAL

Remove impeller no. 6 by turning it counterclockwise.

**NOTICE** Be careful not to damage impeller fins.



TYPICAL

Clean gasket surfaces of pump housing and crankcase.

#### Water Pump Impeller Installation

Install a new gasket.

Reverse removal procedure.

#### Ceramic Seal Replacement

The water/oil pump shaft must be removed to replace the ceramic seal. Refer to *WATER/OIL PUMP SHAFT*.

## Section 02 ENGINE

### Subsection 16 (BOTTOM END (797))

## WATER/OIL PUMP SHAFT

### Water/Oil Pump Shaft Removal


**NOTE:** It is not necessary to split crankcase to pull out shaft.

Remove engine from vehicle Refer to *ENGINE REMOVAL AND INSTALLATION* section.

Remove oil injection pump.


Remove water pump housing and impeller. Refer to *WATER PUMP*.

Remove bearing housing screws no. 7.



TYPICAL  
1. Screws

From oil injection pump side, push shaft out while turning shaft to release it from worm gear.




TYPICAL

## Water/Oil Pump Shaft Disassembly

**NOTICE** Pay attention not to damage the bearing housing no.8 during disassembly. Marks or other damages will lead to coolant and/or oil leaking.

**NOTE:** For disassembly/assembly procedure a press is required.

Protect the threads of shaft with a suitable M8 nut. Properly support bearing housing and push shaft out.



1. M8 nut  
2. Shaft

**NOTICE** When removing water/oil pump shaft, always replace ceramic seal no.9 and oil seal no.10. Ceramic seal cannot be removed without damage.

Pry inner part of ceramic seal no.9 out.



Push out bearing no. 11 from the bearing housing using an appropriate pusher.



A35C4BA

Push oil seal no. 10 out.



A35C1GA


Carefully press the outer part of ceramic seal out.

**NOTE:** Use a mandrel with a diameter of approximately 16 mm (.63 in).



A35C4CA

1. 16 mm (.63 in) mandrel



A35C4DA

1. Outer part of ceramic seal

Remove sealant from bearing housing with sand paper no. 180.



A35C4EA

1. Remove sealant

To extract bearing no. 12 either use a hammer puller or an appropriate pusher.

### Water/Oil Pump Shaft Assembly


Reverse disassembly procedure and pay attention to the following.

**NOTE:** Never put oil in the press fit area of the oil seal and ceramic seal.

Push the new oil seal no. 10 in bearing housing using the OIL SEAL PUSHER (P/N 529 035 757).

## Section 02 ENGINE

### Subsection 16 (BOTTOM END (797))



Press bearing no. 11 into bearing housing no. 8.




Push the new ceramic seal no. 9 in bearing housing no. 8 using the CERAMIC SEAL INSTALLER (P/N 529 036 014).



**NOTICE** Never use a hammer for the ceramic seal installation. Only use a press to avoid damaging the ceramic component.

Put OIL SEAL PROTECTOR (P/N 529 035 822) on water/oil pump shaft no. 13.




1. Water/oil pump shaft
2. Oil seal protector

Press water/oil pump shaft no. 13 into the bearing housing no. 8 with the appropriate force.

**NOTICE** Inadequate force will damage the oil seal no. 10 and bearing no. 11.

**NOTE:** During installation support the ceramic seal using the CERAMIC SEAL INSTALLER (P/N 529 036 014) as shown on the following illustration.



A35C4JA

1. Water/oil pump shaft
2. Bearing housing
3. Ceramic seal installer

Remove oil seal protector from water/oil pump shaft.

### Water/Oil Pump Shaft Installation

Pour 50 ml (1.7 U.S. oz) of injection oil in the pan under worm gear to lubricate pump gearing.

Install water/oil pump shaft assembly in crankcase while turning shaft to mesh gears.

Torque bearing housing screws no. 7.

**NOTE:** The washer behind the impeller is thicker than on other engines. Ensure to use the 1 mm (.039 in) thick washer.

After impeller installation, ensure shaft turns properly.

Torque water pump housing screws in a criss-cross sequence.

Reinstall oil injection pump.

## CRANKCASE

### Crankcase Disassembly

Remove engine from vehicle. Refer to *ENGINE REMOVAL AND INSTALLATION* section.

Remove cylinder head and cylinder-block. Refer to *TOP END (797)* section.

Remove magneto housing. Refer to *MAGNETO SYSTEM* section.

Remove drive pulley. Refer to *DRIVE SYSTEM AND BRAKE*.


Remove PTO oil seal cover no. 1.

**NOTE:** Tap screw heads to break the Loctite bond or use a SNAP-ON MANUAL IMPACT DRIVER (P/N PIT120).



mms2008-021-003\_a

Remove base plate.



mms2008-021-002\_a


**NOTICE** Whenever base plate is removed, crankcase must be opened, cleaned, and resealed.

Remove engine front supports.


Remove all crankcase screws.

## Section 02 ENGINE

### Subsection 16 (BOTTOM END (797))



mmr2007-020-007\_a  
OIL PUMP SIDE




mmr2007-020-008\_a  
WATER PUMP SIDE

Split crankcase.

**NOTE:** To prevent damage to crankcase mating surfaces, use prying lugs to "unstick" crankcase.



mmr2007-020-004



mmr2007-020-005

Remove crankshaft assembly.

### Crankcase Cleaning

Clean all metal components in a non-ferrous metal cleaner. Use LOCTITE CHISEL (P/N 413 708 500) accordingly.

**NOTICE** Never use a sharp object to remove sealant as score marks incurred are harmful to crankcase sealing.

### Crankcase Inspection

Check crankcase for cracks or other damages. Replace if necessary.

### Crankcase Assembly


Install crankshaft in lower crankcase. See *CRANKSHAFT* for procedure.

Apply LOCTITE 5910 (P/N 293 800 081) on crankcase halves as per following procedure.

**IMPORTANT:** The total assembly sequence, including sealing compound application and crankcase torquing, must be performed within 10 minutes.

Use a plexiglass plate and apply some sealant on it. Use a 50 - 75 mm (2 - 3 in) soft rubber roller and spread the sealant to get a thin uniform coat on the plate (spread as necessary). When ready, apply the sealant on crankcase mating surfaces.


**Section 02 ENGINE**  
Subsection 16 (BOTTOM END (797))




TYPICAL

**NOTE:** If you do not use the roller method, you may use your finger to uniformly distribute the sealant.


Spread a small bead of sealant around the water passage groove as illustrated.




Ensure dowel pins are in their holes.



Assemble both crankcase halves.  
Install M6 screws in crankcase. Torque to 11 N•m (97 lbf•in) as per illustrated sequence.



TOP VIEW




BOTTOM VIEW

Ensure dowel pins are in their holes.



## Section 02 ENGINE

### Subsection 16 (BOTTOM END (797))



mmv2007-020-018\_a

**BOTTOM VIEW**


Install engine support.

**NOTE:** Ensure to install a new gasket.

Install M8 screws in crankcase.

As a first step, torque M8 screws following the illustrated sequence to 14 N•m (124 lbf•in).


Then, torque M8 screws following the same sequence to 29 N•m (21 lbf•ft).



mmv2008-021-002\_b

**TORQUE TO 29 N•M (21 LBF•FT) IN 2 STEPS**

Finish by torquing crankcase M6 screws following the illustrated sequence to 11 N•m (97 lbf•in).



mmv2008-021-002\_c

**TORQUE TO 11 N•M (97 LBF•IN)**

Install PTO oil seal cover no. 1.

**NOTICE** After rebuilding an engine always observe a break-in period as described in *OPERATOR'S GUIDE*.

**NOTE:** It is recommended to test engine cooling system for leaks after engine assembly, before installation in vehicle. Refer to *COOLING SYSTEM*.

## CRANKSHAFT

### Crankshaft Removal

To remove crankshaft, use crankcase disassembly procedure.

### Crankshaft Inspection

Refer to table below to find bottom end engine dimension specifications. For dimension measurement procedures, refer to *ENGINE MEASUREMENT*.

ENGINE MEASUREMENT	TOLERANCES		
	NEW PARTS (min.)	(max.)	WEAR LIMIT
Crankshaft deflection on PTO side	N.A.	0.06 mm (.002 in)	N.A.
Crankshaft deflection on MAG side	N.A.	0.05 mm (.002 in)	N.A.
Crankshaft deflection in center of crankshaft	N.A.	0.04 mm (.002 in)	N.A.
Connecting rod big end axial play	0.23 mm (.009 in)	0.62 mm (.024 in)	1.20 mm (.047 in)
Crankshaft end-play	0.10 mm (.004 in)	0.30 mm (.012 in)	N.A.

### Crankshaft Bearing Removal

**NOTE:** 10 minutes is required to heat up a new bearing for its installation. To save time, it is recommended to start the heating process prior to bearing removal operation. See procedure further.

To remove bearings no. 2 and no. 3 from crankshaft no. 4, install proper half rings and puller ring on the outer bearing.

**NOTE:** On MAG side, position tools on inner bearing and pull out both bearings together.

PART	MAG SIDE	PTO SIDE
Half rings	420 977 475	420 977 479
Puller ring	420 977 490	420 977 494
Crankshaft protector	420 876 557	420 877 414

Ensure to position bearing pin between half ring gap.



MAG SIDE



PTO SIDE

1. Half ring
2. Puller ring

**NOTE:** Apply some grease on crankshaft end to hold in place the proper crankshaft protector.

Using SCREWS (P/N 420 840 681), install BEARING PULLER (P/N 529 036 004) on the half rings.

Secure the bearing puller in a vise by one of its rib.



BEARING PULLER SECURED IN THE VISE

**NOTICE** Never use any air impact tool for tightening the puller bolt. Lubricate the bolt with XP-S LUBE (P/N 293 600 016) to avoid damaging the threads.


Screw in the puller bolt until the bearing comes out.

Follow the same procedure for the inner bearing (PTO side).

**NOTE:** As an alternate method to remove bearings, use SNAP-ON BEARING SEPARATOR (P/N CJ 951) or SPX/OTC BEARING SEPARATOR (P/N 1124). Use a press to remove bearings.

## Section 02 ENGINE

### Subsection 16 (BOTTOM END (797))




1. Bearing separator

### Crankshaft Bearing Installation

Inspect crankshaft ends for damage.

Clean crankshaft ends with sand paper no. 180 to remove possible seal marks and debris.



Remove all residue using PULLEY FLANGE CLEANER (P/N 413 711 809).

Smear LOCTITE 767 (ANTISEIZE LUBRICANT) (P/N 293 800 070) on crankshaft bearing mounting area.



### Bearing Heating

Heat up the bearing(s) using BEARING HEATER (P/N 529 035 969). This will expand bearings and ease installation. If required, put a suitable plate or shim to avoid the direct contact between the integrated seal with the heating surface.

## Section 02 ENGINE

### Subsection 16 (BOTTOM END (797))




A32C87A

**NOTICE** Bearing(s) should not be heated to more than 80°C (176°F). Do not heat bearing(s) with direct flame, or with a heat gun or soaked in a heated oil bath. Inappropriate bearing(s) heating may result in inner seals or cage failure.

For even heat distribution, turn bearing several times during heating process.

**NOTE:** Two bearings can be heated at the same time on one bearing heater.



A32C88A

#### 1. Bearings

Probe the side of the inner race of the bearing with the temperature INDICATOR STICK (P/N 529 035 970). Stick will liquefy when the bearing reaches the proper temperature.



A32C88A

#### **⚠ WARNING**

Do not touch heated bearing with bare hands. Always wear heat resisting gloves before handling the heated bearing(s).

**NOTICE** Never reinstall a bearing that has been removed.

#### PTO Side Bearings

Install PTO bearings on crankshaft so that locating pins will be positioned as shown.



mm2007-020-01A\_4

#### PTO SIDE

Slide the heated inner PTO bearing on crankshaft until it bottoms on crankshaft shoulder.

## Section 02 ENGINE

### Subsection 16 (BOTTOM END (797))



**NOTE:** Heated bearing should slide easily onto the crankshaft. If required, push with a steel tube on the inner race of the bearing.

Install retaining disc.

Install DISTANCE GAUGE (P/N 529 036 060) as shown.




TYPICAL

Slide the heated outer PTO bearing onto the crankshaft until it contacts the distance gauge.

### MAG Side Bearings

Install MAG bearings on crankshaft so that locating pins will be positioned as shown.



MAG SIDE

Slide the inner MAG bearing until it bottoms on crankshaft shoulder.

**NOTE:** Heated bearing should slide easily onto the crankshaft. If required, push with a steel tube on the inner race of the bearing.




Slide the outer bearing until it sits on inner bearing.




### Crankshaft Installation


At crankshaft installation, position locating pins in their recess as illustrated.



Pay attention to properly locate MAG seal in its groove.



Pour 50 ml (1.7 U.S. oz) of injection oil in the oil bath under worm gear as shown.



TYPICAL  
1. Oil bath

Apply ISOFLEX GREASE (P/N 293 550 021) as per following procedure:

**NOTICE** Use only the recommended grease. Make sure not to push grease between the outside bearing race and the crankcase half.

Put approximately 25 ml (.8 U.S. oz) of grease in a syringe.


NOTE: The 50 g tube corresponds to 50 ml of grease.

**NOTICE** Do not exceed the recommended amount of grease.

With the syringe, fill the PTO side outer bearing with 19 ml (.6 U.S. oz) of grease.


## Section 02 ENGINE

### Subsection 16 (BOTTOM END (797))



**NOTE:** Inner PTO bearing is already filled with grease (about 8 ml (.3 U.S. oz)).

Apply 5 ml (.2 U.S. oz) of grease to MAG side outer bearing.



**NOTE:** Inner MAG bearing is already filled with grease (about 5 ml (.2 U.S. oz)).

Install MAG seal.

Proceed with crankcase assembly. Refer to *CRANKCASE*.


## OVERVIEW (500SS/600)

### GENERAL

#### SYSTEM DESCRIPTION

The engine management system (EMS) controls the following main systems:

- Ignition system
- Rotax Electronic Reverse (RER)
- Starting system (electric start models)
- Digitally Encoded Security System (DESS).




1. Engine control module (ECM)
2. TM carburetors
3. RAVE valves
4. Coolant temperature sensor (CTS)
5. Ignition coil
6. Trigger coils (2)

The EMS also offers a monitoring system and diagnostic mode to help troubleshooting some problems. Refer to *MONITORING SYSTEM/FAULT CODES* section.

#### Engine Control Module (ECM)

The engine control module (ECM) is the brain of the engine management system.



ECM


The ECM and the multifunction gauge communicate together through the CAN lines (Controller Area Network).

The ECM is located under the hood.



## Section 03 ENGINE MANAGEMENT SYSTEM

### Subsection 01 (OVERVIEW (500SS/600))




**NOTE:** To test the ECM, refer to *IGNITION SYSTEM*.

#### Engine RPM Limiter

The ECM will limit the maximum engine speed (approximately 8600 RPM).



# OVERVIEW (600 HO E-TEC)



## GENERAL

### SYSTEM DESCRIPTION

A highly advanced engine management system (EMS) has been used on this 2-stroke engine to ensure a high power output with a clean combustion with practically no exhaust smoke.

There are 8 main systems that are controlled by the engine management system (EMS):

1. E-TEC Direct fuel injection
2. Ignition system
3. Starting system
4. Rotax electronic reverse (RER)

5. Digitally encoded security system (DESS)
6. Lubrication system
7. 3D RAVE
8. Electrical accessories.

The engine management system features a monitoring system that self-diagnoses its electronic components. For more information, refer to *MONITORING SYSTEM/FAULT CODES*.

The power distribution is also controlled by the engine management system.

## Section 03 ENGINE MANAGEMENT SYSTEM

### Subsection 02 (OVERVIEW (600 HO E-TEC))


#### Engine Control Module (ECM)

The ECM is the central point of the engine management system. It reads the inputs, makes computations, uses pre-determined parameters and sends the proper signals to the outputs for proper engine management.



ECM

The ECM is located near oil injection reservoir.




The ECM features a permanent memory that will keep the fault codes, customer information and other engine information when the engine is stopped.

#### ECM Cooling

Since the ECM manages all the vehicle power needs and incorporates the voltage regulator/rectifier and other power components, a lot of heat needs to be dissipated.

The constant fresh fuel flow from fuel pump is used to cool down the ECM.




#### Throttle Protection

If throttle is not completely closed during engine startup, engine RPM will be limited to idle speed by the ECM.

To revert to normal operation, release the throttle completely and then depress it again.

#### Controller Network Area (CAN)

The CAN protocol is an ISO standard for serial data communication. The CAN bus links the ECM and the multifunction gauge in the vehicle. Two wires connect each component and they are in constant communication with each other. CAN lines consist of a pair of wires (WHITE/BEIGE and WHITE/BLACK).



Fault codes are broadcasted to the CAN bus and can be displayed in B.U.D.S.

## POWER DISTRIBUTION

### Overview

The E-TEC technology is a batteryless system. On electric-start models, the battery is only used to supply the electric starting system.




**FLYWHEEL AND STATOR**

A 1200 W magneto is used.

The flywheel is ventilated to cool down the temperature generated by the high power stator.

The stator is wired with 3 independent windings that works in phase. Each winding is separately wound, they are not connected, so 6 windings go to the ECM.



The EMS requires high voltage at low RPM and high current at higher RPM. To achieve this the stator windings are connected in series at low RPM to increase voltage and then connected in parallel at higher RPM to increase current. This series-parallel switch is done in the ECM. Now the electrical requirements of the EMS can be satisfied.

The series to parallel switching occurs at approximately 1500 RPM.

At high RPM if the magneto power is greater than the loads, the ECM will shunt the stator windings to regulate its power as necessary.

The voltage regulator/rectifier is part of the ECM. The ECM receives the energy produced by the magneto and rectifies the alternating current (AC) to direct current (DC) and regulates the voltage to 55 Vdc and 12 Vdc.

### System Voltage (55 Vdc)

Since the available power is low when cranking, the ECM first supplies 55 Vdc to the components that mandatory need voltage for the starting and the basic operation of the engine:

- ECM (internally powered to a lower voltage)
- Fuel pump
- Fuel injectors
- Ignition coils
- Electronic oil injection pump.

A large capacitor is used to stabilize the 55 Vdc system to provide a constant power to the injectors.



**CAPACITOR**

### System Voltage (12 Vdc)

The 12 Vdc voltage is divided in a primary and a secondary system to distribute current to the engine and vehicle as the power becomes available from the magneto when engine speed increases. This is necessary to prevent a system overload that would lower the power available to the 55 Vdc system. A staged power delivery is used.

## Section 03 ENGINE MANAGEMENT SYSTEM

### Subsection 02 (OVERVIEW (600 HO E-TEC))

#### Primary Voltage (12 Vdc)

Since the available power is not at its maximum at the early stage of engine starting, the ECM supplies 12 Vdc to the components that are critical for the engine and vehicle when engine reaches 800 RPM.

- RAVE solenoid
- Lighting system
- Multifunction gauge.

On electric start models, when the engine speed reaches 1900 RPM and after a delay of 4 seconds has elapsed, the charging system relay (R2) closes and battery charging can take place as required.

#### Secondary Voltage (12 Vdc)

When the engine speed reaches 1900 RPM and after a delay of 2 seconds has elapsed, the accessory relay inside the ECM closes and power is delivered to the vehicle accessories (handle grip heaters for example).

#### Power Distribution Summary

ENGINE OPERATION	VOLTAGE DELIVERED	COMPONENT SUPPLIED
All rpm's	55 Vdc	<ul style="list-style-type: none"><li>- ECM (internally powered)</li><li>- Fuel pump</li><li>- Fuel injectors</li><li>- Ignition coils</li><li>- Electronic oil injection pump</li></ul>
When engine reaches 800 RPM	12 Vdc	<ul style="list-style-type: none"><li>- RAVE solenoid</li><li>- Lighting system</li><li>- Multifunction gauge</li></ul>
When engine reaches 1900 RPM after a delay of 2 seconds has elapsed	12 Vdc	<ul style="list-style-type: none"><li>- Vehicle accessories</li></ul>
When engine reaches 1900 RPM after a delay of 4 seconds has elapsed	12 Vdc	<ul style="list-style-type: none"><li>- Battery charging</li></ul>


#### Power Optimization

To efficiently use the available power from the magneto and to solve different electrical requirements, pulse width modulation (PWM) is used.

The duty cycle (the time a pulse is ON) is changed as required. Therefore, voltage and current can be modulated where needed and as needed.



# OVERVIEW (800R)




mnr2008-024-002\_a

1. Engine control module (ECM) including air pressure sensor (APS)
2. TM carburetors
3. DPM manifold
4. RAVE valves
5. RAVE valve solenoid
6. Air temperature sensor (ATS)
7. Coolant temperature sensor (CTS)
8. Knock sensor (KS)
9. Throttle position sensor (TPS)
10. Ignition coil
11. Trigger coil



## Section 03 ENGINE MANAGEMENT SYSTEM

### Subsection 03 (OVERVIEW (800R))



## GENERAL

### SYSTEM DESCRIPTION

The engine management system (EMS) controls the following main systems:

- Ignition system
- 3D RAVE system
- Digital Performance Management (DPM)
- Rotax Electronic Reverse (RER)
- Digitally Encoded Security System (DESS)
- Starting system (electric start models).

The acronym Power TEK refers to the following technologies found on this engine:

Throttle position sensor

Electronic RAVE

Knock sensor.

The TPS and knock sensor provide inputs to the ECM.

The ECM electronically controls the electric RAVE valve solenoid and the DPM solenoid.

The use of a TPS along with the trigger coils (engine RPM) allows the ECM to recognize the engine load and thus using 3D DPM and ignition maps. This achieves an improved fuel economy, a cleaner engine for emission requirements and improved engine protection (against seizure).

The EMS also offers a monitoring system and diagnostic mode to help troubleshooting some problems. Refer to *MONITORING SYSTEM/FAULT CODES* section for more details.

### Engine Control Module (ECM)

The engine control module (ECM) is the brain of the engine management system.




ECM

The ECM applies the proper ignition and DPM maps for optimum engine operation in all riding conditions.

The ECM and the multifunction gauge communicate together through the CAN lines (Controller Area Network).

The ECM is located in the engine compartment.



### Engine RPM Limiter

The ECM will limit the maximum engine speed (approximately 8600 RPM).

### Warm Up Engine Protection

The engine warm up is electronically controlled. The ignition timing, fuel delivery and 3-D RAVE opening are varied to limit power output on a cold engine to reduce the chance of engine damage. This type of limitation is RPM-related and the warm-up period should be seamless.

**NOTE:** When engine coolant temperature is below 5°C (41°F), the RAVE valves will be kept closed.

### Knock Sensor

A knock sensor is mounted on top of the cylinder head. It detects specific vibration that would be typically generated by engine detonation.

When knocking occurs, the ECM temporarily retards ignition timing and enriches fuel mixture until knocking disappears. Then, previous parameters automatically resume as required. Refer to *COMMUNICATION TOOLS AND B.U.D.S. SOFTWARE*.

**NOTE:** Occasional knocking will not generate a fault code. If knocking occurrence goes over a certain threshold, a fault code will be generated.

Refer to *IGNITION SYSTEM* to test the knock sensor.



# COMMUNICATION TOOLS AND B.U.D.S. SOFTWARE

## SERVICE TOOLS

Description	Part Number	Page
12 V BATTERY SUPPLY CABLE .....	529 035 997 .....	209–210
DIAGNOSTIC CABLE .....	710 000 851 .....	210
DIAGNOSTIC CABLE .....	710 000 851 .....	209
MPI-2.....	529 036 018 .....	208, 210
SUPPLY T-HARNESS.....	529 035 869 .....	208–209
T-HARNESS.....	529 035 869 .....	210

## SERVICE TOOLS – OTHER SUPPLIER

Description	Part Number	Page
OPTIONAL MALE-FEMALE EXTENSION SERIAL CABLE.....	DB9 .....	208

## GENERAL

Refer to *PROCEDURES* for instructions on the communication tools.


If communication problems occur, refer to *TROUBLESHOOTING*.

## TROUBLESHOOTING

### COMMUNICATION PROBLEMS

#### MPI-2 Connection Troubleshooting

The MPI-2 includes 2 status lights to show the connection conditions: USB and CAN. Both lights must be **GREEN** so that MPI-2 works properly. Otherwise, refer to the following charts.



#### Prerequisite for USB Communication:

- PC Computer turned ON
- MPI-2 connected to PC computer.

COMMUNICATION PROBLEM (USB)	
Status	What to do
Light is OFF	<ul style="list-style-type: none"> <li>– Check USB connection between MPI-2 and PC computer.</li> <li>– Check USB operation on PC computer (hardware or Windows drivers).</li> </ul>

#### Prerequisite for CAN Communication:

1. MPI-2 connected to diagnostic connector.
2. DESS key is installed on its post.
3. B.U.D.S. started and logged.


COMMUNICATION PROBLEM (CAN)	
Status	What to do
Light is OFF	<ul style="list-style-type: none"> <li>– Check connection between MPI-2 and diagnostic cable connector.</li> <li>– Check connection between diagnostic cable connector and T-harness.</li> <li>– Check connection between T-harness and diagnostic connector.</li> <li>– Check that battery supply cable is connected to a 12 V battery.</li> <li>– Check that ECM is powered.</li> </ul>
Light is RED	<ul style="list-style-type: none"> <li>– Check CAN wires and connectors on vehicle.</li> </ul>

## Section 03 ENGINE MANAGEMENT SYSTEM

### Subsection 04 (COMMUNICATION TOOLS AND B.U.D.S. SOFTWARE)

#### Communication Problems with B.U.D.S.

If one or more "ECU" is (are) not communicating with the MPI. A module may not be powered or is defective. Check to find which module is missing in B.U.D.S. Its tab at the bottom will not be visible. Then check wiring and power supply to that module.



#### TYPICAL


1. Cluster tab not visible meaning this "ECU" is not communicating

If an "X" is shown, the communication has been lost. Refer to the other *COMMUNICATION PROBLEMS* topics in this section.



#### Supply T-Harness Connection Troubleshooting

500SS/600/800R



When the SUPPLY T-HARNESS (P/N 529 035 869) is connected to the diagnostic connector and powered by a 12 V battery, the engine can not be started as the connections set the ECM in diagnostic mode.

If the engine can abnormally be started with the T-harness connected, some functions will not be available in B.U.D.S. In this case, check the following:

- Fuse of the T-harness. If burnt, check battery condition. A weak battery may cause fuse to blow.
- Diode in the T-harness between pins 4 and 5.
- Damaged wiring or connectors of the T-harness.


## PROCEDURES

### MULTI-PURPOSE INTERFACE-2 (MPI-2)

The MPI-2 (Multi-Purpose Interface-2) is used with B.U.D.S. software to communicate with the engine management system.

#### Parts required

MPI-2 (P/N 529 036 018).




OPTIONAL MALE-FEMALE EXTENSION SERIAL CABLE (P/N DB9)

**NOTE:** The extension cable is available at electronic retail outlets. Do not exceed 7.6 m (25 ft).

## Section 03 ENGINE MANAGEMENT SYSTEM

### Subsection 04 (COMMUNICATION TOOLS AND B.U.D.S. SOFTWARE)



529035687

DIAGNOSTIC CABLE (P/N 710 000 851)



710000851

SUPPLY T-HARNESS (P/N 529 035 869)



529035869

12 V BATTERY SUPPLY CABLE (P/N 529 035 997)



529035997

### MPI-2 Power Supply

#### MPI-2

The MPI-2 uses the PC computer USB port for its power supply.

### MPI-2 Connections with Vehicle

#### **⚠ WARNING**

If the computer you are using is connected to the power outlet, there is a potential risk of electrocution when working in contact with water. Be careful not to touch water while working with the computer.

**NOTE:** Some components will generate heat when leaving vehicle in diagnostic mode for a long period. Always disconnect MPI supply harness and supply cable from vehicle/battery when not working on vehicle.

Connect MPI-2 connector to the USB port of a PC (personal computer).




mmr2006-079-200

Remove the diagnostic connector from the protective cap on the right side of the vehicle.

## Section 03 ENGINE MANAGEMENT SYSTEM

### Subsection 04 (COMMUNICATION TOOLS AND B.U.D.S. SOFTWARE)



Connect the T-HARNESS (P/N 529 035 869) to diagnostic connector.



Connect the MPI-2 (P/N 529 036 018) to diagnostic cable.



**NOTICE** Connecting MPI-2 directly to diagnostic connector (without T-harness) may prevent proper communication. Always use the T-harness.

Connect the 12 V BATTERY SUPPLY CABLE (P/N 529 035 997) to T-harness.



Connect the DIAGNOSTIC CABLE (P/N 710 000 851) to T-harness connector.

## Section 03 ENGINE MANAGEMENT SYSTEM

### Subsection 04 (COMMUNICATION TOOLS AND B.U.D.S. SOFTWARE)



Connect the battery supply cable to a 12 V battery.  
**NOTE:** Connect cable clips to vehicle battery if so equipped.



**NOTICE** Always use the proper supply harness and cables. Make sure to respect polarity when connecting cable clips to battery. Match RED cables together.

Set headlamp to low beam to reduce battery discharge rate.

#### 500SS/600/800R

**NOTE:** Engine cannot be started in diagnostic mode. Battery supply cable must be disconnected from battery to allow engine starting.

## B.U.D.S. SOFTWARE

B.U.D.S. (Bombardier Utility and Diagnostic Software) is designed to allow electrical component inspection, diagnostic options and adjustments such as the closed throttle.

For more information pertaining to the use of the B.U.D.S. software, use its help which contains detailed information on its functions.

Use the latest B.U.D.S. version available on BOSSWeb.


**IMPORTANT:** Make sure all connections have been made **before starting B.U.D.S.** to allow proper operation.

### Reading Data from a Vehicle using the B.U.D.S. Software


Install DESS key on its post.

Start B.U.D.S. and logon.

Select the protocol Kw2000 in MPI under Choose protocol.



If **No vehicle detected...** message is displayed in B.U.D.S.:




Make sure both USB and CAN lights of MPI-2 are GREEN. Otherwise, refer to *TROUBLESHOOTING* in this section.

Make sure the status bar shows the kW2000 and the number 2 to its right. Otherwise, refer to *TROUBLESHOOTING* in this section.

## Section 03 ENGINE MANAGEMENT SYSTEM

### Subsection 04 (COMMUNICATION TOOLS AND B.U.D.S. SOFTWARE)




CONNECTION SUCCESSFUL

**NOTE:** Number 2 indicates that the ECM and the multifunction gauge are recognized by the MPI. Read ECM by clicking the **Read Data** button.



### Writing Data Changes in ECM

When finished, save new data in ECM by clicking the **Write Data** button.



Disconnect MPI connections and reconnect the 6-pin connector in its protective cap.

**NOTICE** Failure to secure the diagnostic connector in its protective cap would allow corrosion and damage to the terminals.

**NOTE:** There is a 120 Ω resistor in protective cap to minimize the possibility of communication error.

### Electronic Modules ("ECU") Update


Whenever B.U.D.S. is started, check if there is an update icon in B.U.D.S. status bar.




TYPICAL

The icon indicates that a file is available in B.U.D.S. to update any of the following electronic modules: ECM or multifunction gauge.

Use the **Module** menu and check all modules one at a time.



1. If the **Update** option is **greyed out**, no update file is available for this module.
2. If the **Update** option is **black**, an update file is available for this module. Select the update option and load the proper file.



1. **Greyed out:** No update to perform  
**Black:** Update file available

# MONITORING SYSTEM AND FAULT CODES

## GENERAL

### MONITORING SYSTEM

The EMS features a monitoring system that self-diagnose its electronic components.

When a predefined condition (engine overheat for example) or a fault occurs, the ECM sends a signal to the multifunction gauge and/or audible signals to a beeper to inform you of this particular condition.

The ECM monitors the following functions and components.

#### 500SS/600

COMPONENT
DESS
RER
Low oil level
Engine RPM
Hi engine temperature (turns on @ 80°C (176°F) then turns off @ 75°C (167°F))
CAN
ECM
CTS
Main relay

#### 600 HO E-TEC

COMPONENT
EMS (TPS, CPS, knock sensor, RAVE valve solenoids, APS, ATS, EGTS, RPS, ignition coils and fuel injectors)
12 V overload and 55 V voltage
DESS
RER
Low oil level, electronic oil injection pump
Engine RPM
Coolant temperature
CAN
ECM
CTS
Starter solenoid (electric start models)
Fuel pump
Charging system relay (electric start models)

#### 800R

COMPONENT
EMS (TPS, knock sensor, 3D RAVE valve solenoids, DPM, APS and ATS)
DESS
RER
Low oil level
Engine RPM
Hi engine temperature (turns on @ 85°C (185°F) then turns off @ 80°C (176°F))
CAN
ECM
CTS
Main relay

### Limp Home Mode

The ECM may automatically set default parameters to ensure the adequate operation of the vehicle if a component of the engine management system is not operating properly.

## Section 03 ENGINE MANAGEMENT SYSTEM

### Subsection 05 (MONITORING SYSTEM AND FAULT CODES)

**NOTE:** Sensor failures will not lead automatically to a limp home mode. The check engine LED will turn on and in some cases the beeper.

The engine RPM may be limited if some critical components fail. In this case, releasing throttle and letting the engine returning to idle speed may allow normal operation to come back. If it does not work, try removing and reinstalling the tether cord cap on DESS post.

These performance-reduced modes allow the rider to go back home which would not be possible without this advanced system.

#### 500SS/600

EMS ACTION	CAUSE
Engine is gradually stopped. Beeper sounds for 5 seconds and a shutdown message is displayed in multifunction gauge before shutdown.	Engine overheat protection: – Engine idled more than 5 minutes while engine temperature raised above 85°C (185°F).

#### 600 HO E-TEC

EMS ACTION	CAUSE
Engine is gradually stopped. Beeper sounds for 5 seconds and a shutdown message is displayed in multifunction gauge before shutdown.	Fuel pump wiring short circuit or open circuit.
	Fuel pump current requirement is too high.
	Engine overheat protection: – Engine idled more than 5 seconds while engine temperature raised above 85°C (185°F). – Engine idled more than 5 minutes while engine temperature raised above 37°C (99°F).
Engine speed is limited to 3000 RPM	DESS key is not recognized by the ECM. The antitheft system is active. RAVE valves are kept at closed position.

EMS ACTION	CAUSE
Engine speed is limited to 5500 RPM (RAVE valves are kept closed)	Oil injection pump wiring short circuit or open circuit.
	Low voltage in the 55 V system. Voltage dropped to 50 Vdc.
	Engine overheat. Engine temperature reached 115°C (239°F).
	Exhaust gas temperature too high. Temperature reached 800°C (1,472°F).
Engine speed is limited to 7000 RPM	High engine detonation.
	Max. RPM allowed to the engine in reverse. RAVE valves are kept closed.
	Max. RPM allowed when engine is cold. Air temperature is below -25°C (-13°F). RAVE valves are kept at mid position. Oil injection pump duty cycle is increased to warm up oil.
Engine speed is limited to 8600 RPM	<b>NOTE:</b> When coolant temperature is below 20°C (68°F), RAVE valves are kept at mid position and no RPM limitation takes place. Oil pump works in its usual mode.
	Maximum engine RPM allowed.

#### 800R

EMS ACTION	CAUSE
Engine is gradually stopped. Beeper sounds for 5 seconds and a shutdown message is displayed in multifunction gauge before shutdown.	Engine overheat protection: – Engine idled more than 5 minutes while engine temperature raised above 85°C (185°F).
Engine speed is limited to 5200 RPM (RAVE valves are kept closed)	Engine overheat: Engine temperature reached 90°C (194°F).



**Section 03 ENGINE MANAGEMENT SYSTEM**  
**Subsection 05 (MONITORING SYSTEM AND FAULT CODES)**

### Pilot Lamps






Warning lights in multifunction gauge and/or a beeper provide signals as vehicle operation feedback or to indicate a problem.

Pilot lamp can flash alone or in combination with another lamp.

Beeper codes will be heard and messages (depending on gauge model) will be displayed to catch your attention.

**NOTE:** Message displayed is not available on all gauges.







#### 500SS/600/800R

PILOT LAMP(S) ON	BEEPER	MESSAGE DISPLAYED	DESCRIPTION
	Fast short beeps	ENGINE	Engine is overheating.
	4 short beeps every 2 minutes	LOW BAT	Indicate a low or high battery voltage condition.
		HIGH BAT	
	4 short beeps	CHECK ENGINE	Engine fault.
	4 short beeps every 2 minutes	KNOCK	Engine detonation. – Ensure recommended fuel is used. – Check fuel quality, replace if necessary.
	Continuously beeps	SHUTDOWN	Shutdown procedure in force due to engine overheating problem.
	4 short beeps every 2 minutes	LOW OIL	Injection oil level is low.
	Slow long beeps	REVERSE	Electronic reverse is selected.
	3 short beeps	REV. FAIL	Engine rotation did not change after reverse try, try again.
<b>DESS</b>	Refer to <i>DESS WARNING SIGNALS</i> below.		

## Section 03 ENGINE MANAGEMENT SYSTEM

### Subsection 05 (MONITORING SYSTEM AND FAULT CODES)

#### 600 HO E-TEC

PILOT LAMP(S) ON OR FLASHING	BEEPER	DESCRIPTION
	Continuous fast short beeps	Major engine, muffler or ECM overheating.
	Continuous fast short beeps	Electronic oil injection pump problem.
	4 short beeps every 2 minutes	Low or high battery voltage or battery charging relay.
	4 short beeps	Minor engine or muffler overheating.
	4 short beeps	Engine management system fault.
	4 short beeps every 2 minutes	High engine detonation.
	Continuously beeps	Engine shutdown procedure due to engine overheating at idle or a fuel pump problem.
	4 short beeps every 2 minutes	Injection oil level is low.
<b>DESS</b>	Refer to <i>DIGITALLY ENCODED SECURITY SYSTEM (DESS)</i> section.	

## FAULT CODES

A fault code is an indication that a glitch or malfunction is detected by the monitoring system of the vehicle.

When there is a problem, the EMS (engine management system) can provide fault codes to ease the troubleshooting.

The faults registered in the ECM (engine control module) are kept when the battery is disconnected.

Many fault codes at the same time is likely to be burnt fuse(s), a faulty relay or a problem with the vehicle wiring harness.

When using the service action suggested in the **Fault** section of B.U.D.S., a system circuit referred to as DA-26 or J1A-26 for instance, means connector "A" on the ECM and the pin 26.

**IMPORTANT:** After a problem has been solved, ensure to clear the fault(s) in the ECM using the B.U.D.S. software. This will properly reset their states.

### How to Read Fault Codes Using B.U.D.S. Software

Refer to *COMMUNICATION TOOLS/B.U.D.S. SOFTWARE* section.

For more information pertaining to the faults code status and report, refer to B.U.D.S. online help or to the EMS fault code tables.

### How to Read Fault Codes on the Premium Multifunction Gauge

Fault codes can also be displayed in the premium multifunction gauge. Refer to *LIGHTS, GAUGE AND ACCESSORIES*.

**Section 03 ENGINE MANAGEMENT SYSTEM**  
**Subsection 05 (MONITORING SYSTEM AND FAULT CODES)**

## SPECIFIC FAULT CODES

The following gives additional information related to specific fault codes.

### Fault Code P0336


*500SS/600/800R*

This code occurs when engine RPM goes too high which could happen under some mechanical-related circumstances and is not necessarily related to a problem with the engine management system.

### Fault Code P1676

*600 HO E-TEC Manual Start*

This code occurs if the wrong option was selected in B.U.D.S. Connect and start B.U.D.S. to uncheck With Electric Start.



**SETTING AND ECM TABS**

1. Vehicle configuration area
2. Uncheck With Electric Start

**NOTE:** If the option is not checked on an Electric Start model, the starter relay (solenoid) and its circuits will not be monitored by the EMS (Engine Management System). The starter operation will not be altered.

### Fault Code P1102 (TPS offset out of range)

*800R*

POSSIBLE CAUSE	ACTION TO PERFORM
Wrong carburetor mechanical position during reset of closed TPS.	<ul style="list-style-type: none"> <li>- Check cable adjustment.</li> <li>- Check idle stop for wear.</li> <li>- Make sure throttle plate is against throttle stop.</li> </ul>
No initialisation of ECM after its replacement.	<ul style="list-style-type: none"> <li>- Reset <b>Closed Throttle</b>.</li> <li>- Adjust idle throttle angle as specified.</li> </ul>
TPS sensor has moved from its original position.	<ul style="list-style-type: none"> <li>- Make sure the TPS body is not loose.</li> </ul>

### Fault Code P1104 (TPS offset not programmed)

*800R*

POSSIBLE CAUSE	ACTION TO PERFORM
No initialisation of ECM after its replacement.	Reset Closed Throttle.

## Section 03 ENGINE MANAGEMENT SYSTEM

### Subsection 05 (MONITORING SYSTEM AND FAULT CODES)

## FAULT CODE TABLES

500SS/600/800R

FAULT CODE	DESCRIPTION
P0079	RAVE solenoid 1 output fault (open circuit/shorted to ground)
P0080	RAVE solenoid 1 output fault (shorted to battery)
P0085	RAVE solenoid 2 output fault (open circuit/shorted to ground)
P0086	RAVE solenoid 2 output fault (shorted to battery)
P0107	Air Pressure Sensor fault (voltage too low)
P0108	Air Pressure Sensor fault (voltage too high)
P0112	Air Temperature Sensor fault (voltage too low)
P0113	Air Temperature Sensor fault (voltage too high)
P0117	Engine Temperature Sensor fault (voltage too low)
P0118	Engine Temperature Sensor fault (voltage too high)
P0122	Throttle Position Sensor fault (voltage too low)
P0123	Throttle Position Sensor fault (voltage too high)
P0326	Knock sensor reference signal fault (voltage too low)
P0336	High engine RPM detected
P0605	System fault (Calibration checksum error)
P1102	System fault (Throttle Position Sensor offset out of range)
P1104	System fault (Throttle Position Sensor offset not programmed)
P1217	Overheat shutdown occurred
P1261	HAC solenoid output fault (open circuit/shorted to ground)
P1262	HAC solenoid output fault (shorted to battery)
P1656	DESS communication link fault (shorted to ground)
P1675	Relay output fault (open circuit/shorted to ground)
P1676	Relay output fault (shorted to battery)
P1520	Critical low oil level detected
P0217	Critical engine temperature detected
P1326	Critical detonation level detected
P0600	CAN Message Missing

**Section 03 ENGINE MANAGEMENT SYSTEM**  
**Subsection 05 (MONITORING SYSTEM AND FAULT CODES)**

**600 HO E-TEC**

FAULT CODE	DESCRIPTION	CAUSE	ACTION
P0079	RAVE solenoid open circuit or shorted to ground	Disconnected RAVE solenoid. Damaged RAVE solenoid, wires or terminals.	Check for approximately 12 volts between RAVE solenoid RD/OR wire and chassis. Check for approximately 30 ohms between RAVE solenoid terminals. Check system circuit J1B-15.
P0106	Intake air pressure sensor functional problem	Damaged air pressure sensor inside in the ECM.	Replace the ECM.
P0107	Intake air pressure sensor voltage too low	Damaged air pressure sensor inside in the ECM.	Replace the ECM.
P0108	Intake air pressure sensor voltage too high	Damaged air pressure sensor inside in the ECM.	Replace the ECM.
P0111	Air temperature sensor functional problem	Intermittent air temperature sensor reading or circuit wires shorted to ground.	Check system circuits J1A-20 for continuity to terminal "B" of the ATS connector and J1A-27 for continuity to terminal "A" of the ATS connector. Check circuits J1A-20 and J1A-27 for resistivity to ground. Sensor can have an intermittent reading, replace the sensor if necessary.
P0112	Air temperature sensor voltage too low	Air temperature sensor or circuit wires shorted to ground.	Disconnect the sensor and check for a change in the fault code. If the fault code stays the same, look for a short circuit on the harness. If the fault code is different, replace the sensor. Check system circuit J1A-20 for continuity to terminal "B" of the ATS connector. Check system circuit J1A-20 for resistivity to ground.
P0113	Air temperature sensor voltage too high	Disconnected sensor or sensor's resistance too high.	Check for disconnected air temperature sensor on the airbox. Check the air temperature sensor for approximately 2280 to 2736 ohms at 19 to 21°C (66 to 70°F). Replace the sensor if necessary. Check system circuits J1A-20 for continuity to terminal "B" of the ATS connector and J1A-27 for continuity to terminal "A" of the ATS connector.
P0116	Coolant temperature sensor functional problem	Intermittent coolant temperature sensor reading or circuit wires shorted to ground.	Check system circuit J1A-19 for continuity to terminal 1 of the CTS connector and J1A-27 for continuity to terminal 2 of the CTS connector. Check circuit J1A-19 and J1A-27 for resistivity to ground. Replace the sensor if necessary.

**Section 03 ENGINE MANAGEMENT SYSTEM****Subsection 05 (MONITORING SYSTEM AND FAULT CODES)**

FAULT CODE	DESCRIPTION	CAUSE	ACTION
P0117	Coolant temperature sensor voltage too low	Coolant temperature sensor or circuit wires shorted to ground.	Disconnect the sensor and check for a change in the fault code. If the fault code stays the same, look for a short circuit on the harness. If the fault code is different, replace the sensor. Check for leakage between sensor's connection and ground. Check system circuit J1A-19 for continuity to terminal 1 of the CTS connector and J1A-27 for continuity to terminal 2 of the CTS connector. Check circuit J1A-19 and J1A-27 for resistivity to ground.
P0118	Coolant temperature sensor voltage too high	Disconnected sensor or sensor's resistance too high.	Check for disconnected coolant temperature sensor. Check the engine temperature sensor for approximately 2280 to 2736 ohms at 19 to 21°C (66 to 70°F). Replace the sensor if necessary. Check system circuit J1A-19 for continuity to terminal 1 of the CTS connector and J1A-27 for continuity to terminal 2 of the CTS connector.
P0121	Throttle position sensor functional problem	Damaged circuit wires or connector, damaged throttle position sensor.	Check throttle position sensor connector for 5 volts between pin 1 and 2. Check system circuit J1A-18.
P0122	Throttle position sensor voltage too low	Damaged circuit wires, damaged throttle position sensor or damaged ECM pins.	Check system circuits J1A-10 for continuity to terminal 1 of the TPS connector, J1A-26 for continuity to terminal 2 of the TPS connector and J1A-18 for continuity to terminal 3 of the TPS connector. Refer to the service manual for complete throttle position sensor testing procedure.
P0123	Throttle position sensor voltage too high	Damaged circuit wires, damaged throttle position sensor or damaged ECM pins.	Check system circuits J1A-10 for continuity to terminal 1 of the TPS connector, J1A-26 for continuity to terminal 2 of the TPS connector and J1A-18 for continuity to terminal 3 of the TPS connector. Refer to the service manual for complete throttle position sensor testing procedure.
P0217	High coolant temperature detected	Poor cooling conditions. Engine may have been idling for too long. Low coolant level. Problem with cooling system.	Check coolant level. Check condition list to find out how it happened. Check cooling system.
P0230	Fuel pump over current	Damaged circuit wires, damaged fuel pump.	Check system circuit J2-4 for continuity to terminal 1 of the fuel pump connector. Check system circuit J2-4 for resistivity to ground. Replace the fuel pump if necessary.
P0231	Fuel pump open circuit or shorted to ground	Disconnected fuel pump. Damaged fuel pump, damaged circuit wires or connectors.	Check system circuit J2-4 for continuity to terminal 1 of the fuel pump connector. Check system circuit J2-12 for continuity to terminal 2 of the fuel pump connector. Check circuit J2-4 and J2-12 for resistivity to ground.

**Section 03 ENGINE MANAGEMENT SYSTEM**  
**Subsection 05 (MONITORING SYSTEM AND FAULT CODES)**

FAULT CODE	DESCRIPTION	CAUSE	ACTION
P0261	MAG injector open circuit or shorted to ground	Damaged or disconnected injector, circuit wires or ECM output pins.	Check system circuit J1B-8 for continuity to terminal 2 of the MAG injector. Check system circuit J2-13 for continuity to terminal 1 of the MAG injector. Check circuit J1B-8 for resistivity to ground.
P0262	MAG injector shorted to system voltage (over current)	Damaged injector, circuit wires or ECM output pins.	Check for approximately 2.4 ohms on injector. Check if system circuit J1B-8 is shorted to system voltage (55 V).
P0264	PTO injector open circuit or shorted to ground	Damaged or disconnected injector, circuit wires or ECM output pins.	Check system circuit J1B-1 for continuity to terminal 2 of the PTO injector. Check system circuit J2-13 for continuity to terminal 1 of the PTO injector. Check circuit J1B-1 for resistivity to ground.
P0265	PTO injector shorted to system voltage (over current)	Damaged injector, circuit wires or ECM output pins.	Check for approximately 2.4 ohms on injector. Check if system circuit J1B-1 is shorted to system voltage (55 V).
P0326	Knock sensor below minimum noise	Damaged or disconnected knock sensor, damaged circuit wires or damaged connector.	Check system circuits J1A-33 for continuity to terminal 2 of knock sensor connector and J1A-34 for continuity to terminal 1 of knock sensor connector. Check sensor mounting surface and torque.
P0339	Crankshaft signal fault (lost of sync)	CPS signal not plausible, damaged circuit wires, damaged connector or damaged tooth wheel.	Check for 190 to 290 ohms between terminals J1A-6 and J1A-7 of ECM connector. Check for 2 volts AC between terminals J1A-6 and J1A-7 of ECM connector while cranking the engine.
P0351	MAG ignition coil open circuit or shorted to ground	Damaged circuit wires or connector, damaged or disconnected ignition coil.	Check system circuit J1B-26 for continuity to terminal 2 of the ignition coil connector. Check for 55 volts on terminal 3 of ignition coil connector. Check for continuity between terminal 1 of ignition coil connector and chassis.
P0352	PTO ignition coil open circuit or shorted to ground	Damaged circuit wires or connector, damaged or disconnected ignition coil.	Check system circuit J1B-19 for continuity to terminal 2 of the ignition coil connector. Check for 55 volts on terminal 3 of ignition coil connector. Check for continuity between terminal 1 of ignition coil connector and chassis.
P0426	Exhaust temperature sensor functional problem	Intermittent exhaust temperature sensor reading or circuit wires shorted to ground.	Check system circuits J1A-12 for continuity to terminal 2 of the EGTS connector and J1A-27 for continuity to terminal 1 of the EGTS connector. Check circuit J1A-12 for continuity to ground. Replace the sensor if necessary.
P0427	Exhaust temperature sensor voltage too low	Exhaust temperature sensor or circuit wires shorted to ground.	Disconnect the sensor and check for a change in the fault code. If the fault code stays the same, check system circuit J1A-12 for continuity to terminal 2 of the EGTS connector and J1A-27 for continuity to terminal 1 of the EGTS connector. Check circuit J1A-12 for continuity to ground. If the fault code is different, replace the sensor.

**Section 03 ENGINE MANAGEMENT SYSTEM****Subsection 05 (MONITORING SYSTEM AND FAULT CODES)**

FAULT CODE	DESCRIPTION	CAUSE	ACTION
P0428	Exhaust temperature sensor voltage too high	Disconnected sensor or sensor's resistance too high.	Check for disconnected exhaust gas temperature sensor. Check the exhaust temperature sensor for 215 to 225 ohms at 19 to 21°C (66 to 70°F). Replace the sensor if necessary. Check system circuits J1A-12 for continuity to terminal 2 of the EGTS connector and J1A-27 for continuity to terminal 1 of the EGTS connector. Check circuit J1A-27 for continuity to ground.
P0562	Primary 12 volts circuit voltage too low	Battery failure, damaged circuit wires or connection, too much load on electrical system.	Check battery condition, check if additional accessories are connected in the circuit.
P0563	Primary 12 volts circuit voltage too high	An external battery charge may have been used, damaged ECM,	Measure primary 12 volts circuit voltage on diagnostic connector pin 3 and 5 for approximately 14 volts while engine is running. If it's higher than 15.5 volts you may have a damaged ECM. Make sure no external power is connected to the primary 12 volt circuit.
P0601	ECM memory checksum error	Damaged ECM.	Replace ECM.
P0608	Sensor's power supply voltage too low	Damaged circuit wires, shorted TPS or RAVE position sensor.	Disconnect TPS and RAVE position sensor. Check RAVE positions sensor connector for 5 volts between pin 1 and 3. Check system circuit J1A-10 for resistivity to ground.
P1217	Major engine overheat occurred	Poor cooling conditions. Engine may have been idling for too long. Low coolant level. Problem with cooling system.	Check coolant level. Check condition list to find out how it happened. Check cooling system.
P1217	Engine shutdown at idle because overheat occurred	Engine coolant temperature reached a high value at idle and the engine was stopped for protection.	Avoid keeping the engine idling for too long. Inspect cooling system for leaks.
P1231	Oil pump open circuit or shorted to ground	Damaged or disconnected oil pump, circuit wires or ECM output pins.	Check connection on oil pump, check system circuit J1B-23. Check WHITE/RED wire on oil pump connector for 55 volts.
P1326	High engine detonation detected on MAG side	Bad timing offset, engine temperature too high.	Check coolant system, check timing offset.
P1327	High engine detonation detected on PTO side	Bad timing offset, engine temperature too high.	Check coolant system, check timing offset.
P1351	MAG ignition shorted to system voltage	Damaged circuit wires or connector, damaged ignition coil.	Check system circuit J1B-26, check WHITE/RED wire on ignition coil connector for 55 volts.
P1352	PTO ignition shorted to system voltage	Damaged circuit wires or connector, damaged ignition coil.	Check system circuit J1B-19, check WHITE/RED wire on injector connector for 55 volts.



**Section 03 ENGINE MANAGEMENT SYSTEM**  
**Subsection 05 (MONITORING SYSTEM AND FAULT CODES)**

FAULT CODE	DESCRIPTION	CAUSE	ACTION
P1426	High exhaust gas temperature detected	Damaged sensor, low fuel pump pressure, air leak in exhaust system, poor fuel quality.	Check fuel pump pressure, check sensor and replace if necessary, check components in exhaust system.
P1471	RAVE position sensor functional problem	Damaged circuit wires or connector, damaged RAVE position sensor.	Check RAVE position sensor connector for 5 volts between pin 1 and 3. Check system circuit J1A-1.
P1472	RAVE position sensor voltage too low	Damaged circuit wires or connector, damaged RAVE position sensor.	Check RAVE position sensor connector for 5 volts between pin 1 and 3. Check system circuit J1A-1.
P1473	RAVE position sensor voltage too high	Damaged circuit wires or connector, damaged RAVE position sensor.	Check RAVE position sensor connector for 5 volts between pin 1 and 3. Check system circuit J1A-1.
P1476	RAVE valve middle position not reached	Damaged bellows. Damaged or disconnected hoses. Damaged E-RAVE solenoid valve. Adjustment of the link between the two E-RAVE valves. Carbon deposit around E-RAVE parts.	Check for damaged bellows. Check for damaged or disconnected vacuum hoses. Check for damaged or disconnected pressure hoses. Check if the E-RAVE valves move freely. Clean and make the necessary adjustment if necessary.
P1477	RAVE valve close position not reached	Damaged bellows. Damaged or disconnected hoses. Damaged E-RAVE solenoid valve. Adjustment of the link between the two E-RAVE valves. Carbon deposit around E-RAVE parts.	Check for damaged bellows. Check for damaged or disconnected vacuum hoses. Check for damaged or disconnected pressure hoses. Check if the E-RAVE valves move freely. Clean and make the necessary adjustment if necessary.
P1478	RAVE valve open position not reached	Damaged bellows. Damaged or disconnected hoses. Damaged E-RAVE solenoid valve. Adjustment of the link between the two E-RAVE valves. Carbon deposit around E-RAVE parts.	Check for damaged bellows. Check for damaged or disconnected vacuum hoses. Check for damaged or disconnected pressure hoses. Check if the E-RAVE valves move freely. Clean and make the necessary adjustment if necessary.
P1520	Critical low oil level detected	Engine has run with oil level lamp lit for too long.	Fill the oil tank with proper oil type.
P1532	High ECM temperature detected	Poor fuel flow in ECM. Damaged ECM.	Check fuel system for clogged filter, damaged regulator or damaged fuel pump.
P1533	Major ECM overheat occurred	Low fuel pressure, low fuel circulation in ECM.	Check fuel pump pressure, check fuel line for pinched hose.

**Section 03 ENGINE MANAGEMENT SYSTEM****Subsection 05 (MONITORING SYSTEM AND FAULT CODES)**

FAULT CODE	DESCRIPTION	CAUSE	ACTION
P1549	Major exhaust gas overheat occurred	Damaged sensor, low fuel pump pressure, air leak in exhaust system, poor fuel quality.	Check fuel pump pressure, check sensor and replace if necessary, check components in exhaust system.
P1562	Low voltage on 55 V system voltage circuit	Damaged circuit wires, connector, injector, ignition coil, oil pump, capacitor or ECM.	Check for inverted wires on magneto connector, loose connection on capacitor. Check for defective component as describe in possible causes.
P1563	High voltage on 55 V system voltage circuit	Damaged circuit wires, connector or ECM.	Check for inverted wires on magneto connector, loose connection on capacitor.
P1621	Overload on 12 V primary circuit	Damaged circuit wires or connector.	Check RED/ORANGE circuit for damaged or shorted wires. Check tail light, headlamp or diagnostic connector.
P1622	Overload on 12 V secondary circuit	Damaged circuit wires or connector.	Check RED/YELLOW circuit for damaged or shorted wire. Check connections on visor outlet, check heated grips if equipped with standard gauge.
P1623	Overload on 12 V battery circuit	Damaged circuit wires, connector or battery.	Check RED/WHITE circuit for damaged or shorted wire. Check battery condition. A blown 30 A fuse is a good indication of a problem with the wires or the battery.
P1660	Tachometer RPM signal open circuit or shorted to ground		
P1656	DESS line shorted to ground	Damaged circuit wires or mixed up connections.	Check system circuits J1A-23 for continuity to terminal 1 of DESS post connector, J1A-11 for continuity to terminal 3 of DESS post connector and J1A-5 for continuity to terminal 2 of DESS post connector. Check system circuit J1A-23 for continuity to circuit J1A-5 when DESS key is installed on DESS post. Check system circuit J1A-11 for continuity to the center contact of the DESS post connector and circuit J1A-5 for continuity to the outer ring of the DESS post. Check system circuits J1A-5, J1A-11 and J1A-23 for continuity to ground.
P1676	Battery relay open circuit or shorted to ground (electric start only)	Damaged or disconnected relay, circuit wires or terminals.	Check for disconnected relay, damaged circuit wires.

# FUEL TANK AND FUEL PUMP

## SERVICE TOOLS

Description	Part Number	Page
FLUKE 115 MULTIMETER .....	529 035 868 .....	245
FUEL HOSE ADAPTER.....	529 036 023 .....	233
FUEL PUMP NUT TOOL .....	529 036 118 .....	241-242
HOSE PINCHER .....	295 000 076 .....	235
LEAK TEST KIT .....	529 033 100 .....	231
PLIERS OETIKER 1099.....	295 000 070 .....	247
PRESSURE GAUGE.....	529 035 709 .....	233
SMALL HOSE PINCHER .....	295 000 076 .....	231, 237, 240
SUCTION PUMP .....	529 035 880 .....	234
VACUUM/PRESSURE PUMP .....	529 021 800 .....	231-232


## SERVICE PRODUCTS

Description	Part Number	Page
DIELECTRIC GREASE .....	293 550 004 .....	247

## Section 04 FUEL SYSTEM


### Subsection 01 (FUEL TANK AND FUEL PUMP)

500SS/600/800R



**Section 04 FUEL SYSTEM**  
Subsection 01 (FUEL TANK AND FUEL PUMP)

600 HO E-TEC



## Section 04 FUEL SYSTEM

### Subsection 01 (FUEL TANK AND FUEL PUMP)

#### GENERAL

**NOTE:** It is a good practice to check for fault codes using B.U.D.S. software as a first troubleshooting step. Refer to *MONITORING SYSTEM AND FAULT CODES*.

#### ⚠ WARNING


Always disconnect battery prior to working on the fuel system.

#### 600 HO E-TEC

#### ⚠ WARNING

Always disconnect the magneto connector prior to:

- Disconnecting any fuel hose.
  - Removing a fuel injector.
  - Removing a spark plug cable or spark plug.
- Otherwise, if the engine is cranked, fuel vapors may ignite in presence of a spark creating a fire hazard.



TYPICAL - 600 HO E-TEC

1. Magneto connector
2. Capacitor support

#### ⚠ WARNING

Always proceed with care and use appropriate safety equipment when working on pressurized fuel system. Wear safety glasses and work in a well ventilated area. Fuel lines remain under pressure at all times.

Use the B.U.D.S. software to release fuel pressure prior to removing a hose.

Cover the fuel line connection with an absorbent shop rag and slowly disconnect the fuel hose to minimize spilling.

#### ⚠ WARNING

Do not allow fuel to spill on hot engine parts and/or on electrical connectors. Wipe off any fuel spillage in the engine compartment. Fuel is flammable and explosive under certain conditions.

#### ⚠ WARNING

After working on the fuel system, carry out a fuel system pressurization test to check for leaks. Failure to carry out a fuel system leak test may result in severe injury or a life threatening situation should a leak occur.

## SYSTEM DESCRIPTION (500SS/600/800R)

### Fuel Pump

The fuel system on these models uses a diaphragm fuel pump. Engine vacuum pulses are used to activate the diaphragm in the fuel pump when the engine is running.

The pump draws in fuel from the fuel tank outlet and pushes it to the carburetors.

### Fuel Tank Vent

A simple fuel tank vent system comprised of a vent check valve is used to protect the fuel system.

The check valve, mounted on the fuel tank vent outlet, is a combination type valve. It acts as both a check valve and a pressure relief valve.

Ambient air pressure can enter the fuel tank at all times through the check valve.

As fuel is consumed by the engine, a negative pressure would occur in the fuel tank. This could eventually prevent the engine from receiving proper fuel pressure. The **negative pressure relieve function** of the valve allows the higher outside air pressure in.

If pressure in the fuel tank builds up and exceeds 2.0 to 4.8 kPa (.3 to .7 PSI), the **positive pressure relief function** opens the valve and lets excess pressure out of the tank.

### Fuel Filter

The system has one level of filtering, a fuel strainer at the fuel pick-up(s) within the fuel tank.

### Fuel Level Gauge

An electric float type fuel level sensor is used with the gauge for fuel level indication.

**SYSTEM DESCRIPTION  
(600 HO E-TEC)**

**Electric Fuel Pump**


The electric fuel pump is mounted in the front RH upper part of fuel tank.

A 12 Vdc high pressure fuel pump with a jet pump is used.

**NOTE:** Although the fuel pump is connected to the 55 Vdc system, the ECM modulates the voltage (Pulse Width Modulation) between 9 and 16 Vdc depending on the engine RPM. The fuel pump output will change as voltage changes.

As soon as the engine is cranked, the electric fuel pump turns on and runs continuously to provide fuel to the injectors.

To ensure a constant delivery of fuel to the engine for uphill, downhill or sideways riding conditions when the fuel quantity is low, a rear pickup and a sump tank at the bottom of the fuel pump module is used. A combination check valve allows the pump to draw fuel either from the front inlet or from the rear pickup.




1. Sump tank  
2. Check valve

The sump tank encompasses the fuel pump.

When there is enough fuel in the fuel tank, the bottom inlet of the fuel pump draws fuel from the sump tank.


When the fuel pump runs in this condition, fuel from the electric pump flows through a jet pump that contains a restrictor.



**VIEW INSIDE SUMP TANK**

- 1. Sump tank
- 2. Bottom inlet
- 3. Check valve (open upwards)
- 4. Restrictor

As the fuel accelerates through the restrictor, it generates a low pressure area at a connection to the rear pickup, which draws in fuel to fill the sump tank.



Step 1: Bottom inlet draws fuel from sump tank  
Step 2: Low pressure from restrictor draws fuel from rear pickup to fill sump tank


At the bottom of the sump tank, a check valve allows the fuel in the fuel tank to enter the sump tank.

As the fuel is drawn out of the sump tank by the electric pump, fuel in the vehicle tank naturally enters the sump tank through the sump tank check valve.

## Section 04 FUEL SYSTEM

### Subsection 01 (FUEL TANK AND FUEL PUMP)

When the vehicle rides downhill with a low amount of fuel in the tank, the fuel moves towards the front of fuel tank. The check valve opens and fuel enters from the fuel tank.



When the vehicle rides uphill with a low amount of fuel in the tank, the gas moves towards the rear of the fuel tank. The check valve closes and traps the fuel in the sump tank. The fuel pump draws fuel from the sump tank, which is fed by the rear pickup (as explained above). This prevents air from being drawn into the fuel lines from the fuel tank.

The continuous fuel flow cools down the fuel pump, the injectors and the ECM. To cool these components, the fuel circulates as follows:


- Out of fuel pump
- Through the ECM
- To the injectors (around the voice coils)
- Through the pressure regulator
- Back to fuel tank.

**NOTE:** The hose loop between the MAG injector outlet and the ECM dampens the engine torque reaction movement.

#### Fuel Pickup

Fuel enters into the sump tank from either an inlet at the bottom of the sump tank, or from a remote pickup in the rear portion of the fuel tank.

The bottom fuel pump inlet uses a nylon mesh filter, and the rear pickup uses a replaceable strainer to filter out relatively large dirt particles.



#### Fuel Pressure Regulator

An external in-line fuel pressure regulator made of plastic is mounted over the oil tank. It is basically a spring loaded valve that opens and closes the path of fuel returning to the tank, thus maintaining a constant fuel pressure in the system.

FUEL PRESSURE
Approximately 303 kPa (44 PSI) at 2000 RPM (will be lower at idle)

#### Fuel Tank Vent

The fuel tank is vented through a combination type check valve that allows ambient air pressure to enter fuel tank at all times.

As fuel is consumed by the engine, a negative pressure would occur in the fuel tank. This could eventually prevent the engine from receiving proper fuel pressure. The **negative pressure relieve function** of the valve allows the higher outside air pressure to enter the fuel tank.



If pressure builds up and exceeds 2.0 to 4.8 kPa (.3 to .7 PSI) in the fuel tank, the check valve opens and lets the excess pressure vent out of the tank.

### In-Line Fuel Filter

An in-line filter is located in front of fuel tank, above the oil tank.

It is a replaceable metallic canister type filter used to deliver dirt-free fuel to the injectors.

The fuel filter is sold as a kit that comprises an assembly of hoses, the filter, and the quick connect fittings.


### Fuel Level Indication

A float type fuel level sensor varies its resistance with fuel level thus providing a signal to the multifunction gauge for fuel level indication.

## INSPECTION

### FUEL SYSTEM PRESSURIZATION

1. Fill up fuel tank.
2. Open the left side panel to access the fuel vent line.
3. Install a SMALL HOSE PINCHER (P/N 295 000 076) on the vent line.



TYPICAL - HOSE PINCHER ON FUEL VENT LINE

### 500SS/600/800R


On these models, also install a hose pincher on the carburetor fuel feed line.

### All Models

4. Install the appropriate test cap from the LEAK TEST KIT (P/N 529 033 100) on fuel tank inlet.



5. Install VACUUM/PRESSURE PUMP (P/N 529 021 800) on pressure test fuel cap.



### TYPICAL

1. Pressure test fuel cap
2. Vacuum/pressure pump

6. Set pump selector to pressure.
7. Pressurize fuel tank as follows.

## Section 04 FUEL SYSTEM

### Subsection 01 (FUEL TANK AND FUEL PUMP)


PRESSURE	TIME WITHOUT PRESSURE DROP
21 kPa (3 PSI)	3 minutes

If pressure drops, locate fuel leak(s) and repair or replace leaking component(s).

To ease locating leak(s), spray soapy water on components; bubbles will indicate leak location(s).

#### Fuel Tank Check Valve Test

1. While the fuel tank is still pressurized as in the previous test, carry out the following:
2. Place a finger over the vent hose outlet.
3. When removing hose pincher, alternately touch and release vent hose outlet. You should feel pressurized air flowing out indicating the pressure relief valve function is working.
4. Release any remaining pressure in the fuel tank by slowly unscrewing fuel tank cap.
5. Remove the pressure test fuel cap.
6. Remove the fuel tank vent line from its fitting on the lower left front body panel.
7. Install the VACUUM/PRESSURE PUMP (P/N 529 021 800) on the vent line and apply air pressure through check valve. Air must flow freely towards the fuel tank neck.



TYPICAL - VACUUM/PRESSURE PUMP ON VENT LINE


**NOTE:** If fuel vent check valve does not function as indicated in test, replace check valve.

8. Remove vacuum/pressure pump.
9. Install vent line on its fitting.
10. Install normal fuel tank cap.

## FUEL PUMP PRESSURE TEST (600 HO E-TEC)

The pressure test will show the available pressure at the fuel pump outlet. It validates the pressure regulator and the fuel pump.

1. Ensure there is enough gas in fuel tank.
2. Connect vehicle to the latest B.U.D.S. software, refer to the *COMMUNICATION TOOLS AND B.U.D.S. SOFTWARE* section.
3. Release the fuel pressure in the system by selecting the following in B.U.D.S.:
  - 3.1 Read Data
  - 3.2 Activation tab
  - 3.3 ECM tab in the lower LH corner of the Activation page
  - 3.4 Fuel Press. Relief button in the Activate field.




RELEASING FUEL SYSTEM PRESSURE IN B.U.D.S.

1. Activation tab
  2. Fuel Press. Relief button on ECM page
4. Press the release button on the fuel pressure hose quick disconnect fitting and slowly pull the fitting off the ECM.

## Section 04 FUEL SYSTEM

### Subsection 01 (FUEL TANK AND FUEL PUMP)



mrv2008-071-002\_a

#### TYPICAL

1. ECM
2. Fuel pressure hose
3. Release button, quick disconnect fitting

**NOTE:** Place a container under the hose fitting to recover the fuel remaining in the system.

5. Install the FUEL HOSE ADAPTER (P/N 529 036 023) and the PRESSURE GAUGE (P/N 529 035 709) between fuel pressure hose and ECM.



mrv2008-030-003

**PRESSURE GAUGE WITH FUEL HOSE ADAPTER**



mrv2008-071-003\_a

1. ECM
2. Fuel pressure hose fitting
3. Fuel hose adapter to ECM fitting
4. Fuel hose adapter to pressure gauge

#### **⚠ WARNING**

When carrying out pressure test, ensure fuel is not leaking from test equipment onto hot exhaust system or electrical components. Ensure fuel hose do not come into contact with hot engine parts or hot exhaust system.

6. Start engine.
7. Run engine above 2000 RPM and observe the fuel pressure.

#### **FUEL PRESSURE**

303 kPa (44 PSI)

#### **FUEL PRESSURE TROUBLESHOOTING**

RESULT	POSSIBLE CAUSE
Pressure above specifications	Defective fuel regulator
	Clogged fuel filter
Pressure below specifications	Defective fuel regulator
	Defective fuel pump
	Leak in the fuel system circuit

8. Stop engine.  
Fuel pressure should remain stable.
9. If fuel pressure drops, check the following for leaks:
  - Tools
  - Hoses
  - Fuel injectors
  - Fuel pressure regulator
  - Fuel pump.

## Section 04 FUEL SYSTEM

### Subsection 01 (FUEL TANK AND FUEL PUMP)

10. Release fuel pressure using B.U.D.S. as described in this procedure.
11. Bleed away any remaining fuel in the pressure gauge and fuel hose adapter using the bleed valve on the fuel hose adapter.



1. Pressure gauge bleed valve

12. Remove pressure gauge and fuel hose adapter.
13. Reinstall the fuel pressure hose on ECM and gently but firmly pull on hose to ensure quick disconnect fitting is properly locked and secure on the ECM.
14. Reinstall all remaining removed parts.

## PROCEDURES


### FUEL TANK

#### Fuel Tank Removal

1. Remove the following items, refer to *BODY* section:
  - Seat
  - Both side panels
  - Hood
  - Console.
2. Drain fuel tank as much as possible using the SUCTION PUMP (P/N 529 035 880).




3. Remove the aft mounting bolt from the rear frame member forward mount, and the top mounting bolts from upper column support as indicated on the illustration. Discard the elastic nuts.



RIGHT SIDE SHOWN

1. At mounting bolt on rear frame member forward mount
2. RH top mounting bolt on upper column support



LEFT SIDE SHOWN

1. Top mounting bolt on LH upper column support
2. Brake hose retaining clamp

## Section 04 FUEL SYSTEM


### Subsection 01 (FUEL TANK AND FUEL PUMP)

4. Release the torque applied to the mounting bolt on the front frame member, but do not remove bolt and elastic nut.




1. Mounting bolt, front frame member

5. Remove trim panels covering the aft end of the rear frame members by pulling upwards, then pulling out (one each side).



6. Remove elastic nut and shoulder bushing retaining the rear frame members (one each side) to the tunnel (discard nuts, keep shoulder bushings).



1. Shoulder bushing  
2. Elastic nut


7. Disconnect the fuel level sensor connector.



#### TYPICAL

1. Fuel level sensor connector to disconnect

8. Disconnect the fuel tank vent line at the check valve.



#### TYPICAL - DISCONNECT FUEL VENT LINE

#### 500SS/600/800R Models


9. Install a small HOSE PINCHER (P/N 295 000 076) on the fuel tank outlet hose.
10. Disconnect the fuel line by cutting the Oetiker clamp and pulling the hose off the fitting.

#### **⚠ WARNING**

Work in a well ventilated area. Use a shop rag to absorb the residual fuel that will drain from the hose as it is disconnected.

## Section 04 FUEL SYSTEM

### Subsection 01 (FUEL TANK AND FUEL PUMP)




1. Install small hose pincher here
2. Remove this Dettiker clamp, fuel tank outlet hose

11. Carefully and slowly lift the aft end of the fuel tank from the side frame mounting studs and remove it from the vehicle.

#### 600 HO E-TEC

12. Connect vehicle to the latest B.U.D.S. software, refer to the *COMMUNICATION TOOLS AND B.U.D.S. SOFTWARE* section.
13. Release the fuel pressure in the system using B.U.D.S., refer to the fuel pump removal procedure in *ELECTRIC FUEL PUMP (600 HO E-TEC)* in this section.
14. Disconnect magneto connector.



- TYPICAL - 600 HO E-TEC**
1. Magneto connector
  2. Capacitor support

### **⚠ WARNING**

The magneto connector must be disconnected to prevent any spark in the engine compartment and to remove power from the fuel pump. Otherwise, if engine is cranked, fuel vapors may ignite in presence of a spark creating a fire hazard.


15. Cut the locking ties securing the fuel return hose to the fuel supply hose and to the upper column.

16. Press the release button on the fuel pressure hose quick disconnect fitting and slowly pull the fitting off the ECM.

**NOTE:** Place a container under the fitting to recover the fuel remaining in the system.

17. Cut the locking tie securing the pressure and return hoses together.


18. Remove the fuel pressure regulator from its holder on top of oil tank.



- TYPICAL**
1. Fuel pressure hose fitting at ECM
  2. Locking tie to remove
  3. Fuel pressure regulator holder

19. Move the fuel tank back sufficiently to access fuel pump connections.

20. Disconnect fuel pump electrical connector.



#### **FUEL PUMP CONNECTOR TO DISCONNECT**

21. Disconnect fuel supply pressure hose from fuel pump.

**Section 04 FUEL SYSTEM**  
Subsection 01 (FUEL TANK AND FUEL PUMP)



FUEL SUPPLY HOSE TO DISCONNECT

22. Install a SMALL HOSE PINCHER (P/N 295 000 076) on the fuel return hose close to the pump inlet.
23. Remove and discard the Oetiker clamp securing the fuel return hose to the fuel pump, then remove the fuel return hose from the pump.



TYPICAL - REMOVE AND DISCARD OETIKER CLAMP

**NOTE:** Place a container under the return hose end to recover the fuel remaining in the system.

24. Carefully and slowly lift the aft end of the fuel tank from the side frame mounting studs and remove it from vehicle.

### Fuel Tank Installation


Installation procedures are the reverse of the removal procedures however, pay attention to the following.

#### 500SS/600/800R

1. Position fuel tank on vehicle.
2. Connect fuel supply hose to fuel tank fitting using a **NEW** Oetiker clamp, then remove hose pincher.

### **⚠ WARNING**

Ensure hose clamp is tight and that hose cannot turn on the fitting.



1. New Oetiker clamp on fuel tank outlet hose

3. To continue installation, go to step 10 in 600 HO E-TEC.

#### 600 HO E-TEC

1. Position fuel tank on vehicle.
2. Install the fuel return hose on the fuel pump using a **NEW** Oetiker clamp before installing pressure hose and electrical connector.


### **⚠ WARNING**

Ensure hose clamp is tight and that hose cannot turn on the fitting.

3. Remove hose pincher from fuel return hose.
4. Connect the fuel supply hose to the fuel pump, then pull on hose to ensure the fitting is properly locked and secure.
5. Connect the fuel tank pump electrical connector.


## Section 04 FUEL SYSTEM

### Subsection 01 (FUEL TANK AND FUEL PUMP)



1. New Oetiker clamp
2. Fitting properly locked
3. Electrical connector installed

6. Move tank forward in normal position.
7. Insert fuel pressure regulator in its holder.
8. Connect pressure hose to ECM and pull on hose to ensure it is properly locked and secure.
9. Install the locking tie securing pressure hose and return hose together.



1. Ensure quick disconnect secure on ECM
2. Locking tie installed
3. Pressure regulator in holder


10. Connect the fuel level sensor connector.



#### TYPICAL

1. Fuel level sensor connected

11. Install the vent tube on check valve.



#### TYPICAL - FUEL VENT LINE CONNECTED

### **⚠ WARNING**

Ensure vent tube is not kinked or pinched.

12. Install shoulder bushings and NEW elastic nuts on the rear frame members (one each side).
13. Torque nuts securing aft end of rear frame members to 33 N•m (24 lbf•ft).




## Section 04 FUEL SYSTEM

### Subsection 01 (FUEL TANK AND FUEL PUMP)




1. Shoulder bushing  
2. Elastic nut

14. Insert the mounting bolts on the rear frame members forward mounts, and the two upper mounting bolts on the upper column supports. Secure with **NEW** elastic nuts.



- RIGHT SIDE SHOWN**  
1. Rear frame member mounting bolt  
2. Mounting bolts on upper column supports (one each side)

**NOTE:** Be sure to install the brake hose clamp on the LH upper column support mounting bolt.



- LEFT SIDE SHOWN**  
1. LH upper column support mounting bolt  
2. Brake hose retaining clamp

15. Torque nut on rear frame members mounting bolt and top nuts on upper column supports to 18 N•m (159 lbf•in).
16. Torque elastic nut on the front frame member mounting bolt to 18 N•m (159 lbf•in).



1. Mounting bolt, front frame member

17. Install all remaining parts.
18. Torque the fuel tank filler neck nut to 11 N•m (97 lbf•in).
19. Carry out a fuel system leak test, refer to **FUEL SYSTEM PRESSURIZATION** in this section.

#### **WARNING**

After working on the fuel system, carry out a fuel system pressurization test to check for leaks. Failure to carry out a fuel system leak test could result in severe injury or a life threatening situation should a leak occur.

20. Refuel tank.

## DIAPHRAGM FUEL PUMP (500SS/600/800R)

### Fuel Pump Test

Check fuel pump valves operation as follows:

1. Empty fuel tank.

**NOTE:** For the following test, ensure hoses have a tight fit.

2. Disconnect outlet hose from fuel tank.
3. Alternately apply pressure and vacuum with pump from leak test kit to disconnected hose. The inlet valve should release with pressure and hold under vacuum.
4. Disconnect inlet hose from carburetor.

## Section 04 FUEL SYSTEM

### Subsection 01 (FUEL TANK AND FUEL PUMP)

5. Repeat the same procedure to disconnected hose. This time the outlet valve should hold with pressure and release under vacuum.

#### Fuel Pump Removal

1. Remove the primary air intake silencer.

**NOTE:** Do not disconnect cables from carburetors.

2. On 800R models, disconnect the TPS connector.
3. Install a SMALL HOSE PINCHER (P/N 295 000 076) on the fuel supply line close to the pump outlet.
4. Remove the Norma spring clamp and disconnect the carburetors fuel supply line at the fuel pump outlet.

**NOTE:** Use a rag and a container to recover the fuel flowing from the disconnected hose.

5. Install larger pinchers on the carburetor(s) coolant lines.
6. Remove Norma spring clamp and disconnect the impulse (vacuum) line at the fuel pump.
7. Disconnect carburetors from engine and move them aside for access to the fuel pump.
8. Remove screws securing fuel pump to chassis.

#### Fuel Pump Installation

1. Reverse the removal procedure.
2. Carry out a fuel system pressurization test to ensure there isn't a leak in the fuel system.

#### **⚠ WARNING**

After working on the fuel system, carry out a fuel system pressurization test to check for leaks. Failure to carry out a fuel system leak test could result in severe injury or a life threatening situation should a leak occur.

### ELECTRIC FUEL PUMP (600 HO E-TEC)

#### Fuel Pump Test With B.U.D.S.

**NOTE:** Activating the fuel pump as described in this procedure can be used for purging air from the fuel system whenever a fuel hose has been disconnected and reconnected. The pump should be activated for 15 seconds to ensure proper purging of the system.

1. Connect vehicle to the latest B.U.D.S. software, refer to *COMMUNICATION TOOLS AND B.U.D.S. SOFTWARE* subsection.

2. In B.U.D.S., select the following to activate the fuel pump.

- 2.1 **Read Data**
- 2.2 **Activation tab**
- 2.3 **ECM tab** in the lower LH corner of the **Activation** page
- 2.4 **Fuel Pump (Click/Hold)** button in the **Activate** field.

3. Listen for fuel pump operation.

**NOTE:** The fuel pump should run as long as you hold the **Fuel Pump (Click/Hold)** button in B.U.D.S.

If you do not hear the pump come ON, select the **Faults** tab in B.U.D.S. and check for fault codes.

If there is no fault code, connect a known good fuel pump to the vehicle harness (in parallel) and repeat the test.

If the second fuel pump functions when connected to the vehicle harness, then replace the fuel pump installed in the vehicle.

#### Fuel Pump Pressure Test


Refer to *INSPECTION* in this section.

#### Fuel Pump Removal

1. Connect vehicle to the latest B.U.D.S. software, refer to the *COMMUNICATION TOOLS AND B.U.D.S. SOFTWARE* section.
2. Release the fuel pressure in the system by selecting the following in B.U.D.S.:
  - **Read Data**
  - **Activation tab**
  - **ECM tab** in the lower LH corner of the **Activation** page
  - **Fuel Press. Relief** button in the **Activate** field.


## Section 04 FUEL SYSTEM

### Subsection 01 (FUEL TANK AND FUEL PUMP)



#### RELEASING FUEL SYSTEM PRESSURE IN B.U.D.S.

1. Activation tab
  2. Fuel Press. Relief button on ECM page
3. Disconnect magneto connector.



#### TYPICAL - 600 HO E-TEC

1. Magneto connector
2. Capacitor support

### ⚠ WARNING


The magneto connector must be disconnected to prevent any spark in the engine compartment and to remove power from the fuel pump. Otherwise, if engine is cranked, fuel vapors may ignite in presence of a spark creating a fire hazard.

Follow procedures for removing fuel tank and move fuel tank back for access to fuel pump. Refer to *FUEL TANK REMOVAL* in this section.

4. Disconnect fuel pump as described in the *FUEL TANK REMOVAL* procedure in this section.
5. Using the FUEL PUMP NUT TOOL (P/N 529 036 118), remove fuel pump spanner nut.



6. Remove fuel pump assembly from fuel tank.



#### TYPICAL — ELECTRIC FUEL PUMP ASSEMBLY

7. Remove and discard fuel pump gasket.

### Fuel Pump Installation


For installation, reverse the removal procedure however, pay attention to the following.

1. Install a **NEW** gasket on the fuel pump prior to installing the pump in the tank.

**NOTE:** The gasket must be installed on the fuel tank side so it is located between the pump and the fuel tank.

## Section 04 FUEL SYSTEM

### Subsection 01 (FUEL TANK AND FUEL PUMP)



mmv2009-022-100\_a

**TYPICAL - FUEL PUMP INSTALLATION**

1. Fuel pump spanner nut
2. Fuel pump face plate
3. Fuel pump gasket

2. Install a torque wrench perpendicularly (90°) to FUEL PUMP NUT TOOL (P/N 529 036 118).
3. Torque fuel pump spanner nut as specified in exploded view.



mmv2009-030-011

**TORQUE WRENCH AT 90°**

4. To reconnect fuel pump and install fuel tank, refer to the *FUEL TANK INSTALLATION* procedure in this section.
5. Carry out a fuel system leak test, refer to *FUEL SYSTEM PRESSURIZATION* in this section.

#### **⚠ WARNING**


After working on the fuel system, carry out a fuel system pressurization test to check for leaks. Failure to carry out a fuel system leak test could result in severe injury or a life threatening situation should a leak occur.

## FUEL PRESSURE REGULATOR (600 HO E-TEC)

The fuel pressure regulator is an in-line type and is acquired as an assembly with the fuel return hose.

### Fuel Pressure Regulator Removal

1. Connect vehicle to the latest B.U.D.S. software, refer to the *COMMUNICATION TOOLS AND B.U.D.S. SOFTWARE* section.
2. Use B.U.D.S. to release fuel pressure as described in the fuel pump removal procedure.
3. Remove both side panels.
4. Disconnect magneto connector.



mmv2009-025-001\_b


**TYPICAL - 600 HO E-TEC**

1. Magneto connector
2. Capacitor support

#### **⚠ WARNING**

The magneto connector must be disconnected to prevent any spark in the engine compartment and to remove power from the fuel pump. Otherwise, if engine is cranked, fuel vapors may ignite in presence of a spark creating a fire hazard.

5. Cut the locking ties securing the fuel return hose to the fuel supply hose and to the upper column.
6. Pull back corrugated plastic sheath and install a small hose pincher on the return hose forward of the fuel pressure regulator.
7. Remove and discard Oetiker clamp on the fuel return hose aft of the fuel pressure regulator.



1. Locking ties to cut
2. Pull back plastic sheath and install hose pincher here
3. Remove this Oetiker clamp

8. Disconnect fuel return hose from the pressure regulator fitting.

**NOTE:** Place a container under the fuel return hose and drain the fuel remaining in hose.

9. Remove fuel pressure regulator from holder on oil tank.

10. Place a container under the pressure regulator, remove the hose pincher, and drain the fuel in the hose.

11. Disconnect the fuel return hose from both fuel injectors, refer to the *E-TEC DIRECT FUEL INJECTION* section for specific details.

**NOTE:** Be sure to place shop rags around the injector hose fittings to catch the fuel spillage.



1. Fuel return hose to remove at injectors

12. Remove fuel pressure regulator hose assembly from vehicle.

### Fuel Pressure Regulator Installation

For installation, reverse the removal procedures. However, pay attention to the following.

Be sure to strictly follow the procedures in the *E-TEC DIRECT FUEL INJECTION* section when re-connecting fuel return hose to injectors.

Install a NEW Oetiker clamp to retain the fuel return hose to the fuel pressure regulator.

#### **WARNING**

Ensure hose clamp is tight and that hose cannot turn on the fitting.

When installation is complete, carry out a fuel system leak test, refer to *FUEL SYSTEM PRESSURIZATION* in this section.


#### **WARNING**

After working on the fuel system, carry out a fuel system pressurization test to check for leaks. Failure to carry out a fuel system leak test could result in severe injury or a life threatening situation should a leak occur.

### IN-LINE FUEL FILTER (600 HO E-TEC)

#### In-line Fuel Filter Removal

1. Connect vehicle to the latest B.U.D.S. software, refer to the *COMMUNICATION TOOLS AND B.U.D.S. SOFTWARE* section.
2. Use B.U.D.S. to release fuel pressure as described in the fuel pump removal procedure.
3. Remove both side panels.
4. Disconnect magneto connector.



- TYPICAL - 600 HO E-TEC**
1. Magneto connector
  2. Capacitor support

## Section 04 FUEL SYSTEM

### Subsection 01 (FUEL TANK AND FUEL PUMP)

#### **⚠ WARNING**

The magneto connector must be disconnected to prevent any spark in the engine compartment and to remove power from the fuel pump. Otherwise, if the engine is cranked, fuel vapors may ignite in presence of a spark creating a fire hazard.


5. Cut the locking ties securing the fuel return hose to the fuel supply hose.

#### **⚠ WARNING**

Work in a well ventilated area. Wipe up all spilled fuel.

6. Press the release button on the fuel pressure hose quick disconnect fitting and slowly pull the fitting off the ECM.

**NOTE:** Place a container under the hose fitting to recover residual fuel remaining in the system.



#### TYPICAL

1. In line fuel filter
2. Locking tie to cut
3. Quick disconnect fitting

7. Remove the primary air intake silencer. Refer to *AIR INTAKE SYSTEM* section.

8. Move fuel tank back sufficiently to access the pressure hose fitting at the fuel pump. Refer to *FUEL TANK REMOVAL* in this section.

**NOTE:** Pressure hose fitting will be accessible from the LH side. It is not necessary to completely disconnect fuel pump or fuel level sensor.

9. Place a rag under the quick disconnect fitting at the fuel pump and disconnect it from the fuel pump.



TYPICAL - FUEL SUPPLY LINE TO DISCONNECT

10. Remove fuel filter from vehicle.

## In-line Fuel Filter Installation

The installation is the reverse of the removal procedure.

#### **⚠ WARNING**

Ensure hose clamp is tight and that hose cannot turn on the fitting.

When reconnecting quick disconnect pressure fittings to fuel pump and ECM, be sure to pull on the each end of the hose to ensure they are properly locked and secure.

When installation is complete, carry out a fuel system leak test, refer to *FUEL SYSTEM PRESSURIZATION* in this section.

#### **⚠ WARNING**


After working on the fuel system, carry out a fuel system pressurization test to check for leaks. Failure to carry out a fuel system leak test could result in severe injury or a life threatening situation should a leak occur.

## FUEL LEVEL SENSOR

### Sensor Fuse Inspection

The fuel level sensor circuit is protected by an in line 0.25 A fuse located near the sensor. Check fuse to see if it is blown.

To access the fuel level sensor fuse, remove the primary air intake silencer.



**TYPICAL**  
 1. Fuel level sensor  
 2. In-line fuse  
 3. Connector  
 4. Corrugated plastic sheath

### Fuel Level Sensor Resistance Test

1. Obtain access to fuel level sensor connector, refer to *FUEL TANK REMOVAL* in this section.
2. Disconnect fuel level sensor.



1. Fuel sensor connector to disconnect

3. Connect the FLUKE 115 MULTIMETER (P/N 529 035 868) between the two pins in the sensor connector and set it to  $\Omega$ .
4. Test resistance of sensor as follows.

FUEL LEVEL SENSOR RESISTANCE TEST	
Full level resistance value	$7 \Omega \pm 3 \Omega$
Empty level resistance value	$95 \Omega \pm 5 \Omega$

Replace sensor if not as specified in table.


### Fuel Level Sensor Removal

1. Drain fuel tank.
  2. Move fuel tank back sufficiently to access fuel sensor and connector. Refer to *FUEL TANK REMOVAL* in this section.
- NOTE:** It is not necessary to disconnect fuel pump.
3. Disconnect fuel sensor connector.



1. Fuel level sensor connector to disconnect

4. Cut locking ties securing grommet.




1. Grommet locking ties

5. Insert a screwdriver between grommet and sensor face plate. Gently pry sensor loose in grommet.

**NOTE:** Do not try to remove sensor from grommet at this time.

## Section 04 FUEL SYSTEM

### Subsection 01 (FUEL TANK AND FUEL PUMP)



#### TYPICAL

1. Screwdriver inserted between grommet and face of sensor

6. Remove grommet from fuel tank.



1. Remove grommet from tank

7. Carefully rotate sensor as you pull it out of fuel tank.

**NOTICE** Float arm is precisely bent and must not be altered on removal or installation.

#### Fuel Level Sensor Installation

1. Fuel level sensor installation is the reverse of removal procedure. Pay attention to the following.
2. Carry out a resistance test of sensor before installation, refer to *FUEL LEVEL SENSOR RESISTANCE TEST* in this section.
3. To ease grommet and fuel level sensor installation, spray a fine mist of plain water (NO SOAP) on outer beveled surface and inner surface of grommet.




1. Spray water on beveled surface
2. Spray water on inner diameter of grommet

4. Insert grommet in fuel tank ensuring it fully locks in position with the grommet alignment indicator at the **twelve o'clock position**.

5. Carefully insert float sensor through hole in grommet gently rotating it in position.


**NOTE:** Ensure the flat side of sensor is pointing in a general upwards direction.



1. Alignment indicator facing up at 12 o'clock position
2. Flat side of sensor upwards position

6. Align top flat portion of sensor with alignment boss on grommet and push it in until it bottoms out.






1. Alignment boss on grommet
2. Flat side of sensor aligned to grommet

**NOTE:** Note the angle at which the fuel level sensor is positioned. Some fuel tanks may have 2 alignment index marks molded on the fuel tank side. Disregard the index marks on fuel tank. The sensor **must** be aligned with the grommet alignment boss, and the grommet alignment indicator must be at the twelve o'clock position for proper sensor operation.

7. Install locking ties to secure grommet on fuel level sensor.



**TYPICAL**


1. Disregard alignment index marks on fuel tank
2. Grommet alignment indicator must be at twelve o'clock
3. Sensor alignment boss on grommet
4. Sensor aligned to grommet boss
5. Locking ties secured

8. Use DIELECTRIC GREASE (P/N 293 550 004) in connector to prevent corrosion.
9. Carry out a fuel system leak test, refer to **FUEL SYSTEM PRESSURIZATION** in this section.
10. Test fuel level indication as you fill fuel tank before you complete reassembly of vehicle.


## OETIKER CLAMPS

### Clamp Replacement


To secure or cut Oetiker clamps on fuel lines, use PLIERS OETIKER 1099 (P/N 295 000 070).



1. Cutting clamp



1. Securing clamp



1. Securing clamp in limited access

### **⚠ WARNING**

Use of improper fuel lines could compromise fuel system integrity.

# TM CARBURETORS


## SERVICE TOOLS

<b>Description</b>	<b>Part Number</b>	<b>Page</b>
CARBURETOR TOOL KIT.....	404 112 000 .....	253
DIGITAL INDUCTIVE TYPE TACHOMETER .....	529 014 500 .....	257
SMALL HOSE PINCHER .....	295 000 076 .....	261
SUPPLY CABLE .....	529 035 997 .....	260
SUPPLY HARNESS.....	529 035 869 .....	260

## SERVICE PRODUCTS

<b>Description</b>	<b>Part Number</b>	<b>Page</b>
DIELECTRIC GREASE .....	293 550 004 .....	263
LOCTITE 243 (BLUE).....	293 800 060 .....	255, 261

**Section 04 FUEL SYSTEM**  
Subsection 02 (TM CARBURETORS)




## PROCEDURES

### CARBURETORS

**NOTE:** On 800R models, it is a good practice to check for fault codes using B.U.D.S. software as a first troubleshooting step. Refer to *MONITORING SYSTEM AND FAULT CODES* section.

#### Carburetor Identification

TM type dual carburetor assembly is identified on PTO side carburetor body.



A32C3KA

TYPICAL

1. Identification number

CARBURETOR IDENTIFICATION NUMBER	
500SS/600	TM40-394
800R (MX Z)	TM40-397
800R (SUMMIT)	TM40-400

#### Carburetor Removal


Remove LH side panel.

Remove belt guard. Refer to *DRIVE SYSTEM AND BRAKE* section.

Remove primary air intake silencer. Refer to *AIR INTAKE SYSTEM* section.

##### 500SS/600


Disconnect vent hose.



1. Hose

##### 800R

Disconnect DPM manifold top hose and connector.




1. Hose  
 2. Connector

##### 500SS/600/800R


Turn heated carburetor coolant inlet line valve to OFF position.

## Section 04 FUEL SYSTEM

### Subsection 02 (TM CARBURETORS)




1. Inlet line valve



1. OFF position

Disconnect inlet line from carburetor taking care to recuperate coolant.



1. Disconnect here


Loosen clamps retaining carburetors to intake adapters.

Detach carburetors from intake adapters.

Lift carburetors then disconnect fuel line from fuel pump. Take care to recuperate fuel.


#### **⚠ WARNING**

Fuel is flammable and explosive under certain conditions. Always wipe off any fuel or oil spillage from the vehicle. Ensure work area is well ventilated. Do not smoke or allow open flames or sparks in the vicinity.



1. Disconnect here

Detach and disconnect throttle and choke cables.




1. Throttle cable  
2. Choke cable

#### **800R**

Disconnect TPS connector.

## Section 04 FUEL SYSTEM


### Subsection 02 (TM CARBURETORS)



1. Connector

#### 500SS/600/800R

Pinch and disconnect heated carburetor outlet line taking care to recuperate coolant.




1. Outlet line  
2. Hose pincher

Remove carburetors.

#### Carburetor Disassembly

**NOTE:** To ease the carburetor disassembly and assembly procedures, it is recommended to use the CARBURETOR TOOL KIT (P/N 404 112 000).



#### Float Bowl

Unscrew drain plug no. 2 and screws no. 3.

Remove float bowl no. 6.

#### Float and Needle Valve Assembly

Unfasten both screws then, pull out float and needle valve assembly no. 1.

#### Main Jet

The main jet no. 5 installed in the carburetor has been selected for a temperature of  $-18^{\circ}\text{C}$  ( $0^{\circ}\text{F}$ ) at sea level. Different jetting can be installed to suit temperature and altitude changes. A Service Bulletin gives information about calibration according to altitude and temperature.

Main jet may be removed without removing float bowl no. 6 by first removing drain plug no. 2.

#### Pilot Jet

Use narrow screwdriver from the CARBURETOR TOOL KIT (P/N 404 112 000) to unscrew pilot jet no. 7.

#### Throttle Slide

#### **WARNING**

It is critical to the free operation of the throttle slide that the 2 connecting plates as assembled in one carburetor be of the exact same length. Always replace the connecting plates by a pair of new ones that were matched at the factory for length and discard the old ones. Simultaneously replace all the plates of the carburetors of a same rack.


Do not disassemble throttle slide no. 17 needlessly.

**NOTICE** After throttle slide reassembly, proceed with a leak test. See below for procedure.

1. Disassemble both carburetors at the same time. Coolant hose between carburetor throttle slide covers must remain in place during the complete disassembly and assembly.
2. Remove carburetor cover.
3. Loosen needle retainer screw no. 8.
4. Fully open throttle and hold in this position.
5. Move aside needle retainer no. 9.


## Section 04 FUEL SYSTEM

### Subsection 02 (TM CARBURETORS)




1. Needle retainer moved aside

6. Turn dual carburetor assembly upside down to free needle no. 10. Take care not to lose plastic washer no. 11 under needle circlip no. 12.




1. Plastic washer

7. Unscrew throttle slide cover screws no. 13.
8. Open throttle 3/4 wide and keep that opening.
9. Lift throttle slide covers bottom first until they are free from carburetor bodies. Then, slide them out.



Step 1: Lift bottom first  
Step 2: Slide out

10. Remove circlip no. 14 retaining throttle slide.



1. Circlip

## Carburetor Cleaning

The entire carburetor should be cleaned with a general solvent and dried with compressed air.

**NOTICE** Heavy duty carburetor cleaner may be harmful to the float material and to the rubber parts, O-rings, etc. Therefore, it is recommended to remove those parts prior to cleaning.

Carburetor body and jets should be cleaned in a carburetor cleaner following manufacturer's instructions. When jets are very dirty or coated with varnish and gum, replace them.

**⚠ WARNING**

Solvent with a low flash point such as gasoline, naphtha, benzol, etc., should not be used as they are flammable and explosive.

### Carburetor Inspection

1. Check throttle slide for wear. Replace as necessary.
2. Check for fuel soaked into float no. 1; replace as necessary.
3. Check float for cracks or other damages affecting free movement; replace as necessary.

### Carburetor Assembly


The assembly is the reverse of the disassembly procedure. Pay attention to the following.

#### Float and Needle Valve Assembly

Apply LOCTITE 243 (BLUE) (P/N 293 800 060) on screw threads.

#### Throttle Slide

At throttle slide assembly, needle retainer must face carburetor body.



1. Needle retainer
2. Ensure O-ring gasket is properly seated in nipple area

After inserting throttle slide cover in place and before installing screws, ensure O-ring gasket is properly seated in its groove especially in the area around vent nipple. See illustration above.

### Carburetor Installation

The installation is the reverse of the removal procedure. However, pay attention to the following.

If carburetors were disassembled, adjustments should be performed following this sequence:

1. Carburetor synchronization


2. Pilot screw adjustment
3. Closed throttle reset (TPS) (800R)
4. Throttle cable adjustment
5. Idle speed adjustment
6. Choke cable adjustment.

Refer to procedures in this section in regards with these adjustments.

### Carburetor Synchronization


To ensure throttle cable does not pull on throttle slide, do the following:

1. Loosen throttle cable housing adjusting and locking nuts.



1. Throttle cable
2. Adjusting nut
3. Locking nut

2. Unscrew idle speed screw until there is a gap between tip of screw and throttle lever stopper.



1. Idle screw
2. Throttle lever stopper
- A. Gap required here




## Section 04 FUEL SYSTEM

### Subsection 02 (TM CARBURETORS)


To perform carburetor synchronization, first proceed on PTO carburetor.

1. Use a drill bit to measure flat slide height (see following table) on outlet side of carburetor (engine side).
2. Adjust by turning idle speed screw no. 15.



1. Adjust PTO carburetor first
2. Drill bit used as a gauge to measure flat slide height
3. Idle speed screw

3. For MAG carburetor use synchronization screw. Use same drill bit as for PTO carburetor to measure flat slide height. Turn synchronization screw to adjust.




1. PTO carburetor adjusted first
2. Drill bit used as a gauge to measure flat slide height
3. Synchronization screw

MODEL	FLAT SLIDE HEIGHT (DRILL BIT SIZE)
500SS/600	1.5 mm $\pm$ 0.1 mm (.059 in $\pm$ .004 in)
800R	Summit: 2.0 mm $\pm$ 0.1 mm (.079 in $\pm$ .004 in) Others: 1.6 mm $\pm$ 0.1 mm (.063 in $\pm$ .004 in)

### Pilot Screw Adjustment

Completely close the pilot screw (until a slight seating resistance is felt) then back off as specified.



1. Pilot screw (one on each carburetor)

Turning screw in clockwise leans mixture and conversely, turning it out counterclockwise enriches mixture.

ENGINE	TURNS
500SS/600/800R	1.5

### Closed Throttle Reset (TPS)

#### 800R

This reset is very important. The setting of the TPS will determine the basic parameters for all fuel and ignition mappings. An improperly set TPS may lead to poor engine performance.

Reset must be done each time one of the following conditions is met:


- Throttle position sensor (TPS) is loosened or removed
- Carburetor is replaced
- ECM is replaced.

Refer to *THROTTLE POSITION SENSOR (TPS)* in this section.

## Idle Speed Adjustment

**NOTICE** Before starting engine for the idle adjustment, make sure that oil pump is adjusted. The oil pump adjustment must be checked after each time carburetor idle is adjusted. Refer to *LUBRICATION SYSTEM* section.

1. Start engine and allow it to warm.
2. Adjust idle speed to specifications by turning idle speed screw clockwise to increase engine speed or counterclockwise to decrease it.
3. Use a DIGITAL INDUCTIVE TYPE TACHOMETER (P/N 529 014 500) to set idle speed.



TACHOMETER

**NOTICE** Do not attempt to set the idle speed by using the pilot screw. Severe engine damage can occur.


MODEL	IDLE SPEED (RPM $\pm$ 200)
500SS/600	1600
800R	Summit: 1900 Others: 1600

## THROTTLE POSITION SENSOR (TPS)

*800R*

### General

The throttle position sensor (TPS) is a potentiometer that sends a signal to the ECM which is proportional to the throttle opening.



1. Throttle position sensor (TPS)

Before replacing the TPS, check the following as these could be causing the fault.

- Throttle cable adjustment too tight or there is not enough free-play. Not returning fully to idle stop.
- Throttle idle set screw is loose or worn.
- TPS is loose.
- Corroded or damaged wiring or connectors.
- Carburetors have been replaced and the Closed Throttle reset has not been performed.
- ECM has been replaced and the Closed Throttle reset has not been performed.

The ECM may generate several fault codes pertaining to the TPS. Refer to *MONITORING SYSTEM AND FAULT CODES* section for more information.

### Closed Throttle Reset (TPS)

This reset is very important. The setting of the TPS will determine the basic parameters for all fuel and ignition mappings. An improperly set TPS may lead to poor engine performance.


Reset must be done each time one of the following conditions is met:

- Throttle position sensor (TPS) is loosened or removed.
- Carburetor is replaced.
- ECM is replaced.

1. Unscrew idle speed screw until there is a gap between tip of screw and throttle lever stopper.


## Section 04 FUEL SYSTEM

### Subsection 02 (TM CARBURETORS)



- 1. Idle screw
- 2. Throttle lever stopper
- A. Gap required here

2. Use B.U.D.S. software.
3. Push the **Reset** button in the **Setting** tab of B.U.D.S.



#### SETTING TAB


4. If TPS is not within the allowed range while re-setting the **Closed Throttle**, the ECM will generate a fault code and will not accept the setting. Verify the following:
  - 4.1 Ensure throttle cable has enough free-play (flat slides must be closed).
  - 4.2 Throttle position sensor (TPS).
  - 4.3 If reset is successful, check throttle cable adjustment.
  - 4.4 Adjust idle speed.

#### TPS Resistance Test

1. Disconnect ECM connector.
2. Unscrew idle speed screw until there is a gap with the throttle lever stopper.

3. **IMPORTANT:** Remember to perform the **Closed Throttle Reset** procedure when all tests will be done since the idle screw was loosened for the test.


**NOTE:** The gap between idle speed screw and stopper is important to ensure throttle slide is completely closed to read TPS resistance values.



- 1. Idle screw
- 2. Throttle lever stopper
- A. Gap required here

4. Activate throttle lever 2 - 3 times to make sure throttle slides are fully closed.
5. Using a multimeter, check resistance values as per the following table.

ECM CONNECTOR		THROTTLE POSITION	
PIN		IDLE	WIDE OPEN
22	4	3680 - 5520 $\Omega$	480 - 720 $\Omega$
22	1	4000 - 6000 $\Omega$	
4	1	480 - 720 $\Omega$	3680 - 5520 $\Omega$



**NOTE:** The resistance value should change smoothly and proportionally to the throttle movement. Otherwise, replace TPS.

- If resistance values are good, perform wear test and voltage test.
- If resistance test fails, perform the following continuity test.

### TPS Wiring Continuity Test

- Disconnect TPS connector.


**NOTE:** To disconnect TPS connector, firmly press locking tab on top outer side of connector to release it.



1. Firmly squeeze here

- Disconnect ECM connector and check continuity of wires between TPS connector and ECM connector.

TPS CONNECTOR	ECM CONNECTOR	RESULT
Pin 1	DA-22	Close to 0 Ω
Pin 2	DA-4	
Pin 3	DA-1	



ECM CONNECTOR

- If test fails, repair or replace wiring harness.
- If test succeeds, check for short-circuit of ECM wiring to ground as follows.

ECM CONNECTOR		RESULT
DA-22	With chassis ground	Open circuit (OL)
DA-4		
DA-1		

- If test fails, repair or replace wiring harness.
- If test succeeds, perform wear test and voltage test.

### TPS Wear Test

- While engine is not running, activate throttle and pay attention for smooth operation without physical stops of the cable.
- Use B.U.D.S. software.
- Use the **Throttle Opening** display under **Monitoring**.
- Slowly and regularly depress the throttle. Observe the needle movement. It must change gradually and regularly as you move the throttle. If the needle "sticks", bounces, suddenly drops or if any discrepancy between the throttle movement and the needle movement is noticed, it indicates a worn TPS that needs to be replaced.

## Section 04 FUEL SYSTEM

### Subsection 02 (TM CARBURETORS)

#### TPS Voltage Test

##### Preparation

To gain access to TPS, do the following:


- Remove pulley guard. Refer to *DRIVE SYSTEM AND BRAKE* section.
- Remove primary air intake silencer. Refer to *AIR INTAKE SYSTEM* section.

##### Test

1. Ensure ECM connectors are connected.
2. Disconnect TPS connector.



3. Check the voltage readings from harness connector as follows.
4. Connect the SUPPLY HARNESS (P/N 529 035 869) to the 6-pin diagnostic connector of vehicle. Connect the SUPPLY CABLE (P/N 529 035 997) to supply harness. Connect clips to vehicle battery. Ensure to match RED wires together and BLACK wires together.




SUPPLY HARNESS



SUPPLY CABLE

NOTE: On manual start models, use an external 12 V battery.


TPS CONNECTOR	VOLTAGE
Pin 1 with pin 3	5.0 Vdc




5. If voltage is not as per specification and all other resistance test were done, try a new ECM.

#### TPS Replacement

1. Remove pulley guard. Refer to *DRIVE SYSTEM AND BRAKE* section.
2. Remove primary air intake silencer. Refer to *AIR INTAKE SYSTEM* section.
3. Remove adapter plate from carburetors.




4. Loosen carburetor clamps.
5. Install a SMALL HOSE PINCHER (P/N 295 000 076) on each coolant hoses connected to carburetors.



1. Install hose pinchers

6. Disconnect coolant hoses from carburetors.
- NOTE:** Keep throttle cable installed to avoid further adjustment.
7. Properly rotate and slightly pull out carburetors to gain access to TPS.
  8. Loosen two screws retaining the TPS.
  9. Remove TPS.



**CARBURETOR**

1. Throttle position sensor (TPS)
2. Screws

10. Install the new TPS.
11. Apply LOCTITE 243 (BLUE) (P/N 293 800 060) on the TPS retaining screws, then torque to 3 N•m (27 lbf•in).
12. Reinstall remaining removed parts.
13. Proceed with the Closed Throttle Reset.

## THROTTLE CABLE

### Throttle Cable Removal

1. Unscrew engine supports from frame and lift the engine to be able to disconnect oil pump cable from oil pump. Refer to *ENGINE REMOVAL AND INSTALLATION* section.
  2. Remove applicable parts to ensure access to oil pump. Refer to *OIL INJECTION PUMP REMOVAL* section for procedures.
- NOTE:** Before removing the cable from vehicle, note its routing for installation.
3. Remove steering cover.
  4. Using long nose pliers to hold the cable, push the end of cable out of its location.
  5. Remove the retaining circlip, keep circlip for re-use.

## Section 04 FUEL SYSTEM


### Subsection 02 (TM CARBURETORS)



TYPICAL


1. Circlip

6. Unhook cable sheath then remove cable from handle.
7. Disconnect cable and cable end from carburetors.



1. Throttle cable
2. Adjusting nut
3. Locking nut

8. Disconnect cable from oil pump then remove cable.



1. Throttle cable

### Throttle Cable Inspection

Inspect throttle cable and housing for any damage. Replace as necessary.

### Throttle Cable Installation

The installation is the reverse of the removal procedure.

**NOTICE** Check that throttle cable is routed away from sharp edges, hot or vibrating parts.

### Throttle Cable Adjustment


#### **⚠ WARNING**

Ensure the engine is turned OFF, prior to performing the throttle cable adjustment.

Engine must be set in its position, carburetors installed on engine and throttle cable properly routed.

#### **500SS/600**

1. Loosen throttle cable housing adjusting and locking nuts.



1. Throttle cable
2. Adjusting nut
3. Locking nut

2. While holding throttle lever in wide open throttle position, use your finger to validate flat side lower edge position inside venturi bore. A small play should be felt. If not, adjust throttle cable accordingly.
3. Also ensure that, when throttle is released to idle position, the idle adjusting screw end touches its stopper. No tension should be applied to throttle cable.
4. Adjust oil pump cable, refer to *LUBRICATION SYSTEM* section.


## Section 04 FUEL SYSTEM

### Subsection 02 (TM CARBURETORS)

**NOTICE** Oil pump cable must be readjusted whenever throttle cable adjustment or idle speed are changed, otherwise serious engine damage may occur.

#### 800R

- Loosen throttle cable housing adjusting and locking nuts.



- Throttle cable
- Adjusting nut
- Locking nut

- Perform the wide open throttle position verification as follows.
  - Use B.U.D.S. software.
  - In **Monitoring** tab, check if throttle opening is within 95 and 100% when throttle lever is fully depressed.




MONITORING TAB

- Adjust throttle cable as required to be within this value.
- Validate the idle position as follows.
- Ensure that some free-play remains in the throttle cable at idle position.

- Tighten idle screw until the specified % appears under Throttle opening in Setting tab of B.U.D.S.

MODEL	THROTTLE OPENING IN B.U.D.S.
MX Z	4%
SUMMIT	5%




TYPICAL — SETTING TAB

- Adjust oil pump cable, refer to *LUBRICATION SYSTEM* section.

**NOTICE** Oil pump cable must be readjusted whenever throttle cable adjustment or idle speed are changed, otherwise serious engine damage may occur.

#### Throttle Cable Lubrication

Lubricate exposed portion of cable with DIELECTRIC GREASE (P/N 293 550 004) when throttle handle is at full throttle.



TYPICAL  
1. Lubricate



## Section 04 FUEL SYSTEM

### Subsection 02 (TM CARBURETORS)

## CHOKE CABLE

### Choke Cable Removal

**NOTE:** Before removing choke cable, note its routing for installation.

1. Remove choke cable nut and pull cable underneath console.
2. Loosen choke cable housing adjusting and locking nuts.
3. Remove cable from support.
4. Disconnect cable barrel from carburetor choke lever.
5. Cut all locking ties retaining cable and remove it from vehicle. Note its routing for installation.


### Choke Cable Installation

The installation is the reverse of the removal procedure.

### Choke Cable Adjustment

Adjust choke cable as per following procedure:

1. Loosen choke cable housing adjusting and locking nuts.
2. While choke lever is fully open, pull choke cable until cam lever reaches the stopper. Tighten cable housing adjusting and locking nuts in this position.
3. As a confirmation, the gap between the stopper and the cam lever should be within 0 mm and 0.5 mm (0 in and .02 in).



A. Within 0 mm and 0.5 mm (0 in and .02 in)

# DPM SYSTEM (800R)

## SERVICE TOOLS


Description	Part Number	Page
FLUKE 115 DIGITAL MULTIMETER .....	529 035 868 .....	268
VACUUM/PRESSURE PUMP .....	529 021 800 .....	271



Copyright © 2011  
All rights reserved.  
This document is the property of  
Cummins Inc. and is not to be  
distributed, copied, or  
reproduced in any form  
without the written permission  
of Cummins Inc.

## Section 04 FUEL SYSTEM

### Subsection 03 (DPM SYSTEM (800R))



mmv2008-032-001\_a

1. TM carburetor
2. DPM manifold
3. DPM solenoid
4. Negative pressure tubes connected to venturi
5. Float bowl tubes
6. Vent tube connected to air intake silencer

## GENERAL

### SYSTEM DESCRIPTION

The DPM receives negative pressure created in the carburetor venturi. A solenoid (controlled by ECM) opens the passage, when activated, to decrease the pressure in the carburetor bowls which in turn, lean the fuel mixture.

**NOTE:** For engine starting and warm-up, the required richer mixture is supplied by a conventional choke (enricher type).

The carburetors are calibrated with the richest jetting required to fulfil the worse operating conditions.

Using predefined maps, the ECM is constantly activating (duty cycle) the DPM solenoid to optimize the air/fuel mixture.

The ECM receives the signals from different sensors which indicate engine operating conditions at millisecond intervals.

The engine RPM (through the trigger coils) and TPS are the primary sensors used to control the DPM. Other sensors (air pressure, air and coolant temperature) are used as secondary inputs.


As air temperature and altitude change, the ECM uses its 3D mapping to maintain the air/fuel mixture at an optimum.

The ECM begins to lean fuel mixture when engine RPM is above approximately 3500 RPM.

## PROCEDURES

**NOTE:** It is a good practice to check for fault codes using B.U.D.S. software as a first troubleshooting step. Refer to *MONITORING SYSTEM AND FAULT CODES* section.


## AIR TEMPERATURE SENSOR (ATS)



1. Air temperature sensor (ATS)

### ATS Sensor Dynamic Test

1. Use B.U.D.S. software.
2. Look **Intake Air** in **Monitoring** tab of B.U.D.S. It should show the ambient temperature. Otherwise, perform the ATS sensor resistance test.




### ATS Sensor Resistance Test

1. Remove pulley guard. Refer to *DRIVE SYSTEM AND BRAKE* section.

## Section 04 FUEL SYSTEM

### Subsection 03 (DPM SYSTEM (800R))


- Remove primary air intake silencer. Refer to *AIR INTAKE SYSTEM* section.
- Rotate intake adapter to disconnect ATS sensor connector.



- Rotate intake adapter
- Disconnect ATS sensor connector

- Using the FLUKE 115 DIGITAL MULTIMETER (P/N 529 035 868), measure ATS sensor resistance.

ATS SENSOR		MEASUREMENT
Pin A	Pin B	Refer to <i>TEMPERATURE SENSOR TABLE</i> below



INTAKE ADAPTER REMOVED FOR CLARITY PURPOSE ONLY

ATS SENSOR TEMPERATURE TABLE		MEASUREMENT
°C	°F	RESISTANCE (Ω)
- 30	- 22	28000
- 20	- 4	14500
0	32	5500
20	68	2500
40	104	1200
60	140	600
80	176	320
100	212	180
130	266	90

If out of specification, replace sensor.


If resistance tests good, **Reconnect** the ATS sensor and test the circuit continuity.

### ATS Sensor Circuit Continuity Test (with Sensor)

Disconnect the ECM connector.

Measure resistance at ECM connector as follows.

ECM CONNECTOR		MEASUREMENT
DA-1	DA-19	Refer to <i>TEMPERATURE SENSOR TABLE</i> above




ECM CONNECTOR

If resistance is out of specification (sensor resistance is good), repair the connectors or replace the wiring harness between ECM connector and the ATS sensor.

Reinstall removed parts. Ensure intake adapter boot is properly installed on the adapter. See below in *ATS SENSOR REPLACEMENT*.


### ATS Sensor Replacement

1. See procedures above to reach sensor.
2. Loosen boot clamp.




1. Boot clamp


3. Unplug ATS sensor connector.
4. Pull out intake adapter.
5. Remove and discard sensor push nuts.



6. Pull out sensor.
7. Use **NEW** push nuts and secure the new sensor to adapter.
8. Ensure adapter boot is properly installed as shown.



**CORRECT BOOT INSTALLATION**



**WRONG BOOT INSTALLATION**

9. Install intake adapter on secondary air intake silencer.
10. Reconnect ATS sensor.
11. Reinstall all other removed parts.

### AIR PRESSURE SENSOR (APS)

APS sensor is integrated in ECM.

## Section 04 FUEL SYSTEM

### Subsection 03 (DPM SYSTEM (800R))



1. Air pressure sensor (APS)

### APS Sensor Dynamic Test

1. Use B.U.D.S. software.
2. Look **Atmospheric Pressure** in **Monitoring** tab. It should show the actual pressure. Otherwise, perform the following.




3. Ensure pressure orifice is free of snow, ice and dirt. Temporarily remove the orifice filter and clean the area.
4. Check for fault codes in B.U.D.S.
5. If sensor does not work replace ECM.

## DPM SOLENOID

### DPM Solenoid Test with B.U.D.S.

1. Connect B.U.D.S. software. Refer to *COMMUNICATION TOOLS AND B.U.D.S. SOFTWARE* section for proper connection instructions.
2. Energize **Leaning valve** (DPM solenoid) from **Activation** tab.



ACTIVATION TAB


3. This will validate the solenoid mechanical and electrical operation.
4. Listen to or touch relay to feel it clicks.
5. If the solenoid does not work, check the input voltage at the solenoid connector.

### DPM Solenoid Input Voltage Test

1. Disconnect the connector from the solenoid.
2. Measure voltage between pin 2 of DPM solenoid on harness side, and battery ground (engine ground on manual start models).
  - 2.1 If 12 V is read, disconnect connector from the ECM and check continuity of circuit between pin DA-29 and pin 1. If wire/connector tests good, try a new ECM.
  - 2.2 If it does not read 12 V, check the corresponding fuse(s), relay and continuity of circuit DP-2. If continuity is faulty, repair or replace wire and connector.

### DPM Solenoid Replacement

At reassembly, ensure that solenoid seals are in place.




1. Plastic seal  
2. O-rings

## DPM MANIFOLD

### DPM Manifold Visual Inspection

With DPM manifold removed from vehicle and all hoses disconnected from DPM manifold, inspect for any broken fittings or missing dust caps. If any part is broken, replace DPM manifold.

Ensure jets are positioned with the taper as shown.



1. Vent jet
2. Lean jet
3. Taper end here

Pay also attention not to mix jets. Refer to the following table for the proper inner diameter size. Refer to the illustration above for the jet location.

MODEL	INSIDE DIAMETER MM (IN)	
	VENT JET	LEAN JET
800R	1.2 mm (.047 in)	2.0 mm (.079 in)

Ensure DPM cap O-ring is in good condition. To install cap, firmly push until tabs click and lock on both sides in DPM.

Leak test the DPM manifold.

### DPM Manifold Leak Test

#### Required Items

The following items will be required:


- Water column with at least 350 mm (13-3/4 in) in height
- 4.8 mm (3/16 in) T-fitting
- 6 mm (15/64 in) T-fitting
- 3.5 mm (9/64 in) ID x 100 mm (4 in) hose

- 6 mm (15/64 in) ID x 300 mm (12 in) hose
- VACUUM/PRESSURE PUMP (P/N 529 021 800).



### DPM Manifold Preparation

Connect hoses as shown.



1. 3.5 mm (9/64 in) ID hose
2. 6 mm (15/64 in) ID hose
3. 6 mm (15/64 in) T-fitting

### Water Column Preparation


Mount water column vertically and secure it to a wall or workbench.

Fill water column to center line (at least 175 mm (6-7/8 in)) in height. Refer to following photo.



## Section 04 FUEL SYSTEM

### Subsection 03 (DPM SYSTEM (800R))




1. Center line at 175 mm (6-7/8 in)

A. 350 mm (13-3/4 in)

#### Connecting the Pump, DPM Manifold and Water Column

Connect hoses as shown.



1. 4.8 mm (3/16 in) T-fitting

2. T-fitting

3. Vented to atmosphere

Collect hose into one of the water column tubes, leave the other tube at atmospheric pressure.

#### Testing

Set pump to «vacuum»

**NOTICE** Never use pump directly on DPM to make a pressure test. The vacuum produced by the pump is too high and would damage DPM components. Use the water column as explained above.

Apply negative pressure (vacuum) until the extremities of the water in the tube attain a difference of 350 mm (13-3/4 in).

Stop pumping and allow water levels to stabilize in tube.

#### Analysis

RESULT	DPM MANIFOLD CONDITION
Water level remains unchanged	Good
Water level drops slowly to return to an even level in <b>more than 10</b> seconds	Defective
Unable to create any vacuum (water level increases and decreases immediately in tube)	Check your set-up and re-do the test. If still not able to create any vacuum, manifold is defective

If DPM manifold is defective, replace its parts (refer to *PARTS CATALOG*) and retest. If test fails again, replace DPM manifold.

# E-TEC DIRECT FUEL INJECTION

## SERVICE TOOLS

Description	Part Number	Page
FLUKE 115 MULTIMETER .....	529 035 868	284, 286, 307-308, 311, 313
HOSE PINCHERS .....	295 000 076	305
INJECTOR ADAPTER .....	529 036 136	288
INJECTOR RETAINER PLATES .....	529 036 137	282
PLIERS OETIKER 1099.....	295 000 070	278
T-HARNES .....	529 035 869	296

## SERVICE TOOLS – OTHER SUPPLIER

Description	Part Number	Page
SNAP-ON HAMMER .....	CJ125-6	288
SNAP-ON SCREW .....	CJ93-1	288

## SERVICE PRODUCTS

Description	Part Number	Page
ANTI-SEIZE LUBRICANT .....	293 800 070	316
DIELECTRIC GREASE .....	293 550 004	291
PULLEY FLANGE CLEANER .....	413 711 809	305

## GENERAL

### ⚠ WARNING

Always disconnect the magneto connector prior to:

- Disconnecting any fuel hose.
  - Removing a fuel injector.
  - Removing a spark plug cable or spark plug.
- Otherwise, fuel vapors may ignite in presence of a spark creating a fire hazard.

### ⚠ WARNING

Fuel is flammable and explosive under certain conditions. Always proceed with care and use appropriate safety equipment when working on pressurized fuel system. Wear safety glasses and work in a well ventilated area. Fuel lines remain under pressure at all times. When removing or installing high pressure test equipment and disconnecting fuel line connections:

- Release fuel pressure prior to removing a hose.
- Cover the fuel line connection with an absorbent shop rag.
- Slowly disconnect the fuel hose to minimize spilling.
- Do not allow fuel to spill on hot engine parts and electrical connectors.
- Wipe up any fuel spillage in the engine compartment.

## Section 04 FUEL SYSTEM

### Subsection 04 (E-TEC DIRECT FUEL INJECTION)

#### **⚠ WARNING**

Perform a fuel pressure test each time a component from the fuel system is removed. Prior to start the engine when a fuel hose was disconnected or an injector removed:

- Ensure all fuel lines are properly connected.
- Crank engine to pressurize fuel system. Do not let engine run. If it starts, stop it right away.
- Inspect engine compartment to detect any fuel leakage or an abnormally strong fuel odor which may be an indication of a fuel leak that is not readily visible.

## SYSTEM DESCRIPTION


The ECM reads the input signals from different sensors which indicate engine operating conditions at micro-second intervals.

The ECM calculates the proper air/fuel ratio and activates the output to injectors.

Signals from sensors are used by the ECM to determine the injection parameters (fuel maps required for optimum air-fuel ratio).

The crankshaft position sensor (CPS), the throttle position sensor (TPS) are the primary sensors used to control the injection. Other sensors (like temperature sensors, etc.) are used as secondary input.

## Air Induction



1. Mesh filter
2. Secondary air intake silencer
3. Primary air intake silencer
4. Air pressure fitting and hose
5. Air pressure sensor in ECM
6. Air temperature sensor
7. Throttle body

Air flows through a mesh filter in the secondary air intake silencer mounted on top of engine. The mesh filter prevents snow from being drawn into the engine.


Air pressure is measured in the secondary air intake silencer through a tube connected to the ECM.

Air then flows through the primary air intake silencer.

Air temperature is measured at the entry point of the primary air intake silencer.

Air is then drawn through a dual throttle body mounted on the engine intake side.


## Throttle Body



1. Throttle body
2. TPS (Throttle Position Sensor)

Dell'Orto dual 46 mm throttle body is directly mounted on intake flange of each cylinder.

The air flow is controlled by two throttle plates. Each throttle plate has a 6.8 mm (.268 in) idle hole.



1. Idle holes


## Section 04 FUEL SYSTEM

### Subsection 04 (E-TEC DIRECT FUEL INJECTION)

Since there is a constant airflow through the idle holes of the throttle plates, the idle speed is controlled by the ECM by varying the amount of fuel injected in the combustion chamber and by controlling the injection timing.

The TPS (Throttle Position Sensor) is fitted on the throttle body. The TPS sends throttle angle position to the ECM.

Engine coolant flows through throttle body to prevent potential freezing of throttle plates due to the temperature drop naturally created by the venturi.



1. Coolant-heated lines

The air then continues through the reed valves into the cylinder base then into the crankcase.

### Fuel Injector

The injectors work on the 55 Vdc system voltage. One injector per cylinder is used.


The E-TEC injector is mounted directly on top of the cylinder head.



1. Fuel injector

The injector achieves a direct injection right into the combustion chamber. This keeps the piston cooler with less fuel.


A voice coil type is used to open and close the injector nozzle. This allows a quick operation of the injector at the opening stage as well as at the closing stage. This results in the ability to operate the engine at a high RPM and this lowers unburned fuel to the exhaust port.



INJECTOR CLOSED

1. Voice coil

When a positive current is supplied to the coil by the ECM, the injector plunger moves towards the spring loaded injector needle. As injector plunger moves, this builds up a pressure in the injector chamber. When the pressure reaches approximately 1724 kPa (250 PSI), this overcomes the injector needle spring strength and the needle opens. Then, the fuel injection takes place while the pressure peaks at 3103 kPa (450 PSI).



INJECTOR OPENED

1. Voice coil

Swirl channels are used in injector to better atomize the fuel charge.

## Section 04 FUEL SYSTEM

### Subsection 04 (E-TEC DIRECT FUEL INJECTION)

The quantity of injected fuel is controlled by varying the injector plunger stroke.

To bring the injector plunger backward to its rest position, current is reversed and the return springs close the injector needle and plunger. Near the end of the return stroke, a brief positive current is applied to "brake" the injector plunger. This results in a quieter operation of the injectors.


In forward engine rotation, the injectors provide a stratified fuel charge to the combustion chamber up to clutch engagement speed. Beyond this RPM, the fuel charge becomes homogeneous.

The stratified fuel charge provides a cleaner combustion, better idling and less smoke.

#### Injector Cooling

Fuel coming from ECM via the fuel pump flows around the voice coil inside the injector housing to cool down the injector components.

Fuel enters the inlet port located at bottom of injector housing then goes out through the outlet port.



## ADJUSTMENT

### IDLE SPEED

Idle speed is controlled by the EMS (Engine Management System) and is not adjustable with an idle screw.

If idle speed is not as per specification (refer to *TECHNICAL SPECIFICATIONS*), perform the *CLOSED THROTTLE RESET (TPS)*.

## CLOSED THROTTLE RESET (TPS)

### General Information

This operation performs a reset of the TPS (throttle position sensor) values in the ECM when the throttle is closed. This reset is very important as the setting of the TPS will determine the basic parameters for all fuel mapping and several ECM calculations for idle speed control of the engine.


Closed throttle reset must be done if:

- TPS is loosen, removed or replaced.
- Throttle body is replaced.
- ECM is replaced.

**NOTICE** An improperly set TPS may lead to poor engine performance.

### Closed Throttle Reset Procedure (TPS)

Check if master zero position screw contacts throttle plate stopper.




1. Master zero position screw (capped)
2. Throttle plate stopper
3. Contact here

**NOTICE** Do not alter the setting of any of the capped screw, otherwise throttle body must be replaced.

### Master Zero Position Screw Does NOT Contact Stopper

Check if idle screw touches the throttle plate lever.



1. Idle screw

If idle screw touches the throttle plate lever, someone tampered with the idle screw. To correct the problem, exceptionally, unscrew idle screw until there is a gap.

If idle screw does not touch the throttle plate lever, adjust throttle cable. Refer to *THROTTLE CABLE* in this section.

Refer to *MASTER ZERO POSITION SCREW DOES CONTACT STOPPER* when the problem is corrected.

#### Master Zero Position Screw DOES Contact Stopper

Push throttle lever approximately one quarter then quickly release. Repeat 2 - 3 times to settle throttle plates.


Connect B.U.D.S. Refer to *COMMUNICATION TOOLS/B.U.D.S. SOFTWARE*.

**IMPORTANT:** First ensure there is no fault code related to the TPS. If so, it will not be possible to perform the **Closed Throttle** reset and the **Throttle Opening** could not be set within the specification.

Use the B.U.D.S. software and look in **Setting** tab.

The **Throttle Opening** must be within the following specification.

THROTTLE OPENING
Within - 0.2 and 0.2% (0 ± 0.2)



If throttle opening is within the % specification, **DO NOT** reset the **Closed Throttle**. It is not required.

If throttle opening is **NOT** within the % specification, press **Reset** button in **Closed Throttle**.

**IMPORTANT:** If the Actual TPS Voltage is not within 0.3 - 0.7 Volts, the **reset will not be done** and no fault code will be set. Verify the following then carry out the reset again.

- Make sure throttle cable is not stuck or too tight.
- Make sure TPS is not loose.
- Check TPS condition and its wiring/connectors.

## TROUBLESHOOTING

### DIAGNOSTIC TIPS

Engine problems are not necessarily related to the injection system.

It is important to ensure the mechanical integrity of the engine is present.

#### Spark Plugs

Improper spark plug indexing may lead to engine misfiring. Check if BRP spark plugs are installed or if spark plugs are properly indexed.

#### 3D RAVE Valves

RAVE valves improper position may lead to engine misfiring. Check RAVE valves.

#### Electrical System

It is important to check that the electrical system is functioning properly:

- System voltage
- Capacitor (refer to *CHARGING SYSTEM*)
- Ground connections
- Wiring connectors.

Ensure that all electronic components are original BRP recommended components.

## Section 04 FUEL SYSTEM

### Subsection 04 (E-TEC DIRECT FUEL INJECTION)

Any modification on the wiring harness may lead to generate fault codes or bad operation.

#### **⚠ WARNING**

The EMS is operating on 55 volts, be careful to avoid electrical shocks.

#### **⚠ WARNING**

All electrical actuators (example: injectors, fuel pump, ignition coils and electronic oil injection pump) are powered as soon as engine is cranked when engine stop switch is at the RUN position.

#### Electrical Connections

Pay particular attention to ensure that pins are not out of their connectors or out of shape.

Make sure that connections are very tight and they make good contact, they are corrosion-free and show no signs of moisture. Particularly check ECM ground connections.

**NOTE:** Do not apply dielectric grease or other lubricant on the ECM connectors.

Check if wiring harness shows any signs of scoring.

#### Resistance Measurement

When measuring the resistance with an ohmmeter, all values are given for a temperature of 20°C (68°F). The value of a resistor varies with the temperature. The value for common resistor or windings (such as solenoid) increases as the temperature increases. However, our temperature sensors are NTC types (Negative Temperature Coefficient) except for the EGTS, and work the opposite which means that the value decreases as the temperature increases. Use the provided tables for sensor resistive values at given temperature.


The resistive value of a temperature sensor may test good at a certain temperature but it might be defective at other temperatures.

A good test would be to put sensor in a container filled with ice and water and measure resistance. Then, heat water and read resistance at different temperatures.


## PROCEDURES

### FUEL HOSES AND OETIKER CLAMPS


To secure or cut Oetiker clamps on fuel lines, use PLIERS OETIKER 1099 (P/N 295 000 070).



1. Cutting clamp



1. Securing clamp



1. Securing clamp in limited access

**⚠ WARNING**

- Never use a hose pincher on high pressure hoses.
- Never change the routing of a fuel hose.
- Always reinstall the corrugated protective tubing on fuel hose.
- Always install new Oetiker clamps on fuel hoses.
- Secure fuel hoses using the appropriate locking tie or fastener to prevent contact with sharp edges or hot, rotating and moving parts.
- After connecting a hose or a quick connect fitting, pull on hose near the fitting to make sure it is securely locked.

Use of improper fuel lines could compromise fuel system integrity.

**THROTTLE CABLE****Throttle Cable Removal**

Remove handlebar cover.

Depress and hold throttle lever.


Pull out circlip using long nose pliers. Keep circlip to re-use.



Pull throttle cable out of its housing.



Unhook cable end barrel from throttle lever and remove cable.



Note cable routing before removal.

Remove drive belt guard. Refer to *DRIVE BELT*.  
Remove primary air intake silencer. Refer to *AIR INTAKE SYSTEM*.

At throttle body, unlock top nut.

Fully unscrew bottom nut.




## Section 04 FUEL SYSTEM

### Subsection 04 (E-TEC DIRECT FUEL INJECTION)



1. Top nut
2. Bottom nut

Loosen throttle body clamps.



Pull out throttle body enough to unhook throttle cable end.



Remove throttle cable.

### Throttle Cable Installation

Reverse removal procedure but pay attention to the following.

Route cable as noted before removal.

Ensure that cable ends are properly secured in their levers.


Proceed with throttle cable adjustment.

### Throttle Cable Adjustment

**NOTICE** Do not alter throttle cable routing. It may cause poor startability and erratic idling.


With throttle lever released, ensure there is some free-play in throttle cable to allow a contact between master zero position screw end and throttle plate stopper.

**NOTICE** Do not tamper with any screw. Otherwise, it may result in throttle body replacement.



1. Master zero position screw
2. Throttle plate stopper
3. Contact here

Otherwise, loosen throttle cable nuts.



- 1. Top nut
- 2. Bottom nut

Set cable adjuster accordingly then tighten nuts. Push throttle lever approximately one quarter then quickly release. Repeat 2 - 3 times to settle throttle plate. Recheck adjustment.


Connect B.U.D.S. Refer to *COMMUNICATION TOOLS/B.U.D.S. SOFTWARE*.

Use the B.U.D.S. software and look in **Monitoring** tab.

Fully depress throttle lever and hold.

Look at the throttle opening. Displayed value must be within the following specification.


THROTTLE OPENING (WIDE OPEN THROTTLE)
95 - 100%



Otherwise re-adjust throttle cable.

**NOTE:** If value is below the minimum, tighten throttle cable. If value is above the maximum value, loosen throttle cable.

## FUEL INJECTOR



- 1. Injector housing
- 2. Top O-ring
- 3. Bottom O-ring
- 4. Crush ring
- 5. Thermal insulator

Every fuel injector is bench tested. Its electrical and flow characteristics are registered throughout all its operating range in a calibration file.

When an injector is replaced, the matching calibrated file must be loaded in the ECM using B.U.D.S. so that the ECM properly controls the injector.

### Injector Visual Inspection

Open LH panel.

Remove drive belt guard. Refer to *DRIVE BELT* section.

Look at the injector area.



- 1. Fuel injector

If a fuel leak is noticed in the hose areas, inspect hoses and connections.

## Section 04 FUEL SYSTEM

### Subsection 04 (E-TEC DIRECT FUEL INJECTION)

If a fuel leak is noticed in injector base area, it indicates a leak of the lower O-ring of injector.

If a dark carbon area is noticed in injector base area, it indicates a leak between injector nozzle and cylinder head. Injector is likely to be under torqued.

#### Injector Troubleshooting Tips

Most of the time a faulty injector will lead to a poor engine idling and a low RPM around 800 RPM and below. It may also lead to engine misfiring.

Ensure the correct injector is installed on the proper cylinder. Refer to *FUEL INJECTOR POSITION VALIDATION*.

While engine is running, try unplugging an injector connector:

#### **⚠ WARNING**

Be careful while working close to rotating parts.

- If engine RPM does not change, this injector could be faulty.
- If engine RPM decreases, the other injector could be faulty.

If one injector is thought to be faulty, proceed with the injector tests.


#### Injector Leakage Test

##### Preparation

First make sure fuel pressure is within specifications. Refer to *FUEL TANK AND FUEL PUMP* section.

**NOTE:** Keep the pressure gauge installed for the leakage test.

Disconnect the magneto connector.



#### **⚠ WARNING**

The magneto connector must be disconnected to prevent any spark in the engine compartment should the engine be cranked. Fuel vapors may ignite in presence of a spark creating a fire hazard.

Release fuel pressure. Refer to *FUEL TANK AND FUEL PUMP*.

**NOTICE** If fuel pressure is not released, pressure will push injector out of its housing when removing injector. This could damage the injector and lead to an important fuel spill.

Remove drive belt guard. Refer to *DRIVE BELT*.

Remove secondary air intake silencer. Refer to *AIR INTAKE SYSTEM*.

Unlock ECM support to move ECM as necessary to lift fuel injectors.

**NOTE:** Injector leakage test can be done on one injector at a time or on both injectors simultaneously.

Unscrew both injectors. Refer to *FUEL INJECTOR REMOVAL* further in this section.

Carefully lift both injectors. Be careful not to pry hoses against their plastic fittings.




**NOTE:** Do not install the thermal insulators against injectors.

Secure both injectors to the INJECTOR RETAINER PLATES (P/N 529 036 137).

## Section 04 FUEL SYSTEM

### Subsection 04 (E-TEC DIRECT FUEL INJECTION)



1. Injector retainer plate

**NOTICE** Ensure to position opening in retainer plate on the injector wiring side.

**NOTE:** An old E-TEC cylinder head can be used assuming injector mating surface is in good condition.



1. Thermal insulator  
2. Old E-TEC cylinder head

Slightly tighten the injector screws.

#### **WARNING**

Injector retainer plate is installed to prevent injector to be projected out when pressurizing the injector during the test. Always use the appropriate technique to prevent injector projection.

Place an appropriate container under injectors. Ensure spark plug caps are installed on spark plugs.

Ensure there is enough fuel in fuel tank.


Connect B.U.D.S. Refer to *COMMUNICATION TOOLS/B.U.D.S. SOFTWARE*.

#### Leakage Test

Use the B.U.D.S. software and go in **Activation** tab.

Click and hold the **Fuel Pump** button.

**NOTE:** Fuel pump will operate as long as button is held depressed in B.U.D.S.



#### ACTIVATION TAB


1. Click and hold

**NOTE:** Ensure fuel pump is enabled in B.U.D.S.



## Section 04 FUEL SYSTEM

### Subsection 04 (E-TEC DIRECT FUEL INJECTION)



#### ACTIVATION TAB

1. Pump enabled

Check for fuel leakage from the injector nozzle. Monitor fuel pressure at fuel pressure gauge. If pressure drops below 275 kPa (40 PSI) during the test, re-activate fuel pump as necessary.

FUEL INJECTOR LEAKAGE	
TEST DURATION	SPECIFICATION
2 minutes	2 drops per minute maximum

If test is not within specification, replace the faulty fuel injector.

Properly reinstall injectors. Refer to *FUEL INJECTOR INSTALLATION*.

Reinstall remaining removed components.

Connect magneto connector.

#### **⚠ WARNING**

Wipe up any spilled fuel.

#### Injector Resistance Test

Remove drive belt guard. Refer to *DRIVE BELT* section.

Disconnect injector connector and measure injector resistance directly on its terminals.

INJECTOR		MEASUREMENT @ 22°C (72°F)
Pin 1	Pin 2	Below 2.7 Ω



If measurement is out of specification, replace injector.

#### Injector Input Voltage Test

Set engine stop switch to STOP to cut ignition and injection.

**NOTE:** Ensure magneto connector is plugged.

Disconnect the connector from the injector.




1. Injector connector

Use the FLUKE 115 MULTIMETER (P/N 529 035 868) and set it to Vdc.


Repeatedly press the **RANGE** button until the display shows Manual Range 6 0.

## Section 04 FUEL SYSTEM

### Subsection 04 (E-TEC DIRECT FUEL INJECTION)



Press the MIN MAX button so that the display shows MIN MAX.



Measure voltage while cranking engine.

INJECTOR CONNECTOR	MEASUREMENT
Pin 1	Battery ground
	30 Vdc minimum



Read the MAX value.

**NOTE:** Reset multimeter by pressing and holding MIN MAX button until meter beeps.

If voltage test is as per specification, check the injector control circuit signal.

If voltage test is not as per specification, check wire continuity from ECM to injector as follows.

Disconnect connector J2 from ECM.

Set multimeter to  $\Omega$ .

ECM CONNECTOR	INJECTOR CONNECTOR	MEASUREMENT
Connector J2, pin 13	Pin 1	Close to 0 $\Omega$



If wiring is faulty, repair/replace wiring/connectors.

If wiring is good, check system voltage. Refer to *CHARGING SYSTEM*.

## Section 04 FUEL SYSTEM


### Subsection 04 (E-TEC DIRECT FUEL INJECTION)

#### Injector Control Circuit Signal Test

Connect B.U.D.S. Refer to *COMMUNICATION TOOLS/B.U.D.S. SOFTWARE*.

Use the FLUKE 115 MULTIMETER (P/N 529 035 868) and set it to Vdc (Hz).

Repeatedly press the **RANGE** button until the display shows Manual Range 6.



Press the Hz button so that the display shows Hz.



Use the B.U.D.S. software and go to **Activation** tab.

Activate injector and read the frequency on the multimeter.

**NOTE:** The multimeter counts the pulses per minute (Hertz) of current the ECM sends to the injector.

INJECTOR CONNECTOR		MEASUREMENT
Pin 1	Pin 2	Approximately 2 Hz



If there is no reading, check continuity of control circuit.

If reading is good, the control circuit is functional.

#### Injector Control Circuit Test

Disconnect connector J1B from the ECM and check continuity of control circuit as per following table.

INJECTOR	INJECTOR CONNECTOR	ECM CONNECTOR	MEASUREMENT
MAG	Pin 2	J1B, pin 8	Close to 0 $\Omega$ (continuity)
PTO		J1B, pin 1	



If continuity is faulty, repair wiring harness.


## Fuel Injector Removal

**IMPORTANT:** New O-rings and crush ring must be installed if injector is removed (injector disassembly required). Otherwise, leakage or damage to injector/cylinder head might occur.

Remove drive belt guard. Refer to *DRIVE BELT*.

Remove primary and secondary air intake silencers. Refer to *AIR INTAKE SYSTEM*.

Disconnect magneto connector.



mm2009-026-001\_a

### **⚠ WARNING**

The magneto connector must be disconnected to prevent any spark in the engine compartment should the engine be cranked. Fuel vapors may ignite in presence of a spark creating a fire hazard.

Clean injector area.

Release the fuel pressure in the system using B.U.D.S. Refer to *FUEL TANK AND FUEL PUMP* section.

**NOTICE** If fuel pressure is not released, pressure will push injector out of its housing when removing injector. This could damage the injector and lead to an important fuel spill.

### **⚠ WARNING**

Fuel vapors in the engine compartment could be lit by a spark. This might create a fire.

Disconnect injector connector.

Install a rag under the hose ends to catch fuel spillage.


Remove retainer.



mm2009-074-007\_b

1. Retainer screw

Disconnect fuel hoses from fuel injector.



mm2009-074-008\_a

1. Pull out

### **⚠ WARNING**

More fuel will flow out than usual injectors. Work in a well ventilated area and wipe up spilled fuel.

Unscrew injector screws.

Gently pull up injector.

**NOTE:** If injector is to be reinstalled, mark it to reinstall it to the same cylinder.

**NOTICE** Use caution when handling fuel injector. Never hold injector by its electrical wires. Prevent dirt and debris from entering fuel inlet and outlet ports of injectors or fuel hoses. Cover the injector nozzle port in cylinder head to prevent contamination of combustion chamber.



## Section 04 FUEL SYSTEM


### Subsection 04 (E-TEC DIRECT FUEL INJECTION)

#### Fuel Injector Disassembly

To remove injector from its housing, use a Snap-on slide hammer puller including:

- SNAP-ON SCREW (P/N CJ93-1)
- SNAP-ON HAMMER (P/N CJ125-6).

The puller is used in conjunction with the INJECTOR ADAPTER (P/N 529 036 136).




1. Snap-on screw
2. Snap-on hammer
3. Injector adapter

Thread injector adapter into face of injector.

Hold injector housing securely in an upside up position to avoid dropping the injector when it will be pulled out.

Work slide hammer to pull out injector.




Remove adaptor from injector.

Remove O-rings, crush ring and filter from injector.



1. Crush ring
2. ORANGE O-ring
3. Filter
4. BLUE O-ring

Inspect and clean injector filter.



mmr2009-023-036

**Fuel Injector Assembly**

Reverse procedure for assembly. However, pay attention to the following.

**IMPORTANT:** Apply oil injection to O-rings.

Install a new crush ring.

Install a new orange O-ring on top.

**NOTICE** Always use BRP snowmobile O-rings. They are designed to work in low temperature environment.

Install filter. Ensure filter is retained firmly on injector. Otherwise, remove it, invert it half a turn, then reinstall. If it still not retained securely, install a new one.

Install a new blue O-ring at bottom.



mmr2009-023-038\_a

**OIL INJECTION ON O-RINGS**

- 1. ORANGE
- 2. BLUE

Reinstall injector into its housing.  
Ensure to position injector wires as shown.




mmr2009-023-037\_a

- 1. Wires opposite to fuel inlet ports

Press on injector outer face until injector seats in its housing. See illustration.

**NOTICE** Never press or tap the injector tip.



mmr2009-023-038\_a

**WRONG INSTALLATION**

- 1. Injector not fully inserted in its housing

## Section 04 FUEL SYSTEM

### Subsection 04 (E-TEC DIRECT FUEL INJECTION)



#### CORRECT INSTALLATION

1. Injector fully inserted in its housing

### Fuel Injector Installation

The following items and their mating surfaces must be cleaned and inspected prior to assembly:

- Injector
- Cylinder head: injector housing base and injector tip contact area
- Injector screw threads and cylinder head threads (must be dry).

**NOTICE** All injector components must be clean to ensure correct torque tightening specifications and to avoid leakage. Carefully follow the installation instructions.

**NOTE:** When installing a **used** injector, reinstall the injector at the same location. If it was not marked at the removal, confirm injector for proper cylinder placement. Refer to **FUEL INJECTOR POSITION VALIDATION**.

1. Position the thermal insulator on cylinder head.



2. Install injector on cylinder head.

**NOTICE** Torque injector prior to installing fuel hoses.


3. Torque both screws in a 4 step sequence by tightening alternately each screw:

- 3.1 Hand tighten
- 3.2 15 N•m (133 lbf•in)
- 3.3 30 N•m (22 lbf•ft)
- 3.4 45 N•m (33 lbf•ft).

4. Check condition of fuel hose O-rings and plastic flange on hose fittings.

5. Apply injection oil to O-rings.

6. Insert fuel hoses into injector housing.



1. Oil injection on O-rings


2. Ensure plastic flange is in good condition

**NOTE:** Both hose fittings must be fully seated into injector housing.

7. Hose retainer must engage the outer groove of the injector housing fittings.


## Section 04 FUEL SYSTEM

### Subsection 04 (E-TEC DIRECT FUEL INJECTION)



1. Retainer
2. Outer groove of injector

**NOTE:** Make sure the hole on the hose retainer to attach the wiring harness is on top.



1. Hole on top

8. Install a NEW screw to secure hose retainer.

**NOTICE** The screw features a scotch grip threadlocker coating that is destroyed when loosening screw. Always replace screw with a new one each time it is loosened.

9. Torque retainer screw to 5 N•m (44 lbf•in).



1. Retainer screw

10. Apply some DIELECTRIC GREASE (P/N 293 550 004) in fuel injector connector.

11. Reconnect fuel injector connector.

**NOTICE** Never fasten the electrical connector to the injector. The connector must be "floating".

12. When installing a new injector, use B.U.D.S. to configure it in the ECM. Refer to *SETTING AN INJECTOR TO A CYLINDER*.

**NOTE:** The engine will run with an improperly matched injector. However, the engine may have a rough idle, a reduced fuel economy or a lean running condition.

#### **⚠ WARNING**

Perform a fuel pressure test and make sure there is no leak.

#### Fuel Injector Position Validation

For troubleshooting or when reinstalling a used injector, injector must be confirmed for proper cylinder placement by serial number using B.U.D.S. Otherwise, improper idling or higher fuel consumption may occur.

**NOTE:** To configure a new injector at the installation, refer to *SETTING AN INJECTOR TO A CYLINDER*.

Look for a tag besides the injector.

## Section 04 FUEL SYSTEM

### Subsection 04 (E-TEC DIRECT FUEL INJECTION)



1. Injector tag


Note the injector serial number (SN) on the tag of the injector you wish to validate.



SN: Serial number  
CS: Checksum number

From B.U.D.S., go to **Injector Coefficient** in **Setting** tab under **ECM** tab.

Look at the PTO or MAG injector S/N. This gives the configured injector in the ECM.



ECM TAB UNDER SETTING TAB

Compare the **MAG** or **PTO** Injector **S/N** that is configured in the ECM with the injector SN installed on the engine.

The installed injector number must match the number seen in B.U.D.S. Otherwise, check if injectors are mixed up.

If numbers do not match, configure the injector in B.U.D.S. Refer to *SETTING AN INJECTOR TO A CYLINDER*.

### Setting an Injector to a Cylinder

Note the serial number (SN) and the checksum (CS) on the injector tag.




SN: Serial number  
CS: Checksum number

Use **BOSSWeb** to get the matching calibration file.

Save the calibration file to your PC computer in the folder: C:\Program Files\BRP\BUDSCommon\InjectorCoefficients.

Start B.U.D.S. and click on the **Read Data** button.



Look into **Injector Coefficient** in **Setting** tab.

## Section 04 FUEL SYSTEM

### Subsection 04 (E-TEC DIRECT FUEL INJECTION)

Click on the **New** button of the injector you want to replace (MAG or PTO).

Injector Coefficient

MAG Injector S/N: 07303050822720

MAG Checksum: 02254

PTO Injector S/N: 07304010921720

PTO Checksum: 50469

mmr2009-074-200

ECM TAB UNDER SETTING TAB

**NOTE:** Every time the **New** button is clicked, B.U.D.S. will automatically go in the **Injector Coefficients** folder.

Select the injector serial number file that matches the injector installed on the engine.

Open

Look in: InjectorCoefficients

07303050822720.inj

07304010921720.inj

File name: 07304010921720.inj

Files of type: Injector Coefficient File (\*.inj)

mmr2009-023-003

Then, enter the checksum matching the injector chosen.

Injector Checksum

Checksum

Serial Number: 07304010921720

Checksum: 50469

mmr2009-074-200

The file will be quickly read and loaded in B.U.D.S. Then, click the **OK** button when the confirmation box appears.

Information

The injector file serial number has been successfully read.

mmr2009-023-004

Click on the **Write Data** button.

File View MPI Module Tools Help

Read Data Write Data

mmr2009-013-100\_ben

**IMPORTANT:** To make sure the proper file has been set into the ECM, do the following:

1. Read the data again in B.U.D.S.
2. Look into **Injector Coefficient** in **Setting** tab.

Injector Coefficient

MAG Injector S/N: 07303050822720

MAG Checksum: 02254

PTO Injector S/N: 07304010921720

PTO Checksum: 50469

mmr2009-023-001\_a

3. Ensure the S/N in B.U.D.S. matches the SN of the injector installed on the engine and the PTO/MAG numbers are not inverted.
4. If there is a mismatch, reload the proper configuration file. Write data and read it again to recheck.

## Section 04 FUEL SYSTEM

### Subsection 04 (E-TEC DIRECT FUEL INJECTION)


#### NOTE

Every time an ECM is read or when a .mpem file is opened, the injector calibration files (example: 07303050822720 and 07304010921720.inj) are automatically stored on your PC computer under a folder that will be common to all versions of B.U.D.S: C:\Program Files\BRP\BUDSCommon\InjectorCoefficients.

If B.U.D.S. is uninstalled, the files won't be deleted.

If you ever replace an ECM from which you were not able to read the data, you could load its latest .mpem file to look at the injector serial numbers stored in the ECM to then read the matching calibration files from the common files without the need to download the file from BOSSWeb.


## ENGINE CONTROL MODULE (ECM)



1. ECM

**NOTE:** Prior to replacing an ECM, ensure to conduct all testing procedures.

## ECM Connectors



ECM CONNECTORS IDENTIFICATION

To reach ECM connectors:

1. Open LH panel.
2. Remove secondary air intake silencer. Refer to *AIR INTAKE SYSTEM*.
3. Unlock ECM support to move ECM as necessary.



ECM CONNECTORS

See the following illustrations to disconnect connectors from ECM.

## Section 04 FUEL SYSTEM


### Subsection 04 (E-TEC DIRECT FUEL INJECTION)



#### J1A AND J1B CONNECTORS


Step 1: Push and hold tabs

Step 2: Pull out connector




#### J2 CONNECTOR

Step 3: Pull out connector




#### J2 CONNECTOR

Step 1: Push down the end of the lock slider




#### J1A PIN-OUT



#### J2 CONNECTOR

Step 2: Fully push down the lock slider




#### J1B PIN-OUT



## Section 04 FUEL SYSTEM

### Subsection 04 (E-TEC DIRECT FUEL INJECTION)




J2 PIN-OUT

## ECM Power Supply Troubleshooting

### Quick Test

Remove drive belt guard. Refer to *DRIVE BELT* section.

While one is cranking engine, check if the 2<sup>nd</sup> LED from the bottom turns on at the ECM.



1. Second LED from the bottom of ECM


**NOTE:** Alternately, you may connect the T-HARNESS (P/N 529 035-869) and a 12 V battery to supply the ECM.

If the LED turns on, the ECM is powered. Otherwise, perform the electrical test.

### Electrical Test

Connect B.U.D.S. Refer to *COMMUNICATION TOOLS/B.U.D.S. SOFTWARE*.

In B.U.D.S, select ECM tab in the Monitoring tab. Crank engine while viewing **System Voltage**.



TEST CONDITION	VOLTAGE
Manual crank speed	30 Vdc min.

If voltage is as per specification, ECM is properly powered.

If voltage is out of specification, refer to *CHARGING SYSTEM*.

## ECM Removal

**NOTE:** If a new ECM is to be installed, first read the procedures in the *ECM REPLACEMENT* below.

Remove muffler. Refer to *EXHAUST SYSTEM*.

Remove the acoustic panel.



Remove console. Refer to *BODY*.


Set engine stop switch to STOP.

Install a rag under the ECM hose quick connect to catch fuel spillage.

Disconnect fuel supply hose from ECM.


## Section 04 FUEL SYSTEM

### Subsection 04 (E-TEC DIRECT FUEL INJECTION)



1. Fuel supply hose
2. Release button

Place a container under the hose connector to recover fuel.



TYPICAL

Slightly pull out ECM.

Lean ECM to drain fuel from ECM.



TYPICAL

Lean hose end to drain fuel.

Unlock ECM.



Disconnect APS tube from ECM.


Disconnect ECM connectors.

Disconnect capacitor connector.

Disconnect remaining fuel hose from ECM.

## Section 04 FUEL SYSTEM

### Subsection 04 (E-TEC DIRECT FUEL INJECTION)



1. ECM connectors
2. Fuel hose

Detach ECM from its support.



### ECM Installation

Reverse removal procedure but pay attention to the following.

Set engine stop switch to STOP.

Ensure to engage tabs of ECM in lugs of oil injection reservoir.



### ⚠ WARNING

Wipe up all spilled fuel.

If a new ECM is installed, refer to *ECM REPLACEMENT* below.

### ECM Replacement

When installing a new ECM, data must be entered and several resets are required.

To transfer/enter data to the new ECM, there are 2 possible methods.

- If the faulty ECM can be read with B.U.D.S., refer to *ECM AUTOMATED DATA TRANSFER*.
- If the faulty ECM cannot be read with B.U.D.S., refer to *ECM MANUAL DATA ENTRY*.

### ECM Automated Data Transfer

To transfer the previous ECM recorded information to the new ECM, use the B.U.D.S. software and proceed as follows.

In B.U.D.S., click the **Read Data** button to load the information from the faulty ECM.




Keep B.U.D.S. running while replacing ECMs. The data will remain stored in the PC computer as long as B.U.D.S. is running.

Remove the old ECM.

Install and connect the new ECM.


**NOTE:** The beeper will continuously sound a sequence of 11 beeps meaning that the DESS key is not programmed. To stop the beeps, remove key. From B.U.D.S., choose **ECM, Replace** under **Module**.



B.U.D.S will automatically write the data from the PC computer into the new ECM.


Then, B.U.D.S. will display the following box asking to carry out the **Closed Throttle Reset**. Clicking **OK** will actually do the reset.

**NOTE:** Refer to **Closed Throttle Reset (TPS)** in **ADJUSTMENTS** in this section for the specific requirements of this reset.



Go in the **Setting** tab and do the following:

1. Carry out the **Rave Mid-Position** reset procedure. Refer to **3D RAVE** section.



2. View all the settings in the **Setting** tab and verify if they seem to be in the proper range. Otherwise, carry out the required reset/setting procedures.



In B.U.D.S., click the **Write Data** button to save the information to ECM.



Lift rear of vehicle and safely support.

Start the engine and increase engine speed above 6000 RPM to be sure no fault appears.

Let engine idle to ensure idle is adequate.

If engine does not run as expected, ensure that the injector calibration files are valid. Check with the tag of the injectors installed on vehicle.

Reinstall remaining removed parts.

### ECM Manual Data Entry

There are 2 possible methods to collect the required information. The 1<sup>st</sup> being the easiest.

- Use B.U.D.S. software and get the data from a saved .mpem file on your PC computer.
- Collect the information from the vehicle and get the injector coefficient files from BOSSWeb.

#### 1<sup>st</sup> Collecting Method: Get the Data from a Saved .mpem File

Remove the faulty ECM.

Install and connect the new ECM.

Use B.U.D.S. software.


Click on the **Open** button.

## Section 04 FUEL SYSTEM


### Subsection 04 (E-TEC DIRECT FUEL INJECTION)



Click once on the Folder Up button in the Open box.




Double click on the AutoSave folder.



**NOTE:** You may have to go to an other AutoSave folder from a previous version of B.U.D.S.

Choose the latest file saved for this specific vehicle.



**IMPORTANT:** Ensure to use the file that specifically matches the vehicle you are servicing.

**NOTE:** The file name structure is as follows:

BUDS version\_VIN\_data read (yyyymmdd)\_hour read (hhmmss).mpem

Example:

P2.3.18.3\_2BPSMJ9A59V000262\_20080201\_142322.mpem

Go in the **Vehicle** tab and record the following information.

1. Engine number (without the leading "M")
2. Customer.

**NOTE:** It is not necessary to record the vehicle (VIN) and model numbers. They will be transferred later.

Go to the **Setting** tab and select **ECM** then record the following information.



3. Ignition/Injection timing: Offset angle
4. Oil compensation: Oil pump code
5. Injector coefficients: MAG/PTO injectors S/N and Checksums.

## Section 04 FUEL SYSTEM

### Subsection 04 (E-TEC DIRECT FUEL INJECTION)

Injector Coefficient	
MAG Injector S/N: 07303050822720	New
MAG Checksum: 02254	
PTO Injector S/N: 07304010921720	New
PTO Checksum: 50469	

mm2009-023-001\_a

INJECTOR SERIAL NUMBER (S/N)

Injector Coefficient	
MAG Injector S/N: 07303050822720	New
MAG Checksum: 02254	
PTO Injector S/N: 07304010921720	New
PTO Checksum: 50469	

mm2009-023-001\_b

INJECTOR CHECKSUM (CS)

Enter data in ECM as detailed in *ENTERING THE COLLECTED INFORMATION INTO THE ECM*.

**2nd Collecting Method: Collect the Information from the Vehicle**

1. Record engine serial number.



RH SIDE OF ENGINE COMPARTMENT

1. Engine serial number

2. Record oil pump code.



BACK OF OIL PUMP

1. Oil pump code (0 to 9)

3. Record MAG/PTO injectors S/N.

Record the serial number (SN) and the checksum (CS) on the injector tag.



SN: Serial number  
CS: Checksum number

Use BOSSWeb to get the matching calibration file.

Save the calibration file to your PC computer in the folder:

C:\Program Files\BRP\BUDSCommon\InjectorCoefficients.

Enter data in ECM as detailed in *ENTERING THE COLLECTED INFORMATION INTO THE ECM*.

**Entering the Collected Information Into the ECM**


Remove the faulty ECM.

Install and connect the new ECM.

Use B.U.D.S. to enter the data into the new ECM.

**NOTE:** The beeper will continuously sound a sequence of 11 beeps meaning that the DESS key is not programmed. To stop the beeps, remove key.

In B.U.D.S., click the **Read Data** button to read the new "empty" ECM.




Then, a message will appear saying that the cluster (multifunction gauge) does not recognize the ECM.




## Section 04 FUEL SYSTEM

### Subsection 04 (E-TEC DIRECT FUEL INJECTION)



8. **Oil Compensation.** Enter the previously recorded Oil Pump Code.




9. **MAG and PTO injector S/N.**

- 9.1 If you got the data from a saved .mpem file, refer to table A.  
9.2 If you got the injector calibration file from BOSSWeb, refer to table B.


**TABLE A (DATA FROM A SAVED .MPEM FILE)**

Click on the **New** button and open the file that matches the previously recorded serial number.



Ensure to match PTO and MAG sides.

Once the file has been read, ensure the checksum number (CS) shown in B.U.D.S. matches the CS you previously recorded.



Otherwise, you read a wrong file. Read the file again until you get the appropriate file.

**TABLE B (CALIBRATION FILE FROM BOSSWEB)**

Click on the **New** button and open the file that you previously saved on your PC computer in the folder:


**C:\Program Files\BRP\BUDSCommon\InjectorCoefficient**

Ensure to match PTO and MAG sides.

Once the file has been read, ensure the injector tag SN matches the S/N shown in B.U.D.S.



SN: Serial Number



Otherwise, you read a wrong file. Read the file again until you get the appropriate file.

10. Click on the **Write Data** button.



Lift rear of vehicle and safely support.

Start the engine and increase engine speed above 6000 RPM to be sure no fault appears.



## Section 04 FUEL SYSTEM


### Subsection 04 (E-TEC DIRECT FUEL INJECTION)

Let engine idle to ensure idle is adequate.

If engine does not run as expected, ensure that the injector calibration files are valid. Check with the tag of the injectors installed on the engine.


Reinstall remaining removed parts.

## THROTTLE BODY



1. Throttle body
2. TPS (Throttle position sensor)

## Throttle Body Screw Identification



1. Master zero position screw (capped)
2. Idle screw
3. Synchronizing screw (capped)
4. Slave zero position screw (capped)

**NOTICE** Do not tamper with any capped screw. Otherwise, it may result in throttle body replacement.

## Throttle Body Inspection


- Check that the throttle plate moves freely and smoothly when depressing throttle lever.
- Check if throttle body master zero position screw is loose. If so, replace throttle body.

- Check if TPS is loose.
- Check for corroded or damaged wiring or connectors.


## Throttle Body Removal

To remove the throttle body from engine, proceed as follows:

1. Remove drive belt guard. Refer to *DRIVE BELT*.
2. Remove primary air intake silencer. Refer to *AIR INTAKE SYSTEM*.
3. Loosen retaining clamps of throttle body.




4. Pull throttle body enough to reach coolant hoses and TPS connector.
5. Detach brake hose from air intake silencer adapter.
6. Remove air intake silencer adapter.
7. Disconnect TPS connector.





## Section 04 FUEL SYSTEM

### Subsection 04 (E-TEC DIRECT FUEL INJECTION)



8. Install HOSE PINCHERS (P/N 295 000 076) on coolant hoses connected to throttle body.



1. Hose pinchers here

9. Detach coolant hoses for throttle body.  
10. Disconnect throttle cable.  
11. Pull throttle body out.

### Throttle Body Installation

Installation of the throttle body is the reverse of the removal procedure. Pay attention to the following details.

Before installation, clean throttle plates and bores with PULLEY FLANGE CLEANER (P/N 413 711 809).


If a new throttle body is installed, carry out the *CLOSED THROTTLE RESET (TPS)* as detailed in this section.

Refill engine coolant. If an important quantity of coolant was spilled, bleed cooling system. Refer to *COOLING SYSTEM* section.

### Throttle Body Synchronization

No synchronization is required as it has already been done at the factory.


**NOTICE** Do not alter setting synchronization screw. Otherwise throttle body must be replaced.



### THROTTLE POSITION SENSOR (TPS)

#### Description

The throttle position sensor (TPS) is a potentiometer that sends a signal to the ECM which is proportional to the throttle shaft angle.



THROTTLE POSITION SENSOR (TPS)

## Section 04 FUEL SYSTEM

### Subsection 04 (E-TEC DIRECT FUEL INJECTION)

#### TPS (Throttle Position Sensor) Faults

TPS Faults that are reported in B.U.D.S. fall in 2 groups; Wrong TPS voltage and TPS functional problem.

##### Wrong TPS Voltage

It is caused by the sensor reading going out of its allowable range. This fault can occur during the whole range of movement of the throttle.

To diagnose this fully, it is recommended to operate the throttle through its full range. It is also recommended to release the throttle quickly as this may also reveal a fault that is intermittent.

POSSIBLE CAUSE	ACTION
Throttle cable is too tight.	Adjust throttle cable.
Connector is disconnected from TPS.	Reconnect.
TPS is loose.	Tighten sensor and reset <b>Closed Throttle</b> .
TPS is damaged or corroded.	Replace sensor and reset <b>Closed Throttle</b> .
Faulty TPS-related wiring/connector.	Test and repair/replace.
TPS has been replaced and Closed Throttle was not reset.	Reset <b>Closed Throttle</b> .
Throttle body has been replaced and Closed Throttle was not reset.	Reset <b>Closed Throttle</b> .
ECM has been replaced and Closed Throttle was not reset.	Reset <b>Closed Throttle</b> .

##### TPS Functional Problem

POSSIBLE CAUSES	ACTION
Connector is disconnected from TPS.	Reconnect.
TPS is damaged or corroded.	Replace sensor and reset <b>Closed Throttle</b> .

##### TPS Wear Test

Ensure TPS connector is plugged.

While engine is not running, activate throttle and pay attention for smooth operation without physical stops of the cable.

Use B.U.D.S. software.

Use the **Throttle Opening** display under **Monitoring**.


Slowly and regularly depress the throttle. Observe the needle movement. It must change gradually and regularly as you move the throttle. If the needle "sticks", bounces, suddenly drops or if any discrepancy between the throttle movement and the needle movement is noticed, it indicates a worn TPS that needs to be replaced.

#### TPS Input Voltage Test

##### TPS Connector Access

To reach the TPS connector, perform the following:


1. Remove drive belt guard. Refer to *DRIVE BELT*.
2. Remove primary air intake silencer. Refer to *AIR INTAKE SYSTEM*.
3. Loosen retaining clamps of throttle body.



4. Pull out throttle body to reach TPS connector.
5. Disconnect TPS connector.

## Section 04 FUEL SYSTEM

### Subsection 04 (E-TEC DIRECT FUEL INJECTION)




#### Test

Check the voltage output from ECM to the throttle position sensor.

Disconnect TPS connector.

Use the FLUKE 115 MULTIMETER (P/N 529 035 868) and set it to Vdc.


Repeatedly press the RANGE button until the display shows Manual Range 6.



Crank engine.

Read voltage at TPS harness connector as follows.

TPS HARNESS CONNECTOR		VOLTAGE
Pin 1	Pin 2	5.0 Vdc



Press the MIN MAX button so that the display shows MIN MAX.



Read the MAX value.

**NOTE:** Reset multimeter by pressing and holding MIN MAX button until meter beeps.

If voltage is good, check the TPS signal wire.

#### TPS Signal Wire Test


Disconnect J1A connector from ECM.

Check the wiring continuity as follows.

## Section 04 FUEL SYSTEM

### Subsection 04 (E-TEC DIRECT FUEL INJECTION)

TPS HARNESS CONNECTOR	ECM J1A CONNECTOR	RESISTANCE
Pin 3	Pin 18	Close to 0 $\Omega$ (continuity)



If tests are good, replace the TPS.

If tests are not good, continue to check the resistance of the rest of the TPS circuit.


### TPS Resistance Test

Reconnect the TPS.

Disconnect the connector J1A from the ECM.

Using the FLUKE 115 MULTIMETER (P/N 529 035 868), check resistive value as per the following table.

ECM CONNECTOR		THROTTLE IDLE POSITION	WIDE OPEN THROTTLE POSITION
PIN		RESISTANCE $\Omega$	
J1A-18	J1A-26	1000	2500
J1A-26	J1A-10	1600 - 2400	1600 - 2400
J1A-18	J1A-10	2500	1000



**NOTE:** The resistive value should change smoothly and proportionally to the throttle movement. Otherwise, replace TPS.

If resistive values are correct, try a new ECM. Refer to *ENGINE CONTROL MODULE (ECM)* elsewhere in this section.


If resistive values are incorrect, repair/replace wiring/connectors. If they are good, replace TPS.

### TPS Replacement

Remove the throttle body as described above.

Loosen two screws retaining the TPS.

Remove TPS.



1. Throttle position sensor (TPS)
2. Screws

Install the new TPS.

Apply Loctite 243 on the TPS retaining screws, then torque to 3 N•m (27 lbf•in).

Reinstall remaining removed parts.

Proceed with the Closed Throttle Reset.

**CRANKSHAFT POSITION SENSOR (CPS)**

**NOTE:** The CPS is used for forward and reverse.

**CPS Output Voltage Test**

Remove muffler. Refer to *EXHAUST SYSTEM*.  
Remove the acoustic panel.



If voltage is out of specification, inspect wiring/connectors. Replace CPS if wiring is good.

**CPS Resistance Test**

Disconnect connector J1A from ECM.  
Measure the resistance of the sensor itself.

ECM J1A CONNECTOR		RESISTANCE @ 20°C (68°F)
Pin 6	Pin 7	190 - 290 Ω



Disconnect CPS connector.



If measurement is out of specification, check wiring continuity between ECM and CPS. If continuity is good, replace CPS.

Also check for a bad ground connection as follows.

ECM J1A CONNECTOR		RESISTANCE @ 20°C (68°F)
Pin 6	Engine ground	Open circuit (OL)
Pin 7	Engine ground	




**CPS CONNECTOR**

Probe terminals coming from CPS while cranking engine.

CPS CONNECTOR		VOLTAGE
Pin 1	Pin 2	1 - 2 Vac min.

## Section 04 FUEL SYSTEM

### Subsection 04 (E-TEC DIRECT FUEL INJECTION)




If measurement is out of specification, check wiring between ECM and CPS.

#### CPS Replacement

Refer to *MAGNETO SYSTEM*.


#### AIR TEMPERATURE SENSOR (ATS)



#### ATS Test with B.U.D.S.

Use B.U.D.S. software.

Look **Intake Air** in **Monitoring** tab of B.U.D.S. It should show the ambient temperature. Otherwise, perform the following test.




#### ATS Resistance Test

Remove drive belt guard. Refer to *DRIVE BELT*.

Remove primary air intake silencer. Refer to *AIR INTAKE SYSTEM*.

Rotate intake adapter to disconnect ATS sensor connector.



#### TYPICAL


1. Rotate intake adapter
2. Disconnect sensor connector

Measure sensor resistance.

**IMPORTANT:** Move wiring harness close to the sensor while measuring the resistance. If resistance varies as harness is moved, check sensor connections.

**Section 04 FUEL SYSTEM**  
Subsection 04 (E-TEC DIRECT FUEL INJECTION)

ATS		MEASUREMENT
Pin 1	Pin 2	Refer to <i>SENSOR TEMPERATURE TABLE</i> below



mmv2008-024-012\_a

INTAKE ADAPTER REMOVED FOR CLARITY PURPOSE ONLY

SENSOR TEMPERATURE TABLE		
TEMPERATURE		RESISTANCE (ohms)
°C	°F	ATS
- 40	- 40	43610
- 30	- 22	25090
- 20	- 4	14900
- 10	14	9102
0	32	5705
10	50	3680
20	68	2436
25	77	2000
30	86	1651
40	104	1144
50	122	808
60	140	580
70	158	424
80	176	316
90	194	238
100	212	182
110	230	141
120	248	111
130	266	88

SENSOR TEMPERATURE TABLE		
TEMPERATURE		RESISTANCE (ohms)
°C	°F	ATS
140	284	70
150	302	57
160	320	47
170	338	39
180	356	32
190	374	27
200	392	23

If resistance is out of specifications, replace sensor.

If resistance tests good, reconnect the ATS and disconnect the J1A connector from ECM connector.

Using the FLUKE 115 MULTIMETER (P/N 529 035 868), measure resistance value as follows.

J1A CONNECTOR		MEASUREMENT
Pin J1A-20	Pin J1A-27	Refer to <i>SENSOR TEMPERATURE TABLE</i> above



mmv2009-027-001\_c

If resistance value is incorrect, repair the connectors or replace the wiring harness between ECM connector and the ATS.

Reinstall removed parts. Ensure intake adapter boot is properly installed on the adapter. See below in *ATS REPLACEMENT*.

### ATS Replacement

See procedures above to reach sensor.

Loosen boot clamp.




## Section 04 FUEL SYSTEM

### Subsection 04 (E-TEC DIRECT FUEL INJECTION)




1. Boot clamp


- Unplug ATS connector.
- Pull out intake adapter.
- Remove sensor push nuts.



- Pull out sensor.
- Use new push nuts and secure the new sensor to adapter.
- Reconnect ATS.
- Ensure adapter boot is properly installed as shown.



CORRECT BOOT INSTALLATION



WRONG BOOT INSTALLATION

Reinstall removed parts.


## COOLANT TEMPERATURE SENSOR (CTS)

### CTS Test with B.U.D.S.

Use B.U.D.S. software.

Look engine temperature in **Monitoring** tab of B.U.D.S. It should show the coolant temperature. Otherwise, perform the following test.

**Section 04 FUEL SYSTEM**  
**Subsection 04 (E-TEC DIRECT FUEL INJECTION)**



CTS		MEASUREMENT
Pin 1	Pin 2	Refer to <i>SENSOR TEMPERATURE TABLE</i> below



**CTS Resistance Test**

Remove drive belt guard. Refer to *DRIVE BELT*.  
 Remove primary air intake silencer. Refer to *AIR INTAKE SYSTEM*.  
 Disconnect CTS sensor connector.

SENSOR TEMPERATURE TABLE		
TEMPERATURE		RESISTANCE (ohms)
°C	°F	CTS
- 40	- 40	72412
- 30	- 22	38681
- 20	- 4	21529
- 10	14	12431
0	32	7418
10	50	4582
20	68	2919
30	86	1912
40	104	1284
50	122	883
60	140	622
70	158	448
80	176	328
90	194	245
100	212	186
110	230	143
120	248	112
130	266	88
135	275	79
140	284	71
145	293	64
150	302	57



Use the FLUKE 115 MULTIMETER (P/N 529 035 868) and set it to Ω.  
 Measure resistance between sensor terminals.

If resistance is out of specifications, replace CTS.

## Section 04 FUEL SYSTEM

### Subsection 04 (E-TEC DIRECT FUEL INJECTION)

If resistance tests good, reconnect the CTS.

Disconnect the J1A connector from ECM.

Measure resistance as follows.

J1A CONNECTOR		MEASUREMENT
Pin 19	Pin 27	Refer to <i>SENSOR TEMPERATURE TABLE</i> above



If resistance value is correct, sensor and wiring/connectors are good.

If resistance value is incorrect, repair/replace wiring/connectors between ECM and CTS.

### CTS Replacement

Remove drive belt guard. Refer to *DRIVE BELT* section.

Lift rear of vehicle to minimize coolant spillage.

Disconnect CTS connector.


Remove CTS.

Install the new CTS and torque to 12N•m (106lb•in).

Reinstall removed parts.

Refill engine coolant. If an important quantity of coolant spilled, bleed cooling system. Refer to *COOLING SYSTEM* section.

### AIR PRESSURE SENSOR (APS)



1. ECM
2. APS
3. APS tube
4. APS fitting in secondary air intake silencer

### APS Inspection

Open RH side panel.

Ensure sensor hose is correctly connected on secondary air intake silencer and on ECM.

Check hose for cleanliness, water, ice. Ensure it is not bent, kinked or burnt.

Connect B.U.D.S. Refer to *COMMUNICATION TOOLS/B.U.D.S. SOFTWARE*.


Use the B.U.D.S. software and look in **Monitoring** tab.

At sea level, atmospheric pressure gauge should read around 101.3 kPa (14.7 PSI) and less as altitude increases.



Otherwise, replace ECM.

**EXHAUST GAS TEMPERATURE SENSOR (EGTS)**




1. EGTS

**EGTS Resistance Test**

Disconnect EGTS connector.

Measure sensor resistance.

EGTS		MEASUREMENT
Pin 1	Pin 2	Refer to <i>SENSOR TEMPERATURE TABLE</i> below



mmr2008-033-040\_x

SENSOR TEMPERATURE TABLE		
TEMPERATURE		RESISTANCE (ohms)
°C	°F	EGTS
- 40	- 40	170
- 20	- 4	185
0	32	201
25	77	220
50	122	239
100	212	276
150	302	313
200	392	349
250	482	385
300	572	420
350	662	454
400	752	488
450	842	521
500	932	554
600	1112	618
700	1292	679
800	1472	738
900	1652	795
1000	1832	849

If resistance is out of specification, replace the sensor.

If resistance is as per specification, reconnect the EGTS.

Disconnect the J1A connector from ECM.

Measure resistance as follows.

J1A CONNECTOR		MEASUREMENT
Pin 12	Pin 27	Refer to <i>SENSOR TEMPERATURE TABLE</i> above

## Section 04 FUEL SYSTEM

### Subsection 04 (E-TEC DIRECT FUEL INJECTION)



If resistive value is correct, try a new ECM. Refer to *ENGINE CONTROL MODULE (ECM)* elsewhere in this section.

If resistive value is incorrect, repair the connector or replace the wiring harness between ECM connector and the EGTS.

#### EGTS Removal

Disconnect EGTS connector.

Remove muffler. Refer to *EXHAUST SYSTEM*.

Remove EGTS.


#### EGTS Installation

**NOTE:** New sensors have paraffin wax on their tip to protect the sensor during shipping. Paraffin will melt at first engine operation.

**NOTICE** Do not drop or use a sensor that has been dropped. Do not use an impact wrench to install sensor.

Apply ANTI-SEIZE LUBRICANT (P/N 293 800 070) over the EGTS threads to prevent possible seizure.

Install sensor and turn it so that it is positioned horizontally.




1. Sensor horizontal

**NOTE:** The sensor needs to be oriented in this specific position for optimum efficiency.

Torque the EGTS to 45 N•m (33 lbf•ft) while preventing sensor to turn.

Install remaining components.

#### KNOCK SENSOR (KS)



1. Knock sensor

#### KS Test with B.U.D.S.


Lift rear of vehicle off the ground and support it with a wide-base mechanical stand.

Use B.U.D.S. software.

Monitor the knock sensor using the **Knock Sensor Signal** in **Monitoring** section in B.U.D.S.

## Section 04 FUEL SYSTEM

### Subsection 04 (E-TEC DIRECT FUEL INJECTION)




#### MONITORING TAB

Start the engine.

Bring engine speed above 5200 RPM and vary engine RPM above 5200 RPM.

Needle of knock sensor signal should move between 0 and 100. The needle movement pattern is of no importance as long as it moves indicating the engine vibrations the knock sensor senses. If needle sticks either to 0 or 100, there is a problem.



If needle moves as described, the knock sensor should be good.

**NOTE:** Ensure ignition coil cables are not close to knock sensor harness. This might generate a false fault code.

Verify knock sensor circuit as follows.

#### KS Circuit Continuity Test

Ensure sensor and head contact surfaces are clean and mounting bolt and washer are correct and properly torqued down.

Disconnect knock sensor connector. Refer to **KNOCK SENSOR REPLACEMENT**.

Disconnect J1A connector from ECM.

Check wire continuity of circuit as per following table.

J1A CONNECTOR	KS CONNECTOR	MEASUREMENT
J1A-34	Pin 1	Close to 0 $\Omega$ (continuity)
J1A-33	Pin 2	



#### ECM CONNECTORS

If test is not good, repair/replace wiring/connectors between ECM and knock sensor.

If test is good, try a new knock sensor.


#### KS Replacement

Unscrew and remove knock sensor from cylinder head.

Remove drive belt guard. Refer to **DRIVE BELT**.

Remove primary air intake silencer. Refer to **AIR INTAKE SYSTEM**.

Unplug knock sensor connector above ATS.



## Section 04 FUEL SYSTEM

### Subsection 04 (E-TEC DIRECT FUEL INJECTION)

Clean contact surface, then install the new knock sensor.

Torque screw to 29 N•m (21 lbf•ft).

**NOTICE** Improper torque might prevent sensor to work properly and lead engine to severe damage of internal components.

Reconnect connector.

Reinstall remaining parts.



Figure 1: Torquing the knock sensor screw.



Figure 2: Cleaning the contact surface of the knock sensor.



Figure 3: The new knock sensor.



Figure 4: Removing the screw from the knock sensor.



Figure 5: Removing the knock sensor from the engine block.



Figure 6: Cleaning the contact surface of the knock sensor.



Figure 7: The cleaned knock sensor.

# IGNITION SYSTEM

## SERVICE TOOLS

Description	Part Number	Page
12 VOLTS BATTERY SUPPLY CABLE.....	529 035 997 .....	338
DIAL INDICATOR ADAPTER KIT.....	529 036 132 .....	322
DIGITAL INDUCTIVE TYPE TACHOMETER .....	529 014 500 .....	324
FLUKE 115 MULTIMETER .....	529 035 868 .....	332, 336
IGNITION TIMING TOOL.....	529 036 129 .....	321
SUPPLY CABLE.....	529 035 997 .....	344
SUPPLY HARNESS.....	529 035 869 .....	344
T-HARNESS.....	529 035 869 .....	337
TDC GAUGE.....	295 000 143 .....	322

## SERVICE PRODUCTS

Description	Part Number	Page
DIELECTRIC GREASE.....	293 550 004 .....	330-331
LOCTITE 767 (ANTISEIZE LUBRICANT) .....	293 800 070 .....	330

## GENERAL

### **⚠ WARNING**

Always electrically disconnect both fuel injectors prior to testing for ignition spark. Otherwise, fuel vapors may ignite in presence of a spark creating a fire hazard.

## SYSTEM DESCRIPTION (500SS/600/800R)

A CDI ignition system is used.

The ECM sends the current to the primary winding of a dual ignition coil which provides a separate high voltage output to each spark plug.

The ECM is programmed for optimum ignition timing under all operating conditions. Using operating conditions provided by a variety of sensors, the ECM controls the ignition timing for optimum engine operation.


The ECM will limit the maximum engine speed to approximately 8600 RPM.

## SYSTEM DESCRIPTION (600 HO E-TEC)

This ignition system is an inductive type specifically designed for the E-TEC engine with a rapid rise time to prevent spark plug fouling. It provides a quick spark similar to a CDI system but with a longer duration.

The ignition system is fully managed by the ECM which controls the ignition system parameters such as spark timing, dwell time, and firing order.

The system uses two separate ignition coils which induce voltage to a high level in their secondary winding to produce a spark at each spark plug independently.



**IGNITION COILS**

The ignition coils receive power from the 55 Vdc system. Their operating voltage varies from 30 to 55 Vdc.



## Section 05 ELECTRICAL SYSTEM

### Subsection 01 (IGNITION SYSTEM)

#### Ignition System Basic Operation

A 3-wire connector is connected to the primary winding of each coil.

The ECM energizes the primary winding of each coil through pin 3. Pin 1 is connected to a ground circuit.

At the appropriate time, the ECM sends a trigger signal of approximately 14 Vdc to pin 2 of each ignition coil. This switches ON the primary winding that is fed by 55 Vdc, for the dwell time.

The ECM will then switch the primary winding off. This produces a high voltage discharge from the secondary winding to the spark plug.

A resistive core spark plug cable is used to prevent the RFI (Radio Frequency Interference). There is no resistor in the spark plug cap.

#### Spark Plugs


A new platinum NGK PZFR6F spark plug is used, one per cylinder.



It has an expected life of approximately 10 000 km (6000 mi).

The OEM spark plug used in the E-TEC engine is specially indexed for optimum engine operation and efficiency.


The threads on the spark plug and in the cylinder head are indexed so that when the plug is installed, the open end of the negative electrode will be facing the injection spray, within  $\pm 90^\circ$ . This ensures the negative electrode does not deviate the injection spray and ensures proper ignition.



**CORRECTLY INDEXED**

1. Injector nozzle
2. Ground electrode

**NOTE:** Using an incorrectly indexed spark plug will result in poor idle and increased emissions.



**INCORRECTLY INDEXED**

1. Injector nozzle
2. Ground electrode

If using a non OEM spark plug, a specific installation procedure must be followed. Refer to *SPARK PLUG INSTALLATION (600 HO E-TEC)* in this section.

#### Ignition Timing

The crankshaft position sensor (CPS), the air pressure sensor (APS) and the throttle position sensor (TPS) are the primary sensors used to control the ignition timing.

The ECM is programmed with data (ignition mappings). Using engine operating parameters provided by the sensors, the ECM controls the ignition timing for optimum engine operation under all operating conditions.

Ignition timing can be adjusted using the B.U.D.S. software.

## Knock Detection

A knock sensor is mounted on top of the cylinder head. It detects specific vibration that would be typically generated by engine detonation.



If detonation occurs, the ECMs retards the ignition advance and extends the injection period temporarily (it goes into a specific operating mode) until detonation stops.

## ADJUSTMENT

### IGNITION TIMING

Normally, ignition timing adjustments should not be required. It has been set at the factory and should remain correctly adjusted as every component is fixed and non adjustable.

The only time the ignition timing may require adjustment is when replacing the crankshaft, the magneto flywheel, a trigger coil (500SS/600/800R) or CPS (600 HO E-TEC), or the ECM.


If the ignition timing is found incorrect, first check for proper crankshaft alignment. This might be an indication of a twisted crankshaft. Refer to *ENGINE MEASUREMENT* section.

### Ignition Timing Tool Installation

#### **⚠ WARNING**


Ensure tether cord is removed from DESS post and engine stop switch is in the STOP position.

1. Remove the LH front engine mounting screw.



LH FRONT ENGINE MOUNT SCREW

- NOTE:** Note position of washers for installation.
2. Install the IGNITION TIMING TOOL (P/N 529 036 129) on the LH front engine mount and torque mounting bolt to 25 N•m (18 lbf•ft).



1. Ignition timing tool
2. Pointer

### TDC Gauge Installation (500SS/600/800R)


#### **⚠ WARNING**

Ensure tether cord is removed from DESS post and engine stop switch is in the STOP position.

1. Clean the area around the MAG spark plug, and remove it.
2. Position the MAG piston at approximately TDC.
3. Assemble the gauge onto the adaptor and tighten the roller lock nut. Do not tighten the adaptor lock nut.
4. Screw the adaptor and TDC gauge in the spark plug hole and tighten to prevent movement of the adapter in the plug hole.

## Section 05 ELECTRICAL SYSTEM

### Subsection 01 (IGNITION SYSTEM)



TYPICAL  
1. TDC gauge on MAG side

5. Position the dial face towards the PTO side. Move the gauge down until the needle just begins to move, then move down a further 5 or 6 mm (approximately 1/4 in). Tighten adaptor lock nut by hand.

### TDC Gauge Installation (600 HO E-TEC)

To install the TDC gauge on the E-TEC engine, you will require the DIAL INDICATOR ADAPTER KIT (P/N 529 036 132).

Modify TDC GAUGE (P/N 295 000 143) using the dial indicator adapter kit as follows.


**NOTE:** TDC gauge (P/N 414 104 700) can also be used. However, you will have to loosen and lift the console, gauge support and secondary air intake silencer to provide clearance for the extra length of the stem adapter.

#### **⚠ WARNING**

Ensure tether cord is removed from DESS post and engine stop switch is in the STOP position.

1. Remove the roller tip from the TDC gauge.
2. Install the long reach contact extension (30 mm), and the rounded tip from the DIAL INDICATOR ADAPTER KIT (P/N 529 036 132) onto the TDC gauge.
3. Remove the PTO injector, refer to *E-TEC DIRECT INJECTION* section.
4. Install the adapter plate from the DIAL INDICATOR ADAPTER KIT (P/N 529 036 132) over the PTO injector hole using Allen socket screws M10 x 1.5 x 35. Tighten screws snug fit.

5. Carefully insert the TDC gauge through the dial indicator adapter hole and into the cylinder.



1. TDC gauge  
2. Dial indicator adapter plate  
3. Allen socket screws M10 x 1.5 x 35

6. Screw the gauge into the adapter plate with the dial face towards the PTO and tighten it enough to prevent movement.

### Locating Piston TDC

**NOTE:** Normal engine rotation as seen from the PTO side is counterclockwise.

1. With a firm hold on the drive pulley, slowly rotate the drive pulley counterclockwise while observing the TDC gauge needle.

**NOTE:** Note that the needle stops moving only as the piston is changing direction at the top of its stroke.

2. Rotate the dial face so the "0" is in line with the needle when it stops moving.
3. Resume rotating the engine in the same direction (counterclockwise) until the gauge needle has rotated approximately 1/4 turn past TDC.
4. Then slowly rotate the engine in a clockwise direction until needle stops moving.

**NOTE:** The needle should stop on the "0". If not, reset the dial "0" to the needle.

5. Again, slowly rotate the drive pulley back and forth across TDC and confirm the needle always stops exactly at "0" before changing direction. "0" now indicates exact TDC.
6. Lock the dial face with the dial lock screw.

**NOTE:** If a difference in "0" setting the dial in each direction of rotation is easily noticeable, the engine components may suffer from excessive wear. The engine may require further inspection and maintenance.


### Scribing the Timing Mark

1. From the "0" (TDC), rotate the drive pulley clockwise (backwards engine rotation) until the dial needle rotates one-quarter turn past the required BTDC measurement (see table below).
2. Then carefully rotate it counterclockwise (forwards engine rotation) until the needle indicates precisely the measurement as specified in the following table.

**NOTE:** Always rotate the engine backwards (clockwise) past the specified BTDC, then forwards to the exact specified BTDC. Final setting must always be made in the normal engine rotation.

IGNITION TIMING BTDC		
ENGINE	MEASUREMENT BTDC	DEGREE SETTING BTDC
500SS/600	2.49 mm (.098 in)	20°
600 HO E-TEC	5.39 mm (.212 in)	28°
800R	2.37 mm (.093 in)	18°

3. With the TDC gauge indicating specified timing, use a permanent marker to draw a line on the drive pulley fixed sheave directly in line with pointer end.



1. Timing mark in line with pointer end

4. Repeat the procedure to ascertain the mark is exactly in line with the pointer.

#### 500SS/600/800R

5. Remove TDC gauge and install spark plug. Refer to *SPARK PLUG INSTALLATION* in this section.
6. Reconnect spark plug cable.

7. Check ignition timing as per applicable procedure in this section.

#### 600 HO E-TEC

8. Remove the TDC gauge and dial indicator adapter.
9. Reinstall the fuel injector. Refer to *E-TEC DIRECT INJECTION* section.
10. Reconnect magneto connector.
11. Check ignition timing as per applicable procedure in this section.

### Checking Ignition Timing (500SS/600/800R)

The ignition timing can be checked with either the engine hot or cold at the specified RPM.

ENGINE SPEED FOR IGNITION TIMING CHECK	
MODELS	ENGINE RPM
500SS/600/800R	3500 <sup>(1)</sup>

<sup>(1)</sup> In the 3000 to 4000 RPM range, the spark advance does not change. Therefore, at 3500 RPM, a change in engine speed of  $\pm 500$  RPM will not affect the timing mark.

To check the ignition timing proceed as follows:

#### **⚠ WARNING**

Place ski tips against a wall, raise rear of vehicle on a stand, so that track does not contact the ground. Do not allow anyone in front of or behind the vehicle while engine is running. Keep clear of track and do not wear loose clothing which can get caught in moving parts.

**NOTE:** On 800R models, disconnect the TPS connector.

1. Connect the timing light pick-up to the MAG spark plug cable.

## Section 05 ELECTRICAL SYSTEM


### Subsection 01 (IGNITION SYSTEM)



#### TIMING LIGHT CONNECTION

1. MAG side spark plug
2. Timing light connection to MAG plug cable


2. Connect the DIGITAL INDUCTIVE TYPE TACHOMETER (P/N 529 014 500) to a spark plug cable.



#### TACHOMETER

**NOTICE** Before starting engine, check cable routing of test equipment to ensure it cannot come into contact with rotating parts or with the exhaust manifold.

3. Start the engine and point timing light on timing mark/pointer.
4. Bring engine to the specified engine speed (3500 RPM) for a brief instant.




1. Inductive timing light
2. Timing light cable to MAG plug
3. Timing mark/pointer alignment

5. Ensure timing mark is aligned with the pointer end within the specified tolerance.


MODEL	TOLERANCE
500SS/600/800R	$\pm 1^\circ$

If marks are aligned, no adjustment is required.

If marks are not aligned, note if timing is retarded or advanced, see following illustrations. Then, adjust timing as described in *ADJUSTING TIMING (500SS/600/800R)* further in this section.



TIMING RETARDED BY ABOUT  $1^\circ$



TIMING ADVANCED BY ABOUT 2°

### Checking Ignition Timing (600 HO E-TEC)

The ignition timing can be checked with either the engine hot or cold at the specified RPM.

#### ENGINE SPEED FOR IGNITION TIMING CHECK

MODEL	ENGINE RPM
600 HO E-TEC	3500

**NOTE:** In the 2500 to 4000 RPM range, the spark advance does not change during the procedure. Therefore, at 3500 RPM, a change in engine speed of  $\pm 500$  RPM will not affect the timing mark.


To check the ignition timing proceed as follows:

#### **⚠ WARNING**

Place ski tips against a wall, raise rear of vehicle on a stand, so that track does not contact the ground. Do not allow anyone in front of or behind the vehicle while engine is running. Keep clear of track and do not wear loose clothing which can get caught in moving parts.

1. Connect the timing light pick-up to the PTO spark plug cable.

**NOTE:** Be careful to route timing light cable away from drive belt and pulleys.



#### TIMING LIGHT CONNECTION

1. PTO spark plug cable
2. Timing light connection to PTO plug cable
3. Timing light wire routing

2. Remove RH side panel, refer to *BODY* section.
3. Connect to the latest B.U.D.S. software applicable to the E-TEC from BOSSWeb. Refer to *COMMUNICATION TOOLS AND B.U.D.S. SOFTWARE* section.
4. Start engine and let idle.
5. In B.U.D.S., select **Read Data**.
6. Select the **Setting** tab.
7. At the bottom of the setting page, select the **ECM** tab.
8. At the bottom left hand corner of the page, you will be able to read the **RPM Value** and the **Offset Angle** in the Ignition/Injection Timing field.



1. RPM Value
2. Timing Offset Angle

9. In the Ignition/Injection Timing field, select **Freeze timing**.

## Section 05 ELECTRICAL SYSTEM

### Subsection 01 (IGNITION SYSTEM)

**NOTE:** Selecting Freeze timing will freeze the timing to 28° advance as required by the 600 HO E-TEC. Timing will be frozen on the PTO cylinder only for RPM stability. RPM will be limited to 4000 RPM.



#### SELECTING FREEZE TIMING

Note how the available buttons in the Ignition/Injection Timing field have changed.




10. Point the timing light on the timing mark and increase engine to the specified engine speed (3500 RPM) for a brief instant.
11. The timing mark must be aligned with the pointer end within the specified tolerance.


MODEL	TOLERANCE
600 HO E-TEC	± 0.5°

If timing mark and pointer are aligned, no adjustment is required.

If they are not aligned, note if timing is retarded or advanced, see following illustrations. Then, adjust timing as described in *ADJUSTING TIMING (E-TEC)* further in this section.



TIMING RETARDED BY ABOUT 1°



TIMING ADVANCED BY ABOUT 2°

#### Adjusting Timing (500SS/600/800R)

1. Connect vehicle to the latest applicable B.U.D.S. software available from BOSSWeb. Refer to *COMMUNICATION TOOLS AND B.U.D.S. SOFTWARE* section.
2. Select **Read Data**.
3. Select the **Setting** page tab.
4. To change the ignition timing, select the appropriate correction in the **Ignition Correction** field.

## Section 05 ELECTRICAL SYSTEM

### Subsection 01 (IGNITION SYSTEM)



#### TIMING ADJUSTMENT

1. Read Data button
2. Setting page tab
3. Ignition Correction field

5. Once the appropriate correction has been selected and verified, select **Write Data** in the **File** menu to save the correction.

Detailed information about the B.U.D.S. software and its usage is available under its **Help** section.

6. Remove all tools and reinstall removed parts.

**NOTE:** On 800R models, be sure to reconnect TPS connector.

#### Adjusting Timing (600 HO E-TEC)

1. In the Ignition/Injection Timing field on the **Setting** page, select **Advance** or **Retard** to change the ignition timing, and **Cancel** to erase the last change.



1. Advance timing button
2. Retard timing button
3. Cancel timing change

**NOTE:** Timing will be changed in 0.5° increments.

2. Adjust the timing using the appropriate button until the timing mark is in line with the pointer, within 0.5°. Then select **Store Offset** to store the ignition timing correction.



1. Timing angle changed by 0.5 degrees
2. Store offset button

3. Shut down engine.

4. Restart engine and select **Read Data** in B.U.D.S.

5. Recheck timing to ensure ignition timing adjustment was properly stored in the ECM.

6. Increase engine RPM pass 4000 RPM to ascertain the **Freeze Timing** function is no longer active.

**NOTE:** The **Freeze Timing** function automatically disengages when the engine is shutdown.

7. Remove all tools.

## TROUBLESHOOTING

### IGNITION SYSTEM TESTING SEQUENCE

**NOTE:** On applicable models, it is good practice to check for fault codes using the B.U.D.S. software as a first troubleshooting step. Refer to the *MONITORING SYSTEM AND FAULT CODES* section.

In the case of ignition problems, check the following in the prescribed order until the problem can be solved:

1. Spark plugs
2. Spark plug cables
3. Wiring harness/electrical connectors
4. Engine stop switch
5. Ignition coil(s)
6. Trigger coils (500SS/600/800R)
7. CPS (600 HO E-TEC)
8. ECM (Engine Control Module).



## Section 05 ELECTRICAL SYSTEM

### Subsection 01 (IGNITION SYSTEM)

#### 600 HO E-TEC

If engine idles roughly or shows signs of increased emissions, the spark plugs may be incorrectly indexed. Refer to *SPARK PLUG INSTALLATION (600 HO E-TEC)* in this section.

## PROCEDURES

### SPARK PLUGS

#### Spark Testing

**NOTE:** Use **ONLY** an approved inductive spark plug tester or a new spark plug to test for ignition spark. In line (series connected) spark testers must not be used. Radio frequency interference (RFI) generated by the arcing current may cause erratic behavior in the ECM.


#### **⚠ WARNING**

On 600 HO E-TEC models, always electrically disconnect both fuel injectors prior to testing for ignition spark. Otherwise, fuel vapors may ignite in presence of a spark creating a fire hazard.

1. Install the inductive spark tester (or a new spark plug) on the spark plug cable (Do not remove spark plugs installed on engine).
2. Bring the new plug into contact with the engine.
3. Pull rewind starter or press START/RER button as applicable.
4. If no spark is produced, refer to *IGNITION SYSTEM TESTING SEQUENCE* in this section.
5. If a spark is produced, install new spark plugs in the engine and repeat the test to assure the new spark plugs are in good condition and functioning correctly.

#### Spark Plug Removal (500SS/600/800R)

**NOTE:** Use only an approved spark plug socket for removal and installation. Extra care should be taken to avoid side stresses which could result in a broken spark plug.



#### TYPICAL

1. Approved socket
2. Improper socket

1. First unscrew the spark plug 1 turn.
2. Clean the spark plug and cylinder head with pressurized air.
3. Remove spark plug from engine.

#### **⚠ WARNING**

Whenever using compressed air, always wear protective eye wear.

#### Spark Plug Removal (600 HO E-TEC)

**NOTICE** Due to limited access, spark plugs should only be removed when absolutely required.

**NOTE:** Use only an approved spark plug socket for removal and installation. Extra care should be taken to avoid side stresses which could result in a broken spark plug.

1. Disconnect the magneto connector.

#### **⚠ WARNING**

Disconnect the magneto connector before disconnecting and removing the spark plugs. Otherwise, fuel vapors may ignite in presence of a spark creating a fire hazard.


## Section 05 ELECTRICAL SYSTEM

### Subsection 01 (IGNITION SYSTEM)



**MAGNETO CONNECTOR**

2. Remove spark plug cables by gently rotating the cap and pulling it off the plug.



1. PTO spark plug
2. Mag spark plug


3. Clean the spark plug and cylinder head with pressurized air.
4. Proceed to applicable spark plug procedure (PTO or MAG side).

#### **⚠ WARNING**

Whenever using compressed air, always wear protective eye wear.

#### PTO Spark Plug

1. Install an approved spark plug socket onto the spark plug.
2. Using a 19 mm (3/4 in) wrench on the spark plug socket, unscrew the spark plug just enough to break the applied torque.



1. Spark plug socket 16 mm (5/8 in)
2. Wrench 19 mm (3/4 in)

3. Remove wrench from spark plug socket and unscrew the spark plug by hand.

#### MAG Spark Plug

1. Remove the primary air intake silencer.
2. Install an approved spark plug socket onto the spark plug.
3. Using a ratchet wrench, extension, and a crowfoot, unscrew the spark plug just enough to break the applied torque.



1. Spark plug socket 16 mm (5/8 in)
2. Crowfoot 19 mm (3/4 in)

4. Remove wrench from spark plug socket and unscrew the spark plug by hand.


#### Spark Plug Installation (500SS/600/800R)

1. Prior to installation, ensure the contact surfaces of the cylinder head and spark plug are free of grime.
2. Using a feeler gauge, ensure electrode gap is set to 8 mm (.31 in). If gap is incorrect, replace spark plug.

## Section 05 ELECTRICAL SYSTEM

### Subsection 01 (IGNITION SYSTEM)

3. Apply LOCTITE 767 (ANTISEIZE LUBRICANT) (P/N 293 800 070) over the spark plug threads to prevent possible seizure.
4. Hand screw spark plug into cylinder head and tighten with a torque wrench and an approved spark plug socket to 28 N•m (21 lbf•ft).



TYPICAL  
1. Approved socket  
2. Improper socket

### Spark Plug Installation (600 HO E-TEC)

#### OEM Spark Plug Installation

1. Prior to installation, ensure the contact surfaces of the cylinder head and spark plug are free of grime.
2. Using a feeler gauge, confirm electrode gap is set to 8 mm (.31 in) If gap is incorrect, use another spark plug.
3. Hand screw spark plug into cylinder head until it bottoms out.
4. Apply specific torque using a torque wrench, crow foot, and approved spark plug socket.

**NOTE:** Spark plug tightening torque is particularly important on this engine as it contributes to the proper positioning of the negative electrode

MODEL	SPARK PLUG	TORQUE
600 HO E-TEC	BRP NGK PZFR6F	28 N•m (21 lbf•ft)

5. Apply DIELECTRIC GREASE (P/N 293 550 004) on contact in spark plug cap of the ignition cable prior to connecting it onto the spark plug.


#### Non-OEM Spark Plug Installation

**NOTE:** When using a non-OEM spark plug, it must be correctly indexed or engine may experience rough idling and higher emissions.

Carry out the following procedure if a non BRP OEM spark plug is used.

1. Using a marker, mark the open end of the negative electrode on the plug shell (above threads).
2. Ensure the contact surfaces of the cylinder head and spark plug are free of grime.
3. Install and torque the spark plug, refer to previous table for specific torque.
4. Visually check to ensure the open end of the negative electrode is facing the injector nozzle within 90° (45° each side of nozzle).

**NOTE:** The following illustration uses the point of attachment of the negative electrode to depict the angle. The injector is illustrated above the spark plug.



SPARK PLUG INDEXING

1. Acceptable
2. Unacceptable

If the plug indexing angle is not within specification, repeat procedure with another spark plug until correct indexing is achieved.

### SPARK PLUG CABLES (500SS/600/800R)

#### Spark Plug Cable Resistance Test

Before removing a spark plug cable from the ignition coil, carry out a resistance test of the coil secondary winding with both spark plug cables installed. Refer to *IGNITION COIL RESISTANCE TEST (500SS/600/800R)* in this section.

If the resistance test through the coil secondary winding failed, carry out the following steps to test each spark plug cable.

1. Take a firm hold of the spark plug cable near the coil and unscrew it from the coil.
2. Set multimeter to  $\Omega$  selection and measure the resistance through the cable.

SPARK PLUG CABLE RESISTANCE TEST	
500SS/600/800R	11.9 k $\Omega$ to 20.3 k $\Omega$

If resistance is not as specified, replace spark plug cable.

**NOTE:** Apply DIELECTRIC GREASE (P/N 293 550 004) on contact in spark plug cap before re-installing cable.

## SPARK PLUG CABLES (600 HO E-TEC)

### Spark Plug Cable Resistance Test

If the spark plug cables are in good condition, carry out the following resistance test.

1. Remove each spark plug cable from its ignition coil and spark plug.
2. Set multimeter to  $\Omega$ .
3. Insert a probe in each cable end and measure the resistance.

SPARK PLUG CABLE RESISTANCE
1283 – 4083 $\Omega$



SPARK PLUG CABLE RESISTANCE TEST

If resistance is not as specified, replace spark plug cable.

**NOTE:** Apply DIELECTRIC GREASE (P/N 293 550 004) on contact in spark plug cap before re-installing cable.

**NOTICE** Do not interchange spark plug cables. The lower LH coil must be matched to the PTO spark plug.

## ENGINE STOP SWITCH

### Engine Stop Switch Operation

The engine stop switch provides a ground signal to the ECM when STOP is selected.

#### 500SS/600/800R

The ground signal is applied to the ECM connector pin 23, through the engine stop switch (STOP position).

#### 600 HO E-TEC

The ground signal is applied to ECM connector "J1A" pin 9, through the engine stop switch (STOP position).

Refer to applicable *WIRING DIAGRAM* for details.

### Engine Stop Switch Troubleshooting

#### Engine Will Not Start, No Spark

If the engine will not start and you do not have ignition spark at the plugs, the engine stop switch or its wiring to the ECM may be shorted to ground.

Carry out an *ENGINE STOP SWITCH CONTINUITY TEST*, and a *ENGINE STOP SWITCH WIRING TEST* as per applicable procedures in this section.

#### Engine Will Not Stop

The engine stop switch and wiring may be open-circuit (no ground available).

Carry out an *ENGINE STOP SWITCH CONTINUITY TEST* and an *ENGINE STOP SWITCH WIRING TEST* as per applicable procedures in this section.


### Engine Stop Switch Continuity Test

To test the engine stop switch, carry out the following steps.

1. Disconnect the RH steering connector (GD) under the steering cover.

## Section 05 ELECTRICAL SYSTEM

### Subsection 01 (IGNITION SYSTEM)



TYPICAL — RH STEERING CONNECTOR (GD)

2. Set the FLUKE 115 MULTIMETER (P/N 529 035 868) multimeter to  $\Omega$ .
3. Measure the resistance through the switch and its wiring as follows.

**NOTE:** Some engine stop switches use two BLACK wires, and others use one BLACK wire and one BLACK/YELLOW. Pin numbers in connectors vary with vehicle types and gauge types. Refer to the appropriate *WIRING DIAGRAM* for pin numbers.

#### ENGINE STOP SWITCH CONTINUITY TEST

SWITCH POSITION	TEST PROBES		RESISTANCE
RUN	BK wire	BK or BK/YL wire	Infinite (OL)
STOP			0 to 0.5 $\Omega$

If readings are not as specified in table, replace switch or repair wiring/connector.

If readings are as specified, refer to *ENGINE STOP SWITCH WIRING TEST* applicable to model.


#### Engine Stop Switch Wiring Test (500SS/600/800R Models)

1. Remove the steering cover.
2. Disconnect the RH steering connector (GD).



TYPICAL — RH STEERING CONNECTOR (GD)

3. Open the RH side panel.
4. Remove acoustic panel.
5. Disconnect the ECM connector.



TYPICAL  
1. Acoustic panel  
2. ECM

6. Test the vehicle wiring harness from the engine stop switch to the ECM to ensure it is not open or shorted to ground as per following table.

Refer to the applicable *WIRING DIAGRAM* for circuit details.

#### ENGINE STOP SWITCH WIRING TEST


##### STANDARD GAUGE

PROBE GD CONNECTOR		RESISTANCE
Pin 7 (BK/YL) Vehicle harness	Chassis ground	Infinite (OL)
	ECM pin 23	Close to 0 $\Omega$ (continuity)

## Section 05 ELECTRICAL SYSTEM

### Subsection 01 (IGNITION SYSTEM)

ENGINE STOP SWITCH WIRING TEST		
PREMIUM GAUGE		
PROBE GD CONNECTOR		RESISTANCE
Pin 5 (BK/YL) Vehicle harness	Chassis ground	Infinite (OL)
	ECM pin 23	Close to 0 $\Omega$ (continuity)



ECM CONNECTOR PIN-OUT (500SS/600/800R)

If a low resistance to chassis ground is found, refer to step 7.

If you do not have continuity to the ECM, refer to step 11.

7. Remove the multifunction gauge.
8. Disconnect the HG connector to isolate the steering harness from the main harness.



DISCONNECT HG CONNECTOR

9. Test each harness as per table to determine which harness is shorted to ground.

PROBE HG CONNECTORS		RESISTANCE
Pin 6 (BK/YL) Vehicle harness side	Chassis ground	Infinite (OL)
Pin 6 (BK/YL) Steering harness side		



TYPICAL - VEHICLE HARNESS TO GROUND



TYPICAL - STEERING HARNESS TO GROUND

10. If a short circuit (low resistance to ground) is found, repair or replace wiring.
11. If engine stop switch circuit is found to be open, test for continuity of each harness as per following table.

STANDARD GAUGE		
STEERING HARNESS SIDE		RESISTANCE
HG pin 6	GD pin 7 (BK/YL)	Close to 0 $\Omega$ (continuity)
HG pin 2	GD pin 8 (BK/BU)	

## Section 05 ELECTRICAL SYSTEM

### Subsection 01 (IGNITION SYSTEM)

PREMIUM GAUGE		
STEERING HARNESS SIDE		RESISTANCE
HG pin 6	GD pin 5 (BK/YL)	Close to 0 $\Omega$ (continuity)
HG pin 2	GD pin 6 (BK/BU)	

STANDARD AND PREMIUM GAUGES		
VEHICLE HARNESS SIDE		RESISTANCE
HG pin 6	ECM pin 23	Close to 0 $\Omega$ (continuity)
HG pin 2	Chassis ground	

### Engine Stop Switch Wiring Test (600 HO E-TEC)

#### Engine Stop Switch Input Wiring Test

1. Remove the steering cover and disconnect the RH steering connector (GD).



TYPICAL — DISCONNECT RH STEERING CONNECTOR (GD)

2. Open the LH side panel.
3. Disconnect J1A from the ECM (top connector).




1. ECM  
2. J1A disconnected

4. Test the vehicle wiring harness from the engine stop switch to the ECM to ensure it is not shorted to ground as per following table.

Refer to the applicable *WIRING DIAGRAM* for circuit details.

ENGINE STOP SWITCH WIRING TEST		
STANDARD GAUGE		
PROBE (VEHICLE HARNESS SIDE)		RESISTANCE
GD pin 7 (BK/YL)	Chassis ground	Infinite (OL)
GD pin 7 (BK/YL)	ECM J1A pin 9	Close to 0 $\Omega$ (continuity)

ENGINE STOP SWITCH WIRING TEST		
PREMIUM GAUGE		
PROBE (VEHICLE HARNESS SIDE)		RESISTANCE
GD pin 3 (BK/YL)	Chassis ground	Infinite (OL)
GD pin 3 (BK/YL)	ECM J1A pin 9	Close to 0 $\Omega$ (continuity)



J1A PIN-OUT

If a low resistance to chassis ground is found, refer to step 5.

If you do not have continuity through the wires, refer to step 9.

5. Remove the multifunction gauge.
6. Disconnect the HG connector to isolate the steering harness from the vehicle harness.

## Section 05 ELECTRICAL SYSTEM

### Subsection 01 (IGNITION SYSTEM)



mmv2009-024-009

DISCONNECT HG CONNECTOR

7. Test each harness as per applicable table to determine which harness is shorted to ground.



mmv2009-024-009\_s

TYPICAL - VEHICLE HARNESS TO GROUND



mmv2009-024-009\_s

TYPICAL - STEERING HARNESS TO GROUND

TEST PROBES		RESISTANCE
HG pin 4 (BK/YL) Vehicle Harness Side	Chassis ground	Infinite (OL)
HG pin 4 (BK/YL) Steering Harness Side		

8. If a short circuit (low resistance to ground) is found, repair or replace wiring.

9. If engine stop switch circuit is found to be open, test for continuity of each harness as per following table.

STANDARD GAUGE		
STEERING HARNESS SIDE		RESISTANCE
HG pin 4	GD pin 7 (BK/YL)	Close to 0 Ω (continuity)
HG pin 1	GD pin 8 (BK/BU)	

PREMIUM GAUGE		
STEERING HARNESS SIDE		RESISTANCE
HG pin 4	GD pin 3 (BK/YL)	Close to 0 Ω (continuity)
HG pin 1	GD pin 4 (BK/BU)	

STANDARD AND PREMIUM GAUGES		
VEHICLE HARNESS SIDE		RESISTANCE
HG pin 4	J1A pin 9	Close to 0 Ω (continuity)
HG pin 1	Chassis ground	

Repair or replace wiring or connections.

## IGNITION COIL (500SS/600/800R)

The ECM energizes the primary side of the ignition coil.



IGNITION COIL (LEFT FRONT VIEW)

The ignition coil induces voltage to a high level in the secondary windings to produce a spark at the spark plugs.

**NOTE:** Keep in mind that an ignition coil with good resistance measurements can still be faulty. Voltage leak can occur at high voltage levels which is not detectable with an ohmmeter. Replacing the ignition coil may be necessary as a test.




## Section 05 ELECTRICAL SYSTEM

### Subsection 01 (IGNITION SYSTEM)

#### Ignition Coil Test With B.U.D.S.

Use the latest B.U.D.S. software available from BOSSWeb. Refer to *COMMUNICATION TOOLS AND B.U.D.S. SOFTWARE* section.

Energize the ignition coil from within the **Activation** tab.




**TYPICAL**  
1. Activate here

You should hear the spark occurring. If in doubt, use an inductive spark tester.


#### Ignition Coil Resistance Test (Primary Winding)

1. Disconnect primary winding terminals from ignition coil.
2. Using the FLUKE 115 MULTIMETER (P/N 529 035 868), test winding resistance as follows.



**IGNITION COIL (SEEN FROM BEHIND)**  
1. Primary winding terminals

PRIMARY WINDING RESISTANCE TEST	
TEST PROBES	RESISTANCE @ 20°C (68°F)
Between primary terminals	0.4 - .6 Ω




**PRIMARY WINDING**

If resistance reading through the primary winding is out of specification, replace the ignition coil.

#### Ignition Coil Resistance Test (Secondary Winding)

1. Disconnect both spark plug cables from the spark plugs.
2. Insert a multimeter probe in each spark plug cable and measure the coil secondary winding resistance.



**SECONDARY WINDING**

#### SECONDARY WINDING RESISTANCE TEST (SPARK PLUG CABLES INSTALLED)

TEST PROBES	RESISTANCE @ 20°C (68°F)
Between secondary terminals	21.5 kΩ - 34.7 kΩ

If resistance readings are out of specification, continue with step 3.

3. Remove spark plug cables from the ignition coil, take a firm hold of each cable close to the coil and unscrew the cable from the coil.

**SECONDARY WINDING RESISTANCE TEST  
 (SPARK PLUG CABLES REMOVED)**

TEST PROBES	RESISTANCE @ 20°C (68°F)
Between secondary terminals	9.6 kΩ - 14.4 kΩ

If secondary coil resistance is not as specified with cables removed, replace ignition coil.

If secondary coil resistance is as specified, refer to *SPARK PLUG CABLE (500SS/600/800R)* and carry out the cable resistance test.

**IGNITION COILS (600 HO E-TEC)**

**Ignition Coil Testing Sequence**

**NOTE:** A resistance test of the ignition coil primary and secondary windings cannot be carried out due to internal circuits.


Before replacing an ignition coil, carry out the following in this order:

- Ignition coil test with B.U.D.S.
- Ignition coil input voltage test
- Ignition control signal test with B.U.D.S.
- Ignition coil control circuit test
- Ignition coil ground circuit test
- Spark plug cable test
- Spark plug replacement.

**Ignition Coil Test with B.U.D.S.**

**NOTE:** The ECM energizes and sends a trigger signal to each ignition coil individually. It can detect if each ignition coil is connected, display a trouble code in the multifunction display, and a CHECK ENGINE upon engine starting.

1. Use the latest B.U.D.S. software applicable to the E-TEC from BOSSWeb. Refer to *COMMUNICATION TOOLS AND B.U.D.S. SOFTWARE* section.
2. Connect B.U.D.S. to the vehicle and select **Read Data**.
3. Select the **Activation** tab.
4. At the bottom LH corner of the activation page, select the **ECM** tab.
5. Energize each ignition coil separately.




1. Activate here

You should hear the spark occurring. If in doubt, use an inductive spark tester.

If there is no spark, carry out an *IGNITION COIL INPUT VOLTAGE TEST*.

**Ignition Coil Input Voltage Test**

1. Remove the primary air intake silencer. Refer to *AIR INTAKE SYSTEM* section.
2. Disconnect the connector from each ignition coil.



**IGNITION COIL CONNECTORS, REAR VIEW**

1. PTO coil connector
2. MAG coil connector
3. MAG ignition coil


3. Install the following tools to supply 12 Vdc to the primary 12 Vdc circuits and to the 55 Vdc circuits for this test. Refer to *LIGHTS, INSTRUMENTS AND ACCESSORIES* for proper connections.

- T-HARNES (P/N 529 035 869)

## Section 05 ELECTRICAL SYSTEM


### Subsection 01 (IGNITION SYSTEM)

- 12 VOLTS BATTERY SUPPLY CABLE (P/N 529 035 997)
  - 12 volts battery.
4. Set multimeter to Vdc and measure supply battery voltage.
  5. Check ignition coil input voltage as follows.



IGNITION COIL CONNECTOR PIN-OUT

IGNITION COIL TERMINAL	VOLTAGE (VDC)
3	Battery ground Battery voltage minus 0.7 Vdc



INPUT VOLTAGE TEST (PRIMARY COIL WINDING)

If voltage is NOT as specified, carry out the following. Refer to applicable *WIRING DIAGRAM* for details.

- Check continuity of wire between terminal 3 of ignition coil and pin 13 of the ECM J2 connector.
- Test for supply battery voltage at pins 15 and 16 of ECM J2 connector.
- Test continuity of all ECM ground circuits, refer to *E-TEC DIRECT INJECTION* section.
- Repair or replace wiring as required.

If battery voltage is read at coil input, carry out the following. Refer to applicable *WIRING DIAGRAM* for details.

- Ignition control signal test with B.U.D.S.
- Spark plug cable resistance test
- Continuity test of ignition coil control circuit
- Continuity test of coil ground circuit, pin 1 to chassis ground
- Replace coil
- Replace ECM.

### Ignition Coil Control Signal Test with B.U.D.S.

1. Disconnect the affected ignition coil connector.
2. Set multimeter to Vdc, then select the frequency function (Hz), and manually set the scale to 6 Hz.

**NOTE:** If the meter is left in automatic range mode, you will not obtain a reading as the ignition control signal is too fast and for too short a period of time for the meter to adjust and take the reading. The meter must be in a low manual Hz range.

3. Set multimeter to a low manual Hz range.
4. Select the MAX. function on the multimeter to record the maximum reading detected.
5. Install an alligator clip adapter to the BLACK (-) probe, and a thin rigid back probe to the RED multimeter probe.




IGNITION SIGNAL TEST AT COIL CONNECTOR

6. Insert the RED probe in pin 2 (OR wire) of the coil connector, and clip the BLACK probe to engine ground.
7. In B.U.D.S., energize the affected ignition coil separately.

## Section 05 ELECTRICAL SYSTEM

### Subsection 01 (IGNITION SYSTEM)



1. Activate here

METER SELECTION	TEST PROBES		READING
Vdc Hz manual range	Coil connector	Engine	Approximately 2 Hz
	Pin 2 (OR)	Ground	

Frequency of ignition signal should consistently be approximately 2 Hz.

If signal is not present, refer to *IGNITION COIL CONTROL CIRCUIT*.


If the ignition coil control signal test was good, test the following before installing a new coil.

- Ignition coil ground circuit test
- Spark plug cable resistance test
- Spark plugs.


### Ignition Coil Control Circuit Test

1. Disconnect connector J1B from ECM.
2. Test for continuity of the circuit between ECM connector and ignition coil connector as follows.

CONNECTOR PIN			
CYLINDER	ECM J1B	IGNITION COIL	RESISTANCE
PTO	19	2	Close to 0 Ω (continuity)
MAG	26	2	



J1B PIN-OUT



IGNITION COIL CONNECTOR PIN-OUT

If wiring harness is defective, repair the connector or replace the wiring harness between ECM connector and the ignition coil.

If wiring harness tested good, refer to *IGNITION COIL GROUND CIRCUIT TEST*.


### Ignition Coil Ground Circuit Test

1. Disconnect the input connector from both coils.
2. Test for continuity of the coil ground circuit as follows.

CYLINDER	IGNITION COIL CONNECTOR		RESISTANCE
PTO	Pin 1	Chassis ground	Close to 0 Ω (continuity)
MAG			

## Section 05 ELECTRICAL SYSTEM

### Subsection 01 (IGNITION SYSTEM)



IGNITION COIL GROUND CIRCUIT TEST (PIN 1)

If wiring harness is defective, repair or replace the wiring and connectors.


If the ground circuit tested good, replace the ignition coil.

#### Ignition Coil Removal

1. Remove the LH side panel.
2. Note position of spark plug cables and remove them from the spark plugs.
3. Remove primary air intake silencer. Refer to *AIR INTAKE SYSTEM* section.

#### PTO Coil Removal

1. Disconnect the ignition coil connector.
2. Remove the coil retaining screw.



PTO IGNITION COIL (REAR VIEW)

1. Disconnect coil connector
2. Remove coil retaining screw

**NOTE:** PTO coil connector is mounted to the support with a retaining clip. Coil must be off support to access clip for removal.

3. Using a screwdriver, lift the retaining tab out of the second coil mounting hole to release coil from support. Do not pull coil away from sup-


4. Using a small screwdriver, remove spring clip retaining coil connector to support and pull connector through support opening.



1. Lift to release coil from support
2. Remove connector retaining clip from support

#### MAG Coil Removal

1. Disconnect the ignition coil connector.
2. Using a small screwdriver, remove connector retaining clip from support.
3. Remove the two coil retaining screws.



1. Disconnect coil connector
2. Remove connector retaining clip
3. Remove two mounting screws

#### Ignition Coil Installation

Reverse the removal procedures but pay attention to the following:

1. On the PTO coil, insert the coil connector through the coil support and install its retaining clip on the support before installing the coil.
2. Insert the PTO coil under the coil support retaining tab and slide it onto the support until the tab drops into the coil mounting hole.




mm2009-024-015\_b

1. Insert coil connector through support
2. Install connector retaining clip
3. Lift tab and insert coil

3. Install the retaining screw(s) and torque to 10 N•m (89 lbf•in) (both coils).
4. Reconnect the primary winding connectors and the spark plug cables.

**NOTE:** Pay attention to the position of the spark plug cables when connecting them. Lower coil connects to the PTO spark plug. Apply dielectric grease, refer to *SPARK PLUG CABLE*.



mm2009-024-013\_b

1. PTO ignition coil
2. Cable To PTO spark plug
3. MAG ignition coil
4. To MAG spark plug

**⚠ WARNING**


Always reconnect ignition coil cables to the same spark plugs they were disconnected from. Otherwise, severe backfire may occur with possible damage to exhaust system components.

**TRIGGER COILS  
 (500SS/600/800R)**

The ECM receives a signal from each of two trigger coils which it uses for establishing spark timing.

**NOTE:** Both trigger coils function continuously.

1. Open RH side panel.
2. Remove acoustic panel.
3. Disconnect ECM connector.



1. Acoustic panel  
 2. ECM


Carry out a resistance and a voltage test for each trigger coil at the ECM connector as per following table.

**NOTE:** The voltage test is carried out while cranking engine.

TEST PROBES	CONTINUITY		OUTPUT	
	Trigger coil no. 1	Trigger coil no. 2	Trigger coil no. 1	Trigger coil no. 2
	Pin 17 and 35	Pin 18 and 36	Pin 17 and 35	Pin 18 and 36
RESISTANCE	190 to 300 Ω	190 to 300 Ω	—	—
VOLTAGE	—	—	.200 to .350 Vac	.200 to .350 Vac

## Section 05 ELECTRICAL SYSTEM

### Subsection 01 (IGNITION SYSTEM)




ECM CONNECTOR PIN-OUT (500SS/600/800R)

If a trigger coil is out of specification, replace it. Refer to the *MAGNETO SYSTEM* section.

## KNOCK SENSOR (800R)

**NOTE:** For knock sensor testing on 600 HO E-TEC engine, refer to the *E-TEC DIRECT FUEL INJECTION* section.




1. Knock sensor (KS)

### KS Dynamic Test

1. Lift rear of vehicle off the ground and support it with a wide-base mechanical stand.
2. Connect vehicle to the latest applicable B.U.D.S. software.
3. Start the engine.
4. In B.U.D.S, choose **Read Data**, then select the **Monitoring** page tab.
5. On the bottom LH corner of the **Monitoring** page, choose the **ECM** page tab.

6. Monitor the knock sensor using the **Knock Sensor Noise Level** gauge on the RH side of the page



1. Knock sensor noise level gauge in B.U.D.S.

7. Bring engine speed above 5200 RPM and vary engine RPM above 5200 RPM.
8. Look for movement of the needle in the B.U.D.S. **Knock Sensor Noise Level** gauge should move between 0 and 100.

The movement pattern of the needle is of no importance as long as it moves, indicating the knock sensor is producing a signal representative of the engine vibrations. If the needle "sticks" either at 0 or 100, there is a problem.

If the needle moves as described, the knock sensor should be functioning correctly.

If the sensor indication is not normal, ensure ignition coil cables are not close to knock sensor harness. This may generate an erroneous fault code.

**NOTE:** Fault code P1326 may occur, but it is not related to a knock sensor failure. If this code occurs, refer to B.U.D.S. for proper action to take.


9. If there is no change in indication, refer to the following *KS CIRCUIT CONTINUITY TEST*.

### KS Circuit Continuity Test

1. Ensure sensor and head contact surfaces are clean.
2. Ensure mounting bolt and washer are correct and properly torqued down.
3. Check the knock sensor circuit on wiring harness.
4. Disconnect knock sensor connector. Refer to *KNOCK SENSOR REPLACEMENT*.
5. Disconnect ECM connector.

6. Test wire continuity of circuit as per following table.

ECM CONNECTOR	KS CONNECTOR	RESISTANCE
Pin-2	Pin 1	Close to 0 $\Omega$
Pin-20	Pin 2	




If you did not obtain close to 0  $\Omega$ , repair or replace wiring and connectors between ECM and knock sensor.

If test was good, try a new knock sensor.

### KS Replacement

1. Unscrew and remove knock sensor from cylinder head.
2. Remove pulley guard. Refer to *DRIVE BELT*.
3. Remove primary air intake silencer. Refer to *AIR INTAKE SYSTEM*.
4. Disconnect knock sensor connector located above ATS.



**KNOCK SENSOR CONNECTOR LOCATION**

5. Clean contact surface, then install new knock sensor.
6. Torque screw to 29 N•m (21 lbf•ft).

**NOTICE** Improper torque may prevent proper sensor operation and lead to severe damage of internal engine components.

7. Reconnect connector.
8. Reinstall remaining parts.

### ENGINE CONTROL MODULE (500SS/600/800R)

**NOTE:** For engine control module (ECM) testing on 600 HO E-TEC engine, refer to the *E-TEC DIRECT FUEL INJECTION* section.

Use the latest B.U.D.S. software available from BOSSWeb for the following procedures. Refer to *COMMUNICATION TOOLS AND B.U.D.S. SOFTWARE* for proper connection instructions.

**IMPORTANT:** Engine-related sensors and actuators are continuously powered during engine operation. The ECM switches, or modulates the ground applied to the sensor, or component, to complete the electrical circuits it controls. Take this into account when troubleshooting the electrical system.


### ECM Connector Pin Identification

Use the following illustration to locate the pin numbers on the ECM connector (wiring harness side) when performing tests.



## Section 05 ELECTRICAL SYSTEM

### Subsection 01 (IGNITION SYSTEM)



#### ECM Basic Operation

During engine cranking, the magneto sends AC current to the voltage regulator/rectifier, that in turn supplies the ECM with DC voltage. The ECM then supplies power to the ignition system for engine starting and operation.

When the engine reaches approximately 800 RPM, the ECM activates the battery charging relay (R2), and the accessories relay (R1), that in turn supplies the electrical loads (lights, multi-function gauge, accessories etc).


#### ECM Power Supply

Power (Vdc)	Pin 14
Ground	Pin 16

#### ECM Troubleshooting with Communication Tools

1. Connect SUPPLY HARNESS (P/N 529 035 869) to the 6-pin diagnostic connector of vehicle.
2. Connect SUPPLY CABLE (P/N 529 035 997) to supply harness.
3. Connect supply harness clips to vehicle battery. Ensure to match RED wires together and BLACK wires together.

**NOTE:** On manual start models, use an external 12 V battery.



**NOTICE** Always use the proper supply harness and cables. Ensure to respect polarity when connecting cable clips to battery. Match RED cables together.

4. **IMPORTANT:** When using the supply harness, the ECM will switch to diagnostic mode and disable the ignition circuit. Engine can not be started.
5. Set engine Stop to RUN.
6. Observe multifunction gauge. The multifunction gauge should turn ON and cycle through a self-test mode.

If the gauge did not come ON and cycle through the self-test mode, refer to *LIGHTS, GAUGE AND ACCESSORIES* section.

If the gauge displayed a COMMUNICATION ERROR message, the problem may be:

- Gauge
- CAN bus
- ECM related.

Check if B.U.D.S. can communicate with the ECM.

- If B.U.D.S. can not communicate with the ECM, check the ECM power supply input and ground circuits.
- If B.U.D.S. can communicate with the ECM, look for fault codes.

### ECM Power Supply Test

1. Open RH side panel.
2. Pull out diagnostic connector.



3. Use a multimeter and set it to Vdc.
4. Set engine stop switch to the STOP position.

#### *500SS/600/800R Electric Start*

The electric starter can be used for the test as follows.

5. Disconnect ORANGE/BLACK wire from the starter solenoid.



6. Install a jumper wire between the solenoid terminal and battery ground.



7. Press START/RER button to crank engine.
8. While cranking engine, read voltage as follows.

MULTIMETER PROBES		VOLTAGE
Diagnostic connector pin 4	Chassis ground	Manual start: approximately 2-3 Vdc. Electric start: approximately 6 Vdc

## Section 05 ELECTRICAL SYSTEM

### Subsection 01 (IGNITION SYSTEM)



If voltage is as per specification, refer to *ECM GROUND CIRCUIT TEST*.

If voltage is not as per specification, refer to *ECM POWER CIRCUIT CONTINUITY TEST*.


#### ECM Ground Circuit Test

1. Remove muffler. Refer to *EXHAUST SYSTEM*.
2. Remove the acoustic panel.



3. Disconnect ECM connector.
4. Set multimeter to  $\Omega$ .
5. Read wiring resistance as follows.

ECM CONNECTOR	RESISTANCE
Pin 16 with frame ground	Close to 0 $\Omega$




If reading is out of specification, repair or replace wiring and connectors.

If reading is as per specification, ground circuit is good. Refer to *ECM POWER CIRCUIT CONTINUITY TEST*.

#### ECM Power Circuit Continuity Test

**NOTE: IMPORTANT:** Disconnecting ECM connector and reading voltage on connector terminal would give false results. ECM connector **must be connected to ECM** to be able to read the voltage. Since it cannot be easily achieved, a continuity test will be carried out instead.

1. Disconnect ECM connector.
2. Disconnect voltage regulator/rectifier connector.




3. Set multimeter to  $\Omega$ .
4. Read wiring resistance as follows.

## Section 05 ELECTRICAL SYSTEM

### Subsection 01 (IGNITION SYSTEM)

ECM CONNECTOR	VOLTAGE REGULATOR	RESISTANCE
Pin 14	RED/BLUE	Close to 0 $\Omega$



If reading is out of specification, check and repair wiring and connectors.

If reading is as per specification, check DC voltage output from voltage regulator/rectifier. Refer to *CHARGING SYSTEM*.

Reinstall removed parts.

## ECM Replacement

### ECM Removal

Disconnect battery cables on electric start models.

#### **⚠ WARNING**

Battery BLACK (-) cable must always be disconnected first and connected last.

Remove muffler. Refer to *EXHAUST SYSTEM*.

Remove the acoustic panel.

Cut locking ties as necessary.


Disconnect ECM connector.

Remove ECM as follows.

1. Push the LH upper tab and hold.



2. Rotate ECM counterclockwise.



3. Pull out ECM.




## Section 05 ELECTRICAL SYSTEM

### Subsection 01 (IGNITION SYSTEM)


#### ECM Installation

Install ECM as follows.

1. Insert the LH bottom tab of ECM first.



2. Rotate ECM clockwise until the other tabs are engaged and ECM locks in position.



Reconnect ECM connector.

3. Reconnect battery cables (if applicable).

Connect the vehicle to the latest applicable B.U.D.S. software and carry out the following.

- Enter the proper information in **Vehicle** tab.
- Reprogram DESS key. Refer to *DESS SYSTEM*.
- Set the ignition correction. Refer to *IGNITION SYSTEM*.
- Set the cluster units. Refer to *LIGHTS/GAUGE/ACCESSORIES*.

**NOTICE** Pay particular attention when typing the VIN and model numbers. Once **Write Data** button is pressed, numbers cannot be modified.

4. Start the engine to be sure no fault appears.
5. Remove tools and reinstall removed parts.



# CHARGING SYSTEM

## SERVICE TOOLS

Description	Part Number	Page
12 VOLTS BATTERY SUPPLY CABLE.....	529 035 997 .....	355, 358
FLUKE 115 MULTIMETER .....	529 035 868 .....	352, 357, 359
T-HARNESSES.....	529 035 869 .....	355, 358

## SERVICE TOOLS – OTHER SUPPLIER

Description	Part Number	Page
FLUKE RIGID BACK PROBES.....	TP88 .....	359
NAPA ULTRA PRO BATTERY LOAD TESTER .....	95260 .....	363

## SERVICE PRODUCTS

Description	Part Number	Page
SILICONE DIELECTRIC GREASE .....	293 550 004 .....	364–365

## GENERAL

### WARNING

Unless otherwise specified, always disconnect the magneto connector and ensure spark plugs are installed in the engine before carrying out electrical system checks on the 600 HO E-TEC. Should the engine be made to rotate with magneto connected, a spark may occur resulting in electrical shock, a fire, or an explosion.

## SYSTEM DESCRIPTION

### Magneto

A magneto provides the primary source of electrical energy. It transforms a magnetic field into an alternating current (AC).

#### *500SS/600/800R Models*

The magneto is comprised of a 3 phase delta wound stator that has a capacity of 360 watts.

AC current is rectified and regulated by a voltage regulator between 13.4 and 15 volts DC for primary power to the vehicle electrical system, and to charge the battery on electric start models.

#### *600 HO E-TEC Models*

The magneto is comprised of a 3 winding, single phase wound stator that has a capacity of 1200 watts.

AC current is rectified and regulated by a voltage regulator/rectifier circuit, and a DC to DC converter, both integrated within the ECM.

The charging system provides 3 outputs to the vehicle electrical system, one 55 Vdc and two 12 Vdc outputs.

### Battery

A battery is installed on electric start models as a secondary power source. It is primarily used for energizing the starter. On E-TEC models, it provides power to instantly wake-up the ECM when the START/RER button is pressed.

On vehicles equipped with a high end multifunction gauge, it also provides power to maintain the clock function within the gauge.

**NOTE:** Never use a battery charger to temporarily substitute the battery as it may cause the ECM (engine control module) to function erratically or not at all.

## TROUBLESHOOTING

**NOTE:** On applicable models, it is good practice to check for fault codes using B.U.D.S. software as a first troubleshooting step. Refer to *MONITORING SYSTEM/FAULT CODES*.

## Section 05 ELECTRICAL SYSTEM

### Subsection 02 (CHARGING SYSTEM)

#### TROUBLESHOOTING GUIDELINES (500SS/600/800R)

##### Weak or Discharged Battery

###### *Electric Start Models*

If the battery is weak or discharged, check the following items:

- Charging fuse (FA)
- Charging relay (R2)
- Charging system voltage, see *DC VOLTAGE OUTPUT TEST (VOLTAGE REGULATOR)* in this section
- Battery
- Wiring and connections.

##### Low or No Charging System Voltage (Engine May Not Start)

###### *Electric and Manual Start Models*

If charging system voltage is low, the engine may not start, be unstable, or stall.

If there is no voltage, the engine will not start. Test the following items:

- Charging system voltage, see *DC VOLTAGE OUTPUT TEST (VOLTAGE REGULATOR)* in this section
- Magneto
- Voltage regulator/rectifier
- Wiring and connections.

#### TROUBLESHOOTING GUIDELINES (600 HO E-TEC)

##### Weak or Discharged Battery

###### *Electric Start Models*

If the battery is weak or discharged, check the following items:

- Charging fuse (FA)
- Charging relay (R2)
- Charging system voltage, see *PRIMARY 12 VDC CIRCUIT TEST WITH B.U.D.S.* in this section
- Battery
- Wiring and connections.

**NOTE:** If there is no primary 12 Vdc circuit output voltage, the headlights and taillight will not function.

##### Charging System Voltages (Engine May Not Start)

The vehicle cannot start without having a minimum voltage to the 55 V power circuit. If the engine does not start, see *VOLTAGE REGULATOR/RECTIFIER* in this section and carry out the 55 Vdc voltage output test with B.U.D.S.

If voltage is not as specified, check the following items in the recommended order until you find the fault:

- Stator (refer to *MAGNETO* section)
- Capacitor (see procedure in this section).

**NOTE:** The 55 Vdc may be unstable or unobtainable if the capacitor is faulty, not connected, or incorrectly connected.

If the above mentioned checks were good, isolate each of the following components by disconnecting them individually, and repeating the voltage test after each one.

- Each injector
- Each ignition coil
- Fuel pump
- Oil pump.

**NOTE:** When the 55 Vdc test good after a component is disconnected, replace that component and repeat the test.

## PROCEDURES

### CHARGING FUSE

#### Fuse Location

##### *500SS/600/800R Models*

A 30 A charging system fuse is located on the battery retaining plate.



TYPICAL - CHARGING SYSTEM FUSE

### 600 HO E-TEC Models

The charging system fuse is attached to the lower edge of the oil tank.



1. Charging system fuse

### Fuse Information

The voltage regulator could be the culprit of a blown charging system fuse.

### 500SS/600/800R Models

To check for this, disconnect the voltage regulator from the circuit and replace the fuse. If the fuse still burns, check for a defective wire (short circuit) between the battery and the charging relay.

### 600 HO E-TEC Models

To check for this, carry out the *PRIMARY 12 VDC CIRCUIT TEST WITH B.U.D.S.* in this section. Also check for an applicable fault code, refer to *MONITORING SYSTEM AND FAULT CODES.*

### CHARGING RELAY (R2)

A charging relay (R2), completes the charging circuit between the voltage regulator output and the battery. It receives its ground control signal from the ECM. Refer to *WIRING DIAGRAM* for more details.

### 500SS/600/800R Models

The ECM provides the ground to the relay at approximately 800 RPM.

### 600 HO E-TEC Models

The ECM provides the ground at 1900 RPM, plus 4 seconds.

### Charging Relay Location

#### 500SS/600/800R Models


The charging relay is a plug-in relay located next to the battery on a harness connector.



TYPICAL - CHARGING RELAY R2

#### 600 HO E-TEC Models

The charging relay is a plug-in relay attached to the main harness routed behind the oil tank. It can be easily accessed by removing the primary air intake silencer.



TYPICAL - CHARGING RELAY R2

1. Charging relay
2. Oil tank
3. Throttle body air inlet adapter

### VOLTAGE REGULATOR/RECTIFIER (500SS/600/800R)

#### Voltage Regulator Continuity Test

Due to internal circuitry, there is no static test available to check continuity.



## Section 05 ELECTRICAL SYSTEM

### Subsection 02 (CHARGING SYSTEM)



mmr2008-035-006

VOLTAGE REGULATOR

### DC Voltage Output Test (Voltage Regulator)

#### Manual Start Models

Proceed as follows:

1. Raise vehicle and ensure the track is off the ground and can turn freely.


#### **⚠ WARNING**

Ensure vehicle track is completely raised off ground. If track should come into contact with ground when engine is at 5000 RPM, equipment damage and severe injury may result.

2. Set the FLUKE 115 MULTIMETER (P/N 529 035 868) to Vdc scale.
3. Disconnect the communication diagnostic connector.
4. Start engine and read voltage as follows.

#### DC VOLTAGE OUTPUT TEST MANUAL START MODELS

TEST ENGINE SPEED	TEST PROBES		VOLTAGE
5000 RPM	Pin 4 (RED/BLUE wire) (diagnostic connector)	Chassis ground	15.1 Vdc ± 0.5



mmr2008-035-004\_a

TYPICAL

If voltage is above specification, replace voltage regulator.

If voltage is below specification, check stator and wiring/connections.

If the stator and associated wiring/connectors test good, try a new voltage regulator.

#### Electric Start Models

Proceed as follows:

1. Raise vehicle and ensure the track is off the ground and can turn freely.

#### **⚠ WARNING**

Ensure vehicle track is completely raised off ground. If track should come into contact with ground when engine is at 5000 RPM, equipment damage and severe injury may result.

2. Remove RED rubber boot protector from positive battery post.
3. Set multimeter to Vdc scale.
4. Connect multimeter to battery posts.
5. Start engine and read voltage as follows.

#### DC VOLTAGE OUTPUT TEST ELECTRIC START MODELS

TEST ENGINE SPEED	TEST PROBES		VOLTAGE
5000 RPM	Battery (+)	Battery (-)	15.1 Vdc ± 0.5

## Section 05 ELECTRICAL SYSTEM

### Subsection 02 (CHARGING SYSTEM)



mvr2008-035-002\_a

#### TYPICAL


If voltage is above specification, replace voltage regulator.

If voltage is below specification, check stator and wiring/connections.

### Voltage Regulator Removal

1. Disconnect battery (if so equipped).

**NOTE:** The voltage regulator is located on the right side of the frame just ahead of the fuel tank, and under the oil tank.



mvr2008-035-008\_a

#### TYPICAL


1. Voltage regulator
2. RH rear engine mount

2. Remove the primary air intake silencer.
3. Disconnect the carburetors from the intake adapters.
4. Move fuel tank back, refer to *FUEL TANK/FUEL PUMP* section.
5. Disconnect the voltage regulator connector.



mvr2008-035-009\_a

#### TYPICAL - VOLTAGE REGULATOR LOCATION



mvr2008-035-010\_a

#### VOLTAGE REGULATOR CONNECTOR ACCESS

1. Voltage regulator
2. Voltage regulator connector


**NOTE:** The regulator connector can be accessed from the front right side, by removing the muffler and the acoustic panel.

6. Loosen the RH elastic nut.
7. Remove the LH elastic nut, star washer and flat washer.

**NOTE:** Note the position of the grounding wire, star washers and flat washers for installation.

## Section 05 ELECTRICAL SYSTEM

### Subsection 02 (CHARGING SYSTEM)



1. Voltage regulator connector
2. Regulator mounting studs
3. Electrical harness grounding wire

8. Remove the regulator from its mounting studs.

### Voltage Regulator Installation

1. Insert the right flange of the regulator on its mounting stud, under the elastic nut, grounding wire and washers.

**NOTE:** Ensure the connector is facing forward and that all the hardware is positioned over the regulator flange.

2. Insert the LH side of the regulator on its mounting stud.

3. Install mounting stud hardware.

**NOTE:** Make sure the ground lug(s) and mounting hardware are positioned over the regulator flange as per disassembly. Be careful not to twist or break the wires and ground lugs when tightening each elastic nuts.

4. Complete the installation in the reverse order of the removal procedure.

5. Torque voltage regulator screws to 5 N•m (44 lbf•in).

## VOLTAGE REGULATOR/RECTIFIER (600 HO E-TEC)

### Description

The voltage regulator/rectifier is integrated within the ECM. It receives three single phase alternating current (AC) inputs from the magneto which it rectifies and regulates to 55 Vdc.

On a single pull start with the engine between 250 and 500 RPM, the magneto, combined with an ingenious series/parallel switching capability of the voltage regulator/rectifier, is capable of producing 55 Vdc. This 55 Vdc is then divided into two outputs.

The first output (55 Vdc), leaves the ECM through connector J2 (pin 13) and provides power to the following components.

- Capacitor
- Injectors
- Ignition coils
- Fuel pump
- Oil pump.



The second output (55 Vdc) feeds a DC to DC converter within the ECM.

### Continuity Test (Voltage Regulator/Rectifier)

Due to internal circuitry, there is no static test available to check continuity.

### 55 Vdc Voltage Output Test with B.U.D.S. (Voltage Regulator/Rectifier)

1. Raise vehicle so that the track is off the ground and can turn freely.

### **⚠ WARNING**

Ensure vehicle track is completely raised off ground. If the track should come into contact with the ground when the engine is at 5000 RPM, equipment damage and severe injury may result.

2. Remove RH side panel, refer to *BODY* section.


3. Connect to the latest B.U.D.S. software applicable to the 600 HO E-TEC from BOSSWeb. Refer to *COMMUNICATION TOOLS/B.U.D.S. SOFTWARE* section.

**Procedure when Engine Cannot be Started**

**Manual Start Models**

1. Install the following tools to supply power to the 12 Vdc circuits and the 55 Vdc circuit for this test. Refer to *COMMUNICATION TOOLS AND B.U.D.S. SOFTWARE* section for proper connections.
  - T-HARNESS (P/N 529 035 869)
  - 12 VOLTS BATTERY SUPPLY CABLE (P/N 529 035 997)
  - 12 volts battery.
2. In B.U.D.S., select **Read Data**.
3. Select the **Monitoring** tab.
4. At the bottom of the monitoring page, select the **ECM** tab.
5. Crank the engine using the rewind starter.
6. Read the voltage on the **System Voltage** meter in B.U.D.S. as the engine is turning over.

55 VDC VOLTAGE OUTPUT TEST	
TEST ENGINE SPEED	VOLTAGE
Pull start (engine not running)	At least 30 Vdc



1. System voltmeter (55 Vdc)

If you cannot obtain the specified voltage, refer to *TROUBLESHOOTING* in this section and carry out the required tests.

Also carry out the *VOLTAGE REGULATOR/RECTIFIER GROUND CIRCUIT TEST* in this section.


**Electric Start Models**

1. Connect T-HARNESS (P/N 529 035 869) to the vehicle before connecting it to the latest applicable B.U.D.S. software. Refer to *COMMUNICATION TOOLS AND B.U.D.S. SOFTWARE* section.

**NOTE:** Pressing the START/RER button momentarily will power the ECM (wake up signal) to allow B.U.D.S. to read the ECM prior to engine cranking for the test.

2. In B.U.D.S., select **Read Data**.
3. Select the **Monitoring** tab.
4. At the bottom of the monitoring page, select the **ECM** tab.
5. Crank the engine over by pressing and holding the START/RER button for a few seconds.
6. Read the voltage on the **System Voltage** meter in B.U.D.S. as the engine is being cranked.

**NOTICE** Do not hold the START/RER button more than 10 seconds. A rest period should be observed between the cranking cycles to let the starter cool down. Holding the START/RER button for extended periods could overheat and permanently damage the starter.



1. System voltmeter (55 Vdc)

7. Refer to the *55 VDC VOLTAGE OUTPUT TEST* table in the previous *MANUAL START MODELS* for specifications.

**Procedure With Engine Running**


1. Connect vehicle to the latest applicable B.U.D.S. software, refer to *COMMUNICATION TOOLS AND B.U.D.S. SOFTWARE* section.
2. Start engine.
3. In B.U.D.S., select **Read Data**.
4. Select the **Monitoring** tab.
5. At the bottom of the **Monitoring** page, select the **ECM** tab.
6. Read the voltage on the **System Voltage** meter in B.U.D.S.

## Section 05 ELECTRICAL SYSTEM

### Subsection 02 (CHARGING SYSTEM)

#### 55 VDC VOLTAGE OUTPUT TEST (ENGINE RUNNING)

TEST ENGINE SPEED	VOLTAGE
Any RPM from idle and above	55 Vdc $\pm$ 2



#### TYPICAL

1. RPM indication
2. System voltage indication (55 Vdc)

If voltage is below or above specification, refer to **TROUBLESHOOTING** in this section and carry out the required tests.


Also carry out the **VOLTAGE REGULATOR/RECTIFIER GROUND CIRCUIT TEST**.

#### Ground Circuit Test (Voltage Regulator/Rectifier)

1. Disconnect the ECM J2 connector.
2. Test ground circuit continuity as follows.

#### VOLTAGE REGULATOR/RECTIFIER GROUND CIRCUIT TEST

ECM J2 CONNECTOR	
Pin 5	Chassis ground
Pin 7	
Pin 8	



ECM J2 PIN-OUT

## DC-DC CONVERTER (600 HO E-TEC)

### Description

The DC-DC converter is integrated within the ECM. It receives 55 Vdc from the voltage regulator/rectifier which, it steps down to 12 Vdc. This 12 Vdc power is then split into two separate circuits, a primary and a secondary 12 Vdc output.

#### Primary 12 Vdc Output

From approximately 800 RPM and 50 V from the voltage regulator, the primary 12 Vdc output provides power to the following:

- ECM
- Multifunction gauge
- 3D RAVE valve solenoid
- Lighting system.

**NOTICE** The 12 Vdc primary circuit is not to be used to power accessory loads. All accessories are to be powered from the secondary 12 Vdc circuit.

#### Secondary 12 Vdc Output

The secondary 12 Vdc output provides power to the accessories when the engine reaches 1900 RPM for at least 2 seconds.

**NOTE:** Should the 12 Vdc outputs fail, the engine will still run on the 55 Vdc supply voltage.

#### 12 Vdc Output Voltage Tests (DC-DC Converter)

The primary 12 volts is supplied through ECM connector J2 pins 15 and 16.

The secondary 12 volts is supplied through ECM connector J2 pins 6 and 14.

ECM connector J2 is not easily accessible. To carry out 12 Vdc output tests, carry out the following procedures.

#### Primary 12 Vdc Circuit Test with B.U.D.S.

1. Remove RH side panel, refer to **BODY** section.
2. Connect to the latest B.U.D.S. software applicable to the 600 HO E-TEC from BOSSWeb. Refer to **COMMUNICATION TOOLS/B.U.D.S. SOFTWARE** section.
3. Raise vehicle so that the track is off the ground and can turn freely.

## Section 05 ELECTRICAL SYSTEM

### Subsection 02 (CHARGING SYSTEM)


#### **⚠ WARNING**

Ensure vehicle track is completely raised off ground. If the track should come into contact with the ground when the engine is at 5000 RPM, equipment damage and severe injury may result.

4. Start engine.
5. In B.U.D.S., select Read Data.
6. Select the Monitoring tab.
7. At the bottom of the Monitoring page, select the ECM tab.
8. Read the primary 12 Vdc system voltage on the Battery Voltage meter in B.U.D.S.

#### PRIMARY 12 VDC CIRCUIT TEST WITH B.U.D.S.

TEST ENGINE SPEED	VOLTAGE
Any RPM from 1100 RPM and above	14.75 Vdc $\pm$ .5



#### TYPICAL

1. RPM indication
2. Primary 12 Vdc indication (battery)

If voltage is above specification, replace ECM.  
 If voltage is below specification, check the 55 Vdc. Refer to *VOLTAGE REGULATOR/RECTIFIER*.  
 Also carry out the *VOLTAGE REGULATOR/RECTIFIER GROUND CIRCUIT TEST* in this section.

Install all removed parts and connectors.

#### Secondary 12 Vdc Circuit Test

The secondary 12 Vdc system is not monitored in B.U.D.S.

To test the secondary 12 Vdc system, carry out the following procedure.

1. Remove multifunction gauge to access HG connector.

**NOTE:** Do not disconnect gauge or HG connector.



#### TYPICAL

1. HG connector
2. AC connector

2. Raise vehicle so that the track is off the ground and can turn freely.

#### **⚠ WARNING**


Ensure vehicle track is completely raised off ground. If the track should come into contact with the ground when the engine is at 5000 RPM, equipment damage and severe injury may result.

3. Set FLUKE 115 MULTIMETER (P/N 529 035 868) to Vdc scale.
4. Start the engine.
5. Accelerate the engine above 1900 RPM and hold for at least 2 seconds.
6. To measure the secondary 12 Vdc, back-probe the HG connector as follows.


ENGINE SPEED	BACK-PROBE HG CONNECTOR		VOLTAGE
Over 1900 RPM + 2 sec.	Red test probe	Black test probe	14.75 Vdc $\pm$ .5
	Pin 11	Chassis ground	
	Pin 11	Pin 1	

## Section 05 ELECTRICAL SYSTEM

### Subsection 02 (CHARGING SYSTEM)



TYPICAL — VOLTAGE TEST PIN 11 TO PIN 1



TYPICAL — VOLTAGE TEST PIN 11 TO CHASSIS GROUND

If the secondary 12 Vdc voltage is as specified to chassis ground, but not present when measuring between pins 11 and 1, test continuity of BLACK wire to ground.

If voltage cannot be measured, test continuity of RED/YELLOW wire from pin 11 of HG connector to pins 6 and 14 of ECM J2 connector.

If the RED/YELLOW wire continuity is good and other voltages from ECM tested good, ECM may not output secondary 12 Vdc.


Carry out the *VOLTAGE REGULATOR/RECTIFIER GROUND CIRCUIT TEST*. If the ground circuit tests good, the ECM will need to be replaced.

**NOTE:** Before replacing ECM, all ECM grounds, power output circuits, and input circuits from the magneto must be tested.

Repair or replace as applicable.

## CAPACITOR (600 HO E-TEC)

The engine fuel injectors, which require 55 Vdc for their operation, are particularly sensitive to voltage variations. A capacitor is connected to the 55 Vdc electrical system to stabilize the system voltage.



CAPACITOR LOCATION

The capacitor is located on the RH side of the vehicle, just ahead of the ECM.

## Quick Troubleshooting

A faulty capacitor will lead to the following symptoms:

- Unstable, low, or no system voltage (55 V).
- Engine will not start
- Engine hard to start
- Poor idling
- Engine misfiring.

**NOTE:** A defective capacitor is likely to give off a burn like odor.

## Discharging Capacitor

### ⚠ WARNING

The capacitor remains charged approximately 10 seconds after engine is stopped. A high energy could suddenly be discharged if capacitor terminals were shorted. Always discharge capacitor before servicing.

To properly discharge capacitor, leave it connected for at least 10 seconds after engine has been stopped, or after engine was last cranked before carrying out any maintenance procedure on the capacitor or 55 volt electrical system.

## Capacitor Charge Hold Test

1. Connect the following tools to power 55 Vdc system for capacitor charging:
  - T-HARNESS (P/N 529 035 869)
  - 12 VOLTS BATTERY SUPPLY CABLE (P/N 529 035 997)
  - 12 V battery.

## Section 05 ELECTRICAL SYSTEM

### Subsection 02 (CHARGING SYSTEM)

2. Use a FLUKE 115 MULTIMETER (P/N 529 035 868) set to Vdc to measure the capacitor charge voltage.

**NOTE:** Ensure to use the multimeter RED probe with the WHITE/RED wire.

3. Back-probe capacitor connector using the FLUKE RIGID BACK PROBES (P/N TP88).



VOLTAGE MEASUREMENT AT CAPACITOR CONNECTOR

4. Read and note capacitor charge voltage with battery power applied.
5. Disconnect capacitor connector.
6. Wait 5 minutes.
7. Read capacitor charge voltage again.



#### CAPACITOR CHARGE HOLD TEST

Capacitor Vdc must be within 1 Vdc of battery Vdc after 5 minutes

If voltage is out of specification, replace capacitor.

If in doubt, proceed with the following residual voltage test.

#### Capacitor Residual Voltage Test

##### **⚠ WARNING**

Disconnect the magneto connector. Should the engine be made to rotate with magneto connected, a spark may occur resulting in electrical shock, a fire or an explosion.

1. Disconnect magneto connector.
2. Remove capacitor from vehicle and carry out the following test on a non metallic workbench.
3. Connect the following items to the capacitor, see following illustration.
  - A switch
  - Resistor (300  $\Omega$ /5 W)
  - 12 V battery (fully charged).

**NOTICE** Ensure the test switch is in the OFF position when connecting the battery to the capacitor to prevent sparking or electrical shock.

##### **⚠ WARNING**

Be sure to connect the battery POSITIVE post to the capacitor POSITIVE terminal.



4. Turn switch to ON and read capacitor voltage. Wait until voltage reaches 12 V to ensure the capacitor is fully charged.



## Section 05 ELECTRICAL SYSTEM

### Subsection 02 (CHARGING SYSTEM)




5. Turn test switch to OFF.

**NOTE:** Carry out the following steps within the following minute to ensure the capacitor does not begin to discharge before the test.

6. Remove battery from circuit and connect the resistor and switch across capacitor terminals.

**NOTICE** Ensure test switch is in the OFF position during the circuit configuration change.



7. Turn test switch to the ON position for 12 seconds  $\pm$  1 second to slowly discharge capacitor.

8. Read capacitor voltage.



#### CAPACITOR RESIDUAL VOLTAGE

Must be above 2.6 Vdc


If voltage is out of specification, replace capacitor.

#### Capacitor Removal

##### **⚠ WARNING**

Disconnect the magneto connector. Should the engine be made to rotate with magneto connected, a spark may occur resulting in electrical shock, a fire or an explosion.

1. Ensure capacitor remained connected for at least 10 seconds after engine shut down, or after engine was last cranked. This ensures capacitor is fully discharged.
2. Remove muffler. Refer to *EXHAUST SYSTEM*.
3. Remove acoustic panel.




4. Remove retaining screws from capacitor support cover.

**Section 05 ELECTRICAL SYSTEM**  
Subsection 02 (CHARGING SYSTEM)



5. Pull capacitor support cover open.



6. Pull capacitor out of support and remove terminal screws.



**⚠ WARNING**

Do not remove plastic protector from top of capacitor unless the capacitor is to be replaced. The cover prevents the two capacitor contacts from being easily shorted together which may cause a spark, possibly resulting in a fire.

7. Check inspection hole on top of capacitor.



*INSPECTION HOLE (SHIELD IS INTACT)*

If the top shield is open (pierced), replace capacitor.

**NOTE:** The following illustration shows a perforated shield with capacitor fluid leakage. This capacitor was connected in reverse polarity.



1. Perforated shield
2. Capacitor fluid leakage

**Capacitor Installation**

1. If capacitor was replaced, install a plastic protector cap on new capacitor.

## Section 05 ELECTRICAL SYSTEM


### Subsection 02 (CHARGING SYSTEM)

**NOTE:** When reinstalling plastic protector, ensure the + sign on top of capacitor is visible through the hole in protector. If + sign is not visible, pull off protector, rotate it one half turn, then reinstall it.



2. Connect wire terminals to capacitor. Ensure to connect the WHITE/RED wire to the + terminal on capacitor. Position wires so as to route them away of the + sign.

**NOTICE** Improper polarity could destroy the capacitor while in operation.



3. Insert capacitor in its support ensuring it bottoms out completely.



4. Complete assembly of remaining parts in the reverse order of removal.

## BATTERY (YTX20L-BS)

Electric start models are equipped with a sealed valve regulated lead acid (VRLA) battery. It is a non-spillable, maintenance reduced type (no electrolyte level to be checked and readjusted). No ventilation tube is attached to the battery.



TYPICAL

## Battery Testing

### Battery Voltmeter Test (No Load Applied)

**NOTE:** An unloaded voltmeter test is carried out on a battery without discharging current. It is the simplest and most commonly used. However, be aware that a voltage test can indicate that the battery is in good condition even though the battery does not have enough power to crank the engine. A voltage reading provides an instant indication of the state of charge of the battery, not of its current storage capacity. A battery load test gives a more accurate indication of the battery condition.

If the battery has just received a charge, allow it to rest for 1-2 hours before taking a voltage reading.

Set multimeter to Vdc and connect to battery terminals. Always respect polarity.



TYPICAL

Batteries with a voltage above 12.8 V do not need to be charged.

Batteries with a voltage of 12.8 V and below need to be charged. Refer to **BATTERY CHARGING** in this section.

### Battery Testing (Load Applied)

This is the best test used to determine the battery condition.

Using a load testing device such as the NAPA ULTRA PRO BATTERY LOAD TESTER (P/N 95260), test the storage capacity of the battery. It has a 500 A carbon pile adjustable load.

The battery should be fully charged before testing. If battery has just been recharged, allow battery to rest for at least one hour.

Follow battery load tester instructions.


If battery voltage has dropped below 10 Vdc (or voltage indicated on battery temperature compensation chart), battery storage capacity has decreased appreciably and should be replaced.

## Battery Removal

### **⚠ WARNING**

The BLACK (-) battery cable must always be disconnected first and reconnected last. Never charge or boost a battery while installed on vehicle.

1. Open right side panel of vehicle.
2. Disconnect BLACK (-) cable terminal from the negative battery post.
3. Slide the RED rubber protector off the (+) cable terminal and disconnect it from the battery post.




TYPICAL

1. Negative post (-)
2. Red rubber protector
3. Positive terminal (+)
4. Battery retaining bolt and nut
5. Retaining plate hook

4. Remove electrical harness from retaining clip.
5. Unclip both fuses from oil tank (500SS/600/800R).
6. Remove the battery retaining plate nut and bolt.

## Section 05 ELECTRICAL SYSTEM

### Subsection 02 (CHARGING SYSTEM)



#### TYPICAL

1. Harness retaining clip
2. Fuse holder retaining clips
3. Battery retaining plate bolt

7. Lift the retaining strip and unhook it from the battery support to remove it.

8. Move retaining strip aside.

9. Remove battery.

**NOTICE** Should any electrolyte spillage occur, immediately wash off with a solution of baking soda and water to prevent damage to vehicle components.

### Battery Cleaning

Clean the battery, battery casing, cables and battery posts using a solution of baking soda and water.

Remove corrosion from battery cable terminals and battery posts using a firm wire brush. Battery top should be cleaned with a soft brush and any grease-cutting soap or baking soda solution.

### Battery Inspection

Visually inspect battery casing for cracks, leaks or other possible damage.

Discoloration, warping or raised top, indicates that the battery has overheated or been overcharged.

If the casing is damaged, replace battery and thoroughly clean battery tray and surrounding area with a water and baking soda solution.

#### **⚠ WARNING**

Should the battery casing be damaged, wear a suitable pair of non-absorbent gloves when removing the battery by hand.

Inspect the battery posts for security of mounting.

### Battery Storage

**NOTICE** A discharged battery will freeze and may damage its casing. A damaged casing will allow electrolyte spillage that may damage surrounding parts.

1. Disconnect and remove battery from the vehicle.
2. Clean battery terminals and cable connections using a wire brush. Apply a light coat of SILICONE DIELECTRIC GREASE (P/N 293 550 004) or petroleum jelly on terminals.
3. Clean battery casing using a solution of baking soda and water. Rinse battery with clear water and dry thoroughly using a clean cloth.

**NOTE:** The battery must always be stored in fully a charged state.

4. Charge the battery every month if stored at a temperature below 15°C (59°F).

5. Charge the battery every two week if stored at a temperature above 15°C (59°F).

### New Battery Activation

Refer to the instructions provided with the battery.

### Battery Charging

#### **⚠ WARNING**

Always wear safety glasses and charge the battery in a ventilated area. Never charge or boost a battery while installed on a vehicle. Do not open the sealed caps during charging. Do not place battery near an open flame.

**NOTICE** If the battery becomes hot to the touch, stop charging and allow it to cool before continuing.

**NOTE:** Sealed VRLA batteries have an internal safety valve. If battery pressure increases due to overcharging, the valve opens to release excess pressure, preventing battery damage.

Carry out a battery *UNLOADED VOLTMETER TEST* as described in this section, then proceed as described here.

An automatic charger is the fastest and most convenient way for error-proof charging.

When using a constant current charger, charge battery according to the chart below.

**Battery Voltage Below 12.8 V and Above 11.5 V**

<b>STANDARD CHARGING (RECOMMENDED)</b>		
<b>BATTERY TYPE</b>	<b>TIME</b>	<b>CHARGE</b>
YTX20L-BS	4-9 hours	2 A

<b>QUICK CHARGING</b>		
<b>BATTERY TYPE</b>	<b>TIME</b>	<b>CHARGE</b>
YTX20L-BS	50 minutes	10 A

**Battery Voltage Below 11.5 V**

A battery with a voltage below 11.5 V requires a special procedure to recharge. In charging an over discharged battery, its internal resistance may be too high to charge at a normal charging rate.

Set charger to the 10 A charging rate and monitor charging current for approximately 30 minutes. If there is no change in charging current or battery becomes abnormally hot, the battery is most likely at the end of its service life and should be replaced.

**Battery Installation**

Reinstall battery and secure retaining strip to support properly.

Install fuse box, fuse holders, relays and harness as applicable to model.

Connect RED (+) cable FIRST to positive battery terminal.

Connect BLACK (-) cable LAST.

**⚠ WARNING**

Battery BLACK (-) cable must always be disconnected first and reconnected last.

Cover the RED (+) cable terminal with the protective rubber boot.

Apply SILICONE DIELECTRIC GREASE (P/N 293 550 004) on battery posts and connectors.


# STARTING SYSTEM

## SERVICE TOOLS

Description	Part Number	Page
FLUKE 115 MULTIMETER .....	529 035 868 .....	376, 378, 383-384


## SERVICE PRODUCTS

Description	Part Number	Page
THERMOLUBE SYNTHETIC GREASE.....	219 700 417 .....	371, 374



## Section 05 ELECTRICAL SYSTEM

### Subsection 03 (STARTING SYSTEM)





## GENERAL

### BASIC STARTING SYSTEM OPERATION

When the START/RER button is pressed, a 12 Vdc signal is sent to the ECM, which completes the starter solenoid circuit by providing a ground. The battery then supplies current to the starter through the starter solenoid to crank the engine.

#### Conditions for Engine Cranking

- Engine stop switch to RUN
- DESS cap installed
- Press START/RER button.

## TROUBLESHOOTING

### TROUBLESHOOTING TIPS

**NOTE:** On applicable models, it is good practice to check for fault codes using B.U.D.S. software as a first troubleshooting step. Refer to *MONITORING SYSTEM/FAULT CODES*.

In case of starter malfunction, first ensure the problem is not related to an engine mechanical component.

#### 500SS/600/800R

1. Try to pull start the engine.
2. If engine can be started, test starting system as per *STARTING SYSTEM TESTING SEQUENCE*.
3. If engine does not start or cannot be rotated, the problem is not related to the starting system.

#### 600 HO E-TEC

This model is not equipped with a rewind starter. Carry out the following procedure to ensure engine can be rotated.

1. Set engine stop switch to STOP.
2. Ensure DESS key is **not** installed.
3. Manually rotate the engine using the drive pulley.

### **⚠ WARNING**

When manually rotating engine, the engine stop switch **MUST BE** set to STOP and DESS cap **MUST NOT** be installed or severe injury may occur.

If the engine can be rotated, test starting system as per *STARTING SYSTEM TESTING SEQUENCE*.

If the engine cannot be rotated, check engine.

### STARTING SYSTEM TESTING SEQUENCE

Test starting system in the following order:

- 30 A fuse (FA)
- 5 A fuse (FB)
- Battery connections and voltage test, refer to *CHARGING SYSTEM*
- Starter. Refer to *STARTER QUICK TEST*
- Starter solenoid. Refer to *STARTER SOLENOID QUICK TEST*
- Start switch. Refer to *START/RER SWITCH USING B.U.D.S.*

If the engine cannot be rotated using the rewind starter, the problem is not related to the starting system. Inspect the engine.

## PROCEDURES

### START/RER FUSE

**NOTE:** When a burnt fuse is found, always identify the cause before replacing it.

#### Fuse Inspection

The ECM power circuit used for the starting system first passes through the 30 A battery charging fuse (FA).

Then it passes through a 5 A START/RER fuse (FB), to the starting system circuits.



TYPICAL - 500SS/600/800R  
1. START/RER fuse (FB)  
2. Charging fuse (FA)

## Section 05 ELECTRICAL SYSTEM

### Subsection 03 (STARTING SYSTEM)



TYPICAL - 600 HO E-TEC

1. START/RER fuse (FB)
2. Charging fuse (FA)

If no voltage is present at the ECM, or the starter does not crank the engine, test each fuse condition and replace it if necessary.

If fuses are good, try a starter solenoid quick test, refer to *STARTER SOLENOID* in this section.

## ELECTRIC STARTER

### Starter Quick Test

1. Set engine cut-out switch to STOP or remove DESS cap to prevent engine from starting.

#### **⚠ WARNING**

Do not touch spark plug or cables when cranking engine. High voltage can cause a powerful electrical shock if you touch them.

2. Connect one end of a battery booster cable to the positive (+) battery post.
3. Momentarily touch the other end of the booster cable to the starter cable terminal on the starter solenoid.

#### **⚠ WARNING**

A spark will be generated when making the final contact of the booster cables to power the starter directly. If there is a fuel or acid smell (fuel system or battery leak), or visible evidence of a leak, do not carry out this procedure as the spark generated may ignite the fuel or acid vapors. This would produce a fire or explosion possibly resulting in severe injury, or fatality.

**NOTE:** This procedure will bypass the starter solenoid and supply current from the battery directly to the starter through its power input cable.

If the starter does not turn, check for the following:

- Starter power cable/connections
- Starter.

If the starter rotated, carry out a *STARTER SOLENOID QUICK TEST*.


### Starter Removal

1. Remove both side panels and hood, refer to *BODY* section.
2. Disconnect BLACK (-) cable from battery.
3. Disconnect RED (+) cable from battery.

#### **⚠ WARNING**

Always disconnect BLACK (-) cable first and reconnect last.

4. Remove tool kit holder and drive belt guard.
5. Remove drive belt and drive pulley, refer to *ENGINE DRIVE SYSTEM* section.
6. Remove muffler and tuned pipe, refer to *EXHAUST SYSTEM* section.
7. Disconnect RED power cable from starter.




TYPICAL - STARTER POWER CABLE

1. Elastic nut
2. Washer
3. Power cable

8. Remove the LH front and rear engine mounting hex screws (PTO side). Discard the screws.

## Section 05 ELECTRICAL SYSTEM

### Subsection 03 (STARTING SYSTEM)




mmr2008-026-011\_s

**LH FRONT ENGINE MOUNT**

1. Conical washer
2. Flat washer

**NOTE:** Pay attention to the washer positions for installation. The front mount screw has a flat washer under the head of the screw followed by a conical spring washer.

9. Remove and discard the three bolts retaining the engine torque stopper support.



- mmr2008-026-014\_s
1. Screws, torque stopper support
  2. Starter screws
  3. Pry bar position

10. Insert a pry bar over the LH frame member and gently raise the engine just enough to access the lower mounting torx screw on the starter.
11. Remove and discard the lower mounting screw from the starter.
12. Remove the pry bar.
13. Remove and discard the upper mounting screw from the starter.
14. Remove and discard the RH starter mounting screw from the front of the engine.



mmr2008-026-016\_3i


**STARTER MOUNTING SCREW, RH**

1. Washer under screw head
2. Washer spacer between starter and engine

**NOTE:** When removing the mounting screw on the RH side of the starter, pay attention to the spacer between engine and starter, and the washer under the screw head.

### Starter Disassembly

1. Refer to the exploded view in the beginning of this section.
2. Before disassembling, trace index marks on the starter housing and covers for parts alignment at reassembly.




#### TYPICAL

1. Alignment index marks for reassembly
3. Remove starter through bolts.
4. Separate end cap from starter housing.
5. Withdraw armature from starter housing.
6. If necessary, remove brush holder from end cap.
7. Check for radial play between the armature shaft and end cap bearing. Replace the end cap bearing or replace starter if radial play is detected.
8. If parts are in good condition, coat them with THERMOLUBE SYNTHETIC GREASE (P/N 219 700 417) before reinstalling them.

## Section 05 ELECTRICAL SYSTEM

### Subsection 03 (STARTING SYSTEM)

9. Push back the collar near the starter gear/clutch assembly using a screwdriver.
10. Remove snap ring, collar, and spring.



1. Collar
2. Snap ring

11. Turn starter clutch clockwise to remove it from the armature assembly.
12. Pull yoke from armature.

### Starter Cleaning

**NOTICE** Yoke, drive unit (clutch assembly) and end cap must not be immersed in cleaning solvent.

1. Clean brushes and holders with a clean cloth impregnated with solvent. Brushes must be dried thoroughly with a clean cloth.
2. Blow brush holders clean using compressed air.

#### **WARNING**

Always wear safety glasses when using compressed air.

3. Remove dirt, oil or grease from commutator using a clean cloth soaked in suitable solvent. Dry well using a clean and dry cloth.
4. Clean engine ring gear teeth and drive unit (clutch).

**NOTE:** Bushings or bearings must not be cleaned with grease dissolving agents.


5. Immerse all metal components in cleaning solution. Dry using a clean and dry cloth.

### Starter Inspection

#### Armature

**NOTE:** An ohmmeter may be used for the following test procedures, except when testing for shorted windings in the armature.

1. Check the commutator for roughness, burnt or scored surface. If necessary, turn the commutator on a lathe, enough to remove grime only.
2. Check the commutator for mica depth. If the depth is less than 0.20 mm (.008 in), undercut the mica. Be sure that no burrs are left and no copper dust remains between the segments after the undercutting operation is completed.




1. Commutator undercut 0.20 mm (.008 in)

3. Check the commutator out-of-round condition with V Blocks and an indicator. If the commutator out-of-round is more than 0.40 mm (.016 in), the commutator should be turned on a lathe.
4. Check commutator outer diameter for signs of excessive wear. Replace starter as necessary.

#### Test for Grounded Armature Winding

Use growler test probes. Check between armature core and the commutator bars. If growler lamp turns on, bars are grounded. If so, replace starter.




1. Test probes
2. Commutator bars

## Section 05 ELECTRICAL SYSTEM

### Subsection 03 (STARTING SYSTEM)

#### Test Armature for Shorted Winding

When the armature is rotated in the growler with a steel strip (hacksaw blade) held above it, the strip will vibrate over that area of the armature which has a short circuit. Replace starter if a shorted winding is found.



1. Steel strip (hack-saw blade)
2. Growler

#### Test the Armature for Open Circuit

1. Use growler test probes.
2. Place one test probe on a commutator bar and the other test probe on the neighboring bar.
3. Repeat this operation for all bars, moving one test probe at a time.

If the growler lamp does not turn on, the armature circuit between these 2 bars is opened. If an open circuit is found, the starter should be replaced.

**NOTE:** Open circuits most often occur at the commutator riser where windings are soldered. Burnt commutator bars are usually an indication of an open-circuit in an armature winding.

#### Brush Holder


1. Check the brush holder for insulation using growler test probes.
2. Place one test probe on the insulated brush holder and the other test probe on the brush holder plate.

If the growler lamp turns on, the brush holder has to be repaired or replaced.

#### Brush Length

Measure brush length as illustrated. If less than the specified value, replace them.

MODEL	LENGTH	
	NEW	WEAR LIMIT
All	10 mm (.40 in)	6 mm (.24 in)




TYPICAL

1. New
2. Wear limit

#### End Cap

Check the mica insulation of the positive brush. Check the roller bearing (or bushing) condition. Replace, if necessary.



1. Roller bearing
2. Positive brush

#### Overrunning Clutch

The pinion of the overrunning clutch should turn smoothly in a clockwise direction, and should not slip in a counterclockwise direction. If defective, replace clutch assembly.

Check the pinion teeth for wear and damage. If defective, replace.

## Section 05 ELECTRICAL SYSTEM

### Subsection 03 (STARTING SYSTEM)


#### Starter Assembly

Reverse the order of disassembly to reassemble starter. However, pay attention to the following operations.

Prior to assembling, coat sliding surfaces on armature shaft splines, overrunning clutch and bushing with THERMOLUBE SYNTHETIC GREASE (P/N 219 700 417).

After placing collar on armature shaft, install a new snap ring on the armature shaft and ensure that it is properly secured.


Slide collar over snap ring and secure in place by punching it at two or three places.



1. Armature shaft
2. Snap ring
3. Collar
4. Punch

#### Starter Housing, Yoke and End Cap

1. Align previously traced index marks on housing, yoke and end cap.



#### TYPICAL

1. Aligned index marks

2. Open brushes and slide over commutator.
3. Align end cap locating notch with yoke locating protrusion and properly sit brush holder into cap.



1. Brush holder

**NOTE:** To ease end cap installation, retain brush holder with a small screwdriver while installing armature assembly.

**NOTICE** Place two end caps on a flat surface before tightening the through bolts. Ensure end cap fits perfectly on yoke.

4. Torque starter through bolts as per exploded view.

#### Starter Installation

Install removed parts in the reverse order of removal, however, pay attention to the following.

- Ensure starter and engine mating surfaces are free of grime. Serious trouble may arise if starter is not properly aligned.
- Replace all scotch grip screws.
- For ease of installation, install the three new starter mounting screws loosely before torquing.
- Torque the two starter mounting Torx screws first, then the hex screw to 28 N•m (21 lbf•ft)
- Install the torque stopper support and two new engine mounting bolts, refer to *ENGINE REMOVAL AND INSTALLATION* section.
- Connect the RED wire to the large terminal on the starter.
- Install the drive belt, refer to *DRIVE SYSTEM AND BRAKE* section.
- Install the muffler and tune pipe, refer to *EXHAUST SYSTEM* section.
- Reconnect the positive (+) RED battery cable, then the negative (-) BLACK cable.

**⚠ WARNING**

Always disconnect ground cable first and re-connect last.

**NOTICE** Be sure to install the spacer between engine and starter, and the washer under the screw head when installing the mounting screw on the RH side of the starter.



STARTER MOUNTING SCREW, RH

1. Washer under screw head
2. Washer spacer between starter and engine


## STARTER SOLENOID

### Solenoid Quick Test

1. Test battery voltage, it should be approximately 12.8 Vdc for a fully charged battery.
2. Disconnect the small positive connector from the solenoid coil.

MODEL	POSITIVE TERMINAL
500SS/600/800R	BEIGE
600 HO E-TEC	RED/GREEN

3. Install a jumper wire (with insulated clips) between the positive solenoid terminal and the positive battery terminal.
4. Disconnect the small negative connector (ORANGE/BLACK wire) from the starter solenoid.
5. Install a jumper wire on the negative solenoid terminal and momentarily touch the other end to battery ground.



STARTER SOLENOID QUICK TEST

**NOTICE** The two small solenoid coil terminals are close to each other. When installing the two jumper wires, ensure the ends of the jumper wires are insulated and cannot come into contact with each other or a short circuit will occur.

If the starter engages, refer to *INPUT VOLTAGE TEST (STARTER SOLENOID)*.

If the starter did not engage, refer to *STARTER SOLENOID STATIC TEST*, or try a known good solenoid.

### Input Voltage Test (Starter Solenoid)

1. Install DESS cap on DESS post.
2. Set engine stop switch to RUN.
3. Set multimeter to Vdc.
4. Press and hold the START/RER button as you back-probe the solenoid coil 12 Vdc input connector.



BACK-PROBE COIL 12 VDC INPUT WIRE

## Section 05 ELECTRICAL SYSTEM

### Subsection 03 (STARTING SYSTEM)

5. Measure the solenoid input voltage as per following table.

MODEL	PROBE		VOLTAGE
500SS/600/800R	BEIGE	Battery ground	Battery voltage
600 HO E-TEC	RED/GREEN		

If voltage is not as specified, refer to *SOLENOID WIRING CONTINUITY TEST* in this section and test for solenoid power wire continuity.

If the input voltage to the solenoid control winding is as specified, refer to *SOLENOID GROUND SIGNAL TEST*.

#### Solenoid Ground Signal Test

1. Reconnect the coil 12 Vdc input wire to the positive solenoid terminal.
2. Disconnect the small ORANGE/BLACK wire from the solenoid negative terminal (ground signal).



DISCONNECT ORANGE/BLACK WIRE

3. Connect a jumper wire between solenoid negative terminal and battery ground.



JUMPER NEGATIVE TO SOLENOID TERMINAL

4. Press START/RER button.

If solenoid does not function and starter solenoid input voltage test was good, carry out the following:

- *SOLENOID STATIC TEST*
- *SOLENOID DYNAMIC TEST*.

If solenoid functions normally, ECM may not be providing a ground signal, or the ground signal wire from ECM to starter solenoid may be open circuit.

Carry out the following:

- *SOLENOID WIRING CONTINUITY TEST*
- *VEHICLE HARNESS CONTINUITY* (refer to START/STOP SWITCH in this section).

Repair or replace wiring/connectors.

**NOTE:** If ground signal wire tested good, and all other previous test were good, try a new ECM.

#### Solenoid Wiring Continuity Test

##### 500SS/600/800R

1. Disconnect both small connectors from the solenoid coil terminals.
2. Disconnect the CF connector attached to the oil tank above battery.



1. Solenoid coil connectors
2. CF connector
3. Oil tank

3. Set the FLUKE 115 MULTIMETER (P/N 529 035 868) to  $\Omega$  selection.
4. Measure for continuity of each wire between the CF connector and the solenoid coil connectors.

**NOTE:** Resistance should be close to 0  $\Omega$ . Ground signal wire is ORANGE/BLACK.

Repair or replace wiring.


5. Reconnect wires to solenoid.



6. Reconnect CF connector.

### Solenoid Static Test

1. Disconnect the small terminals from the starter solenoid.



2. With a multimeter set to  $\Omega$ , test coil winding resistance as follows.

SOLENOID CONNECTOR		MEASUREMENT
TERMINAL		RESISTANCE @ 20°C (68°F)
A	B	Approximately 7.5 $\Omega$



3. Disconnect battery ground cable.

4. Check for a stuck solenoid plunger by measuring the resistance through the solenoid main contacts as follows.

SOLENOID CONNECTOR		MEASUREMENT
Battery post	Starter post	Open circuit



If a reading other than an open circuit is measured, replace solenoid.

### Solenoid Dynamic Test

1. Reconnect battery ground cable and solenoid connectors.
2. Disconnect the ignition coil(s) primary winding connector(s) to prevent engine from starting.
3. Press START/RER button and hold. While engine is cranking, measure the voltage drop across the solenoid main contacts as follows.

SOLENOID CONNECTOR		VOLTAGE
Post coming from battery	Post going to starter	0.2 Vdc max.



4. Reconnect coil connector(s).

If voltage is out of specification, replace solenoid. If solenoid tests good, refer to *ELECTRIC STARTER*.

### START/RER SWITCH (500SS/600/800R)


#### START/RER Switch Test Using B.U.D.S.

1. Connect the vehicle to the latest B.U.D.S. software available from BOSSWeb. Refer to *COMMUNICATION TOOLS/B.U.D.S. SOFTWARE* for proper connection instructions.
2. In B.U.D.S., select the Read Data button.

## Section 05 ELECTRICAL SYSTEM

### Subsection 03 (STARTING SYSTEM)

3. Select the **Monitoring** tab.
4. At the bottom LH corner of the **Monitoring** page, select the **ECM** tab.
5. Set engine stop switch to RUN and install DESS cap on DESS post.
6. Press the **START/RER** button and look for the **START/RER Button** LED in the bottom field. It should come ON (turn GREEN).



#### TYPICAL

1. Should turn on (GREEN)


If the START/RER button LED comes on in B.U.D.S., the starting system is functional on the input side (START/RER button, ECM and input circuit wiring). Test the output side of the starting system:

- ECM ground signal to starter solenoid
- *STARTER SOLENOID QUICK TEST*
- *SOLENOID WIRING CONTINUITY*
- Starter power cables.

If the LED does not come on, refer to *INPUT VOLTAGE TEST START/RER SWITCH*.

#### Input Voltage Test START/RER Switch

1. Remove multifunction gauge. Refer to *LIGHTS, GAUGE AND ACCESSORIES* section.
2. Disconnect the HG connector from the steering harness.




HG CONNECTOR, STEERING HARNESS

3. Set the FLUKE 115 MULTIMETER (P/N 529 035 868) to Vdc.

4. Measure voltage at battery terminals. It should be approximately 12.8 Vdc for a fully charged battery.
5. Measure the input voltage on the **vehicle harness side** of the HG connector as per following table.

TEST PROBES		VOLTAGE
Pin 5 (RED/GRAY)	Battery ground	Battery voltage



TYPICAL - HG CONNECTOR

If you do not measure battery voltage, test the following:

- 30 A battery charging fuse (FA)
- 5 A ECM fuse (FB)
- Input circuit continuity (HG connector to battery), refer to *VEHICLE HARNESS CONTINUITY TEST (START/RER SWITCH)*.

If you measure battery voltage, refer to *CONTINUITY TEST START/RER SWITCH*.


#### Continuity Test START/RER Switch

1. Set multimeter to  $\Omega$ .
2. Measure continuity of switch and steering harness wiring as per following table (steering harness side).

TEST MULTIMETER	NOTES

## Section 05 ELECTRICAL SYSTEM

### Subsection 03 (STARTING SYSTEM)



START/RER SWITCH CONTINUITY TEST, STEERING CONNECTOR

CONTINUITY TEST START/RER SWITCH			
SWITCH POSITION	(HG)CONNECTOR		RESISTANCE
Released	Pin 5 (RED/GRAY)	Pin 8 (BEIGE)	High value or infinite (OL)
Pressed and held			Continuity (Close to 0 Ω)

If START/RER switch continuity was good, test start control wiring to ECM, refer to *VEHICLE HARNESS CONTINUITY TEST (START/RER SWITCH)*.

If continuity test fails at HG connector, remove multifunction switch from handlebar and test continuity of steering harness from HG connector to LB connector in multifunction switch housing. Refer to *WIRING DIAGRAM* for circuit details.

#### Vehicle Harness Continuity Test (START/RER Switch)

1. Remove RH side panel, refer to *BODY* section.
2. Disconnect battery or remove the 5 A (FB) fuse (START/RER fuse).



START/RER FUSE (FB)

3. Disconnect the (CF) connector located above the battery.



TYPICAL - CONNECTOR (CF)

4. Remove acoustic panel, and disconnect ECM connector, refer to *IGNITION SYSTEM* section.




1. Acoustic panel  
2. ECM

5. Measure for continuity between the steering harness connector (HG), the ECM connector, and the CF connector. Refer to following table.

## Section 05 ELECTRICAL SYSTEM

### Subsection 03 (STARTING SYSTEM)



1. Steering harness connector
2. ECM connector

#### CONNECTORS

CF	STEERING (HG)	ECM	RESISTANCE
Pin 2 (BEIGE)	Pin 8 (BEIGE)	Pin 8 (BEIGE)	Continuity (Close to 0 Ω)
Pin 3 (RED/GRAY)	Pin 5 (RED/GRAY)	Pin 34 (RED/GRAY)	

If the vehicle harness continuity test for the START/RER switch circuit was within specification, test continuity of the ECM power circuit from the battery (ECM connector pin 34 to CF connector pin 3).

## START/RER SWITCH 600 HO E-TEC

### START/RER Switch Test Using B.U.D.S.

1. Connect the vehicle to the latest B.U.D.S. software available from BOSSWeb. Refer to *COMMUNICATION TOOLS/B.U.D.S. SOFTWARE* for proper connection instructions.
2. In B.U.D.S., select the **Read Data** button.
3. Select the **Monitoring** tab.
4. At the bottom LH corner of the **Monitoring** page, select the **ECM** tab.
5. Set engine stop switch to RUN and install DESS cap on DESS post.
6. Press the START/RER button and look for the **START/RER Button LED** in the bottom field. It should come ON (turn GREEN).



#### TYPICAL


1. Should turn on (GREEN)

If the START/RER button LED comes on in B.U.D.S., the starting system is functional on the input side (START/RER button, ECM and circuit wiring to ECM). Test the output side of the starting system, refer to *VEHICLE HARNESS CONTINUITY TEST (START/RER SWITCH)*.

If the LED does not come on, refer to *INPUT VOLTAGE TEST START/RER SWITCH (SB CONNECTOR)*.

### Input Voltage Test START/RER Switch (SB Connector)

1. Set multimeter to Vdc.
2. Open RH side panel and measure voltage at battery terminals. It should be approximately 12.8 Vdc for a fully charged battery.
3. Remove steering cover from top of handlebars.
4. Disconnect the three pin connector (SB).



3-PIN SB CONNECTOR

5. Measure START/RER switch input voltage at the vehicle harness connector as per following table.

#### INPUT VOLTAGE TEST START/RER SWITCH (SB CONNECTOR)

PROBE		VOLTAGE
Pin 3 (RED/BROWN)	Battery ground	Battery voltage


If battery voltage is measured, refer to *CONTINUITY TEST START/RER SWITCH (SB CONNECTOR)*.

If battery voltage is not measured, test the following in the recommended order:

- 30 A battery charging fuse (FA)
- 5 A fuse (F9)
- *INPUT VOLTAGE TEST START/RER SWITCH (HG CONNECTOR)*.

### Input Voltage Test START/RER Switch (HG Connector)

1. Remove multifunction gauge, refer to *LIGHTS, GAUGE AND ACCESSORIES* section.
2. Disconnect HG connector.



1. Steering connector HG (11-pin)  
 2. Accessories connector AC (8-pin)

3. Measure switch input voltage at the vehicle harness connector as per following table.

INPUT VOLTAGE TEST START/RER SWITCH (HG CONNECTOR)		
PROBE		VOLTAGE
Pin 6 (RED/GRAY)	Battery ground	Battery voltage

If battery voltage is measured, repair or replace the RED/BROWN wire between the HG connector (pin 6) and SB connector (pin 3).

If battery voltage is not measured, test the following in the recommended order:

- 30 A battery charging fuse (FA)
- 5 A fuse (F9)
- *START/RER Switch Power Circuit Continuity in VEHICLE HARNESS CONTINUITY TEST (START/RER SWITCH)*.


### Continuity Test START/RER Switch (SB Connector)

1. Disconnect the start button harness 3-pin connector (SB) on top of the handlebars.



3-PIN (SB) CONNECTOR

2. Set multimeter to  $\Omega$  selection.
3. Measure start switch continuity as per following table.



### CONTINUITY TEST START/RER SWITCH (SB CONNECTOR)

SWITCH POSITION	3-PIN (SB) CONNECTOR		RESISTANCE
Released	Pin 1 (BLACK)	Pin 2 (RED)	Continuity (Close to 0 $\Omega$ )
	Pin 1 (BLACK)	Pin 3 (WHITE)	High value or infinite (OL)
Pressed and held	Pin 1 (BLACK)	Pin 2 (RED)	High value or infinite (OL)
	Pin 1 (BLACK)	Pin 3 (WHITE)	Continuity (Close to 0 $\Omega$ )

## Section 05 ELECTRICAL SYSTEM


### Subsection 03 (STARTING SYSTEM)

If continuity test failed, replace START/RER switch.

If continuity test of start switch was good, refer to *CONTINUITY TEST START/RER SWITCH (HG AND AC CONNECTORS)*.

#### Continuity Test START/RER Switch (HG and AC Connectors)

1. Remove multifunction gauge, refer to *LIGHTS, GAUGE, AND ACCESSORIES* section.
2. Disconnect the (HG) steering harness connector, and (AC) accessories connector.



1. 11-pin steering connector (HG)
2. 8-pin accessories connector (AC)

3. Measure for continuity as per following table.

CONNECTORS			RESISTANCE
3-PIN (SB)	11-PIN (HG)	8-PIN (AC)	
Pin 2 (BLACK/BLUE)	Pin 1 (BLACK/BLUE)	N.A.	Continuity (Close to 0 Ω)
Pin 3 (RED/BROWN)	Pin 6 (RED/BROWN)	N.A.	
Pin 1 (BEIGE)	N.A.	Pin 3 (BEIGE)	

If continuity readings were not as specified, repair or replace steering harness.

If continuity test of steering harness was good, refer to *VEHICLE HARNESS CONTINUITY TEST (START/RER SWITCH)* in this section.

#### Vehicle Harness Continuity Test (START/RER Switch)


1. Remove 30 A charging fuse (FA) and 5 A START/RER fuse (FB) located above battery.




TYPICAL - 600 HO E-TEC

1. START/RER fuse (FB)
2. Charging fuse (FA)

2. Disconnect the two small solenoid winding connectors.




3. Remove LH side panel, refer to *BODY* section.
4. Remove tool kit holder and drive belt guard.
5. Disconnect ECM connectors J1A and J1B. (Top two connectors).




ECM CONNECTORS IDENTIFICATION

## Section 05 ELECTRICAL SYSTEM

### Subsection 03 (STARTING SYSTEM)



J1A PIN-OUT




J1B PIN-OUT

- Set FLUKE 115 MULTIMETER (P/N 529 035 868) to  $\Omega$  selection and carry out the following continuity tests.

#### START/RER Switch Power Circuit Continuity

CONNECTORS		RESISTANCE
1	FB socket B (RED/GRAY)      HG Pin 6 (RED/GRAY)	Continuity (Close to 0 $\Omega$ )
2	FB socket A (RED/WHITE)      FA socket A (RED/WHITE)	



- Steering connector (HG)
- 8-pin connector (AC)

If resistance is not within specification, repair or replace wiring and connectors.

#### Starter Solenoid Power Wire Continuity

CONNECTORS		RESISTANCE
1	AC Pin 3 (RED/GREEN)      Solenoid wire (RED/GREEN)	Continuity (Close to 0 $\Omega$ )

If resistance is not within specification, repair or replace wiring and connectors.

#### Starter Solenoid Ground Wire Continuity

CONNECTORS		RESISTANCE
1	Solenoid wire (ORANGE/BLACK)      J1B pin 9	Continuity (Close to 0 $\Omega$ )

If resistance is not within specification, repair or replace wiring and connectors.

#### ECM START/RER Signal Circuit Continuity

**NOTE:** Connect the RED multimeter lead to the AC connector pin when carrying out this test.

CONNECTORS		RESISTANCE
1	AC Pin 3 (RED/GREEN)      J1A pin 28	Continuity (Close to 0 $\Omega$ )
2	AC Pin 3 (RED/GREEN) (RED meter probe)      J1B pin 10 (BLACK meter probe)	Erratic See D1 diode test

**NOTE:** Diode D1 is connected to the J1B pin 10 circuit. If multimeter leads are connected in reverse polarity, multimeter will read an open circuit (OL) to J1B pin 10.

If resistance is not within specification, repair or replace wiring and connectors.


#### D1 Diode Test

- Remove the diagnostic connector (COM) from its storage cap.

## Section 05 ELECTRICAL SYSTEM

### Subsection 03 (STARTING SYSTEM)

2. Set FLUKE 115 MULTIMETER (P/N 529 035 868) to diode test function and carry out the following test.



3. Connect multimeter test probes as per following table. Pay attention to diode polarity.

CONNECTORS			READING
-	COM pin 4	J1A pin 28	N.A.
1	RED (+) probe	BLACK (-) probe	OL (open circuit)
2	BLACK (-) probe	RED (+) probe	Approximately 0.5 V

If readings are not within specification, replace diode.



# DIGITALLY ENCODED SECURITY SYSTEM (D.E.S.S.)

## SERVICE TOOLS

Description	Part Number	Page
FLUKE 115 MULTIMETER .....	529 035 868 .....	386

## GENERAL

### SYSTEM DESCRIPTION

The following components are specially designed for this system: ECM, D.E.S.S. key and post.

This system allows the engine to reach pulley engagement speed only if a D.E.S.S. key is installed on D.E.S.S. post and the key is recognized as valid by the ECM.

The D.E.S.S. key contains a magnet and a ROM chip.

- The magnet closes the reed switch inside the D.E.S.S. post. It is the equivalent of a rotary mechanical ignition switch.
- The ROM chip owns a unique digital code. It is the equivalent of the tooth-pattern cut on a conventional ignition key.

The D.E.S.S. system is quite flexible. Up to 8 D.E.S.S. keys may be programmed in the memory of the ECM using the B.U.D.S. software. The keys can also be erased individually.

**NOTE:** If desired, a D.E.S.S. key can be used on another vehicle equipped with the D.E.S.S. It only needs to be programmed for that vehicle.

### D.E.S.S. Beeper Codes

When starting the engine with a D.E.S.S. key on the post, the key is identified by the ECM and D.E.S.S. signals will be issued according to the key recognition. See table.

D.E.S.S. SIGNAL		DESCRIPTION	COMMENT
BEEPER	DISPLAYED MESSAGE <sup>(1)</sup>		
2 shorts beeps	WELCOME... or SKI-DOO	Welcome message, good key	Working D.E.S.S. key.
Slow short repetitive beeps	CHECK KEY	Unable to read key (bad connection)	Make sure the key contacts are free of dirt, snow or ice. Reinstall key and restart engine. Vehicle can not be driven.
Fast short repetitive beeps	BAD KEY	Invalid key or key not programmed	Use the proper key for this vehicle or have the key programmed. Vehicle can not be driven.

<sup>(1)</sup> Only available on premium gauge

## PROCEDURES

### D.E.S.S. KEY

#### D.E.S.S. Key Programming

Use the latest B.U.D.S. software available from BOSSWeb.

Carry out the proper connections to use B.U.D.S. Refer to *COMMUNICATION TOOLS/B.U.D.S. SOFTWARE*.


**IMPORTANT:** Ensure all connections have been made **before starting B.U.D.S.** to allow proper operation.

Start B.U.D.S. and logon.

To read the ECM, click the **Read Data** button.


## Section 05 ELECTRICAL SYSTEM

### Subsection 04 (DIGITALLY ENCODED SECURITY SYSTEM (D.E.S.S.))




Install the new key to be programmed on vehicle D.E.S.S. post.

Click on Keys tab.



Click on Add Key button at bottom of screen.




1. Click on this button

A new key is now saved in the computer.

**NOTE:** To program other key(s), install a new key and click again on Add Key button.

Save the new key(s) in the ECM by clicking the Write Data button.



## D.E.S.S. POST

### D.E.S.S. Post Continuity Test


Remove LH side panel. Refer to *BODY*.

Remove belt guard. Refer to *DRIVE SYSTEM AND BRAKE*.

Remove primary intake silencer. Refer to *AIR INTAKE SYSTEM*.

Remove intake adaptor.

Disconnect D.E.S.S. post connector.



1. D.E.S.S. post connector

The following continuity tests can be performed using the FLUKE 115 MULTIMETER (P/N 529 035 868).

### D.E.S.S. Key Removed from Post


Set multimeter to  $\Omega$ .

Connect test probes to D.E.S.S. post and its connector as per tables and measure resistance.

D.E.S.S. POST		RESISTANCE $\Omega$ @ 20°C (68°F)
WIRE		
BLACK/ GREEN	BLACK/ WHITE	Open circuit


## Section 05 ELECTRICAL SYSTEM

### Subsection 04 (DIGITALLY ENCODED SECURITY SYSTEM (D.E.S.S.))




TYPICAL

D.E.S.S. POST		RESISTANCE $\Omega$ @ 20°C (68°F)
WIRE		
WHITE/ GRAY	Post terminal	Close to 0 $\Omega$



TYPICAL

D.E.S.S. POST		RESISTANCE $\Omega$ @ 20°C (68°F)
WIRE		
BLACK/ GREEN	Post ring	Close to 0 $\Omega$



TYPICAL

#### D.E.S.S. Key on Post

Connect test probes to D.E.S.S. post connector as per table and measure resistance.

D.E.S.S. POST		RESISTANCE $\Omega$ @ 20°C (68°F)
WIRE		
BLACK/ GREEN	BLACK/ WHITE	Close to 0 $\Omega$




TYPICAL

If any resistance test fails, replace D.E.S.S. post.

#### D.E.S.S. Post Vehicle Harness Continuity Test

**500SS/600/800R**

Disconnect D.E.S.S. post connector.



1. D.E.S.S. post connector

Disconnect ECM connector.




Set multimeter to  $\Omega$  and check wire continuity between D.E.S.S. post connector and ECM as follows.

## Section 05 ELECTRICAL SYSTEM


### Subsection 04 (DIGITALLY ENCODED SECURITY SYSTEM (D.E.S.S.))

D.E.S.S. POST CONNECTOR	ECM CONNECTOR	RESISTANCE $\Omega$ @ 20°C (68°F)
WIRE	PIN	
WHITE/GRAY	24	Close to 0 $\Omega$
BLACK/WHITE	6	
BLACK/GREEN	1	




#### 600 HO E-TEC

Disconnect D.E.S.S. post connector.




1. DESS post connector

Remove RH side panel. Refer to *BODY*.  
Disconnect the J1A connector from ECM.




1. ECM



Set multimeter to  $\Omega$  and check wire continuity between D.E.S.S. post connector and ECM as follows.

D.E.S.S. POST CONNECTOR	ECM CONNECTOR	RESISTANCE $\Omega$ @ 20°C (68°F)
WIRE	PIN	
WHITE/GRAY	11	Close to 0 $\Omega$
BLACK/WHITE	23	
BLACK/GREEN	5	

***All Models***

- If any continuity test failed, repair or replace wiring connectors/terminals.
- If problem persists and all tests have been performed, try a new ECM. Refer to *ECM REPLACEMENT*.

Reinstall removed parts.

**BEEPER**

The beeper is integrated in the multifunction gauge and cannot be replaced alone.

If the beeper does not sound when starting engine, check the beeper operation. Refer to *LIGHTS, GAUGE AND ACCESSORIES*.

# ROTAX ELECTRONIC REVERSE

## SERVICE TOOLS

Description	Part Number	Page
12 VOLT BATTERY SUPPLY CABLE.....	529 035 997 .....	392-394, 396
FLUKE 115 MULTIMETER .....	529 035 868 .....	393, 395
T-HARNES.....	529 035 869 .....	392-394, 396

## GENERAL

The main components of the RER system are:

- START/RER switch
- ECM
- Trigger coils (500SS/600/800R)
- Crankshaft position sensor (600 HO E-TEC).

The ECM receives signals from both trigger coils (or the CPS) for forward and reverse engine rotation.

The ECM recognizes a signal sent by the START/RER switch.

When the START-RER switch is activated and the engine is running at or near idle speed, the ECM cuts off ignition, therefore causing the engine RPM to drop off gradually.

When the engine reaches a predetermined low RPM (approximately 450 RPM), the ECM initiates an ignition spark that is greatly advanced in timing, creating a thrust which reverses engine rotation.

Below a low RPM threshold, or above 4300 RPM, the RER function is disabled and nothing takes place when the RER button is pressed.

**NOTE:** Refer to *IGNITION SYSTEM* for trigger coil testing.

**NOTE:** Refer to *E-TEC DIRECT FUEL INJECTION* for crankshaft position sensor (CPS) testing.

## TROUBLESHOOTING

### DIAGNOSTIC TIPS

#### RER Does Not Respond When Depressing RER Button

*Manual Start Models (500SS/600/800R)*

Check the following:

- *RER SWITCH CONTROL CIRCUIT TEST*
- ECM.

#### *Manual Start Models (600 HO E-TEC)*

Check the following:

- Manual start connector (jumper) is installed
- 5 A RER fuse condition
- *RER SWITCH SIGNAL TEST WITH B.U.D.S.*

#### *Electric Start Models (500SS/600/800R)*

The START and RER control circuits are almost the same. If vehicle started normally, test the following:

- *RER SWITCH SIGNAL CIRCUIT TEST*
- ECM.

#### *Electric Start Models (600 HO E-TEC)*

Check the following:

- *RER SWITCH SIGNAL TEST WITH B.U.D.S.*

#### Engine Stops after Pressing RER Button

This confirms that RER control circuits function normally. Check the following:

- Trigger coil (500SS/600/800R)
- CPS (600 HO E-TEC)
- Reed valves leaking, refer to applicable *TOP END* section
- RAVE valve adjustment or sticking, refer to applicable *RAVE* section
- Drive belt adjustment, refer to *DRIVE SYSTEM AND BRAKE* section
- ECM.

#### RER Functions Erratically

1. Check engine compression.

**NOTE:** A low compression resulting in loss of engine power may cause the RER to function erratically, leading you to believe the problem is in the electronic control system.

2. Low compression may be due to the following items:
- REED valves leaking or broken
  - RAVE valves sticking
  - Worn engine parts.

## Section 05 ELECTRICAL SYSTEM

### Subsection 05 (ROTAX ELECTRONIC REVERSE)

3. Check piston condition through the intake and exhaust ports.

**NOTE:** Look for scoring on piston skirts. Scored piston skirts or other mechanical problems resulting in excessive friction which may cause the RER to function erratically.

4. Also check the following:

- RER switch for intermittent operation, refer to *RER SWITCH CONTINUITY TEST* in this section
- Loose (intermittent) electrical connections
- Drive belt adjustment, refer to *DRIVE SYSTEM AND BRAKE* section
- ECM.

## PROCEDURES

### RER FUSE (600 HO E-TEC)

The RER circuit is protected by a 5 A fuse attached to the oil tank.

#### RER Fuse Location

The RER fuse is attached to the bottom of the oil tank.

To access fuse, open RH side panel. Refer to *BODY* section.




TYPICAL - MANUAL START MODEL ILLUSTRATED  
1. RER fuse

**NOTE:** The Manual Start Connector (jumper) can be seen attached to oil tank in previous illustration.

#### RER Fuse Inspection

Check if filament is melted. Replace as necessary.



1. Fuse
2. Check if melted

**NOTICE** Do not use a higher rated fuse as this can cause severe damage to electric components and/or a fire. If fuse has burnt out, the cause of the malfunction should be determined and corrected before restarting.

### RER SWITCH (500SS/600/800R)

#### RER Switch Signal Test with B.U.D.S.

Install the following items to supply power to the ECM for this test.

- T-HARNESS (P/N 529 035 869)
- 12 VOLT BATTERY SUPPLY CABLE (P/N 529 035 997)
- 12 volt battery.

**NOTE:** On electric start models, the 12 volt supply harness may be connected to the vehicle battery instead of an external battery.

1. Connect the vehicle to the latest B.U.D.S. software available from BOSSWeb. Refer to *COMMUNICATION TOOLS/B.U.D.S SOFTWARE* for proper connection instructions.
2. In B.U.D.S., select the **Read Data** button.
3. Select the **Monitoring** tab.
4. At the bottom LH corner of the **Monitoring** page, select the **ECM** tab.
5. Set engine STOP switch to STOP.
6. Press the START/RER button and look for the **START/RER Button** LED in the bottom field. It should turn ON, indicating START/RER switch, ECM and wiring are functioning normally.



TYPICAL  
1. Should turn ON (green)

## Section 05 ELECTRICAL SYSTEM

### Subsection 05 (ROTAX ELECTRONIC REVERSE)


If light turns on, test trigger coils and associated wiring. Refer to *IGNITION SYSTEM* section.

If light does not turn on, refer to *RER SWITCH CONTINUITY TEST* in this section.

#### RER Switch Continuity Test

Remove multifunction gauge. Refer to *BODY* section.


Disconnect the 13-pin HG connector (steering harness).



TYPICAL - HG CONNECTOR

Set the FLUKE 115 MULTIMETER (P/N 529 035 868) to  $\Omega$  selection and measure RER switch continuity as per following table.

SWITCH POSITION	HG CONNECTOR		RESISTANCE
Released	Pin 5 RED/GRAY	Pin 8 BEIGE	High value or infinite (OL)
Pressed and held			Continuity (0.2 $\Omega$ max.)



TYPICAL

If continuity test fails, remove the multifunction switch cover and check wires and connectors to START/RER switch.

If wires and connector are good, replace the multifunction switch.

#### RER Switch Input Voltage Test

If RER switch continuity tests were good, measure voltage on harness side of HG connector as follows.

##### Manual Start Models

Install the following items to supply power to the ECM for this test.

- T-HARNESS (P/N 529 035 869)
- 12 VOLT BATTERY SUPPLY CABLE (P/N 529 035 997)
- 12 volt battery.

Refer to *COMMUNICATION TOOLS AND B.U.D.S. SOFTWARE* subsection for proper connection details.

Install DESS key on post.

##### All Models

Set multimeter to Vdc and measure as per following table.

HG CONNECTOR		VOLTAGE
Pin 5 (RED/GRAY)	Chassis ground	12 Vdc



If voltage is good, carry out a *RER SWITCH SIGNAL CIRCUIT TEST*.

If voltage is not as specified, carry out a continuity test of the RED/GRAY power wire:

- On **manual start models**, ECM pin 34 to HG connector pin 5
- On **electric start models**, CF connector pin 3 to HG connector pin 5 (RED/GRAY power wire).



## Section 05 ELECTRICAL SYSTEM

### Subsection 05 (ROTAX ELECTRONIC REVERSE)

#### RER Switch Output Voltage Test

Measure switch voltage output from vehicle harness side of HG connector as per following table.

SWITCH POSITION	WIRES		RESISTANCE
Pressed and held	Pin 8 (BEIGE)	GROUND	Approximately 12 Vdc
Released	Pin 8 (BEIGE)	GROUND	Close to 0 Vdc

If test fails, replace switch.

#### RER Switch Control Circuit Test

1. Disconnect ECM connector.
2. Set multimeter to  $\Omega$  selection.
3. As you press and hold the RER switch, measure for continuity of the control circuit at the ECM connector as per following table.

RER SWITCH POSITION	ECM CONNECTOR		RESISTANCE
Pressed and held in	Pin 8 (BEIGE)	Pin 34 (RED/GRAY)	Close to 0 $\Omega$ continuity

If continuity test fails, carry out the following tests in this order:

- RER SWITCH CONTINUITY TEST
- RER SWITCH SIGNAL CIRCUIT TEST
- RER SWITCH INPUT VOLTAGE TEST.

Repair or replace affected wiring or connections.


#### RER Switch Signal Circuit Test

Disconnect ECM connector and test signal wire continuity between HG connector and ECM connector as follows.

ENGINE	HG CONNECTOR	ECM CONNECTOR	RESISTANCE
500SS/600/800R	Pin 8 (BEIGE)	Pin 8 (BEIGE)	Continuity (0.2 $\Omega$ max.)

If it tests good, try a new ECM.

If test fails, repair open circuit.



1. HG connector (vehicle harness side)  
2. ECM connector

#### RER SWITCH (600 HO E-TEC)

##### RER Switch Signal Test with B.U.D.S.

1. Connect vehicle to the latest B.U.D.S. software available from BOSSWeb. Refer to *COMMUNICATION TOOLS/B.U.D.S. SOFTWARE* for proper connection instructions.

Install the following items to supply power to the ECM for this test.

- T-HARNESS (P/N 529 035 869)
- 12 VOLT BATTERY SUPPLY CABLE (P/N 529 035 997)
- 12 volt battery.

**NOTE:** On electric start models, the 12 volt supply harness may be connected to the vehicle battery instead of an external battery.

2. In B.U.D.S., select the **Read Data** button.
3. Select the **Monitoring** tab.
4. At the bottom LH corner of the **Monitoring** page, select the **ECM** tab.
5. Set engine STOP switch to STOP.
6. Press vehicle START/RER button and look for the **START/RER Button LED** in the bottom field. It should come ON (turn green) indicating the START/RER switch, ECM and wiring are functioning properly.



**TYPICAL**  
1. Should turn ON (green)


If LED comes ON, test CPS. Refer to *E-TEC DIRECT INJECTION*.

If LED does not come on, test the START/RER switch.

**NOTE:** When the B.U.D.S. RER test is carried out with engine running, when reverse engages, the RER LED on the ECM Monitoring page and the reverse LED on the Cluster Monitoring page should both turn ON (green).

### RER Switch Continuity Test

1. Remove steering cover.
2. Disconnect the START/RER switch 3-pin (SB) connector.



TYPICAL — 3 PIN SB CONNECTOR

3. Using the FLUKE 115 MULTIMETER (P/N 529 035 868) set to  $\Omega$ , measure continuity of RER switch as per following table.

SWITCH POSITION	SB CONNECTOR		RESISTANCE
Released	Pin 1 (BK)	Pin 2 (RD)	Continuity (0.2 $\Omega$ max.)
		Pin 3 (WH)	High value or infinite (OL)
Pressed and held	Pin 1 (BK)	Pin 2 (RD)	High value or infinite (OL)
		Pin 3 (W)	Continuity (0.2 $\Omega$ max.)




START/RER SWITCH CONTINUITY TEST

If continuity test fails, replace switch.

If continuity test is good, reconnect SB connector.

4. Remove multifunction gauge, refer to *BODY* subsection.
5. Disconnect the 11-pin (HG) connector and the 8-pin (AC) connector.



TYPICAL


1. HG connector (11-pin)
2. AC connector (8-pin)

6. Test for continuity as per following table.

SWITCH POSITION	CONNECTORS		RESISTANCE
	11-pin (HG)	8-pin (AC)	
Released	Pin 1 (BK/BU)	Pin 3 (BE)	Continuity (0.2 $\Omega$ max.)
	Pin 6 (RD/BR)	Pin 3 (BE)	High value or infinite (OL)
Pressed and held	Pin 1 (BK/BU)	Pin 3 (BE)	High value or infinite (OL)
	Pin 6 (RD/BR)	Pin 3 (BE)	Continuity (0.2 $\Omega$ max.)

## Section 05 ELECTRICAL SYSTEM

### Subsection 05 (ROTAX ELECTRONIC REVERSE)



TYPICAL

If continuity test fails, repair steering harness between HG and SB connectors.

If continuity tests were good, measure voltage on vehicle harness side of HG connector as per *RER SWITCH INPUT VOLTAGE TEST*.

#### RER Switch Input Voltage Test

1. Install the following tools to supply power to the primary 12 Vdc circuits for this test:


- T-HARNESS (P/N 529 035 869)
- 12 VOLT BATTERY SUPPLY CABLE (P/N 529 035 997)
- 12 volt battery.

**NOTE:** On electric start models, the 12 volt supply harness may be connected to the vehicle battery instead of an external battery.

Refer to *COMMUNICATION TOOLS/B.U.D.S. SOFTWARE* for proper connection instructions.

2. Set multimeter to Vdc.
3. Measure voltage of battery used to power the vehicle.
4. Disconnect the HG connector and measure RER switch input voltage at the HG connector (vehicle harness side) as follows.

11-PIN (HG) CONNECTOR		VOLTAGE
Pin 6 (RD/GY)	Chassis ground	Battery voltage



TYPICAL

If RER switch input voltage is good, reconnect HG connector and carry out an *RER SWITCH OUTPUT VOLTAGE TEST* in this section.

If RER switch input voltage is not measured, test the following:

- RER fuse input voltage at contact "A".
- Continuity of the RD/GY power wire between the fuse contact "B" and HG connector pin 6.
- By-pass connector mounted on oil tank and circuit wiring (manual start models).

#### RER Switch Output Voltage Test

Measure RER switch voltage output by back-probing the AC connector from main harness side of steering connector as follows.

SWITCH POSITION	AC CONNECTOR		RESISTANCE
Released	Pin 3 (BE)	Chassis ground	Close to 0 Vdc
Pressed and held			Approximately 12 Vdc

If RER switch output voltage test failed, replace switch.


If RER switch output voltage test is good, carry out the *RER SWITCH CONTINUITY TEST TO ECM*.

#### RER Switch Continuity Test to ECM

1. Disconnect the AC connector and ECM J1A connector.
2. Test wire continuity between the 8-pin (AC) connector and the ECM connector as follows.

**Section 05 ELECTRICAL SYSTEM**  
Subsection 05 (ROTAX ELECTRONIC REVERSE)

AC CONNECTOR	ECM J1A CONNECTOR	RESISTANCE
Pin 3 (RD/GN)	Pin 28 (RD/GN)	Continuity (0.2 $\Omega$ max.)
Pin 3 (RD/GN)	Chassis ground	Infinite (OL)



*PIN-OUT — ECM CONNECTOR J1A*

If continuity test is good, try a new ECM.

If test fails, repair or replace wiring.

## BEEPER (REVERSE ALARM)

The reverse alarm (beeper) is integrated in the gauge cluster and is also used for emitting the vehicle beep codes. If the beeper does not function, replace the gauge.

To test it, start vehicle. You should hear the beeper on start up. If you do not hear the beeper on start up, check for fault codes and refer to *MONITORING SYSTEM/FAULT CODES* section.

Press the START/RER button to put the vehicle in reverse. You should hear slow long beeps advising you that you are in reverse.

If you hear 3 short beeps, the reverse selection failed. Try the procedure again.

# LIGHTS, GAUGE AND ACCESSORIES

## SERVICE TOOLS

Description	Part Number	Page
12 VOLTS BATTERY SUPPLY CABLE.....	529 035 997 .....	399-400
FLUKE 115 MULTIMETER .....	529 035 868 .....	413
FLUKE 115 MULTIMETER .....	529 035 868 .....	402
T-HARNESS.....	529 035 869 .....	399-400

## SERVICE TOOLS – OTHER SUPPLIER

Description	Part Number	Page
MULTILOCK - TERMINAL EXTRACTION TOOL.....	755430-2 .....	420

## GENERAL

**NOTE:** On applicable models, it is a good practice to check for fault codes using B.U.D.S. software as a first troubleshooting step. Refer to *MONITORING SYSTEM/FAULT CODES*.

**⚠ CAUTION** The charging system fuse should always be removed before carrying out any maintenance on the vehicle to prevent any unexpected electrical activation. Removal of this fuse isolates the battery from the vehicle electrical system, except for the starter relay input terminal.

### **⚠ WARNING**

Torque wrench tightening specifications must be strictly adhered to. Locking devices (e.g.: locking tabs, elastic stop nuts, self-locking fasteners, cotter pins, etc.) must be replaced with new ones.

### *600 HO E-TEC*

**NOTICE** The 12 Vdc primary circuit is not to be used to power accessory loads. All accessories are to be powered from the secondary 12 Vdc circuit.

## TROUBLESHOOTING

### LIGHTING AND ACCESSORIES SYSTEM TESTING

#### *500SS/600/800R*

All vehicle lights and accessories are powered from the accessories relay (R1) through one of two fuses, FC and FD.

When the engine reaches 800 RPM, the ECM will provide a ground to R1 which will close its contacts and power all vehicle lights and accessories.

Refer to *WIRING DIAGRAM* for circuit details.

To provide power to the lighting and accessories systems for testing, install the following items.

- T-HARNESS (P/N 529 035 869)
- 12 VOLTS BATTERY SUPPLY CABLE (P/N 529 035 997)
- 12 volts battery.

Refer to the *COMMUNICATION TOOLS AND B.U.D.S. SOFTWARE* subsection for proper connections.

**NOTE:** It is not necessary to connect the MPI-2 interface unless a test calls for a connection to B.U.D.S. software.

### *600 HO E-TEC*

All vehicle lights are powered from the primary 12 Vdc circuit. This circuit is powered from and controlled by the ECM when the engine reaches 800 RPM.

There are no relays or fuses outside the ECM to test or replace for the lights circuits. Refer to *CHARGING SYSTEM* for more information on testing the primary 12 Vdc circuits.

If a light does not come ON, carry out the following:

- Obtain access to the bulb and make sure it is not burnt.
- Test for input voltage to the bulb.
- Test for continuity of the ground circuit.
- Test the applicable control switch (brake switch, headlight switch).

## Section 05 ELECTRICAL SYSTEM

### Subsection 06 (LIGHTS, GAUGE AND ACCESSORIES)

All accessories such as heating devices and accessory outlets are powered from the secondary 12 Vdc system.

Refer to *WIRING DIAGRAM* for light circuit details.

To provide power to the lighting and accessories systems for testing, install the following items.

- T-HARNESS (P/N 529 035 869)
- 12 VOLTS BATTERY SUPPLY CABLE (P/N 529 035 997)
- 12 volts battery.

Refer to the *COMMUNICATION TOOLS AND B.U.D.S. SOFTWARE* subsection for proper connections.

**NOTE:** It is not necessary to connect the MPI-2 interface unless a test calls for a connection to B.U.D.S. software, or the accessory circuit to test is powered from the secondary 12 Vdc circuit.

Headlights should turn ON as soon as vehicle is connected as described in *COMMUNICATION TOOLS AND B.U.D.S. SOFTWARE*, or engine is started and running above 800 RPM.

The secondary 12 Vdc circuits (accessory circuits) come ON 2 seconds after the engine reaches 1900 RPM.

The secondary 12 Vdc circuits will also come ON when the vehicle is connected with the MPI-2 interface as described in *COMMUNICATION TOOLS AND B.U.D.S. SOFTWARE*.

The **accessory relay** is then activated using the button provided on the **ECM Activation** page. Refer to *ACCESSORY CIRCUIT TEST WITH B.U.D.S.*

**NOTE:** The accessories relay for the 600 HO E-TEC is internal to the ECM.

## ACCESSORY CIRCUIT TEST WITH B.U.D.S.

### 600 HO E-TEC

1. The accessory circuits can be powered for testing using the B.U.D.S. software.
2. Connect to the latest B.U.D.S. software applicable using the MPI-2 interface, refer to *COMMUNICATION TOOLS AND B.U.D.S. SOFTWARE* section.
3. In B.U.D.S., select **Read Data**.
4. Select the **Activation** tab.
5. At the bottom of the **Setting** page, select the **ECM** tab.

6. On the RH side of the page, select the **Accessory Relay** button.

12 Vdc power is now available for the following:

- 12 volt accessories connector
- Heated handle grips
- Heated throttle lever.


If the relay does not function, see procedure in this section.

## PROCEDURES

### FUSES

#### Fuse Inspection

Check if filament is melted. Replace as necessary.



1. Fuse
2. Check if melted

**NOTICE** Do not use a higher rated fuse as this can cause severe damage to electric components and/or a fire. If fuse has burnt out, the cause of the malfunction should be determined and corrected before restarting.

#### Fuse Location

All fuses except for the fuel level sensor fuse are located near the battery. The following illustrations depict the locations of the various fuses as in an electric start model. The fuse(s) applicable to the manual start models will be in the same locations.

**Section 05 ELECTRICAL SYSTEM**  
**Subsection 06 (LIGHTS, GAUGE AND ACCESSORIES)**

**500SS/600/800R**



**TYPICAL - FUSE LOCATIONS (ELECTRIC START MODEL)**

1. Starting fuse
2. Charging system fuse
3. Accessories fuse
4. Headlights fuse

**600 HO E-TEC**



**TYPICAL - FUSE LOCATIONS (ELECTRIC START MODEL)**

1. START/RER fuse (FB)
2. Charging fuse (FA)

**All Models**


**Fuel Level Sensor Fuse**

The fuel level sensor circuit is protected by an in line fuse located near the sensor. It is an integral part of the wiring that comes with the sensor assembly.

**NOTE:** If you have a faulty fuel level indication, or a low fuel level warning light continuously ON even on a full fuel tank, test the fuse for continuity and ensure the fuse and its holder make good contact. Also check to ensure the fuse connector is properly connected.

To access the fuel level sensor fuse, remove the primary silencer from the engine air inlet system.

**NOTE:** In the following illustration, the fuel tank was moved back for access and clarity of illustration.



1. Fuel level sensor
2. In-line fuse
3. Connector
4. Corrugated flex conduit

**Fuse Description**

**500SS/600/800R**

MODEL	FUSE	DESCRIPTION	LOCATION
Manual start	15 A	Headlight (FD)	Attached to oil tank
	20 A	Gauge and Accessories (FC)	
Electric start	5 A	START/RER (FB)	LH side of battery support
	15 A	Headlight (FD)	Attached to oil tank
	15 A	Gauge and Accessories (FC)	
	30 A	Charging system (FA)	LH side of battery support
All	0.25 A	Fuel level sensor (in-line type)	Behind primary air inlet silencer

**600 HO E-TEC**

MODEL	FUSE	DESCRIPTION	LOCATION
Electric start	30 A	Charging system (FA)	LH side of battery support
All	5 A	START/RER (FB)	LH side of battery support
	0.25 A	Fuel level sensor (in-line type)	Behind primary air inlet silencer

## Section 05 ELECTRICAL SYSTEM

### Subsection 06 (LIGHTS, GAUGE AND ACCESSORIES)

#### RELAY R1 (LIGHTS AND ACCESSORIES)

**NOTE:** On 600 HO E-TEC models, the accessories relay is incorporated within the ECM. See *ACCESSORY CIRCUIT TEST WITH B.U.D.S.* in this section.


500SS/600/800R

#### R1 Description

The lights and accessories relay (R1) is a plug in relay type attached to the vehicle main wire harness by its harness connector, and a locking tie.

To access R1, remove the following:

1. Left side panel
2. Drive belt guard
3. Primary silencer on the engine air inlet system.



TYPICAL - ACCESSORIES RELAY LOCATION

1. Lights and accessories relay (R1)

2. R1 locking tie

3. Throttle bodies

It receives power to its input contact (pin 30) and activation coil (pin 85) directly from the voltage regulator/rectifier when the engine is running. The ECM (pin 28) provides the ground signal to the coil (pin 86) when the engine reaches approximately 800 RPM.

Once closed, it supplies power to the lights and accessories:

- Headlights
- High beams indicator signal
- Tail/brake light
- Handle grips and throttle lever heaters
- 12 volt accessory connector.

#### R1 Input Voltage Test

1. Cut locking-tie securing relay to harness.

2. Remove R1 relay from its connector.

3. Start engine and test for power at the connector as follows.

RELAY R1	PROBE	VOLTAGE
Coil input (pin 85)	RD/BU and OR/WH	10.5 to 13.5 Vdc
	RD/BU and ground	
Contact input (pin 30)	RD/BU and ground	

**NOTE:** Engine idling (1500 to 1600 RPM).

If R1 input voltages are good, carry out a *RELAY CONTINUITY TEST*. See procedure in this section.

If there is no voltage measured to the OR-ANGE/WHITE wire, test continuity of ground signal circuit from ECM (ORANGE/WHITE wire at relay connector to ECM connector pin 28).

If R1 input voltages are not as specified, test wiring/connections from voltage regulator/rectifier. Refer to *WIRING DIAGRAM* for circuit details.

#### R1 Continuity Test

1. Using the FLUKE 115 MULTIMETER (P/N 529 035 868), select the beeper position.




2. Position the RED probe on the terminal 30 and the BLACK probe on the terminal 87a.



## Section 05 ELECTRICAL SYSTEM


### Subsection 06 (LIGHTS, GAUGE AND ACCESSORIES)



1. Terminal 30
2. Terminal 87a

A continuous signal should be audible. If not, replace the relay.

3. If a signal is audible, apply 12 volts on terminals 85 and 86 then place the RED probe on terminal 30 and the BLACK on the terminal 87.



1. Terminal 30
2. Terminal 87
3. Terminal 85
4. Terminal 86

The audible signal should be continuous. If not, replace the relay.

## HEADLIGHTS

### Headlight Bulb Removal

If a headlight bulb is burnt, proceed as follows.

1. Remove multifunction gauge, see procedure in this section.
2. Remove bulb connector.
3. Remove top and center portion of rubber boot from headlight assembly.



1. Remove headlight connector
2. Remove rubber boot

**NOTE:** It is not necessary to fully remove rubber boot.



4. Press both sides of the bulb holder (spring clip) inwards at the same time, and pull it out to release it from the bulb support.




**SQUEEZE INWARDS AND PULL OUT**

## Section 05 ELECTRICAL SYSTEM

### Subsection 06 (LIGHTS, GAUGE AND ACCESSORIES)

5. Pull bulb from headlight assembly.



PULL TO REMOVE BULB


### Headlight Bulb Installation

**NOTICE** Never touch glass portion of a halogen bulb with bare fingers, it shortens its operating life. If glass is touched, clean it with isopropyl alcohol which will not leave a film on the bulb.

1. Insert bulb in light assembly.


**NOTE:** Widest alignment tab on bulb should be at top of assembly.

2. Insert top of bulb holder (spring clip) as you squeeze the two sides inwards. Release bulb holder so that it locks in the grooves on either side of headlight assembly.



1. Wide bulb tab  
2. bulb holder locked

3. Install rubber boot. Ensure cover is properly inserted in groove provided in the headlight assembly, and around the base of the bulb.



1. Insert around bulb  
2. Insert in groove provided

4. Install light connector.

5. Always test light operation after bulb replacement.

6. Install gauge, see procedure in this section.

### Headlight Input Voltage Test

If headlight(s) does not function, proceed as follows.

1. Remove multifunction gauge, see procedure in this section.

2. Disconnect headlight connector(s).


3. Apply electrical power to the headlights for testing. Refer to *LIGHTING AND ACCESSORIES SYSTEM TESTING* in this section for proper procedure.

4. Read voltage at headlight connector as follows.

SWITCH POSITION	WIRE COLOR (HEADLIGHT CONNECTOR)		VOLTAGE
LO beam	GY/VI	BK	Battery voltage (Vdc)
HI beam	GY	BK	


## Section 05 ELECTRICAL SYSTEM

### Subsection 06 (LIGHTS, GAUGE AND ACCESSORIES)



If voltage is inadequate, carry out the following to find the source of the problem:

- Check applicable fuse. Refer to *FUSES* in this section.
- Test relay R1 (500SS/600/800R).
- Test headlights dimmer switch from the HG connector under multifunction gauge, refer to *WIRING DIAGRAM* for circuit details.
- Test wiring harness and connectors.
- Test voltage regulator/rectifier. Refer to *CHARGING SYSTEM*.



**TYPICAL - PREMIUM GAUGE MODEL**


- 1. AC connector
- 2. HG connector

**NOTE:** When testing headlights dimmer switch from HG connector, if an open circuit is found through the switch, remove the screws retaining the multifunction switch, disconnect the LB connector and test for continuity of switch and wiring separately. Dimmer switch is replaced with multifunction switch assembly.

### Headlight Beam Aiming


Beam aiming is correct when center of high beam is 25 mm (1 in) below the headlight horizontal center line, scribed on a test surface, 381 cm (12 ft 6 in) away.

1. Place the vehicle on a flat surface perpendicular to test surface (wall or screen) and 381 cm (12 ft 6 in) away from it.
2. Ask rider to sit rider on, or apply equivalent weight on the vehicle.
3. Select **high beam**.
4. Measure headlight center distance from ground. Scribe a line at this height on test surface (wall or screen). Light beam center should be 25 mm (1 in) below scribed line.



#### TYPICAL

- 1. Headlight center line
- A. 381 cm (12 ft 6 in)
- B. 25 mm (1 in) below center line




- 1. Headlight horizontal
- 2. Light beam (high beam) (projected on the wall)
- 3. Light beam center
- A. 25 mm (1 in)

### Beam Aiming Adjustment

1. Remove multifunction gauge.
2. Turn knob on light assembly to adjust beam height.

## Section 05 ELECTRICAL SYSTEM

### Subsection 06 (LIGHTS, GAUGE AND ACCESSORIES)



TYPICAL

1. Beam height adjustment knobs

## TAILLIGHT


### Taillight Bulb Replacement

1. Remove taillight lens by carefully pulling on lens at both ends.



CAREFULLY PULL OUT AT CORNERS


**NOTICE** Taillight lens is held in place by two plastic pins inserted in rubber grommets. If lens is forced too far sideways when removing, the lens mounting pins may break and lens will have to be replaced. Do not pull lens out too far to avoid damaging wiring.



1. Lens retaining pins  
2. Retaining grommets  
3. Light wire harness

2. Rotate bulb holder counterclockwise to remove it from lens.
3. Push in and rotate bulb counterclockwise to remove it from its socket.
4. Install the new bulb by pushing it in the socket and turning it clockwise.

**NOTE:** Note position of bulb locking pins on its base, and bulb holder alignment key to lens.



1. Bulb locking pins  
2. Bulb holder alignment key

### Taillight Assembly Replacement

If the taillight lens is broken, see the *TAILLIGHT BULB REPLACEMENT* procedure in this section.

The taillight housing is part of the snow guard. If it needs to be replaced, refer to *FRAME* section.

If the light bulb holder (socket) or wiring need to be replaced, you will have to lift up the rear of the fuel tank to access and disconnect the harness connector, refer to *FUEL TANK AND FUEL PUMP* section.

## GAUGE

### Gauge Description


Two different type gauges which provide all indications in a single unit are used. An **analog/digital gauge (standard gauge)** and a **multifunction analog/digital gauge (premium gauge)**.

The premium gauge provides more functions and display features.

Both units can be set to indicate in metric or imperial units.

## Section 05 ELECTRICAL SYSTEM


### Subsection 06 (LIGHTS, GAUGE AND ACCESSORIES)



mmc2008-003-013\_g

**ANALOG/DIGITAL GAUGE (STANDARD)**

1. Speedometer
2. Tachometer (RPM)
3. Gauge Digital Display
4. Gauge Pilot Lamps
5. Gauge SET "S" button




mmc2009-003-013\_d

**SET "S" BUTTON**

#### *Multifunction Analog/Digital Gauge (Premium)*

Premium gauge is equipped with MODE and SET buttons at the top of the indicator.



mmc2007-009-066\_s

**MULTIFUNCTION ANALOG/DIGITAL GAUGE (PREMIUM)**


1. Speedometer
2. Tachometer (RPM)
3. Gauge Digital Display
4. Gauge Multifunction Digital Display
5. Gauge Pilot Lamps
6. Gauge MODE "M" button
7. Gauge SET "S" button

The premium gauge is also used to control 9 temperature settings for the heated hand grips and the heated throttle lever.

#### **Mode and Set Buttons**

##### *Analog/Digital Gauge*

The standard gauge is equipped with a SET button only.



mmc2007-009-066\_y

**PREMIUM GAUGE**

1. MODE button
2. SET button

These buttons allow you to toggle through the different functions and settings of the indicator.


The vehicles that are factory equipped with the premium gauge also come with a remote M/S button on the LH multifunction switch. It can be used instead of the buttons on the gauge simply by pressing the "M" for MODE and "S" for SET.

#### **Clock Activation (Premium Gauge)**

The gauge has an internal clock that can display the time of day in the lower digital display (when selected). This clock requires power from the vehicle battery to maintain the proper time of day.

## Section 05 ELECTRICAL SYSTEM


### Subsection 06 (LIGHTS, GAUGE AND ACCESSORIES)



1. Clock displayed

Without battery power, this clock resets every time the vehicle is shut down, then restarted. It is then only used as a timer.

1. To activate the clock function in B.U.D.S., choose the **Setting** tab.




1. Choose **Setting** tab

2. At the bottom LH corner of the **Setting** page, choose the **Cluster** tab.



1. Click here to select **Cluster** page

3. At the bottom of the **Cluster** page, choose **Installed** in the **Real time clock** field if the vehicle is equipped with a battery. Choose **Not installed** if the vehicle does not have a battery.



REAL TIME CLOCK SELECTION FIELD

### Changing Gauge Units of Measurement

The gauges are factory preset to indicate in metric units and can be changed using the B.U.D.S. software.

1. To change the gauge units of measurement in B.U.D.S., first choose the **Setting** tab.
2. At the bottom LH corner of the **Setting** page, choose the **Cluster** tab.



1. Click here to select **Cluster** page

3. At the bottom of the **Cluster** page, select **Imperial** or **Metric** in the **Cluster Units** field.



CLUSTER UNITS FIELD

**NOTE:** Speedometer, odometer and trip meter will have their units (kilometer or miles) changed all together.

### Displaying "P" Codes (Premium Gauge Only)

1. To activate P CODE mode, push and hold the "M" button for 2 seconds.

## Section 05 ELECTRICAL SYSTEM

### Subsection 06 (LIGHTS, GAUGE AND ACCESSORIES)

2. As you hold the "M" button, quickly turn ON and OFF the high beams a few times. The gauge should enter P CODE mode.
3. While in P CODE mode, use the "M" or "S" button to scroll over available failure codes.
4. Push and hold the "M" button to exit P CODE mode.


A NO ACTIVE P CODE message is displayed if there are no P CODES in memory.

### Gauge Self Test

On ECM wake-up, the gauge will perform a self-test. All indications will come ON. You will have a few seconds to ensure the indications (LEDs and LCDs) are functioning correctly.


### Gauge Test With B.U.D.S.

1. In B.U.D.S., choose the Activation tab.



1. Activation tab

2. On the bottom of the activation page on the RH side, click the arrow next to the window that says Page 1 and select Page 2.



1. Press here to select Page 2

3. On Page 2, select the WOW Test button. All indications will come ON and stay ON allowing the time required to verify each indication.



1. Select WOW Test button

**NOTE:** The WOW Test only test the gauges LEDs and LCDs. It does not test the actual circuit functions related to each indication.

### Gauge Power Input Test (Main 12 Vdc)

If the gauge does not come on when the engine is started, carry out the following test.

1. Remove multifunction gauge.
2. Disconnect the gauge connector.
3. Set multimeter to Vdc.
4. Start engine.
5. Measure voltage as per following table.

MODEL	GAUGE CONNECTOR	VOLTAGE
500SS/600/800R	Pin 8 (RD/YL)	Over 12 Vdc
E-TEC	Pin 8 (RD/OR)	Approximately 14.75 Vdc

6. If gauge main power input test was as specified, carry out the gauge *GROUND CIRCUIT CONTINUITY TEST*.
7. If no voltage was read, test wiring continuity. Refer to *WIRING DIAGRAM* for details.

**NOTE:** On 500SS/600/800R models, the gauge receives power from the 20 A accessories fuse FC. This fuse also provides power to the tail light, brake light and heaters.

**NOTE:** On 600 HO E-TEC models, the gauge receives its main power input directly from the primary 12 Vdc bus. There are no fuses or relays to test, only wiring and connectors.

### Gauge Ground Circuit Continuity Test

1. Set multimeter to  $\Omega$  selection.
2. Measure for continuity of gauge ground wire as per following table.

## Section 05 ELECTRICAL SYSTEM

### Subsection 06 (LIGHTS, GAUGE AND ACCESSORIES)

GAUGE CONNECTOR	RESISTANCE
Pin 11 (BK)	Close to 0 $\Omega$

If gauge power input test and ground circuit continuity tests are good, replace gauge.

#### Clock 12 Vdc Input Test (Premium Gauge)

If the clock function in the premium gauge does not hold the proper time of day when the engine is not running, carry out the following test.

**NOTE:** The clock receives 12 Vdc from the battery through the 5 A START/RER fuse in order to maintain correct time when the engine is not running.

1. Remove multifunction gauge.
2. Disconnect the gauge connector.
3. Set multimeter to Vdc.
4. Measure voltage as per following table.


MODEL	GAUGE CONNECTOR	VOLTAGE
All	Pin 9 (RD/GR)	Battery voltage

**NOTE:** If the START/RER fuse was open, the electrical start and RER functions would not be operational.

5. If there is no voltage read, test input wire continuity. Refer to *WIRING DIAGRAM* for circuit details.

#### Gauge Removal

1. Insert a small screwdriver in one of the rectangular slots at top of gauge.
2. As you gently press down on the screwdriver to release multifunction gauge locking tab, pull out and hold gauge in position.
3. Insert screwdriver in second hole and press to release other tab.



1. Locking tabs

4. Gently pull multifunction gauge from gauge support.



5. Press on connector locking tab and pull connector off gauge.
6. Store gauge in a secure area to prevent it from being damaged.

#### Gauge Installation

1. Carefully align and install gauge connector, pressing it in until connector lock engages.
2. Insert bottom of gauge in gauge holder.
3. Press top of gauge in holder until you feel locking tabs engage in holder.
4. Start vehicle engine and test gauge functions.

**NOTE:** If a new gauge is installed, refer to *GAUGE TO ECM MATCHING*.

#### Gauge to ECM Matching

**NOTE:** If the gauge is replaced, the V.I.N. (Vehicle Identification Number) and the vehicle model number must be entered in the gauge memory so they match those stored in the vehicle ECM.



## Section 05 ELECTRICAL SYSTEM


### Subsection 06 (LIGHTS, GAUGE AND ACCESSORIES)

If the numbers stored in the gauge do not match those stored in the ECM, the engine will start but the new gauge will stop operating within 10 seconds after the engine is started. The indicator needles will function normally but the LCD display will remain blank and the DESS LED will be turned ON. This is a gauge anti theft feature.


1. To write the V.I.N. number and model number into the gauge, connect to the latest B.U.D.S. software applicable to the 600 HO E-TEC from BOSSWeb. Refer to the *COMMUNICATION TOOLS AND B.U.D.S. SOFTWARE* section.
2. Follow the instructions in the referenced section and in the software.
3. Once connected and activated, select the **Read Data** button. You will see a message similar to the following illustration.



4. Select **Yes** in the displayed window.




The following window illustrates that the V.I.N. number or model number in the ECM and cluster are not the same.




1. Numbers stored in ECM
2. No numbers stored in new cluster

5. Select each of the arrows indicated in the following illustration to copy the V.I.N. and model numbers from the ECM to the cluster.



1. Select each arrow button indicated

Note how the numbers in the **Cluster** field now matches those in the **ECM** field.




1. Numbers in Cluster field now match those in the ECM field

6. Select **OK** to continue.


## Section 05 ELECTRICAL SYSTEM

### Subsection 06 (LIGHTS, GAUGE AND ACCESSORIES)



7. Once the gauge has been matched to the ECM, you will need to set the units of measurement, imperial or metric. See procedures in this section.
8. Ensure the gauge functions properly and that all settings and indications are within parameters.
9. Be sure to set the clock function according to gauge and vehicle type, refer to *CLOCK ACTIVATION (PREMIUM GAUGE)* in this section.
10. Shut down vehicle and disconnect the communication tools.


## REMOTE MODE AND SET BUTTON



**REMOTE M/S BUTTON**  
1. MODE selection "M"  
2. SET selection "S"


## Remote M/S Button Testing with B.U.D.S.

Using the B.U.D.S. software, select the Monitoring tab.




### 1. Monitoring tab

On the lower LH side of the Monitoring page, choose the Cluster tab.



### 1. Press here to select Cluster page

Alternately press on the "M" and "S" and look for applicable indicator light in the Switch inputs field to turn GREEN.



### 1. Indicator lights


If the indicator lights come ON in B.U.D.S., the remote M/S button is functioning correctly.

**Section 05 ELECTRICAL SYSTEM**  
**Subsection 06 (LIGHTS, GAUGE AND ACCESSORIES)**

If the indicator lights do not come ON, carry out the following *REMOTE M/S BUTTON TESTING* procedure.

### Remote M/S Button Continuity Test

1. If using the M/S button does not affect the indication, try using the buttons on the gauge. If they function, the remote M/S button circuit may be open.
2. Remove the gauge.
3. Disconnect the HG and the AC connectors.



**TYPICAL**  
 1. AC connector  
 2. HG connector

4. Using a multimeter set to  $\Omega$ , carry out the following continuity test.



800R REMOTE M/S BUTTON TESTING			
SWITCH SELECTION	AC CONNECTOR WIRE	HG CONNECTOR WIRE	RESISTANCE
Centered	Pin 5 (YL/BR)	Pin 1 (BK)	Infinite $\Omega$
	Pin 6 (YL/GN)		
"M"	Pin 5 (YL/BR)	Pin 1 (BK)	Close to 0 $\Omega$
"S"	Pin 6 (YL/GN)		

600 HO E-TEC REMOTE M/S BUTTON TESTING			
SWITCH SELECTION	AC CONNECTOR WIRE	HG CONNECTOR WIRE	RESISTANCE
Centered	Pin 6 (YL/BR)	Pin 1 (BK/BU)	Infinite $\Omega$
	Pin 7 (YL/GN)		
"M"	Pin 6 (YL/BR)	Pin 1 (BK/BU)	Close to 0 $\Omega$
"S"	Pin 7 (YL/GN)		


If you do obtain the values as specified, repair or replace switch, wiring and connections.

### SPEED SENSOR

The speed sensor is mounted in the chain case cover. It is sealed in the cover and is replaced with the cover.

#### Speed Sensor Static Test

1. Locate speed sensor connector.



1. Chain case cover  
 2. Speed sensor  
 3. Speed sensor connector

2. Lift and support back end of vehicle so that the track is completely off the ground.
3. Start engine and let it run at idle speed so that the driven pulley does not engage and track does not rotate.
4. To perform verifications, use the FLUKE 115 MULTIMETER (P/N 529 035 868) with Fluke TP88 rigid back probe pins or equivalent.
5. With multimeter set to Vdc, back-probe connector and read sensor supply voltage as follows.

## Section 05 ELECTRICAL SYSTEM

### Subsection 06 (LIGHTS, GAUGE AND ACCESSORIES)

SPEED SENSOR CONNECTOR (SENSOR SIDE)		VOLTAGE
RD	BK	Approximately 12 Vdc



SENSOR INPUT VOLTAGE TEST

If you do not have proper supply voltage, shut down engine and carry out a continuity test of wiring from sensor to gauge. Refer to *WIRING DIAGRAM* for circuit detail.


If supply voltage is good, measure the signal voltage as follows.

#### **⚠ WARNING**

Before accelerating engine to rotate track, ensure track is free of particles which could be thrown out while track is rotating. Keep hands, tools, feet and clothing clear of track. Ensure no one is standing in close proximity to the vehicle. Never rotate at high speed.

6. Slowly accelerate engine so that driven pulley engages and track rotates **SLOWLY**.
7. Back-probe connector between GREEN and BLACK wires, read voltage.


ROTATE TRACK	SPEED SENSOR CONNECTOR (SENSOR SIDE)		VOLTAGE
	GN	BK	Alternate 12 Vdc and 0 Vdc



SENSOR SIGNAL VOLTAGE TEST

The signal voltage should alternate between approximately 12 Vdc and 0 Vdc.

**NOTE:** Since a pulsating voltage is measured, the numeric display will continuously change. The analog display may be easier to follow.



TYPICAL

1. Analog display

If voltage is as specified, repair or replace wiring and connectors between sensor and gauge.

If wiring and connectors are good, try a new gauge.

If signal voltage is not as specified, replace the speed sensor.

**NOTE:** To replace the speed sensor, the chain case cover must be replaced. Refer to *CHAIN CASE* section.

## FUEL LEVEL SENSOR

A float type fuel level sensor equipped with an in-line fuse (0.25 A) is used to provide a signal to the gauge for indication. Refer to *FUEL TANK AND FUEL PUMP* for sensor testing.

## HEATED THROTTLE LEVER

### System Description


There are two types of throttle lever heating systems used on the REV-XP platform.

The type of system used is determined by the gauge package installed at the factory, standard gauge or premium gauge.

#### *Models with Standard Gauge*

On vehicles equipped with a "Standard" gauge, the throttle lever heater is controlled by a toggle switch on the LH multifunction switch assembly.

The switch allows you to select **High**, center **Off**, and **Low** heat settings. The switch button will remain in the selected position until another selection is made.




1. Throttle lever heat switch
2. High
3. Low
4. Heat OFF (center position)

#### *Models with Premium Gauge*

On vehicles factory equipped with a "Premium" gauge, the throttle lever heat is controlled through the gauge.

The heated throttle lever will not be powered until the engine is at or above 2000 RPM.


A three position switch on the LH multifunction switch assembly allows selection of 9 heat levels, which are displayed in the indicator.



**THROTTLE LEVER HEAT INDICATOR**

1. Decrease heat
2. Increase heat

The switch selection sends a signal to the premium gauge to increase or decrease heat.



1. Throttle lever heat switch
2. Increase heat
3. Decrease heat

The gauge then applies the appropriate amount of current to the heater according to the selection.

To turn OFF the heaters, select heat down until there is no more indication on the bar graph.


When released, the switch springs back to the center neutral position.

### Heat Selector Switch Testing with B.U.D.S. (Premium Gauge)

1. Using the B.U.D.S. software, select the Monitoring tab.

## Section 05 ELECTRICAL SYSTEM

### Subsection 06 (LIGHTS, GAUGE AND ACCESSORIES)




1. *Monitoring tab*

- On the lower LH side of the Monitoring page, choose the Cluster tab.



1. *Press here to select Cluster page.*

- Press on the lever heat selector switch to alternately increase or decrease heat.
- In B.U.D.S., look for the applicable indicator light in the **Switch inputs** field to turn GREEN (Thumb Up or Thumb Dn). If they do, the heat selector switch for the throttle lever is functioning correctly.



1. *Indicator lights, throttle lever heat selection*

- If the selector switch and the heater test good, replace the gauge.

### Lever Heating Element Testing

- Disconnect the RH steering connectors located



mmv2006-038-003\_3

TYPICAL - 600 HO SDI MODEL SHOWN

- Carry out a resistance check of the heating elements as follows.

STANDARD GAUGE		
INTENSITY	HEATER WIRE	RESISTANCE @ 20°C (68°F)
LOW	BR/YL	5.7 to 18.5 Ω
HIGH	BR	
	YL/BK	1.7 to 4.2 Ω

PREMIUM GAUGE		
HEATER WIRE		RESISTANCE @ 20°C (68°F)
BR	BK/YL	1.7 to 4.2 Ω

If readings are out of specifications, replace throttle lever.

If heating element readings are within specifications, carry out a switch continuity test. Refer to *WIRING DIAGRAM* for wiring and connector details.

- Reconnect connectors.

## HEATED HANDLEBAR GRIPS

### System Description


There are two types of grip heating systems used on the REV-XP platform.

The type of system used is determined by the gauge package installed at the factory, standard gauge or premium gauge.

### Models with Standard Gauge

On vehicles equipped with a "Standard" gauge, the grip heater is controlled by a toggle switch on the LH multifunction switch assembly.

**Section 05 ELECTRICAL SYSTEM**  
**Subsection 06 (LIGHTS, GAUGE AND ACCESSORIES)**



1. Grip heat control switch
2. High
3. Low
4. Heat OFF (center position)


The switch allows you to select **High**, center **Off**, and **Low** heat settings. The switch button will remain in the selected position until another selection is made.

**Models with Premium Gauge**

On vehicles factory equipped with a "Premium" gauge, the grip heat is controlled through the gauge.


The heated hand grips will not be powered until the engine is at or above 2000 RPM.

A three position switch on the LH multifunction switch assembly allows selection of 9 heat levels, which are displayed in the indicator.



1. Decrease heat
2. Increase heat

The switch selection sends a signal to the premium gauge to increase or decrease heat.



1. Grip heat control switch
2. Increase heat
3. Decrease heat


The gauge then applies the appropriate amount of current to the heater according to the selection.

To turn **OFF** the heaters, select heat down until there is no more indication on the bar graph.

When released, the switch springs back to the center neutral position.

**Heat Selector Switch Testing with B.U.D.S. (Premium Gauge)**

1. Using the B.U.D.S. software, select the **Monitoring** tab.




1. **Monitoring** tab

2. On the lower LH side of the Monitoring page, choose the **Cluster** tab.

## Section 05 ELECTRICAL SYSTEM


### Subsection 06 (LIGHTS, GAUGE AND ACCESSORIES)



1. Press here to select Cluster page

3. Press on the hand grip selector switch to alternately increase or decrease heat.

4. In B.U.D.S., look for the applicable indicator light in the **Switch inputs** box to turn GREEN (Handle Up or Handle Dn). If they do, the heat selector switch for the hand grips is functioning correctly.



1. Indicator lights, grip heat selection


If the indicator lights do not come ON in B.U.D.S., carry out the same test with the thumb heat and the remote mode (M) and set (S) switches. If the indicator lights do not come ON for these other two switches, test continuity of the switch ground wire circuit. Refer to the *WIRING DIAGRAM* for circuit details.

If the selector switch, wiring and the heaters test good, replace the gauge.

### Grip Heating Element Testing

If you cannot feel the temperature increase of a hand grip heating element, carry out the following steps.

1. Disconnect the two steering connectors located under the steering cover.



TYPICAL - 600 HO SDI MODEL SHOWN

1. LH steering connector  
2. RH steering connector

2. Test heating elements on either side as per following specifications.

#### INTEGRATED HEATERS (STANDARD GAUGE)

INTENSITY	HEATER WIRE		RESISTANCE @ 20°C (68°F)
LOW	OR/VI	BK	15.5 to 19. Ω
HIGH	OR	BK	7.74 to 9.5 Ω

#### INTEGRATED HEATERS (PREMIUM GAUGE)

HEATER WIRE		RESISTANCE @ 20°C (68°F)
OR	BK	7.7 to 9.5 Ω

#### 20 WATT ADHESIVE FILM HEATERS (STANDARD GAUGE)

INTENSITY	HEATER WIRE		RESISTANCE @ 20°C (68°F)
LOW	OR/VI	BK	17 to 21 Ω
HIGH	OR	BK	8.5 to 10.5 Ω

#### 20 WATT ADHESIVE FILM HEATERS (PREMIUM GAUGE)

HEATER WIRE		RESISTANCE @ 20°C (68°F)
OR	BK	8.5 to 10.5 Ω



**Section 05 ELECTRICAL SYSTEM**  
Subsection 06 (LIGHTS, GAUGE AND ACCESSORIES)

32 WATT ALUMINUM HANDLEBAR HEATERS (STANDARD GAUGE)			
INTENSITY	HEATER WIRE		RESISTANCE @ 20°C (68°F)
LOW	OR/VI	BK	10.7 to 13.1 Ω
HIGH	OR	BK	5.3 to 6.6 Ω

32 WATT ALUMINUM HANDLEBAR HEATERS (PREMIUM GAUGE)		
HEATER WIRE		RESISTANCE @ 20°C (68°F)
OR	BK	5.3 to 6.6 Ω

- If readings are out of specifications, replace applicable handle grip heating element.
- If heating element readings are within specifications, carry out a switch continuity test. Refer to *WIRING DIAGRAM* for wiring and connector details.
- Reconnect connectors.

### Heater Element Removal

**NOTICE** Heater wire routing may vary significantly due to different type handlebars and vehicles. Its highly important to take note of exact positioning of grip heaters, locking ties, and wire routing before removing them from the handlebars. Failure to properly route wires may lead to equipment damage or failure.

#### *Models with Integrated Heaters*


On models with heaters integrated within the rubber hand grip, refer to the *STEERING SYSTEM* section for removal procedures.



**TYPICAL - LH SIDE**  
1. Grip with integrated heater element  
2. Heater wire

#### *Models with Adhesive Film Heaters (Steel Handlebar)*

This model heater is used on vehicles with a painted steel handlebar.



**TYPICAL - LH SIDE**  
1. Hand grip with adhesive film heater  
2. Heater wire

To remove this type heater, follow the instructions in the *MODELS WITH ADHESIVE FILM HEATERS (ALUMINUM HANDLEBARS)* procedure.

#### *Models with Adhesive Film Heaters (Aluminum Handlebars)*

- Remove the following items as applicable, refer to *STEERING SYSTEM* section for details.
  - Steering cover
  - Rubber hand grip
  - Multifunction switch cover.
- Disconnect the LH or RH steering connectors under the steering cover (as applicable).




**TYPICAL - STEERING CONNECTORS**

- Open the cover on the back of the connector housing using a small screwdriver or a suitable tool.

## Section 05 ELECTRICAL SYSTEM

### Subsection 06 (LIGHTS, GAUGE AND ACCESSORIES)




mbg2008-006-006\_b

#### TYPICAL

1. Connector housing cover locks (one each side)

4. Using an appropriate tool such as the MULTILOCK - TERMINAL EXTRACTION TOOL (P/N 755430-2), unlock the heater wire terminals and push them out of the connector housing.



mbg2008-009-008\_b

#### TYPICAL - UNLOCKING CONNECTOR PIN (FRONT SIDE)

1. Pin removal tool inserted above pin

**NOTE:** Terminals are unlocked and pushed out from the front (pin side) of the connector housing.

**NOTICE** Be sure to take note of exact positioning of grip heaters, locking ties, and wire routing before removing them from the handlebars.

5. Cut locking ties securing heater wires to handlebars.
6. Pull wires from harness protective sheath, multifunction switch housing or throttle lever housing.
7. Cut and remove black electrical tape from heater element and remove heater from cork insulator.



mbg2008-009-011\_b

#### TYPICAL - LH HEATER

1. Electrical tape (4 places)
2. Heater element


8. If damaged, remove cork insulator from handlebar and clean all adhesive residue from the handlebar.

## Heater Element Installation

### Models with Integrated Heaters

On models with heaters integrated within the rubber hand grip, refer to the *STEERING SYSTEM* section for installation procedures.

**NOTE:** When installing the hand grips with integrated heaters, be sure to position them with the heater wire horizontally at the front of the handlebar for proper routing, both sides.




mrr2009-080-004\_a

#### TYPICAL - LH HEATER

1. Grip with integrated heater element
2. Heater wire front horizontal position

## Section 05 ELECTRICAL SYSTEM

### Subsection 06 (LIGHTS, GAUGE AND ACCESSORIES)



#### TYPICAL - RH HEATER

1. Throttle lever housing
2. Heater wire front horizontal position
3. Throttle lever heater wire
4. Locking tie

#### Models with Adhesive Film Heaters (Steel Handlebar)

To install this type heater, follow the instructions in the *MODELS WITH ADHESIVE FILM HEATERS (ALUMINUM HANDLEBARS)* procedure.

However, pay attention to the following.

- Reference line for locating inside edge of heater shall be at 129 mm (5 in) from the end of the handlebar. This will leave 14 mm (1/2 in) not covered by the heater at the end of the bar.
- Cork insulators shall be applied centered on top of the handlebar so that the ends meet to form the joint under the handlebar.
- LH heater shall be applied so that its wiring is in front of the handlebar to ensure proper routing through the multifunction switch housing.
- RH heater shall be applied so that its wiring is in back of the handlebar to ensure proper routing through the throttle lever housing.

**NOTE:** Heater wire is routed through multifunction switch housing in following illustration.




#### TYPICAL - ADHESIVE FILM HEATER HAND GRIP LH

1. Rubber hand grip
2. Heater wire horizontal position

**NOTICE** Ensure LH heater wires are properly routed through multifunction switch housing to prevent them from being pinched when installing housing cover. Pinched or damaged wires may result in a short circuit.

**NOTE:** Heater wire is routed through throttle lever housing in following illustration.




#### TYPICAL - ADHESIVE FILM HEATER HAND GRIP RH

1. Throttle lever
2. Film heater wire
3. Passage hole in throttle lever housing

## Section 05 ELECTRICAL SYSTEM

### Subsection 06 (LIGHTS, GAUGE AND ACCESSORIES)




TYPICAL - REAR VIEW, THROTTLE FULLY DEPRESSED

1. Throttle lever
2. Throttle lever housing
3. Film heater wire routing through throttle lever housing

#### **⚠ WARNING**

To ensure RH heater wires do not prevent smooth operation of throttle lever, it must be passed straight through the housing without any slack, and secured with a locking tie immediately after the lever housing.



TYPICAL

1. Locking tie
2. Heater wire straight through throttle lever housing
3. Throttle lever
4. Lever housing

#### **Models with Adhesive Film Heaters (Aluminum Handlebars)**

1. Measure 159 mm (6.25 in) from the end of the handlebar, and across the top of the bend in the bar. Trace a reference line with a marker at that point on the handlebar.



TYPICAL - MEASURING FOR HEATER POSITION


1. Trace reference line

2. Align the edge of the cork insulator with the reference line centered with the handlebar folding axis as illustrated.



TYPICAL - CORK INSULATOR ALIGNMENT

3. Apply firm pressure to cork insulator to assure proper adherence to handlebar.
4. Align the film heater element with the cork insulator and center of handlebar folding axis as illustrated.



TYPICAL - HEATER ALIGNMENT


1. Heater wire position (LH front, RH rear)

5. Apply firm pressure to heater to assure proper adherence to cork insulator.

**Section 05 ELECTRICAL SYSTEM**  
**Subsection 06 (LIGHTS, GAUGE AND ACCESSORIES)**


**NOTE:** The same heater element is used for both the LH and RH sides. Therefore, the electrical wiring will be in front of the handlebar on the LH side, and behind the handlebar (towards driver) on the RH side.

6. Apply two turns of black electrical tape at each of the four locations illustrated so that it covers the edges of the heater element and prevents snagging and damage to the element during rubber grip installation.




**TYPICAL**  
1. Electrical tape application (4x)

**NOTE:** It is highly important to apply tape so that it fully secures the electrical wire connections. This will ease installation of the rubber hand grip and prevent undue stress to the connections.



**TYPICAL - IMPORTANT**  
1. Tape application over wire connections

7. Install rubber hand grip, refer to *STEERING SYSTEM* section for detail.
8. Route wiring as noted during the removal procedure.
9. Insert wire connectors in steering connector housing, refer to *WIRING DIAGRAM* for wire color and pin number locations.




**TYPICAL**  
1. Heater wire terminals  
2. Insertion through back of connector

**NOTE:** On vehicles equipped with premium gauges, only two of the heater wires are used. The ORANGE/VIOLET wire terminal will need to be cut off near the connector, insulated using heat shrink, a terminal end or electrical tape, then stored inside the wire harness protective sheath.

10. Install locking ties to secure the heater wire tightly against the handlebar.

**⚠ WARNING**

To ensure RH heater wires does not prevent smooth operation of throttle lever, it must be passed straight through the housing without any slack, and secured with a locking tie immediately after the lever housing.



**TYPICAL**  
1. Locking tie  
2. Heater wire straight through throttle lever housing  
3. Throttle lever  
4. Lever housing

## Section 05 ELECTRICAL SYSTEM

### Subsection 06 (LIGHTS, GAUGE AND ACCESSORIES)

**NOTICE** Ensure LH heater wires are properly routed through multifunction switch housing to prevent them from being pinched when installing housing cover. Pinched or damaged wires may result in a short circuit.

11. Start vehicle or apply power to the accessories system using the procedure described in *COMMUNICATION TOOLS AND B.U.D.S. SOFTWARE* section.
12. Using the hand grip heat selector switch, turn on the hand grip heaters and ensure they are functioning correctly.

## 12-VOLT POWER OUTLET

### Power Outlet Testing

1. First try another accessory, if it does not function, test outlet.
2. Remove console, refer to *BODY* section.
3. Unplug the power outlet connectors.
4. Apply power to the accessories circuits, see *LIGHTING AND ACCESSORIES SYSTEM TESTING* in this section.
5. Measure the voltage as follows.

WIRES		VOLTAGE
RD/YL	BK	Approximately 12 Vdc

If voltage reading is good, replace 12 Volt power outlet.

If you did not read any voltage, check the taillight. If it isn't functioning either, test the following:

- Accessories fuse
- Accessories relay
- Connectors and wiring.

MODEL	ACCESSORIES FUSE	ACCESSORIES RELAY
500SS/600/800R	FC	R1

### Power Outlet Removal

1. Remove the console, refer to *BODY* section.
2. Remove connectors from the power outlet.
3. Unscrew the large nut then remove the power outlet.

### Power Outlet Installation

The installation is the reverse of the removal procedure, refer to *BODY* section for console installation.

## VISOR OUTLET

### Visor Outlet Testing

1. First, try another accessory, if it does not function, test visor outlet.
2. Remove the console, refer to *BODY* section.
3. Unplug the visor connector.
4. Apply power to the accessories circuits, see *LIGHTING AND ACCESSORIES SYSTEM TESTING* in this section.
5. Check voltage as follows.

WIRES		VOLTAGE
RD/YL	BK	Approximately 12 Vdc

If voltage reading is good, replace visor outlet.

If you did not read any voltage, check the taillight. If it isn't functioning either, test the following:

- Accessories fuse
- Accessory relay
- Wiring and connectors.

MODEL	ACCESSORIES FUSE	ACCESSORIES RELAY
500SS/600/800R	FC	R1

### Visor Outlet Removal

1. Remove the console, refer to *BODY* section.
2. Unplug the visor connector.
3. Unscrew visor outlet.

### Visor Outlet Installation

The installation is the reverse of the removal procedure, refer to *BODY* section for console installation.

# DRIVE BELT

## SERVICE TOOLS

### Description

Description	Part Number	Page
BELT TENSION TESTER.....	414 348 200 .....	431
DRIVEN PULLEY OPENING TOOL .....	529 017 200 .....	427
	529 036 127 .....	427, 429

## GENERAL

### APPLICATION CHART

MODEL	DRIVE BELT (P/N)
500SS 600	417 300 197
600 HO E-TEC 800R (MX Z)	417 300 383
800R (Summit)	417 300 377

## PROCEDURES

### DRIVE BELT GUARD


#### Drive Belt Guard Removal

#### **⚠ WARNING**

NEVER operate the snowmobile without the drive belt guard securely installed.

Open the LH side panel.

Remove retaining pin.



1. Retaining pin

Lift rear portion of guard then release from front tabs by pivoting the guard outwards.

#### Drive Belt Guard Installation

Place the front LH slot of the guard over the longest tab.

Pivot the guard inward to engage the shortest tab in the RH slot.



1. Tabs

Position the grommet over the retaining rod. It may be necessary to slightly lift the console to make room.



1. Retaining rod

## Section 06 DRIVE SYSTEM AND BRAKE

### Subsection 01 (DRIVE BELT)

Position rear portion of the drive belt guard over the retainer and secure it using the retaining pin.




1. Retaining pin

## DRIVE BELT GUARD SUPPORT

### Guard Support Removal

Remove the drive belt guard.

Remove screws securing the support to vehicle.



1. Drive belt guard support  
2. Screws

### Guard Support Installation

The installation is the reverse of the removal procedure.

Tighten screws to 5 N•m (44 lbf•in).


## DRIVE BELT

### Drive Belt Removal (Ring Type Pulley Adjuster)

Open the LH side panel.

Remove the drive belt guard.

Using the spark plug tool (included in the tool kit) or an 11/16 in thin wall socket, loosen ( $\pm 4$  turns) the adjustment ring adapter located inside adjustment ring.



1. Spark plug tool  
2. Driven pulley adjustment ring


To open the driven pulley, proceed as follows with one of the following tools.

### Procedure with Suspension Adjustment Tool

Using the suspension adjustment tool (included in the tool kit), open the driven pulley by turning the tool clockwise.



SUSPENSION ADJUSTMENT TOOL




1. Suspension adjustment tool  
2. Driven pulley adjustment ring

To remove belt, slip the belt over the top of driven pulley.




## Section 06 DRIVE SYSTEM AND BRAKE

### Subsection 01 (DRIVE BELT)




#### Procedure with Driven Pulley Opening Tool

Using the DRIVEN PULLEY OPENING TOOL (P/N 529 036 127), open the driven pulley by turning the tool clockwise.



DRIVEN PULLEY OPENING TOOL (P/N 529 036 127)



1. Driven pulley opening tool
2. Driven pulley adjustment ring

To remove belt, slip the belt over the top of driven pulley, then over the drive pulley.



#### Drive Belt Removal (Screw Type Pulley Adjuster)

1. Remove the drive belt guard.
2. Insert the DRIVEN PULLEY OPENING TOOL (P/N 529 017 200) (or the tool provided in the tool box) in the threaded hole on the adjuster hub.



DRIVEN PULLEY OPENING TOOL (P/N 529 017 200)




DRIVEN PULLEY OPENING TOOL (IN TOOL KIT)

3. Open the driven pulley by screwing the tool in.
4. To remove belt, slip the belt over the top of driven pulley, then over the drive pulley.

## Section 06 DRIVE SYSTEM AND BRAKE

### Subsection 01 (DRIVE BELT)



TYPICAL

### Drive Belt Inspection

Inspect belt for:

- Cracks
- Fraying
- Abnormal wear (uneven wear, wear on one side, missing cogs, cracked fabric).

If abnormal wear is noted, probable cause could be:

- Pulley misalignment
- Excessive RPM with frozen track
- Fast starts without warm-up period
- Scratched or rusty sheave
- Oil on belt
- Distorted spare belt.

Check drive belt width. Replace the drive belt if its width is under minimum recommended specification.


MODEL	MINIMUM WIDTH (wear limit)
500SS/600	34.9 mm (1.374 in)
600 HO E-TEC 800R (MX Z)	35.9 mm (1.413 in)
800R (Summit)	34.4 mm (1.354 in)

### Drive Belt Installation (Ring Type Pulley Adjuster)

1. Make sure the driven pulley is opened. If not, refer to *DRIVE BELT REMOVAL (RING TYPE PULLEY ADJUSTER)* above.
2. Place the belt inside drive pulley, then slip the top of belt over the driven pulley.

**NOTICE** Do not force or use tools to pry the belt into place, as this could cut or break the cords in the belt.

**NOTE:** The maximum drive belt life span is obtained when the arrows on the drive belt are directed toward the front of vehicle. This will ensure that correct direction of rotation is respected.



1. Arrows pointing the front of vehicle


3. Adjust the drive belt height. Refer to *DRIVE BELT HEIGHT ADJUSTMENT (RING TYPE PULLEY ADJUSTER)* and follow steps 4 to 11.

### Drive Belt Installation (Screw Type Pulley Adjuster)

1. Make sure the driven pulley is opened. If not, refer to *DRIVE BELT REMOVAL (SCREW TYPE PULLEY ADJUSTER)*.
2. Set the drive belt inside drive pulley, then slip the top of belt over the driven pulley.

**NOTICE** Do not force or use tools to pry the belt into place, as this could cut or break the cords in the belt.

**NOTE:** The maximum drive belt life span is obtained when the arrow on the drive belt is directed toward the front of the vehicle. This will ensure that correct direction of rotation is respected.



1. Arrow pointing the front of vehicle

3. Unscrew and remove the driven pulley opening tool from the pulley.
4. Rotate the driven pulley several times to properly set the belt between the sheaves.

- Adjust the drive belt height. Refer to *DRIVE BELT HEIGHT ADJUSTMENT (SCREW TYPE PULLEY ADJUSTER)* and follow steps 3 to 9.

**Drive Belt Height Adjustment (Ring Type Pulley Adjuster)**

**NOTE:** Adjust drive belt height every time drive belt is installed.

- Open the LH side panel.
- Remove the drive belt guard.
- Using the spark plug tool (included in the tool kit) or an 11/16 in thin wall socket, loosen ( $\pm 4$  turns) the adjustment ring adapter located inside adjustment ring.



MANUALLY ROTATE DRIVE BELT

**500SS**

Repeat steps 4 and 5 until the external side of drive belt exceeds the driven pulley edge by 2 mm (.079 in).




PRELIMINARY SETTING  
A. 2 mm (.079 in)

**600 HO E-TEC and 800R**

Repeat steps 4 and 5 until the bottom of grooves on the external side of drive belt are flush with the driven pulley edges.




PRELIMINARY SETTING  
1. Driven pulley edge  
2. External drive belt grooves



1. Spark plug tool  
2. Driven pulley adjustment ring

- Using the suspension adjustment tool or the DRIVEN PULLEY OPENING TOOL (P/N 529 036 127), turn the driven pulley adjuster accordingly to achieve the required drive belt height.



1. Suspension adjustment tool  
2. Adjustment ring


- Manually rotate drive belt to position it properly inside pulley sheaves.

## Section 06 DRIVE SYSTEM AND BRAKE

### Subsection 01 (DRIVE BELT)

#### All Models

- When the drive belt is properly positioned, ensure that the swivel ring leans against the driven pulley cam.




#### CORRECT POSITION

- Swivel ring
- Driven pulley cam
- In contact with driven pulley

- If the swivel ring is not in contact with the cam, turn adjustment ring clockwise to lean the swivel ring against the driven pulley cam.


**NOTICE** Overtightening swivel ring will modify drive belt adjustment and reduce drive belt life span.



#### INCORRECT POSITION

- Swivel ring
- Driven pulley cam
- Not in contact with driven pulley

- Check drive belt deflection. Refer to *DRIVE BELT DEFLECTION VERIFICATION*.
- Using the spark plug tool (included in the tool kit) or an 11/16 in thin wall socket, snug up the locking nut ( $\pm 4$  turns).



- Locking nut
- Adjustment ring

- Reinstall the drive belt guard.


- Close LH side panel.

### Drive Belt Height Adjustment (Screw Type Pulley Adjuster)

**NOTE:** The drive belt height adjustment must be performed every time a new belt is installed.

To adjust the drive belt height, proceed as follows:

- Open the LH side panel.
- Remove the drive belt guard.
- Keep the set screws from turning using a 3 mm Allen key and loosen both lock nuts using a 10 mm open wrench.



#### LOOSEN THE LOCK NUTS

- 3 mm Allen key
- 10 mm open wrench

- Turn one set screw 1/4 turn at a time then rotate the driven pulley to properly set the belt between the pulley sheaves. Repeat until the belt cord reaches the recommended height.

## Section 06 DRIVE SYSTEM AND BRAKE

### Subsection 01 (DRIVE BELT)

**NOTE:** Turning the set screws clockwise lowers the belt in the pulley. Turning the set screws counterclockwise raises the belt in the pulley.

#### 500SS

The external side of drive belt must exceed the driven pulley edge by 2 mm (.079 in).



#### PRELIMINARY SETTING

A. 2 mm (.079 in)

#### 600 HO E-TEC and 800R


The bottom of grooves on the external side of drive belt reach the driven pulley edges.



#### PRELIMINARY SETTING

1. Driven pulley edge
2. External drive belt grooves

5. Set the other set screw so that it rests on the steel ring.



1. Set screw
2. Lock nut
3. Steel ring

6. Check drive belt deflection. Refer to *DRIVE BELT DEFLECTION VERIFICATION*.


7. Keep the set screws from turning and tighten the lock nuts towards the adjuster hub to 5 N•m (44 lbf•in)

8. Install the drive belt guard.

9. Close side panel.

#### Drive Belt Deflection Verification

1. Make sure drive belt height is adjusted (preliminary setting).
2. Position a reference rule on drive belt.
3. Use the BELT TENSION TESTER (P/N 414 348 200) as explained below.
  - 3.1 Slide lower O-ring of deflection scale to specified measure.
  - 3.2 Slide upper O-ring to 0 (zero) on the force scale.




1. Lower O-ring
2. Upper O-ring
3. Force (read down)
4. Deflection (read up)

4. Apply pressure until lower O-ring is flush with edge of rule and read force on the upper scale at top edge of O-ring.

## Section 06 DRIVE SYSTEM AND BRAKE

### Subsection 01 (DRIVE BELT)



1. Upper O-ring — force
2. Lower O-ring — deflection
3. Reference rule

5. The drive belt deflection should be within the following specification.

MODEL	DEFLECTION	FORCE
All	$32 \pm 5$ mm ( $1.260 \pm .197$ in)	11.3 kgf (24.9 lbf)

6. If the deflection is slightly out of specification, readjust drive belt height from the preliminary setting until deflection is correct.

6.1 If deflection is too far out from the drive belt height preliminary setting, check for the following:

- Try a new belt.
- Inspect engine supports.
- Inspect countershaft and bearing.
- Inspect chassis for damages.

# DRIVE PULLEY

## SERVICE TOOLS

<b>Description</b>	<b>Part Number</b>	<b>Page</b>
BUSHING REMOVER/INSTALLER .....	529 031 200 .....	440
DRIVE PULLEY HOLDER .....	529 035 674 .....	436, 445
DRIVE PULLEY PULLER .....	529 022 400 .....	436
SLIDER SHOE FORK.....	529 005 500 .....	437, 443
SLIDING SHEAVE BUSHING REMOVER/INSTALLER.....	529 035 931 .....	440, 442
SPRING COMPRESSOR .....	529 036 012 .....	438, 440, 442-443

## SERVICE PRODUCTS


<b>Description</b>	<b>Part Number</b>	<b>Page</b>
LOCTITE 680 .....	293 800 114 .....	442
PULLEY FLANGE CLEANER .....	413 711 809 .....	440

## Section 06 DRIVE SYSTEM AND BRAKE

### Subsection 02 (DRIVE PULLEY)

TRA III


500SS/600/600 HO E-TEC





**Section 06 DRIVE SYSTEM AND BRAKE**  
Subsection 02 (DRIVE PULLEY)

TRA VII  
800R



## Section 06 DRIVE SYSTEM AND BRAKE

### Subsection 02 (DRIVE PULLEY)

## GENERAL

TRA drive pulley stands for Total Range Adjustable drive pulley.

These are lubrication free drive pulleys. Do not lubricate any component.

Always refer to appropriate *PARTS CATALOG* for replacement part.

Most parts of TRA III are not interchangeable with those of the TRA VII.

**NOTICE** Never use any type of impact wrench at drive pulley removal and installation. The use of impact wrench could damage the drive pulley and modify the calibration.

Some drive pulley components (return spring, ramp) can be changed to improve vehicle performance in high altitude regions. A Service Bulletin gives information about calibration according to altitude.

**NOTICE** Such modifications should only be performed by experienced mechanics since they can greatly affect vehicle performance. Verify spring specifications before installation. Do not only refer to the spring color code.

### **⚠ WARNING**

Any drive pulley repairs must be performed by an authorized Ski-Doo dealer. Subcomponent installation and assembly tolerances require strict adherence to procedures detailed.

During assembly/installation, use torque values and service products as in the exploded views.

Clean threads before applying a threadlocker. Refer to *SELF-LOCKING FASTENERS* and *LOCTITE APPLICATION* at the beginning of this manual for complete procedure.

### **⚠ WARNING**

Torque wrench tightening specifications must be strictly adhered to. Locking devices (e.g.: locking tabs, elastic stop nuts, cotter pins, etc.) must be replaced with new ones.


## PROCEDURES

### DRIVE PULLEY

#### Drive Pulley Removal


Remove drive belt. Refer to *DRIVE BELT* section.

Secure drive pulley with the DRIVE PULLEY HOLDER (P/N 529 035 674). Install it over a sliding sheave tower.




1. Drive pulley
2. Drive pulley holder

Remove the drive pulley bolt and its conical spring washer.



1. Drive pulley bolt
2. Conical spring washer


To remove drive pulley from engine, use the DRIVE PULLEY PULLER (P/N 529 022 400).



Retain drive pulley with the DRIVE PULLEY HOLDER (P/N 529 035 674), and install the puller in pulley shaft then tighten.

## Section 06 DRIVE SYSTEM AND BRAKE

### Subsection 02 (DRIVE PULLEY)




1. Drive pulley holder
2. Drive pulley puller

**NOTICE** These pulleys have metric threads. Do not use imperial threads puller. Always tighten puller by hand to ensure that the drive pulley has the same type of threads (metric vs imperial) prior to fully tightening.

#### Drive Pulley Disassembly

**NOTICE** NEVER tap on governor cup.

To separate fixed sheave from sliding sheave, screw puller into fixed sheave shaft about 13 mm (1/2 in). Raise drive pulley and hold it by the sliding sheave while knocking on puller head to disengage fixed sheave.




- TYPICAL
1. Puller
  2. Sliding sheave
  3. Fixed sheave

**NOTE:** No components marking is required before disassembling this drive pulley since it has factory mark and arrows as indexing reference.

#### Ring Gear

To remove the ring gear, use a heat gun to break the threadlocker on ring gear screws. Discard the ring gear screws.




1. Ring gear
2. Ring gear screws

**NOTICE** If another tool than a heat gun is used, do not exceed 150°C (302°F).

#### Slider Shoes and Governor Cup

Carefully lift governor cup until slider shoes come at their highest position into guides.




1. Governor cup
2. Slider shoes

Hold a slider shoe set then carefully lift its housing and install a SLIDER SHOE FORK (P/N 529 005 500). Proceed the same way for other housings lifting one at a time.




## Section 06 DRIVE SYSTEM AND BRAKE

### Subsection 02 (DRIVE PULLEY)



1. Governor cup
2. Slider shoe forks

When all slider shoes are held with the forks, remove the governor cup.




1. Governor cup
2. Slider shoe forks
3. Sliding sheave

#### Spring Cover


To remove the spring cover, always use the SPRING COMPRESSOR (P/N 529 036 012). The spring cover is under high clutch spring preload.

#### **⚠ WARNING**

Clutch spring is very strong. Never attempt to remove spring cover without the recommended tools.



Install support guide of spring compressor in a vice.




1. Support guide

**NOTE:** The support guide will prevent bushing damages.

Install sliding sheave then the support cup over spring cover.

Remove 3 Allen screws retaining spring cover then unscrew compressor.




TYPICAL — TRA VII SHOWN

1. Sliding sheave
2. Support cup
3. Spring cover screws

Remove spring cover, spring and spring seat.


## Section 06 DRIVE SYSTEM AND BRAKE

### Subsection 02 (DRIVE PULLEY)



1. Spring
2. Spring cover


**Lever, Roller and Pin**  
Remove lever screws.



1. Pin
2. Thrust washers
3. Roller


#### Ramp

Turn the governor cup up side down.  
Remove screws retaining ramp to governor cup.



1. Lever screws


Pull lever to remove it from sliding sheave.  
Remove and discard the cotter pin.



1. Ramp
2. Ramp screws
3. Governor cup

#### Calibration Screw

Unscrew the nut securing the calibration screw.



1. Cotter pin
2. Lever


Remove pin, thrust washers and roller.



Remove calibration screw and its washer.

## Section 06 DRIVE SYSTEM AND BRAKE

### Subsection 02 (DRIVE PULLEY)




1. Calibration screw
2. Washer

#### Sliding Sheave Bushing Removal

**NOTE:** In case of worn out bushing, it is advisable to replace whole sliding sheave assembly as replacing just the bushing may reduce the drive pulley performance.


If bushing is out of specifications, remove it as follows:

1. Remove circlip from the sliding sheave.



1. Circlip

2. Secure the SPRING COMPRESSOR (P/N 529 036 012) in a vice.
3. Mount the BUSHING REMOVER/INSTALLER (P/N 529 031 200) and the sliding sheave assembly on it.



1. Spring compressor
2. Bushing remover/installer

4. Use the SLIDING SHEAVE BUSHING REMOVER/INSTALLER (P/N 529 035 931) to press out old bushing.

**NOTE:** Make sure to use the tool as marked; to remove the bushing press using the side marked "OUT", as shown below in the picture.



5. Use a soft sand paper to clean sliding sheave bushing mounting surface.



6. Clean sliding sheave bushing mounting surface with PULLEY FLANGE CLEANER (P/N 413 711 809).
7. Clean the circlip groove.

#### Drive Pulley Cleaning

Parts must be at room temperature before cleaning.

Clean pulley sheaves and shaft with fine steel wool and dry cloth.

Using a paper towel with PULLEY FLANGE CLEANER (P/N 413 711 809), clean crankshaft tapered end and the taper inside the fixed sheave of the drive pulley, crankshaft threads and retaining screw threads.

**NOTICE** Avoid contact between cleaner and crankshaft seal because damage may occur.

Remove all hardened oil deposits that have baked on crankshaft and pulley tapered surfaces with coarse or medium steel wool and/or sand paper no. 600.

**NOTICE** Do not use any other type of abrasive.

Reclean mounting surfaces with paper towel and cleaning solvent.

Wipe off the mounting surfaces with a clean, dry paper towel.

**NOTICE** Mounting surfaces must be free of any oil, cleaner or towel residue.

### Drive Pulley Inspection

**NOTE:** During inspection, replace any component if found defective or out of specifications.

#### Fixed Sheave and Governor Cup

Inspect fixed sheave for marks or scratches.

#### 500SS/600/600 HO E-TEC

Inspect splines and free play between both parts. Maximum free play is 0.5 mm (.02 in) measured at calibration screw radius.

#### Slider Shoes

Check slider shoes for wear. Replace if groove is not apparent on top.

Check if slider shoe O-rings are cracked, cut or crushed.




1. O-ring  
 2. Slider shoe

#### Sliding Sheave

Inspect pulley sheave for marks or scratches.

Visually inspect coating of bushings.

Using a bore gauge, measure the inner diameter of sliding sheave bushing. Measuring point must be at least 5 mm (1/4 in) from bushing edge.



mmv2008-041-118\_a

A. Inner diameter of sliding sheave bushing


BUSHING	SERVICE LIMIT
Sliding sheave bushing	40.3 mm (1.587 in)

#### Lever, Roller and Pin

Check levers for cracks, distortion or other damages.

Check lever pivot for wear.

Check lever flanged bushing for wear.



mmv2008-041-120\_a

1. Lever pivot  
 2. Lever flanged bushing

Check rollers for roundness of external diameter.

Check thrust washers for thickness wear.

Check roller pins for wear.

#### Spring Cover


Check spring cover for cracks or wear.

Visually inspect the coating of spring cover bushing for wear.

Using a bore gauge, measure the inner diameter of spring cover bushing. Measuring point must be at least 5 mm (1/4 in) from bushing edge.

## Section 06 DRIVE SYSTEM AND BRAKE

### Subsection 02 (DRIVE PULLEY)



A. Inner diameter of spring cover bushing

BUSHING	SERVICE LIMIT
Spring cover bushing	30.4 mm (1.197 in)

Replace the spring cover if the inner diameter of bushing is out of specification.

## Drive Pulley Assembly

### Sliding Sheave Bushing Installation

To install a **NEW** bushing, secure the SPRING COMPRESSOR (P/N 529 036 012) in a vice and mount the sliding sheave.

Apply LOCTITE 680 (P/N 293 800 114) on the outside of bushing face.


Insert the bushing from inner side of sliding sheave.

Mount the SLIDING SHEAVE BUSHING REMOVER/INSTALLER (P/N 529 035 931) with side marked "IN" to press in a new bushing.




1. Mark "OUT" toward outside

**NOTE:** Make sure that the bushing is well seated on the sliding sheave.



1. Bushing

Install the circlip.



1. Circlip

**NOTICE** Make sure that the circlip is properly position in its groove.

### Ring Gear

Clean ring gear and the inner threads of fixed sheave.

Install **NEW** ring gear screws and torque them in accordance with the following chart.

RING GEAR SCREW TORQUE	
500SS 600 600 HO E-TEC	27 N•m (20 lbf•ft)
800R	52 N•m (38 lbf•ft)


### Sliding Sheave, Slider Shoes and Governor Cup

Install an O-ring on each slider shoes.




## Section 06 DRIVE SYSTEM AND BRAKE

### Subsection 02 (DRIVE PULLEY)




1. Slider shoe
2. O-ring

Insert slider shoes into governor cup so that groove in each slider shoe is vertical to properly slide in guides.



1. Governor cup
2. Slider shoe grooves

Install a SLIDER SHOE FORK (P/N 529 005 500) into slider shoe grooves to maintain them for governor cup installation. Proceed on 3 set of slider shoes.



Make sure to align governor cup arrow with sliding sheave mark.




1. Sliding sheave mark
2. Governor cup arrow

Carefully slide governor cup into sliding sheave. Remove forks and push governor cup.

#### Spring Cover

To install spring cover, use SPRING COMPRESSOR (P/N 529 036 012).

Align spring cover arrow with sliding sheave mark.



- TYPICAL**
1. Spring cover arrow
  2. Sliding sheave mark

Tighten spring cover screws to 25 N•m (18 lbf•ft).

#### Lever, Roller and Pin

Always use the same type of pin as originally installed when servicing. Refer to *TECHNICAL SPECIFICATIONS*.

## Section 06 DRIVE SYSTEM AND BRAKE

### Subsection 02 (DRIVE PULLEY)



SOLID PIN



HOLLOW PIN

**NOTE:** Different types have different weights for calibration purpose. Refer to *HIGH ALTITUDE BULLETIN*.

While installing lever make sure that the curved sides of the levers are outwards as shown.




Always install lever assemblies so cotter pin heads are oriented on top when lever is set at the bottom of sliding sheave.

Bend cotter pin ends to sit perfectly against lever.

### **⚠ WARNING**

Whenever replacing centrifugal levers, always replace all 3 at the same time. Otherwise, drive pulley unbalance will occur because of levers difference.




1. Cotter pin head on top
2. All on the same side

Torque lever screws to 18 N•m (159 lbf•in).

**NOTICE** Levers and rollers must move easily after installation.

### Ramp

Insert dowel tube from chamfered side.




1. Chamfered side

Position dowel tube split at the angle "A".


## Section 06 DRIVE SYSTEM AND BRAKE

### Subsection 02 (DRIVE PULLEY)



MODEL	ANGLE "A"
All	$45 \pm 3^\circ$

Make sure ramp is centered on dowel tube.




1. Equal distance

Torque ramp screws to  $12 \text{ N}\cdot\text{m}$  ( $106 \text{ lbf}\cdot\text{in}$ ).

#### Calibration Screw

When installing calibration screw, make sure to install washer as shown.



1. Washer  
2. Calibration screw

**NOTE:** Refer to *DRIVE PULLEY ADJUSTMENT*, further in this section, to install the calibration screws in original setting.

Torque locking nut to  $10 \text{ N}\cdot\text{m}$  ( $89 \text{ lbf}\cdot\text{in}$ ).

#### Sliding Sheave and Fixed Sheave

To assemble the sliding sheave on the fixed sheave, align sliding sheave mark with the dot at the back of fixed sheave.



1. Sliding sheave mark  
2. Fixed sheave dot

**NOTE:** Push sliding sheave until governor cup splines are engaged on fixed sheave splines (except 800R).

#### Drive Pulley Installation

Clean mounting surfaces as described in *DRIVE PULLEY CLEANING* above.

**NOTICE** Do not apply antiseize or any lubricant on crankshaft and drive pulley tapers.

Install drive pulley on crankshaft extension.

Install a **NEW** conical spring washer with its concave side towards drive pulley then install drive pulley bolt.

**NOTICE** Always use BRP genuine parts for conical spring washer and bolt.

Use the DRIVE PULLEY HOLDER (P/N 529 035 674) to retain drive pulley. See removal procedure.

Torque drive pulley bolt.

DRIVE PULLEY FIRST TORQUE	
All engines	$120 \text{ N}\cdot\text{m}$ ( $89 \text{ lbf}\cdot\text{ft}$ )

Before starting engine, perform drive pulley adjustment, see further in this section.

Install drive belt and guard.

Raise the rear of the vehicle and support it with a mechanical stand.

## Section 06 DRIVE SYSTEM AND BRAKE

### Subsection 02 (DRIVE PULLEY)

#### **⚠ WARNING**

Ensure that the track is free of particles which could be thrown out while track is rotating. Keep hands, tools, feet and clothing clear of track. Ensure nobody is standing near the vehicle.

Accelerate the vehicle at low speed (maximum 32 km/h (20 MPH) and apply the brake, repeat 5 times.

Re-torque drive pulley bolt.

#### DRIVE PULLEY FINAL TORQUE

All engines	120 N•m (89 lbf•ft)
-------------	---------------------

#### **⚠ WARNING**

After 10 hours of operation the transmission system of the vehicle must be inspected to ensure drive pulley bolt is properly torqued.

### Drive Pulley Adjustment

The drive pulley is factory calibrated to transmit maximum engine power at a predefined RPM. Factors such as ambient temperature, altitude or surface condition may vary this critical engine RPM thus affecting snowmobile efficiency.


This adjustable drive pulley allows setting maximum engine RPM in the vehicle to maintain maximum power. Refer to *ENGINE MANAGEMENT SYSTEM* for engine RPM adjustment.

Calibration screws should be adjusted so that actual maximum engine RPM in vehicle matches the maximum horsepower RPM given in *TECHNICAL SPECIFICATIONS*.

**NOTE:** The adjustment has an effect on high RPM only.

To adjust, modify ramp end position by turning calibration screws.

Calibration screw has a notch on top of its head.



1. Notch

Governor cup has 6 positions numbered 1 to 6.



1. Position 1

See the following table for original setting.

CALIBRATION SCREW			
ENGINE	MODEL		POSITION
500SS	GSX	Sport	3
	GTX	Sport	3
	MX Z	Trail and TNT	3
600	Summit	Everest	3
600 HO E-TEC	GSX	Limited	3
	GTX	LE	3
	MX Z	50 <sup>th</sup> , Adrenaline, Renegade, Renegade X, TNT and X	3
	Summit	Everest and X	3
800R	MX Z	Adrenaline, Renegade, Renegade X and X	3
	Summit	X 154* (Europe)	3
		All other models	1

Each number modifies maximum engine RPM by about 200 RPM.

Lower numbers decrease engine RPM in steps of 200 RPM and higher numbers increase it in steps of 200 RPM.

Example:

Calibration screw is set at position 3 and is changed to position 5. So maximum engine RPM is increased by about 400 RPM.

**To Adjust:**

Just loosen locking nut enough to pull calibration screw **partially** out. Do not completely remove the locking nut.

**NOTICE** Do not completely remove calibration screw otherwise its inside washer will fall off.



1. Loosen just enough to permit rotating of calibration screw

Adjust to desired position.

**NOTICE** Always adjust all 3 calibration screws and make sure they are all set at the same number.

Torque locking nuts to 10 N•m (89 lbf•in).

# DRIVEN PULLEY AND COUNTERSHAFT

## SERVICE TOOLS

<b>Description</b>	<b>Part Number</b>	<b>Page</b>
COUNTERSHAFT BEARING INSTALLER .....	529 036 066 .....	459
COUNTERSHAFT BEARING REMOVER .....	529 036 065 .....	458
COUNTERSHAFT SUPPORT .....	529 036 067 .....	458
DRIVEN SPRING COMPRESSOR .....	529 036 064 .....	453
QRS HUB TORQUING TOOL .....	529 036 147 .....	453, 458
UPPER GEAR RETAINING TOOL .....	529 036 110 .....	452

## SERVICE TOOLS – OTHER SUPPLIER

<b>Description</b>	<b>Part Number</b>	<b>Page</b>
ROTOR CLIP® APPLICATOR .....	A-150 .....	456


## SERVICE PRODUCTS

<b>Description</b>	<b>Part Number</b>	<b>Page</b>
LOCTITE 243 (BLUE) .....	293 800 060 .....	458
LOCTITE 609 .....	413 703 100 .....	459
LOCTITE 767 (ANTISEIZE LUBRICANT) .....	293 800 070 .....	457
LOCTITE PRIMER N .....	293 800 041 .....	458
PULLEY FLANGE CLEANER .....	413 711 809 .....	456, 459

## Section 06 DRIVE SYSTEM AND BRAKE

### Subsection 03 (DRIVEN PULLEY AND COUNTERSHAFT)


#### DRIVEN PULLEY (RING TYPE ADJUSTER)



## Section 06 DRIVE SYSTEM AND BRAKE

### Subsection 03 (DRIVEN PULLEY AND COUNTERSHAFT)

#### DRIVEN PULLEY (SCREW TYPE ADJUSTER)





## Section 06 DRIVE SYSTEM AND BRAKE

### Subsection 03 (DRIVEN PULLEY AND COUNTERSHAFT)

## GENERAL

During assembly/installation, use the torque values and the service products as in the exploded views.

Clean threads before applying a threadlocker. Refer to *SELF-LOCKING FASTENERS* and *LOCTITE APPLICATION* at the beginning of this manual for complete procedure.

### **⚠ WARNING**

Torque wrench tightening specifications must be strictly adhered to. Locking devices (e.g.: locking tabs, elastic stop nuts, cotter pins, etc.) must be replaced with new ones.

### **⚠ WARNING**


Never start engine when the pulley guard is removed.

## PROCEDURES

### DRIVEN PULLEY


#### Driven Pulley Removal

1. Open left side panel.
2. Remove the muffler. Refer to *EXHAUST SYSTEM* section.
3. Remove the filling plug on the top of chaincase.




1. Filling plug
2. Chaincase

4. Release drive chain tension by unscrewing tensioner adjustment screw.



1. Tensioner adjustment screw
2. Lock nut


5. Remove the upper gear screw and the conical spring washer.



1. Upper gear screw
2. Conical spring washer

**NOTE:** Slightly tilt the bolt to avoid dropping washer inside chaincase.

6. Install the UPPER GEAR RETAINING TOOL (P/N 529 036 110) on countershaft end.




## Section 06 DRIVE SYSTEM AND BRAKE

### Subsection 03 (DRIVEN PULLEY AND COUNTERSHAFT)



1. Upper gear retaining tool

7. Open right side panel.
8. Remove the drive belt. Refer to *DRIVE BELT* section.
9. Behind driven pulley, remove screw securing the countershaft bearing flange.



1. Driven pulley  
2. Countershaft bearing flange

10. Pull the driven pulley to disengage countershaft and upper gear.

**NOTE:** If necessary, tap the upper gear retaining tool with a plastic hammer.



11. Unscrew countershaft from the upper gear retaining tool. Do not remove tool.

**NOTE:** While countershaft is removed from vehicle, the upper gear retaining tool keeps the drive chain and the upper gear in position inside chaincase.

### Driven Pulley Disassembly

#### Cam and Spring

1. Unscrew and remove the following parts according to pulley adjuster type.



**RING TYPE ADJUSTER**  
1. Adjusting ring



**SCREW TYPE ADJUSTER**  
1. Adjuster hub  
2. Washer


**NOTE:** To remove the screw type adjuster, use the QRS HUB TORQUING TOOL (P/N 529 036 147).

2. Install the threaded adapter of the DRIVEN SPRING COMPRESSOR (P/N 529 036 064) at the end of driven pulley.




## Section 06 DRIVE SYSTEM AND BRAKE

### Subsection 03 (DRIVEN PULLEY AND COUNTERSHAFT)




1. Threaded adapter

3. Install the external sleeve over the threaded adapter and secure sleeve with the driven spring compressor screw.




1. External sleeve  
2. Driven spring compressor screw

4. Tighten the driven spring compressor screw to compress the cam.
5. Install the driven spring compressor in a vice.



1. Driven spring compressor  
2. Driven pulley

6. Using a heat gun, heat cam screws to break the thread locker.




1. Heat cam screws

7. Remove and discard cam screws.
8. Unscrew the driven spring compressor screw completely.
9. Remove cam and spring.

#### Sliding Sheave

1. Remove the cam and spring.
2. Remove the *COUNTERSHAFT BEARING*, see procedure in this section.
3. Remove sliding sheave.



1. Fixed sheave  
2. Sliding sheave  
3. Countershaft

#### Fixed Sheave

The fixed sheave and countershaft are sold as an assembly. They are not available separately.

#### Driven Pulley Rollers

1. Move apart sliding and fixed sheaves.
2. Remove and discard pivot screws.

**Section 06 DRIVE SYSTEM AND BRAKE**  
**Subsection 03 (DRIVEN PULLEY AND COUNTERSHAFT)**




1. Pivot screw
2. Sliding sheave
3. Fixed sheave

3. Remove rollers.
4. Discard E-clips.

### Driven Pulley Inspection

#### Cam and Spring

1. Verify contact surfaces of cam for visible damages. Replace cam if necessary.
2. Using a dial bore gauge, measure the inner diameter of cam bushing. Measuring point must be at least 5 mm (1/4 in) from bushing edge.



A. Inner diameter of cam bushing

BUSHING	SERVICE LIMIT
Cam bushing	41.5 mm (1.634 in)

3. Replace the cam if the inner diameter of bushing is out of specification.

#### Sliding Sheave

1. Inspect pulley sheave for marks or scratches.
2. Using a dial bore gauge, measure the inner diameter of sliding sheave bushing. Measuring point must be at least 5 mm (1/4 in) from bushing edge.



A. Inner diameter of sliding sheave bushing

BUSHING	SERVICE LIMIT
Sliding sheave bushing	41.5 mm (1.634 in)

3. Replace the sliding sheave if the inner diameter of bushing is out of specification.


#### Fixed Sheave

Replace fixed sheave and countershaft if one of the following problem is detected:

- Marks or scratches on pulley sheave
- Bent, twisted or otherwise damaged countershaft
- Defective splines and threads at the end of countershaft.

#### Driven Pulley Rollers

1. Check the rollers for flat spots, cracks or other visible damages. Replace if necessary.
2. Measure inner and outer diameter of rollers.




A. Inner diameter  
 B. Outer diameter

ROLLER DIAMETER	SERVICE LIMIT
Inner diameter	8.5 mm (.335 in)
Outer diameter	21.5 mm (.846 in)

3. Measure the roller thickness.

## Section 06 DRIVE SYSTEM AND BRAKE

### Subsection 03 (DRIVEN PULLEY AND COUNTERSHAFT)



A. Thickness of roller

ROLLER THICKNESS	
SERVICE LIMIT	14.75 mm (.581 in)

4. If a roller is out of specifications, replace both rollers at the same time.

### Driven Pulley Cleaning

Use the PULLEY FLANGE CLEANER (P/N 413 711 809) and a clean rag to clean pulley sheaves.

### Cam and Spring

During break-in period, teflon from bushing moves to cam or countershaft surface. A teflon over teflon running condition occurs, leading to low friction. So it is normal to see gray teflon deposit on cam or countershaft. Do not remove this deposit.

When a dust deposit has to be removed from the cam or the countershaft, use dry cloth to avoid removing transferred teflon.


### Driven Pulley Assembly

#### Driven Pulley Rollers

1. Using a screw tap, clean pivot screw threaded holes into fixed sheave.
2. Install rollers into fixed sheave using NEW pivot screws with ribbed lock washers.

**NOTICE** Always use new pivot screws with pre-applied threadlocker.


3. Torque pivot screws to 20 N•m (15 lbf•ft).



1. Pivot screw
2. Ribbed lock washer
3. E-clip
4. Roller

4. Using a ROTOR CLIP® APPLICATOR (P/N A-150), install NEW E-clips to lock pivot screws.


**NOTE:** To purchase an applicator, contact Rotor Clip Company at [www.rotorclip.com](http://www.rotorclip.com).



1. E-clip applicator
2. E-clip
3. Roller

### Cam and Spring

1. Install a spring stopper, the spring, the other spring stopper and the cam.




1. Spring stopper
2. Spring
3. Cam

## Section 06 DRIVE SYSTEM AND BRAKE

### Subsection 03 (DRIVEN PULLEY AND COUNTERSHAFT)

- Align the arrow on cam with the arrow on fixed sheave. At the end of cam installation, the arrow on the cam should be move clockwise ( $\pm 30^\circ$ ).



- Install the driven spring compressor sleeve and tighten the driven spring compressor screw until cam is completely pressed against sliding sheave.
- Behind sliding sheave, install 4 NEW cam screws.
- Torque cam screws to 32 N•m (24 lbf•ft).
- Remove the driven spring compressor.

#### Sliding Sheave

The assembly of sliding sheave is the reverse of the disassembly. However, pay attention to the following.

When installing sliding sheave, make sure to align its arrow with the arrow on cam.



SLIDING SHEAVE ARROW



CAM ARROW

#### Driven Pulley Installation

- Using sand paper (600-grit or 1000-grit) or steel wool, remove any rust on bearing shoulder of countershaft bearing support.



- Bearing shoulder
- Countershaft bearing support

- Apply a thin layer of LOCTITE 767 (ANTISEIZE LUBRICANT) (P/N 293 800 070) on bearing shoulder.
  - Insert countershaft through countershaft bearing support.
  - Fasten the end of countershaft to upper gear retaining tool.
  - Align countershaft splines with upper gear splines.
  - Using the upper gear retaining tool as a puller, install countershaft into upper gear. Ensure countershaft bearing is installed properly into countershaft bearing support.
  - Remove the upper gear retaining tool.
  - Install the upper gear screw and the conical spring washer.
- NOTE:** The conical spring washer must be installed with its concave side towards upper gear.
- Tighten upper gear screw to 48 N•m (35 lbf•ft).
  - Install filling plug.

## Section 06 DRIVE SYSTEM AND BRAKE

### Subsection 03 (DRIVEN PULLEY AND COUNTERSHAFT)

11. On LH side, install the bearing flange.
12. Tighten nut to 15 N•m (133 lbf•in).

#### *Driven Pulley with Ring Type Adjuster*

1. Install the adjuster into the countershaft end and fully tight it.
2. Install and adjust belt drive. Refer to *BELT DRIVE* section.
3. Install all other removed parts.

#### *Driven Pulley with Screw Type Adjuster*


1. First, apply LOCTITE PRIMER N (P/N 293 800 041) then LOCTITE 243 (BLUE) (P/N 293 800 060) on threads of adjuster hub.
2. Install the adjuster hub with its washer into the countershaft end and fully tight it.

**NOTE:** Ensure to position the washer against the adjuster nuts. Washer must turn freely.



1. Adjuster hub
2. Washer against adjuster nuts

3. Using the QRS HUB TORQUING TOOL (P/N 529 036 147), torque adjuster hub to 100 N•m (74 lbf•ft).



1. QRS hub torquing tool

4. Install and adjust belt drive. Refer to *BELT DRIVE* section.
5. Install all other removed parts.

## COUNTERSHAFT

The countershaft and the fixed sheave are sold as an assembly. They are not available separately.

### Countershaft Removal and Installation


Refer to *DRIVEN PULLEY* for the procedures.

## COUNTERSHAFT BEARING

### Countershaft Bearing Removal

Remove *DRIVEN PULLEY*, see procedure in this section.

Install the COUNTERSHAFT BEARING REMOVER (P/N 529 036 065) on countershaft.



Tighten the screw at the end of tool to extract the bearing. Discard the bearing.


### Countershaft Bearing Installation

Remove the adjustment ring on cam.

Insert the COUNTERSHAFT SUPPORT (P/N 529 036 067) into countershaft.

## Section 06 DRIVE SYSTEM AND BRAKE

### Subsection 03 (DRIVEN PULLEY AND COUNTERSHAFT)



mmv2008-042-116\_a


1. Countershaft support

**NOTICE** The countershaft support is mandatory to avoid damaging the countershaft threaded end and the cam during bearing installation.

Using PULLEY FLANGE CLEANER (P/N 413 711 809), clean residues on countershaft bearing surface.

Check countershaft bearing surface for wear.


Apply LOCTITE 609 (P/N 413 703 100) on countershaft bearing surface.



mmv2008-044-020\_a

1. Apply Loctite 609 in this region

Using a press and the COUNTERSHAFT BEARING INSTALLER (P/N 529 036 066), install the NEW bearing on countershaft.



mmv2008-044-021\_a

1. Countershaft bearing installer  
2. NEW bearing


**NOTICE** Use a press only, never tap on countershaft bearing installer with an hammer to avoid damaging bearing and countershaft.

Clean the surplus of Loctite with a rag to avoid having Loctite on sliding sheave bushing.

## COUNTERSHAFT BEARING SUPPORT

### Countershaft Bearing Support Removal

1. Remove *DRIVEN PULLEY*, see procedure in this section.
2. Remove nuts securing the bottom of countershaft bearing support.



mmv2008-008-011\_a

1. Nuts
2. Countershaft bearing support

3. Remove bolt retaining the top of countershaft bearing support.



mmv2008-008-012\_a

1. Countershaft bearing support
2. Upper bolt

4. Remove primary air intake silencer.
5. Loosen lower nut located behind support.



## Section 06 DRIVE SYSTEM AND BRAKE

### Subsection 03 (DRIVEN PULLEY AND COUNTERSHAFT)



1. Loosen this nut

6. Remove the countershaft bearing support.

#### Countershaft Bearing Support Installation


1. Position the countershaft bearing support.
2. Install upper bolt and nuts loosely.
3. Tighten the upper bolt to  $14 \text{ N}\cdot\text{m}$  ( $124 \text{ lbf}\cdot\text{in}$ ).
4. Torque all nuts to  $34 \text{ N}\cdot\text{m}$  ( $25 \text{ lbf}\cdot\text{ft}$ ).
5. Install the driven pulley with the countershaft then all other removed parts.



Remove the countershaft bearing support. [Photo](#)  
Install the countershaft bearing support. [Photo](#)  
Tighten the upper bolt to  $14 \text{ N}\cdot\text{m}$  ( $124 \text{ lbf}\cdot\text{in}$ ).  
Torque all nuts to  $34 \text{ N}\cdot\text{m}$  ( $25 \text{ lbf}\cdot\text{ft}$ ).



Position the countershaft bearing support on the shaft. [Photo](#)  
Install the upper bolt and nuts loosely. [Photo](#)



Tighten the upper bolt to  $14 \text{ N}\cdot\text{m}$  ( $124 \text{ lbf}\cdot\text{in}$ ). [Photo](#)  
Torque all nuts to  $34 \text{ N}\cdot\text{m}$  ( $25 \text{ lbf}\cdot\text{ft}$ ). [Photo](#)

# BRAKE

## SERVICE TOOLS


<b>Description</b>	<b>Part Number</b>	<b>Page</b>
CALIPER PULLER .....	529 036 145 .....	467
PROTECTIVE CAP .....	529 036 150 .....	467

## SERVICE PRODUCTS

<b>Description</b>	<b>Part Number</b>	<b>Page</b>
DOT 4 BRAKE FLUID GTLMA.....	293 600 062 .....	463
LOCTITE 767 (ANTISEIZE LUBRICANT) .....	293 800 070 .....	468

# Section 06 DRIVE SYSTEM AND BRAKE

## Subsection 04 (BRAKE)



## GENERAL

During assembly/installation, use torque values and service products as in the exploded view.

Clean threads before applying a threadlocker. Refer to *SELF-LOCKING FASTENERS* and *LOCTITE APPLICATION* at the beginning of this manual for complete procedure.

### ⚠ WARNING

Torque wrench tightening specifications must be strictly adhered to. Locking devices (e.g.: locking tabs, elastic stop nuts, cotter pins, etc.) must be replaced with new ones.

Hoses or cables removed or disconnected must be installed and routed at the same place.

**NOTICE** Locking ties removed during a procedure must be replaced and installed at the same location.

### ⚠ WARNING

Never apply anything to brake fittings. The use of threads sealant or Teflon tape could cause brake system failure. Severe injury or death can occur.

### ⚠ WARNING

A contaminated brake disc or pad reduces stopping power. Discard contaminated pads and clean contaminated disc with a high quality brake degreasing agent.

**NOTICE** Avoid spilling brake fluid on plastic, rubber or painted parts. Protect these parts with a rag when servicing brake system.

**NOTICE** Wipe up any brake fluid spillage.

**NOTICE** To avoid serious damage to the brake system, use only DOT 4 brake fluid from a sealed container. Do not use brake fluid taken from old or already opened containers, nor mix different fluids for topping off.

**NOTICE** Sealing washers must be discarded and replaced with NEW ones every time a Banjo fitting is unscrewed.

Dispose brake fluid as per your local environmental regulation.

## MAINTENANCE

### BRAKE FLUID

The brake fluid must be changed in accordance with the maintenance chart.


#### Recommended Brake Fluid

Always use brake fluid meeting the specification DOT 4 such as DOT 4 BRAKE FLUID GTLMA (P/N 293 600 062).

#### Brake Fluid Level Verification

With the vehicle on a level surface, position steering in straight-ahead position to ensure reservoir is level.

Brake fluid must always be above the MIN. line when brake lever is squeezed.



1. MINIMUM line


Add fluid as required. Do not overfill.

**NOTE:** A low level may indicate leaks or worn brake pads.

### Brake Fluid Replacement


#### Draining

1. Place vehicle on a level surface.
2. Remove reservoir cover with its diaphragm.




## Section 06 DRIVE SYSTEM AND BRAKE

### Subsection 04 (BRAKE)



1. Reservoir cover  
2. Diaphragm

3. Connect a clear hose to caliper bleeder.
4. Place the other end of hose in a container.
5. Loosen bleeder and pump brake lever until no more fluid flows out of bleeder.



1. Bleeder  
2. Clear hose to catch used brake fluid

#### Filling

To fill brake circuit when it is empty do the following:

1. Ensure reservoir cover is removed.
2. Using a big syringe, push brake fluid slowly into the caliper.



mmv2008-043-104

3. Continue to push brake fluid until reservoir is half full.
4. Close bleeder.
5. Add brake fluid into reservoir and install cover.
6. Squeeze brake lever.
  - 6.1 If brake lever is firm, it is not required to bleed brake system. Tighten bleeder to  $9\text{ N}\cdot\text{m}$  ( $80\text{ lbf}\cdot\text{in}$ ).
  - 6.2 If brake lever is spongy, bleed brake system as per following procedure.

#### Bleeding

1. Install a clear hose on bleeder.
2. Place the other end in a container partially filled with clean brake fluid.
3. Pump up circuit pressure with brake lever until lever resistance is felt.
4. Squeeze brake lever and open bleeder. When lever touches the handlebar, do not release lever and close bleeder.
5. Release brake lever slowly.
6. Repeat the procedure until no more air bubbles appear in hose.
7. Install cover on reservoir.
8. Squeeze brake lever.

**NOTE:** Check fluid level often to prevent air from being pumped into the circuit.

- 8.1 If brake lever is firm, bleeding procedure is completed. Tighten bleeder to  $9\text{ N}\cdot\text{m}$  ( $80\text{ lbf}\cdot\text{in}$ ).
- 8.2 If brake lever is still spongy, go to step 9.
9. Push back brake pads with caliper in place and squeeze brake lever.
10. Repeat step 2 to step 5.
11. Tighten bleeder to  $9\text{ N}\cdot\text{m}$  ( $80\text{ lbf}\cdot\text{in}$ ).
12. Install diaphragm and cover on reservoir.

## PROCEDURES


### BRAKE PADS

#### Brake Pads Inspection

1. Measure brake pad lining thickness.

SERVICE LIMIT	
Brake pad thickness	1 mm (1/32 in)

**NOTICE** Brake pads must always be replaced in pairs.




1. Groove on pad lining
- A. Brake pad minimum thickness 1 mm (1/32 in)

2. Inspect brake disc at the same time.


### Brake Pads Replacement

1. Place the vehicle on a level surface.
2. Cover the plastic parts under and near master cylinder in the event that brake fluid would be spilled.
3. Remove reservoir cover with its diaphragm.




1. Reservoir cover
2. Diaphragm

4. Remove the disc brake protective cover.



1. Retaining screws

5. Remove the clip securing pad pin.
6. Unscrew and remove the pad pin.




1. Clip
2. Brake pad pin

7. Using a flat screwdriver, depress pistons into their bores.

**NOTICE** Pay attention to avoid scratching brake disc.

8. Remove the circlip securing disc brake to drive shaft.



1. Brake disc circlip

9. Remove brake pads.

9.1 Remove the external pad first.

9.2 Pull the brake disc and remove the internal pad.



## Section 06 DRIVE SYSTEM AND BRAKE

### Subsection 04 (BRAKE)

10. At this time, check brake disc condition. Refer to *BRAKE DISC INSPECTION* further in this section.

11. Install **NEW** brake pads with tabs upward.



1. Brake pad tab

12. Install brake pad pin.


13. Tighten pin to 10 N•m (89 lbf•in).

14. Install clip on brake pad pin. If the clip seems loose, replace it with a new one.

15. Make sure spring ends on brake pads pins are correctly installed as per the following pictures.



CORRECT



INCORRECT (ON RIGHT SIDE)

16. Operate the brake lever several times to bring the brake pads into contact with the disc brake.

17. Check brake fluid level in master cylinder and refill if necessary.

18. Install the diaphragm and the reservoir cover.

19. Install the disc brake protective cover.

20. Ride the vehicle a few minutes to make sure the repair is successful.

## CALIPER

### Caliper Removal

1. Open the RH side panel.

2. Refer to *CHAINCASE* section and carry the following steps.

2.1 Remove chaincase cover.

2.2 Loosen drive chain.

2.3 Remove lower sprocket.


3. Open LH side panel.

4. Remove drive belt guard support. Refer to *DRIVE BELT* section.

**NOTE:** If the caliper is not replaced, omit steps 5 and 6 concerning the brake system draining and brake hose removal.

5. Drain the brake system, refer to *BRAKE FLUID REPLACEMENT* in this section.

6. Remove the Banjo fitting and discard the sealing washers.




1. Banjo fitting  
2. Sealing washers

7. Remove the brake disc protective cover.


## Section 06 DRIVE SYSTEM AND BRAKE

### Subsection 04 (BRAKE)



1. Screws

8. Lift the rear of vehicle and release track tension completely.
9. Turn driven pulley to align brake disc slots with caliper bracket screws.
10. Remove caliper screws (4) behind brake disc.



1. Brake disc slots  
2. Caliper screws behind brake disc

11. Pull the drive axle assembly (brake disc, caliper and bearing) from LH side.



PULL


12. Remove *BRAKE PADS*, see procedure in this section.

13. Install the CALIPER PULLER (P/N 529 036 145) on the brake caliper through brake disc slots.

**NOTE:** Make sure puller tabs are correctly engaged on caliper.



14. Install the PROTECTIVE CAP (P/N 529 036 150) between caliper puller bolt and plastic cap.



1. Caliper puller  
2. Protective cap  
3. Caliper bracket  
4. Brake disc

15. Tighten caliper puller bolt to separate caliper from drive axle bearing.

**NOTICE** Never use an impact tool to operate caliper puller. The caliper or the puller could break.

16. When brake disc is out of splines, remove it.
17. Remove caliper.

**NOTICE** Do not let caliper hangs by the hose and do not stretch or twist the hose.

#### Caliper Inspection

1. Check pistons for:
  - Rust




## Section 06 DRIVE SYSTEM AND BRAKE

### Subsection 04 (BRAKE)


- Scratches
  - Leaks.
2. Check caliper bracket for:
    - Cracks
    - Rust on bearing shoulder (clean with a steel wood).
  3. Replace caliper if required.

### Caliper Installation

1. Using your fingers or a small piece of wood, push both pistons into their bores.
2. Clean brake caliper bearing shoulder with fine steel wool.
3. Apply **LOCTITE 767 (ANTISEIZE LUBRICANT)** (P/N 293 800 070) on drive shaft splines and on caliper bracket bearing shoulder.




1. Drive shaft splines
2. Drive shaft bearing




1. Caliper bracket
2. Bearing shoulder

4. Insert brake disc into caliper. The brake disc collar must be inserted into caliper bracket.




1. Brake disc collar
2. Caliper bracket

5. Ensure bearing flange is properly locked. Tabs must be properly inserted in frame.




- VIEW FROM OUTSIDE FRAME
1. Bearing flange locking tabs

6. Align brake disc splines with drive shaft splines and push the disc on the shaft.
7. Push the caliper bracket over drive shaft bearing.



1. Caliper bracket
2. Drive shaft bearing

8. Align caliper bracket holes with bearing flange holes and install caliper screws.



1. Bearing flange (inside frame)  
 2. Caliper bracket  
 3. Caliper screws

9. **HAND TORQUE** each caliper bracket screws evenly in a criss-cross pattern until bracket is correctly positioned against frame.

**NOTICE** Never use an air tool to tighten caliper screws. The caliper bracket could cracked.

10. Torque screws to 25 N•m (18 lbf•ft).

11. Install **BRAKE PADS**, see procedure above in this section.

12. Install the brake disc circlip.

13. Apply brake fluid on Banjo fitting threads.

14. Install the Banjo fitting with two **NEW** sealing washers.

15. Torque Banjo fitting to 35 N•m (26 lbf•ft).

16. Fill and bleed the brake system. Refer to **BRAKE FLUID REPLACEMENT** in this section.

17. Install all other removed parts.

18. Check the operation of the brake carefully before riding the snowmobile.

## BRAKE DISC

### Brake Disc Inspection

#### Prior Brake Disc Removal

1. Remove the disc brake protective cover.
2. Check for scoring, cracking or bending, replace as required.
3. Measure brake disc thickness. If the brake disc is out of specification, replace it with a new one.

**NOTICE** Brake disc should never be machined.

#### BRAKE DISC THICKNESS

Minimum thickness	4.5 mm (.177 in)
-------------------	------------------

#### After Brake Disc Removal

1. Check brake disc splines and drive shaft splines for wear or other damages. Replace defective parts.

#### Brake Disc Removal and Installation


Use the same procedure as for the caliper.

## MASTER CYLINDER

### Master Cylinder Removal

**NOTE:** If the master cylinder is not replaced, omit the next steps concerning the brake system draining and brake hose removal.

1. Drain the brake system, refer to **BRAKE FLUID REPLACEMENT** at the beginning of this section.
2. Remove the Banjo fitting and discard the sealing washers.



1. Banjo fitting  
 2. Sealing washers

3. Remove steering pad.




**TYPICAL - MX Z TNT SHOWN**  
 1. Steering pad

4. Unplug the LH connector.


## Section 06 DRIVE SYSTEM AND BRAKE

### Subsection 04 (BRAKE)



TYPICAL

5. Cut locking tie securing brake light switch wiring to handlebar.
6. Remove screws and clamp securing master cylinder to handlebar.



1. Master cylinder clamp
2. Master cylinder clamp screws

7. Remove master cylinder.


**NOTICE** Do not let master cylinder hang by the hose and do not stretch or twist the hose.

#### Master Cylinder Inspection

1. Discard all remaining fluid inside master cylinder reservoir.
2. Check if the seal of the reservoir cap is brittle, hard or damaged. Replace if necessary.
3. If the reservoir is damaged or leaking, replace master cylinder.
4. Check if brake lever is bent, cracked or otherwise damaged. Replace brake lever if required.

#### Master Cylinder Installation

1. Place the master cylinder on the handlebar.
2. Install master cylinder clamp with its arrow pointing toward the front of vehicle.




1. Arrow on clamp

3. Install master cylinder clamp screws and tighten loosely.
4. With the handlebar in straight ahead position, place the reservoir parallel to the ground.
5. Tighten brake lever clamp screws to  $10\text{ N}\cdot\text{m}$  ( $89\text{ lb}\cdot\text{in}$ ).
6. Install the Banjo fitting with two **NEW** sealing washers.
7. Torque Banjo fitting to  $18\text{ N}\cdot\text{m}$  ( $159\text{ lb}\cdot\text{in}$ ).
8. Fill and bleed the brake system. Refer to **BRAKE FLUID REPLACEMENT** at the beginning of this section.
9. Connect brake light switch connector.
10. Install steering cover.

## BRAKE LIGHT SWITCH

### Brake Light Switch Resistance Test

1. Remove steering cover and unplug the LH connector.



2. Validate switch operation with an ohmmeter.


SWITCH	WIRE	RESISTANCE
Released	Pin 3 and pin 4	Infinite (OL)
Pushed and held	Pin 3 and pin 4	$0.2\ \Omega$

If readings do not correspond to the above specifications, replace switch.

If readings correspond to the above specifications, check fuse, wiring and connectors going to switch. Repair or replace defective part(s).


### Brake Light Switch Removal

1. Slip a small screwdriver between brake light switch and brake lever and separate them.



1. Brake light switch.
2. Brake lever.

2. Remove the steering cover and unplug the LH connector.



3. Cut all locking ties securing switch wires.
  4. Remove switch wires from connector.
- NOTE:** Check wires location for reinstallation.

### Brake Light Switch Installation

1. Plug switch wires into connector.
2. Squeeze brake lever.
3. Insert the both tabs of switch into brake lever body.
4. Plug the connector.
5. Check if switch is working properly.
6. Install new locking ties and the steering cover.

# CHAINCASE

## SERVICE TOOLS

<b>Description</b>	<b>Part Number</b>	<b>Page</b>
CHAINCASE BEARING EXTRACTOR/INSTALLER .....	529 036 111 .....	480
	529 036 112 .....	480

## SERVICE TOOLS – OTHER SUPPLIER


<b>Description</b>	<b>Part Number</b>	<b>Page</b>
SNAP-ON SEAL PULLER .....	YA105 .....	481

## SERVICE PRODUCTS

<b>Description</b>	<b>Part Number</b>	<b>Page</b>
XP-S SYNTHETIC CHAINCASE OIL .....	413 803 300 .....	475

## Section 06 DRIVE SYSTEM AND BRAKE

### Subsection 05 (CHAINCASE)



## GENERAL

During assembly/installation, use the torque values and service products as in the exploded view. Clean threads before applying a threadlocker. Refer to *SELF-LOCKING FASTENERS* and *LOCTITE APPLICATION* at the beginning of this manual for complete procedure.

### ⚠ WARNING

Torque wrench tightening specifications must be strictly adhered to. Locking devices (e.g.: locking tabs, elastic stop nuts, cotter pin, etc.) must be replaced with new ones.


Hoses or cables removed or disconnected must be installed and routed at the same place.

**NOTICE** Locking ties removed during a procedure must be replaced and installed at the same location.

## ADJUSTMENT

### DRIVE CHAIN

1. Remove the muffler. Refer to *EXHAUST SYSTEM* section.
2. Unscrew the lock nut on tensioner adjustment screw.



1. Tensioner adjustment screw
2. Lock nut
3. Washer with rubber surface

3. Push back washer with rubber surface.
4. Tighten tensioner adjustment screw **BY HAND**.  
**NOTE:** Turn adjustment screw until resistance is strong enough that it can not be turned by hand.
5. Hold tensioner adjustment screw and tighten lock nut to 36 N•m (27 lbf•ft).

## MAINTENANCE

### CHAINCASE OIL

#### Recommended Oil

Use XP-S SYNTHETIC CHAINCASE OIL (P/N 413 803 300).

**NOTICE** Use only the recommended type oil when servicing. Do not mix synthetic oil with other types of oil.

#### Oil Level Verification

1. Place the vehicle on a level surface.
2. Remove the magnetic check plug on the left side of chaincase. Oil level must be equal with the lower edge.



1. Magnetic check plug


3. Remove metal particles from magnetic check plug.

**NOTE:** It is normal to find metallic particles stuck to magnetic check plug. If bigger pieces of metal are found, remove the chaincase cover and inspect the chaincase parts.

4. To add oil, remove the filler cap on top of chaincase cover.

## Section 06 DRIVE SYSTEM AND BRAKE

### Subsection 05 (CHAINCASE)



1. Filling plug
2. Chaincase cover

5. Pour recommended oil in chaincase by the filler hole until oil comes out by the magnetic check plug hole.

6. Reinstall magnetic check plug and torque it to  $6\text{ N}\cdot\text{m}$  ( $53\text{ lbf}\cdot\text{in}$ ).

#### Draining Procedure

1. Place a drain pan under chaincase drain plug area.
2. Loosen chaincase cover screws and pull cover.
3. Wait a while to allow oil to flow out of chaincase.

#### Filling Procedure


1. Place the vehicle on a level surface.
2. Make sure cover is tightened correctly. Refer to *CHAINCASE COVER INSTALLATION*.
3. Pour approximately 250 ml (8.5 U.S. oz) of recommended oil in chaincase by the filler hole until oil comes out by the magnetic check plug hole.
4. Reinstall magnetic check plug and torque it to  $6\text{ N}\cdot\text{m}$  ( $53\text{ lbf}\cdot\text{in}$ ).

## PROCEDURES

### CHAINCASE COVER


#### Chaincase Cover Removal

1. Remove the muffler. Refer to *EXHAUST SYSTEM* section.
2. On so equipped models, remove battery and battery rack. Refer to *CHARGING SYSTEM* section.
3. Remove filling plug on top of chaincase cover.



1. Filling plug
2. Chaincase cover


4. Disconnect the speed sensor connector.



1. Speed sensor connector

5. Place a container under vehicle in line with chaincase to catch chaincase oil.

6. Unscrew and remove chaincase cover screws.



1. Chaincase cover screws

7. Pull the bottom of chaincase cover to drain oil. Wait a moment then remove the cover completely.

#### Chaincase Cover Inspection

1. Check the cover for cracks or other damages. Replace it if necessary.




2. Check if O-ring inside cover is brittle, hard or damaged. Replace it if necessary.

### Chaincase Cover Installation

The installation is the reverse of the removal procedure. However, pay attention to the following:

1. Ensure cover O-ring is positioned correctly in its groove.
2. Tighten chaincase cover screws in accordance with the following sequence.




#### CHAINCASE COVER SCREWS TORQUE

SAME CHAINCASE	10 N•m (89 lbf•in)
NEW CHAINCASE	15 N•m (133 lbf•in)

## CHAINCASE


### Chaincase Removal

1. Apply parking brake.
2. Remove muffler. Refer to *EXHAUST SYSTEM* section.
3. Remove *CHAINCASE COVER*, see procedure in this section.
4. Remove the upper sprocket screw and its conical spring washer.




1. Upper socket
2. Conical spring washer

5. Release tension from drive chain by unscrewing the tensioner adjustment screw.



1. Tensioner adjustment screw

6. Remove tensioner arm.




1. Tensioner arm
2. Drive chain

7. Remove the lower sprocket circlip.

## Section 06 DRIVE SYSTEM AND BRAKE

### Subsection 05 (CHAINCASE)




1. Lower sprocket
2. Circlip

8. Remove the upper sprocket, lower sprocket and drive chain simultaneously.



9. Remove the countershaft spacer.




1. Countershaft spacer

10. Remove drive axle. Refer to *DRIVE AXLE* section.


11. Remove countershaft. Refer to *DRIVEN PULLEY AND COUNTERSHAFT* section.

12. Remove bolts securing the injection oil reservoir.



1. Reservoir retaining bolts


13. Using a small angle grinder, remove the following rivet heads.



14. Using a 1/4 in drill bit, remove rivet located on right side of chaincase.



15. Unscrew bolt behind the top of chaincase.



- 1. Chaincase
- 2. Retaining bolt
- 3. RH side frame member
- 4. Injection oil reservoir

16. Using 2 large pry bars inserted between chaincase and frame, pry chaincase out of vehicle.

### Chaincase Inspection

Visually inspect the chain and sprockets for:

- Wear
- Cracks
- Damages teeth
- Missing links.

If a problem is detected, replace drive chain and sprockets as an assembly.

Check the drive chain deflection.

If the deflection is greater than 38 mm (1-1/2 in) without the chain tensioner, replace the chain.

Check for worn or defective bearings.


Check chain tensioner slider for wear or other damages.

### Chaincase Installation

To install the chaincase, have the following parts in hands:

PARTS TO INSTALL CHAINCASE		
QTY	FASTENERS	P/N
1	Mounting plate	518 325 816
2	M6 x 20 hexagonal flanged bolt	207 662 034
7	M6 elastic flanged nut	233 261 434

Install the mounting plate.




**UNDERNEATH FRAME**  
1. Mounting plate

Install the chaincase.

Install 5 elastic flanged nuts to secure chaincase.

**NOTE:** Unless otherwise noted, bolts and nuts holding the chaincase must be installed loosely **FIRST**.

Install 2 flanged bolts and secure with elastic flanged nuts.



1. Install bolt here  
2. Mounting plate

Install a flange bolt to securing chaincase to RH side member.





**NUT LOCATED OUTSIDE**

Install bolt behind the top of chaincase.

## Section 06 DRIVE SYSTEM AND BRAKE

### Subsection 05 (CHAINCASE)

Using the following sequence, tighten all nuts to 10 N•m (89 lbf•in).



Install all other removed parts.

Make sure to install sprockets with their inscriptions outward.

Install the conical spring washer on the upper socket with its concave side toward sprocket.

Torque upper sprocket screw to 48 N•m (35 lbf•ft).

Install the *CHAINCASE COVER*, see procedure in this section.

Refill the chaincase, refer to *CHAINCASE OIL* above in this section.

Adjust drive chain. Refer to *DRIVE CHAIN ADJUSTMENT* in this section.

## CHAINCASE BEARING

**NOTE:** This procedure can be applied either for the countershaft bearing or the drive shaft bearing.


### Chaincase Bearing Removal

Remove chaincase cover.

Remove both sprockets and drive chain. Refer to *CHAINCASE REMOVAL*.

Remove the countershaft or the drive axle, depending which bearing is replaced. Refer to appropriate section, *DRIVEN PULLEY AND COUNTERSHAFT* or *DRIVE AXLE*.

Remove the snap ring securing bearing into chaincase.



DRIVE AXLE BEARING SHOWN

1. Snap ring
2. Bearing

Install the appropriate bearing extractor:

BEARING	TOOL
Countershaft	CHAINCASE BEARING EXTRACTOR/INSTALLER (P/N 529 036 111)
Drive axle	CHAINCASE BEARING EXTRACTOR/INSTALLER (P/N 529 036 112)




COUNTERSHAFT



DRIVE AXLE


Install the extractor/installer tool behind the bearing.

**Section 06 DRIVE SYSTEM AND BRAKE**  
Subsection 05 (CHAINCASE)



mm/2008-044-114\_a  
1. Extractor/installer tool

Install the extractor cup over bearing.  
Tighten the extractor/installer tool screw to remove the bearing.



mm/2008-044-115\_a  
1. Extractor cup  
2. Tighten to remove bearing


Using a seal puller such as the SNAP-ON SEAL PULLER (P/N YA105), remove and discard the oil seal.



mm/2008-044-116


### Chaincase Bearing Installation

Install the **NEW** oil seal on the extractor/installer tool. Position the lips toward bearing.



mm/2008-044-117\_a  
1. Extractor/installer tool  
2. Oil seal lips on this side


Install the extractor cup inside frame.



mm/2008-044-118\_a  
1. Extractor cup

Tighten the extractor/installer tool screw to install the oil seal.

Install the large washer and the extractor/installer tool screw inside frame.




mm/2008-044-119\_a  
1. Large washer  
2. Extractor/installer tool screw

In chaincase, install **NEW** bearing and the extractor/installer tool.

## Section 06 DRIVE SYSTEM AND BRAKE

### Subsection 05 (CHAINCASE)



1. Bearing
2. Extractor/installer tool

Tighten the extractor/installer tool screw to install the bearing.

Remove tool.


Install all other removed parts.

## CHAIN TENSIONER

### Chain Tensioner Removal


Remove the *CHAINCASE COVER*, see procedure in this section.

Release tension from drive chain by unscrewing the tensioner adjustment screw.



1. Tensioner adjustment screw

Remove tensioner arm.




1. Tensioner arm
2. Drive chain

### Chain Tensioner Disassembly

Remove the shaft ring securing the tensioner shaft to tensioner arm.

Remove the tensioner shaft to remove the slider.



1. Shaft ring
2. Tensioner shaft
3. Tensioner arm
4. Slider

### Chain Tensioner Inspection

Check chain tensioner slider for wear or other damages. Replace if necessary.

Check threads of tensioner adjustment screw for damages or wear.

Replace screw if necessary and check chaincase for damages.

Check rubber washer condition, replace as required.

### Chain Tensioner Assembly

The assembly is the reverse of the disassembly.

**NOTE:** When assembly is completed, make sure circlip turns freely and slider moves easily.

### Chain Tensioner Installation

The installation is the reverse of the removal procedure.

Adjust drive chain tension. Refer to *DRIVE CHAIN ADJUSTMENT* at the beginning of this section.


# DRIVE AXLE

## SERVICE TOOLS – OTHER SUPPLIER

<b>Description</b>	<b>Part Number</b>	<b>Page</b>
SNAP-ON 3-JAW PULLER .....	cg273 .....	486


## SERVICE PRODUCTS

<b>Description</b>	<b>Part Number</b>	<b>Page</b>
THERMO LUBE SYNTHETIC GREASE.....	219 700 417 .....	487



## Section 06 DRIVE SYSTEM AND BRAKE

### Subsection 06 (DRIVE AXLE)





## GENERAL

During assembly/installation, use torque values and service products as in the exploded view.

Clean threads before applying a threadlocker. Refer to *SELF-LOCKING FASTENERS* and *LOCTITE APPLICATION* at the beginning of this manual for complete procedure.

### **⚠ WARNING**

Torque wrench tightening specifications must be strictly adhered to.


Locking devices (e.g.: locking tabs, elastic stop nuts, cotter pins, etc.) must be replaced with new ones.

## PROCEDURES

### DRIVE AXLE


#### Drive Axle Removal

1. Remove the rear suspension. Refer to *REAR SUSPENSION* section.
2. Remove the caliper. Refer to *BRAKE* section.
3. Remove the chaincase cover. Refer to *CHAINCASE* section.
4. Release tension from drive chain by unscrewing the tensioner adjustment screw.



1. Tensioner adjustment screw
2. Lock nut
3. Washer with rubber surface

5. Remove the lower sprocket circlip.



1. Lower sprocket
2. Circlip

6. Remove lower gear and drive chain.

7. From underneath of vehicle, turn the LH bearing flange counterclockwise to unlock it from frame.



1. Bearing flange locking tabs

8. Release drive axle sprockets from track and at the same time, push the drive axle toward the LEFT side.

9. Move the drive axle towards the right side to remove it from vehicle.

#### Drive Axle Inspection

Check if bearing turns smoothly and freely. Replace bearing if necessary.

Check if bearing seals are not damaged. Replace bearing if necessary.

Check if the bearing flange is cracked, bent or otherwise damaged. Replace it if required.

Replace drive axle if one of the following situations is detected:


- Cracked, worn or damaged drive axle
- Worn or damaged drive axle splines
- Worn or damaged sprockets
- Worn bearing journal.

## Section 06 DRIVE SYSTEM AND BRAKE

### Subsection 06 (DRIVE AXLE)

#### Drive Axle Bearing Removal

1. Remove the O-ring.



1. Drive axle bearing
2. Bearing flange
3. O-ring


2. Using a 3-jaw puller such as the SNAP-ON 3-JAW PULLER (P/N CG273), remove the drive axle bearing.



3. Remove the bearing flange.

#### Drive Axle Bearing Installation

1. Install bearing flange on drive axle.



1. Locking tabs outwards

2. Using a press and a suitable pipe, push the bearing.

**NOTICE** Always push the bearing by inner race.




#### Drive Axle Installation

The installation is the reverse of the removal procedure. However, pay attention to the following.

1. Install drive axle then lock the bearing flange on frame.

**NOTE:** Ensure bearing flange is properly locked. Tabs must be properly inserted in frame.



VIEW FROM OUTSIDE FRAME

1. Bearing flange locking tabs

2. Install the caliper and the disc brake. Refer to *BRAKE* section for the specific procedure.
3. Install all other removed parts. Refer to the appropriate sections.

## MAGNETIC CAPS

### Magnetic Cap Removal

1. For the LH cap, remove brake disc protective cover. Refer to *BRAKE* section.
2. For the LH cap, remove the chaincase cover. Refer to *CHAINCASE* section.
3. Using two screwdrivers or pliers, pry or pull the magnetic cap out of drive axle end.
4. Discard the magnetic cap.

### Magnetic Cap Installation

1. Apply THERMO LUBE SYNTHETIC GREASE (P/N 219 700 417) on O-ring.
2. Insert the magnetic cap into drive axle.
3. Install all other removed parts.

# TRACK

## SERVICE TOOLS

Description	Part Number	Page
BELT TENSION TESTER.....	414 348 200 .....	490
NARROW-CLEAT INSTALLER.....	529 036 044 .....	489

## PROCEDURES

### TRACK

#### Track Inspection

Visually inspect track for:

- Cuts and abnormal wear
- Broken rods
- Broken or missing track cleats
- Perforations in the track
- Tears in the track (particularly around traction product holes)
- Lugs that are broken or torn off, exposing portion of rods
- Delamination of the rubber
- Broken studs
- Bent studs
- Studs that are torn off the track
- Missing track guide(s).

If track is damaged or rods are broken, replace track. For damaged or missing cleats, replace by new ones.

#### WARNING

Do not operate a snowmobile with a cut, torn or damaged track.

#### Track Cleat Replacement

Raise rear of vehicle off the ground.

Lift snow guard.

Rotate track to expose a cleat to be replaced.


Remove cleat from track using plastic hammer and a big screwdriver.



TYPICAL  
1. Cleat

Place new cleat in position on the track.

Secure cleat using the NARROW-CLEAT INSTALLER (P/N 529 036 044).



Bend cleat and push tabs into rubber.



TYPICAL  
1. Narrow-cleat installer

Reopen narrow-cleat installer.

Position cleat tabs on open end of tool.

## Section 06 DRIVE SYSTEM AND BRAKE

### Subsection 07 (TRACK)

Squeeze tabs until they are indented in rubber.

#### Track Removal


Remove rear suspension from vehicle. Refer to *REAR SUSPENSION*.

Remove track from rear suspension.

#### Track Installation

Reverse the removal procedure.

**NOTE:** When installing the track, respect rotation direction indicated by an arrow on track thread.



1. Arrow pointing forwards

#### Track Adjustment

Track tension and alignment are interrelated. Do not adjust one without checking the other. Track tension procedure must be carried out prior to track alignment.

##### Tension

**NOTE:** After track adjustment, ride the snowmobile in snow about 15 to 20 minutes and recheck track tension.


Lift snowmobile by a rope, chain or lift strap hooked to rear bumper.

Allow the rear suspension to fully extend and check gap halfway between front and rear idler wheels.

Measure between slider shoe bottom and inside of track. The gap should be as given in the following table.

TRACK ADJUSTMENT	
TRACK ADJUSTMENT FORCE	7.3 kgf (16.1 lbf)
TRACK DEFLECTION	30 mm to 35 mm (1.181 in to 1.378 in)

The BELT TENSION TESTER (P/N 414 348 200) may be used to measure deflection as well as force applied.




1. Tool top O-ring positioned at 7.3 kgf (16 lbf)
2. Apply pressure on tool until it contacts the upper O-ring
3. Measured track deflection

**NOTICE** Too much tension will result in power loss and excessive stresses on suspension components.

To adjust tension, do the following:

1. Lift rear of vehicle and support it off the ground.
2. Remove rear idler wheel caps.



1. RH rear idler wheel cap

3. Unscrew and remove rear axle screws (one each side).


## Section 06 DRIVE SYSTEM AND BRAKE

### Subsection 07 (TRACK)



1. RH rear axle screw

4. Tighten or loosen both adjustment screws to increase or decrease track tension.



1. RH adjustment screw


### Alignment

#### **⚠ WARNING**

Before checking track alignment, ensure that the track is free of all particles which could be thrown out while track is rotating. Keep hands, tools, feet and clothing clear of track. Ensure no one is standing in close proximity to the vehicle. Never rotate at high speed.


Start the engine and accelerate slightly so that track barely turns. This must be done in a short period of time (1 to 2 minutes).

Check that the track is well centered; equal distance on both sides between edges of track guides and slider shoes.



1. Guides
2. Slider shoes
3. Equal distance

To correct, stop engine, loosen rear wheel screws, then tighten the adjustment screw on side where the slider shoe is the farthest from the track insert guides.



1. Guides
2. Slider shoes
3. Tighten on this side

Restart engine, rotate track slowly and recheck alignment.

If the satisfactory alignment is achieved, then tighten the idler wheel retaining screws to 48 N•m (35 lbf•ft).

Reinstall the wheel caps.

## TRACTION ENHANCING PRODUCTS (STUDS)

### Important Safety Rules

All REV-XP and REV-XR (2-stroke) tracks use special single ply of fabric track to reduce weight and rolling resistance. The conventional track design is a 2 layers of fabric and one layer of high strength tensile cord. These new tracks design is a single layer of fabric and one layer of tensile cord. This results in a thinner track and if studded, absolutely requires the use of the 286 Phantom series designed studs.

## Section 06 DRIVE SYSTEM AND BRAKE

### Subsection 07 (TRACK)

#### WARNING

REV-XP and REV-XR (2-stroke) require special studs. Use only the 286 phantom series studs and support plates on these tracks. The use of other kinds of studs on these tracks may cause risks of injuries.

#### WARNING

Installing an incorrect number of studs or an improper installation could reduce the track life and possibly resulting in serious injury or death.

#### WARNING

Never stud a track that has not been approved for studs. Installing studs on an unapproved track could increase the risk of the track tearing or severing, possibly resulting in serious injury or death. Approved tracks can be identified by a stud symbol molded into the track surface.

Studs should only be installed in the locations indicated by molded bulges in the track surface.

Never stud a track with a profile of 35 mm (1.378 in) or more.

The maximum allowable stud penetration range is 6.4 mm to 9.5 mm (1/4 in to 3/8 in).

The number of studs installed must match the number of molded bulges in the track.

Strictly adhere to the specified tightening torque.

#### WARNING

To prevent serious injury to individuals near the snowmobile:

- NEVER stand behind or near a moving track.
- ALWAYS use a wide-base snowmobile stand with a rear deflector panel.
- When the track is raised off the ground, only run it at lowest possible speed.

Centrifugal force could cause debris, damaged or loose studs, pieces of torn track, or an entire severed track to be violently thrown backwards out of the tunnel with tremendous force, possibly resulting in the loss of a leg or other serious injury.

### Effects of Having a Studded track on the Life of the Snowmobile

The use of traction enhancing products can increase the load and the stress on certain snowmobile components, as well as the vibration level. This can cause premature wear on parts such as belts, brake lining, bearings, chain, and chain-case sprockets, and on approved studded tracks, shorten track life. For this reason, it is even more important to follow the detailed maintenance program given in the *MAINTENANCE CHART*.

Studs on the track can also cause serious damage to the snowmobile if it is not equipped with the tunnel protectors designed for the particular model. Damage to the electrical wiring or perforation of the heat exchangers are potential hazards, that could cause the engine to overheat and be severely damaged.

#### WARNING

If tunnel protectors are excessively worn or not installed, the gas tank could be punctured, causing a fire.

### Studs and Track Inspection

A visual inspection of the track should be performed before each use. Refer to *TRACK INSPECTION*.

Replace broken or damaged studs immediately. If the track shows signs of deterioration, it must be replaced immediately. In doubt, replace the track.

#### WARNING

Riding with a damaged track or studs could lead to loss of control, resulting in a risk of serious injury or death.

### Stud Installation Tables

Use the following table for appropriate size and quantity of studs.

<b>APPROVED STUDS ACCORDING TO TRACK LUG HEIGHT</b>			
<b>LUG HEIGHT</b>	<b>STUD SIZE</b>	<b>QTY OF STUDS FOR A 120" TRACK</b>	<b>QTY OF STUDS FOR A 137" TRACK</b>
1.000"	1.075"	84	96
1.250"	1.325"	84	96

Use the following table for appropriate tunnel protector kits.

<b>TUNNEL PROTECTOR KITS</b>		
<b>CHASSIS TYPE</b>	<b>TRACK DIMENSION</b>	<b>KIT P/N</b>
REV-XP	All 120" and 137" (up to 1.250")	860 200 267
REV-XR (2-stroke)		

### **Stud Installation Procedure**

Refer to manufacturer's instruction for complete installation procedure.




# FRONT SUSPENSION

## SERVICE TOOLS

Description	Part Number	Page
BALL JOINT INSTALLER.....	529 035 975 .....	504
BALL JOINT REMOVER.....	529 035 827 .....	501
	529 036 121 .....	503-504
SPRING COMPRESSOR TOOL.....	529 036 007 .....	499

# Section 07 CHASSIS

## Subsection 01 (FRONT SUSPENSION)



## GENERAL

The procedure explained below is the same for the RH and LH sides unless otherwise noted.

During assembly/installation, use torque values and service products as in the exploded view.

Clean threads before applying a threadlocker. Refer to *SELF-LOCKING FASTENERS* and *LOCTITE APPLICATION* at the beginning of this manual for complete procedure.

### **⚠ WARNING**

Torque wrench tightening specifications must be strictly adhered to. Locking devices (e.g.: locking tabs, elastic stop nuts, cotter pins, etc.) must be replaced with new ones.

Check for loose, bent, worn out, rusted or otherwise damaged components. Replace the faulty components.

## ADJUSTMENT

### SUSPENSION SPRING

SPRINGS ADJUSTMENT GUIDELINE		
HANDLING	STEERING	SOLUTION
Too soft	Too easy to turn	Increase spring preload
Too hard	Hard to turn	Decrease spring preload

### **⚠ WARNING**


Adjust both springs to the same load. Uneven adjustment can cause poor handling and loss of stability, and/or control, and increase the risk of an accident.

### Spring Preload Adjustment

#### Screw Type Adjustment

*MX Z (50<sup>th</sup>, Renegade X, TNT, X) and SUMMIT (50<sup>th</sup>, Hill Climb, X (CA/US), X (154° EUR))*


Grab and turn the spring to increase or decrease spring preload.



1. Adjustment ring  
2. Ring positions


#### Cam Type Adjustment

Using the suspension adjustment tool (included in the tool kit), turn the cam to increase or decrease spring preload.



SUSPENSION ADJUSTMENT TOOL

*GSX (Limited), GTX (LE), MX Z (Adrenaline, Renegade) and SUMMIT (Everest 600 (EUR), 600 E-TEC, 800R)*



1. Adjustment cam  
2. Cam positions

## Section 07 CHASSIS

### Subsection 01 (FRONT SUSPENSION)

*GSX (Sport), GTX (Sport), MX Z (Trail) and SUMMIT (Everest 600 146" (CA/US))*



1. Adjustment cam  
2. Cam positions

## SHOCK ABSORBER

### Compression/Rebound Adjustment

*MX Z (Renage X, TNT (EUR), X) and SUMMIT (Hill Climb)*

Front shock on the above mentioned models feature a compression/rebound adjustment.

Turn the damping adjuster accordingly. Turning it clockwise increases shock damping action (stiffer).



- TYPICAL  
1. Damping adjuster

## PROCEDURES

### SHOCK ABSORBER


#### Shock Absorber Removal

Refer to *BODY* section to remove the following:

- Hood
- Side panel(s)

To remove the RH shock absorber, remove the muffler. Refer to *EXHAUST SYSTEM* section.


To remove the LH shock absorber, remove the tool kit support by pressing the locking tab.



- Step 1: Press tab  
Step 2: Lift tool kit support


Lift the front of vehicle until skis are off the ground.

Remove the shock absorber upper bolt.



1. LH shock absorber upper bolt  
2. Secondary air intake silencer  
3. Front bumper

Remove the shock absorber lower bolt.



1. Lower bolt
2. Lower suspension arm

Remove the shock absorber.

### Shock Absorber Disassembly

To remove spring from the shock absorber, use the SPRING COMPRESSOR TOOL (P/N 529 036 007).




Place the tool in a vise.




On models with a screw type adjuster, unscrew the adjuster completely.

Position the shock absorber in the tool and install the spring compressor pins.



TYPICAL

Lock the end of the shock absorber with a bolt or a steel pin.



TYPICAL

1. Spring compressor tool screw
2. Locking device (bolt or steel pin)
3. Shock absorber end

Tighten the spring compressor tool screw until the spring is sufficiently compressed to remove spring locking devices.

Remove spring stopper then release the spring compressor tool screw.



TYPICAL

### Shock Absorber Inspection

Inspect the spring for damage. Replace if necessary.

Inspect shock as following:

#### Hydraulic Shock

1. Examine shock for leaks. Extend and compress the piston at least 5 complete strokes with its rod upward.
2. After, check that shock moves smoothly and with uniform resistance over its entire stroke.

**NOTE:** For the first 5 complete strokes, it could be normal to note uneven resistance.

## Section 07 CHASSIS

### Subsection 01 (FRONT SUSPENSION)

3. Check the following conditions that will denote a defective shock:
  - A skip or a hang back when reversing stroke at mid travel.
  - Seizing or binding condition except at extreme end of either stroke.
  - Oil leakage.
  - A gurgling noise, after completing one full compression and extension strokes.
4. If suspecting a shock is freezing, place it in a freezer (temperature below 0°C (32°F)) for 4 hours.
5. Push down on rod and note its resistance. If shock is frozen it will be much more difficult to compress than one in normal condition.
6. Renew if any faults are present.

#### Gas Shock

**NOTE:** Because of gas pressure, strong resistance is felt when compressing shock.

To inspect shock operation, or if suspecting an internal leak between oil chamber and gas chamber, check shock as follows:

1. Install shock in a vise clamping on its bottom eyelet with its rod upward. Verify the compression stroke when the rod is fully extended.
2. Completely push down the shock rod then release.
3. The shock should extend unassisted. Rod must come out at a steady speed. If speed suddenly increases particularly at end of extension, replace shock.
4. If suspecting a shock is freezing, place it in a freezer (temperature below 0°C (32°F)) for 4 hours.
5. Push down on rod and note its resistance. If shock is frozen it will be much more difficult to compress than one in normal condition.

#### Shock Absorber Assembly and Installation

For assembly and installation, reverse the disassembly and removal procedures.

**NOTE:** Always install shock valve outwards when applicable.

## UPPER SUSPENSION ARM

### Upper Suspension Arm Inspection

1. Check suspension arm for distortion or damage. Replace if necessary.

2. Move suspension arm from side to side then up and down. There should be no noticeable looseness. Replace bushings and/or sleeves if necessary.

**NOTE:** A play of 2 mm (.079 in) is acceptable when the suspension arm is moved forward and backward.

3. Check sleeves inside suspension arm attachments for wear or damage.


### Upper Suspension Arm Removal

1. Lift the front of vehicle until skis are off the ground.
2. Remove muffler and tuned pipe. Refer to *EXHAUST SYSTEM* section.
3. Remove shock absorber upper bolt. See procedure in *SHOCK ABSORBER REMOVAL* in this section.
4. Remove the upper suspension arm bolts.



1. Upper suspension arm bolts

5. Remove ball joint from ski leg. See procedure in *UPPER BALL JOINT REMOVAL* in this section.



1. Ball joint nut  
2. Ball joint  
3. Ski leg

6. Remove upper suspension arm.

### Upper Suspension Arm Installation

The installation is the reverse of the removal procedure.


### UPPER BALL JOINT

#### Upper Ball Joint Inspection

Check both upper ball joints for damage, pitting, looseness and roughness. If so, replace with a new one.

#### Upper Ball Joint Removal

1. Position upper suspension arm so that ball joint becomes parallel with ski leg.
2. Detach tie-rod end from ski leg.



1. Ball joint nut
2. Ball joint
3. Ski leg

5. Install the BALL JOINT REMOVER (P/N 529 035 827) and detach ball joint from ski leg.



1. Tie-rod end bolt
2. Ski leg

3. Unscrew nut retaining ball joint housing to upper suspension arm.



1. Ball joint housing nut
2. Upper suspension arm
3. Ball joint housing

4. Remove nut securing ball joint to ski leg.



6. Remove ball joint.


#### Upper Ball Joint Installation

The installation is the reverse of the removal procedure. However, pay attention to the following.


1. Install ball joint washers as shown.

## Section 07 CHASSIS

### Subsection 01 (FRONT SUSPENSION)




1. Ball joint housing
2. Washer
3. Upper suspension arm



1. Washer
2. Ski leg
3. Ball joint

2. Tighten nuts to 48 N•m (35 lbf•ft).

Ensure ball joint has the proper angle as shown. The ball joint must be parallel to ski leg tab. This mounting position corresponds to  $10^\circ \pm 3^\circ$  angle from upper arm.



- A.  $10^\circ \pm 3^\circ$   
B. Parallel

## LOWER SUSPENSION ARM

### Lower Suspension Arm Inspection

1. Check suspension arm for distortion or damage. Replace if necessary.
2. Detach shock absorber and stabilizer bar from lower suspension arm. Move suspension arm from side to side then up and down. There should be no noticeable loose. Replace bushings and/or sleeves if necessary.

**NOTE:** A play of 2 mm (.079 in) is acceptable when the suspension arm is moved forward and backward.

3. Check sleeves inside suspension arm attachments for wear or damage.


### Lower Suspension Arm Removal

1. Lift the front of vehicle until skis are off the ground.
2. Remove shock absorber lower bolt.



1. Shock absorber lower bolt


3. Detach stabilizer link from lower suspension arm. Refer to *STABILIZER BAR* further in this section.
4. Remove lower ball joint nuts.



1. Ball joint nut
2. Lower suspension arm
3. Lower ball joint



5. Using a suitable ball joint remover, detach lower ball joint from ski leg.
6. Remove suspension arm bolts.



**UNDERNEATH FRONT OF VEHICLE**  
 1. Suspension arm bolts  
 2. Rear nuts  
 3. Bottom pan

**NOTE:** To hold rear nuts, modify a 15 mm opened wrench as shown.




7. Remove lower suspension arm from vehicle.

**Lower Suspension Arm Installation**

The installation is the reverse of the removal procedure. However, pay attention to the following.

1. Install a wear plate over bushings.
2. Position the wear plate on top.
3. Fold all tabs against bushings.



1. Wear plate  
 2. Wear plate tabs  
 3. Bushings  
 4. Lower suspension arm

Install all other removed parts.

**LOWER BALL JOINT**

**Lower Ball Joint Inspection**

Inspect ball joint end for damage. Ensure it's moving freely without play. Replace ball joints as required.

**Lower Ball Joint Removal**

1. Remove the *LOWER SUSPENSION ARM*, see procedure in this section.
2. Remove circlip securing ball joint to suspension arm.




1. Circlip

3. Using a press and the BALL JOINT REMOVER (P/N 529 036 121), press ball joint out of the lower suspension arm.

## Section 07 CHASSIS


### Subsection 01 (FRONT SUSPENSION)



1. Ball joint remover
2. Press

### Lower Ball Joint Installation

1. Using a press, the BALL JOINT REMOVER (P/N 529 036 121) and the BALL JOINT INSTALLER (P/N 529 035 975), press ball joint into the suspension arm end.




1. Ball joint remover support
2. Ball joint installer
3. Steel plate

2. Reinstall the circlip. If the circlip seems loose, replace it with a new one.
3. Install the LOWER SUSPENSION ARM on vehicle, see procedure in this section.

### SKI LEG

#### Ski Leg Removal

1. Remove ski from ski leg.
2. Detach tie-rod end from ski leg.



1. Tie-rod end bolt
2. Ski leg

3. Remove upper and lower ball joints from ski leg. Refer to UPPER BALL JOINT and LOWER BALL JOINT in this section.


#### Ski Leg Installation

The installation is the reverse of the removal procedure.

### STABILIZER BAR


#### Stabilizer Bar Removal

1. Remove the RH side panel. Refer to BODY section.
2. Remove the muffler. Refer to EXHAUST SYSTEM section.
3. Remove the cap at the bottom of the RH side bottom pan.



1. Stabilizer bar cap
2. RH side bottom pan

4. Remove bolts securing stabilizer links to lower suspension arms.




mmr2008-047-123\_a

**RH SIDE SHOWN**

1. Stabilizer link bolt  
2. Lower suspension arm

5. Unscrew stabilizer lever bolts.  
6. Remove stabilizer levers from stabilizer bar.



mmr2008-047-123\_a

**RH SIDE SHOWN**

1. Stabilizer lever  
2. Stabilizer bar

7. Slide stabilizer bar out of vehicle.



mmr2008-047-134\_a

**RH SIDE SHOWN**

## Stabilizer Bar Installation

The installation is the reverse of the removal procedure.

# REAR SUSPENSION

## SERVICE TOOLS

Description	Part Number	Page
FLOATING PISTON PULLER .....	529 035 901 .....	530-531
FLOATING PISTON REMOVER TOOL .....	529 035 907 .....	524
GAS FILL TOOL KIT .....	503 190 102 .....	522, 528, 531
GAS SHOCK VALVE TOOL (TIRE VALVE TYPE) .....	529 035 570 .....	528
HPG SHOCK HOLDING TOOL .....	529 035 769 .....	522
SHOCK WRENCH .....	529 035 727 .....	523
VACUUM/PRESSURE PUMP .....	529 021 800 .....	524

## SERVICE PRODUCTS



Description	Part Number	Page
LOCTITE 271 (RED).....	293 800 005 .....	525
MOLYKOTE G-N .....	420 297 433 .....	526
PULLEY FLANGE CLEANER .....	413 711 809 .....	529-531
SHOCK ABSORBER OIL .....	293 600 035 .....	527, 531
SUSPENSION SYNTHETIC GREASE.....	293 550 033 .....	542

## Section 07 CHASSIS

### Subsection 02 (REAR SUSPENSION)



## RAILS AND IDLERS WHEELS

GSX, GTX and MX Z



**Section 07 CHASSIS**  
Subsection 02 (REAR SUSPENSION)

SUMMIT




## Section 07 CHASSIS

### Subsection 02 (REAR SUSPENSION)


## FRONT ARM

GSX and MX Z (50<sup>th</sup>, Adrenaline, Trail, TNT, X)



**Section 07 CHASSIS**  
Subsection 02 (REAR SUSPENSION)

GTX and MX Z (Renegade, Renegade X)







## Section 07 CHASSIS

### Subsection 02 (REAR SUSPENSION)

SUMMIT






## Section 07 CHASSIS


### Subsection 02 (REAR SUSPENSION)

SUMMIT



# SHOCK ABSORBERS

*GSX, GTX and MX Z*




# Section 07 CHASSIS


## Subsection 02 (REAR SUSPENSION)

### SUMMIT

SUMMIT Everest  
600 (CA/US)



All except  
Everest 600 (CA/US)



SUMMIT Everest 600 (CA/US)



All SUMMIT Everest  
except 600 (CA/US)



SUMMIT 50th  
SUMMIT HillClimb  
SUMMIT X

## GENERAL

**NOTE:** Refer to *TECHNICAL SPECIFICATIONS* to identify the snowmobile suspension type.

During assembly/installation, use torque values and service products as in the exploded views.

Clean threads before applying a threadlocker. Refer to *SELF-LOCKING FASTENERS* and *LOCTITE APPLICATION* at the beginning of this manual for complete procedure.

### **⚠ WARNING**

Torque wrench tightening specifications must be strictly adhered to.

Locking devices (e.g.: locking tabs, cotter pins, etc.) must be replaced with new ones.

## PROCEDURES

**NOTE:** Many parts can be changed with rear suspension in place. When specified, refer to *SUSPENSION ASSEMBLY* to remove rear suspension from vehicle.

## SUSPENSION ASSEMBLY

### Suspension Assembly Removal

1. Lift rear of vehicle and support it off the ground.
2. Completely loosen track tension.
3. Remove and discard rear arm bolts from chassis. Use the following procedure to remove bolts easily.
  - 3.1 Unscrew one of the socket screws securing the rear arm to frame.



1. Socket bolt

- 3.2 Replace this socket screw with an hexagonal bolt (longer than socket screw) and a nut.
- 3.3 Screw in the hexagonal bolt by approximately 7 turns.

- 3.4 Hold the hexagonal bolt and tighten locking nut.




1. Hexagonal bolt  
2. Locking nut

- 3.5 Unscrew the socket screw on the other side then unlock nut and remove the hexagonal bolt.

4. Remove bolts retaining front arm to tunnel.

**NOTE:** On **SUMMIT** models, discard the front arm bolts.




**TYPICAL**  
1. Front arm bolt  
2. Chaincase

5. Lift rear of vehicle until front arm as enough clearance to pass underneath tunnel.

## Section 07 CHASSIS

### Subsection 02 (REAR SUSPENSION)



TYPICAL  
1. Enough clearance



TYPICAL — REMOVE SUSPENSION

### Suspension Assembly Installation

Installation is the reverse of removal procedure. Pay attention to the following details.

1. Inspect track thoroughly before reinstalling suspension. Refer to *TRACK* section.
2. Install suspension into track with front portion first.
3. Install front arm bolts. On **SUMMIT** models, install **NEW** bolts.
4. Torque them to 48 N•m (35 lbf•ft).
5. Install **NEW** rear arm bolts and tighten them.


REAR ARM BOLTS TIGHTENING	
GSX, GTX and MX Z	85 N•m (63 lbf•ft)
SUMMIT	48 N•m (35 lbf•ft)

6. Adjust track tension.

## REAR AXLE


### Rear Axle Removal

1. Lift rear of vehicle and support it off the ground.
2. Remove rear idler wheel caps.



1. RH rear idler wheel cap

3. Loosen rear axle screws (one each side).




1. RH rear axle screw

4. Completely loosen track tension by unscrewing both adjustment screws.



1. RH adjustment screw

5. Remove both rear axle screws.
6. Remove rear idler wheels, seals and wheel spacers.



*RH SIDE SHOWN*  
 1. Rear idler wheel  
 2. Seal  
 3. Rear axle  
 4. Wheel spacer


7. Pull out the rear axle.

**Rear Axle Installation**

Installation is reverse of removal procedure. However, pay attention to the following.


1. Make sure to position all parts correctly.

**SUMMIT HillClimb**




1. Idler wheels  
 2. Seals  
 3. Wheel spacers  
 4. Rear axle  
 5. Rear axle spacer

*All Other Models*




1. Idler wheels  
 2. Seals  
 3. Wheel spacers  
 4. Rear axle  
 5. Rear axle spacer  
 6. Washer

2. Position wheel spacers with a flat side up and a groove in front of tensioner screw.



1. Wheel spacer  
 2. Groove  
 3. Flat side  
 4. Tensioner screw

**NOTE:** When tightening rear axle, make sure each wheel spacer protuberance is engaged into runner slot.



1. Wheel spacer protuberance  
 2. Runner slot



## Section 07 CHASSIS

### Subsection 02 (REAR SUSPENSION)

3. Adjust track tension. Refer to *TRACK* section.

## SHOCK ABSORBERS


### Rear Shock Absorber Removal

#### *GSX, GTX and MX Z*

1. Lift rear of vehicle and support it off the ground.

**NOTE:** If necessary, to ease shock removal, unfasten stopper strap to release shock pressure.

2. Remove bolts and nuts from shock.




1. Rear shock absorber
2. Remove bolts and nuts

3. Lower the bottom end of throttle rods to reach the bar axle.

4. Remove bar axle retaining the bottom of shock absorber.

**NOTE:** Pay attention to plastic spacers located between rocker arms and shock absorber.



1. Bar axle
2. Plastic spacers


5. Remove rear shock absorber.

### **SUMMIT**

1. Lift rear of vehicle and support it off the ground.

**NOTE:** If necessary, to ease shock removal, unfasten stopper strap to release shock pressure.

2. Remove bolts and nuts from shock.




1. Rear shock absorber
2. Remove bolts and nuts

### Center Shock Absorber Removal

#### *GSX, GTX and MX Z*


1. Lift the rear of vehicle and support it off the ground.

2. Unfasten stopper strap.



1. Stopper strap
2. Stopper strap bolt

3. Remove bolts and nuts from shock.




1. Front shock absorber
2. Remove bolts and nuts

### **SUMMIT**


1. Lift the rear of vehicle and support it off the ground.

2. Unfasten stopper strap.




1. Stopper strap
2. Stopper strap bolt

3. Remove upper shock absorber bolt.



1. Front shock absorber
2. Remove bolt and nut

4. Remove and discard socket screws (one each side) securing shock shaft.



1. RH socket screw

5. Remove shock absorber from vehicle.


6. Remove bushings and shock shaft from shock absorber.

## Shock Absorber Inspection

### Hydraulic Shock

1. Secure the shock body end in a vise with its rod upward.

**NOTICE** Do not clamp directly on shock body.



1. Clamp

2. Examine shock for leaks. Extend and compress the piston at least 5 complete strokes with its rod upward.

3. After, check that shock moves smoothly and with uniform resistance over its entire stroke.

**NOTE:** For the first 5 complete strokes, it could be normal to note uneven resistance.

4. Check the following conditions that will denote a defective shock:

- A skip or a hang back when reversing stroke at mid travel.
- Seizing or binding condition except at extreme end of either stroke.
- Oil leakage.
- A gurgling noise, after completing one full compression and extension strokes.

5. If suspecting a shock is freezing, place shock in a freezer (temperature below 0°C (32°F)) for 4 hours.

6. Push down on rod and note its resistance. If shock is frozen it will be much more difficult to compress than one in normal condition.

7. Renew if any faults are present.

### Gas Shock Except Variable Rate

1. Because of gas pressure, strong resistance is felt when compressing shock.

2. To inspect shock operation, or if suspecting an internal leak between oil chamber and gas chamber, check shock as follows:

3. Install shock in a vise clamping on its bottom eyelet with its rod upward. Verify the compression stroke when the rod is fully extended.

4. Completely push down the shock rod then release.

5. The shock should extend unassisted. Rod must come out at a steady speed. If speed suddenly increases particularly at end of extension, replace shock.

6. If suspecting a shock is freezing, place shock in a freezer (temperature below 0°C (32°F)) for 4 hours.

## Section 07 CHASSIS

### Subsection 02 (REAR SUSPENSION)

7. Push down on rod and note its resistance. If shock is frozen it will be much more difficult to compress than one in normal condition.
8. Renew if any faults are present.

#### *Variable Rate Gas Shock*

1. Because of gas pressure, strong resistance is felt when compressing shock.
2. To inspect shock operation, or if suspecting an internal leak between oil chamber and gas chamber, check shock as follows:
3. Install shock in a vise clamping on its bottom eyelet with its rod upward. Verify the compression stroke when the rod is fully extended.
4. Push down the shock rod. The feeling should be stiff for around the first 25 mm (1 in), then softer from 25 mm to 50 mm (1 in to 2 in) and stiffer again after that. This stiff/soft/stiff phenomenon shows the normal operation of shock.
5. When released, the shock should extend unassisted. The rod speed coming out will go slow - faster and slow again due to the VR zone.
6. If suspecting a shock is freezing, place shock in a freezer (temperature below 0°C (32°F)) for 4 hours.
7. Push down on rod and note its resistance. If shock is frozen it will be much more difficult to compress than one in normal condition.
8. Renew if any faults are present.

#### *HPG T/A Shock*

1. Because of gas pressure, strong resistance is felt when compressing shock.
2. To inspect shock operation, or if suspecting an internal leak between oil chamber and gas chamber, check shock as follows:
3. Install shock in a vise clamping on its bottom eyelet with its rod upward. Verify the compression stroke when the rod is fully extended.
4. Completely push down the shock rod then release.
5. The shock should extend unassisted. Rod must come out at a steady speed. If speed suddenly increases particularly at end of extension, replace shock.
6. If suspecting a shock is freezing, place shock in a freezer (temperature below 0°C (32°F)) for 4 hours.
7. Push down on rod and note its resistance. If shock is frozen it will be much more difficult to compress than one in normal condition.

8. Repair or replace if any faults are present.

### Shock Absorber Rebuilt Procedure (HPG T/A)

There are two types of high pressure gas take apart (HPG T/A) shock. One type has a tire valve and the other has a needle valve.

SHOCK TYPE	INFLATION TOOL
Tire valve type	529 035 570
Needle valve type	503 190 102

HPG T/A shocks come in two sizes. C-36 shock is 36 mm (1.417 in) in diameter and C-46 shock is 46 mm (1.811 in).


SHOCK SIZE	SERVICING TOOL	P/N
C-36	Piston guide	529 026 600
	Seal guide	529 026 500
	Shock wrench	529 035 727
C-46	Piston guide	529 035 608
	Seal guide	529 035 728
	Shock wrench	529 035 727

1. Release nitrogen (N) pressure on any HPG T/A shock with internal floating piston (IFP).

#### **⚠ WARNING**

Nitrogen gas is under extreme pressure. Use caution when releasing this gas volume. Protective eye wear should be used.

2. Mount shock in a vise with the HPG SHOCK HOLDING TOOL (P/N 529 035 769).



3. Remove screw on top of valve. Place the needle guide of GAS FILL TOOL KIT (P/N 503 190 102) on the shock valve. Press the detent pin and

**Section 07 CHASSIS**  
**Subsection 02 (REAR SUSPENSION)**

push forward the needle assembly very slowly towards rubber of needle valve. Push on shock tool valve center rod to release gas pressure.



4. Remove tool from shock.

**Screw Cap Type HPG T/A Shock**

5. Using the SHOCK WRENCH (P/N 529 035 727), unscrew seal carrier.




TYPICAL

**Snap Ring Cap Type HPG T/A Shock**

6. Using a flat tool (small screwdriver or small chisel), pop-out the cap.



7. Compress the carrier to access and using a pick, remove the snap ring.




- 1. Snap ring
- 2. Carrier

**All HPG T/A Shocks**

8. With the seal carrier removed, slowly lift and remove damper rod assembly from the damper body.

**NOTE:** Remove damper rod assembly slowly to reduce oil spillage and prevent piston seal damage by damper body threads. Wrap the damper body with a shop cloth to capture possible overflow oil while removing the damper piston.



- 1. Oil flows


## Section 07 CHASSIS

### Subsection 02 (REAR SUSPENSION)

9. Discard old oil into storage container. Never reuse damper oil during shock rebuild.

#### *HPG T/A Shock without Remote Reservoir*

10. Remove valve core.  
11. Place shock absorber in a position where opened extremity is blocked.  
12. Using compressed air pressure, carefully remove floating piston from damper body. Hold shop cloth over damper body opening to catch released floating piston. Allow room for floating piston to leave damper body.



TYPICAL


#### *HPG T/A Shock with Remote Reservoir*

13. Install the FLOATING PISTON REMOVER TOOL (P/N 529 035 907) on shock absorber, as shown below.



1. Floating piston remover tool

14. Place shock absorber in a position where remote gas reservoir opened extremity is blocked. Refer to following photo.



1. Tool  
2. Reservoir opened extremity blocked by leaning on work bench

15. With the VACUUM/PRESSURE PUMP (P/N 529 021 800), pressurize shock absorber until remote reservoir piston pops-out.




**NOTE:** Use towels to prevent damaging remote reservoir piston when it pops-out.

16. Thoroughly clean, with a typical cleaning solution, and blow dry using low pressure air. Carefully inspect the damper body for any imperfections or signs of wear in the damper bore.  
17. Replace damper body if wear is identified.

#### *All HPG T/A Shocks*


18. Holding the damper rod assembly in a bench vise by the eyelet section, begin piston and valve removal.

**Section 07 CHASSIS**  
**Subsection 02 (REAR SUSPENSION)**



A. Remove damper rod nut


19. Always arrange parts removed in the sequence of disassembly.



20. If revalving is to be done, it is imperative that you identify the original shim pack (size and number of shims). There is no need to remove seal carrier if only revalving is to be done.
21. Shims can be measured by using a vernier caliper or a micrometer.

**NOTE:** All shims should be carefully inspected and any bent or broken shims must be replaced for the shock to function properly.

22. After the new or replacement shim pack has been selected, reassemble in the reverse order of disassembly. Torque damper rod nut to 18 N•m (159 lbf•in).



1. Damper rod nut
2. Spacer
3. Stopper with its round edge facing nut
4. Shim pack

23. As a general rule, we suggest replacing the damper rod nut after 4 rebuilds to ensure proper locking friction and the use of LOCTITE 271 (RED) (P/N 293 800 005) each time.

**NOTICE** Do not substitute the damper rod nut for non - O.E.M.


24. This (these) spacer washer(s) must be used as shown to ensure damper rod nut does not bottom out or contact shaft threads.

25. Rebound valve stopper with round edge facing nut.

**NOTE:** Rebound shim stack must not reach into threads of damper rod. Spacer under damper rod nut is used to prevent damper rod nut from bottoming on threads.

## Section 07 CHASSIS

### Subsection 02 (REAR SUSPENSION)




1. Rebound dampening shim pack
2. Rebound dampening shim pack
3. Piston
4. Compression dampening shim pack
5. Compression dampening shim pack
6. Stopper

26. If the seal carrier assembly is replaced, use seal pilot to guide seal over damper rod. Lubricate seal carrier guide pilot before use.

**NOTICE** Failure to use seal pilot will result in seal damage.


27. Reassemble damper rod assembly, taking care to properly assemble shim packs as required for your dampening needs. Ensure that the shaft piston is installed with the slits/larger intake holes facing the rebound shim stack.



1. Seal guide

28. If internal floating piston has been removed, reinstall it into damper body (ensure that valve core has been removed). Use MOLYKOTE G-N (P/N 420 297 433) to ease O-ring past damper body threads with floating piston guide.

**NOTICE** Failure to install internal floating piston correctly could result in shock damage.




1. Push (slowly) by hand
2. Floating piston guide

29. Lubricate inside of piston guide with MOLYKOTE G-N (P/N 420 297 433).

30. Install floating piston to the proper depth refer to following the table.

31. On all HPG T/A shocks, the floating piston is installed hollow side up.



- A. Installation distance for floating piston installation

## Section 07 CHASSIS

### Subsection 02 (REAR SUSPENSION)

SHOCK P/N	INSTALLATION DISTANCE OF FLOATING PISTON
503 192 024	54.5 mm (2-9/64 in)
503 192 025	
503 191 532	119.5 mm (4-11/16 in)
503 191 791	
503 192 035	
503 192 678	164 mm (6-15/32 in)
505 071 991	167 mm (6-9/16 in)
505 072 232	
503 191 534	171.5 mm (6-3/4 in)
503 192 023	

**NOTE:** If the floating piston is installed too far into the damper body, light air pressure through valve (with core removed) will move piston outward.


32. Reinstall tire valve core after internal floating piston has been installed at the correct height and before adding oil.

#### **⚠ WARNING**

Whenever using compressed air exercise extreme caution, cover damper opening with shop cloth to reduce chance of possible injury.

**NOTICE** Moisture laden compressed air will contaminate the gas chamber and rust floating piston.


33. Fill the shock with SHOCK ABSORBER OIL (P/N 293 600 035) to approximately 10 mm (3/8 in), from the base of seal carrier threads.



1. Fill to 10 mm (3/8 in)

**NOTE:** Although we do not measure the exact amount of oil added to the damper, approximately 252 ml (8.52 U.S. oz) will be used.

34. Carefully insert damper rod into the damper body. Lightly oil damper piston seal ring with shock oil to ease installation.



**NOTE:** Some shock oil will overflow when installing damper. Wrap damper with shop cloth to catch possible overflow oil.

**NOTICE** Use care when passing piston into damper body at damper body threads.

35. Slight oscillation of damper rod may be required to allow piston to enter damper body bore.
36. Slowly push piston into damper body. Slight up and down movement may be required on short stroke to allow all air to pass through piston assembly. The gentle tapping of a small wrench, on the shock eye, may help dislodge air trapped in the submerged piston. Be careful not to drive the shaft any deeper into the oil than is necessary to just cover the shim stack.

**NOTE:** Fast installation of the damper rod may displace the floating piston from its original position. This must not occur if the damper is expected to perform as designed.

37. With damper rod piston into oil, TOP OFF damper oil volume. Oil level should be to damper body thread base.

#### **Screw Cap Type HPG T/A Shock**

38. Seal carrier assembly can now be threaded into damper body. This should be done slowly to allow weepage of oil and to minimize internal floating piston displacement. Torque seal carrier to 65 N•m (48 lbf•ft).



## Section 07 CHASSIS

### Subsection 02 (REAR SUSPENSION)

**NOTE:** Some oil must overflow when installing the cap

#### *Snap Ring Cap Type HPG T/A Shock*


39. Seal carrier assembly can now be pushed into damper body to pass snap ring groove. Install snap ring into groove.

**NOTE:** Some oil must overflow when the seal carrier is pushed down.

40. Tap the cap on the shock body.

#### *All HPG T/A Shocks*

41. After the seal carrier is fully in place avoid pushing the shaft into the body until the nitrogen charge is added.
42. When removing and retightening the tire valve acorn nut use minimal torque. When the cap is over tightened and subsequently removed it may prematurely break the seal of the tire valve to the shock body and cause a loss of nitrogen charge without being noticed. If you suspect this has happened then recharge the shock as a precaution. Inspect the tire valve cap before installation to ensure that the internal rubber gasket is in its proper position.
43. Nitrogen (N) can now be added to damper body.



1. High pressure hose
2. Stage regulator, delivery pressure range 2070 kPa (300 PSI)
3. High pressure cylinder filled with industrial grade nitrogen
4. Valve tip permanently installed

**NOTE:** Never substitute another gas for nitrogen. Nitrogen has been selected for its inert qualities and will not contaminate the gas chamber of the shock.


44. Preset your pressure regulator to 2070 kPa (300 PSI) nitrogen (N), this gas pressure will restore the correct pressure for your damper.

**NOTICE** Do not exceed the recommended pressure values.

#### **⚠ WARNING**


Whenever working with high pressure gas, use eye wear protection. Never direct gas pressure toward anybody.

45. Install the GAS FILL TOOL KIT (P/N 503 190 102) on GAS SHOCK VALVE TOOL (TIRE VALVE TYPE) (P/N 529 035 570). Set the regulator pressure on the nitrogen cylinder as per the shock requirement.
46. Mount the shock on vise. Remove screw on top of valve. Place the needle guide of gas refill tool on the shock valve. While depressing the detent pin of the gas refill tool and pushing forward the needle assembly, insert the needle through the rubber core of the pressure valve assembly of the shock.



**NOTE:** For replacement of the needle or filling the shock, carefully follow the instructions provided with the GAS FILL TOOL KIT (P/N 503 190 102).

47. On some models, rubber may pop out of needle valve when inserting tool needle. If so, remove valve core and rubber then, reinstall rubber with its larger diameter last.



1. Larger diameter

48. Carefully inspect damper for gas or oil leaks. Any leaks must be corrected before continuing. If no leak is detected, install the screw on top of the valve and clean the shock with the PULLEY FLANGE CLEANER (P/N 413 711 809).
49. Damper gas pressure cannot be confirmed by using a pressure gauge. The volume of gas in the shock is very small, and the amount lost during gauge installation will lower the pressure too much and require refilling.
50. After recharging is complete the rebuilt shock should be bench-tested. Stroke the shock to ensure full travel and smooth compression and rebound action. If the shaft moves in or out erratically this could indicate too much air is trapped inside. If the shaft will not move or has partial travel then it may be hydraulically locked. In either event the shock must be rebuilt again. Pay particular attention to the placement of the IFP, quantity of oil and shim stack/piston assembly.

### Shock Absorber Rebuilt Procedure (HPG T/A Racing Clicker)

1. Tightly secure the shock base in vise. DO NOT CLAMP ONTO SHOCK BODY.
2. Using a 12 mm wrench, slowly remove air inlet valve, allowing the gas inside the reservoir to escape.
3. Remove top shock cover using a 36 mm wrench.



4. Pull shock rod out of main shock body.
5. Drain oil from the shock body. Dispose of used oil properly.



6. Push down the remote reservoir cover to remove the retaining circlip.

## Section 07 CHASSIS


### Subsection 02 (REAR SUSPENSION)



- Using the FLOATING PISTON PULLER (P/N 529 035 901), remove the remote reservoir cover then the floating piston inside the remote reservoir.




- Using a 14 mm wrench, remove the lock nut securing shims, washers and piston to shock rod.
- Carefully remove and layout shims, washers and piston from shock rod. Pay close attention to shims and washers sequence and piston position.



#### TYPICAL

- Clean all shock components using PULLEY FLANGE CLEANER (P/N 413 711 809). DO NOT MIX SHIMS AND WASHERS TOGETHER.
- Assemble valve shims, washers and piston in proper order and place them back onto shock rod.
- Torque the shock rod nut at 18N•m (159 lbf•in).



- Fill main shock body with shock absorber oil to a level of half full.
- Fill also remote reservoir with shock absorber oil to within 6.4 mm (1/4 in) from the top.
- Hold the remote reservoir in a way so the oil level in the shock and the remote reservoir are at the same height.
- Cup your hand and place it over the remote reservoir. Pump with your hand to circulate oil through the shock and reservoir to remove any trapped air. Low speed adjuster must be open 1 turn minimum.
- Fill the remote reservoir with shock absorber oil.

18. Lubricate the O-ring on floating piston with shock oil and install it.



**NOTE:** The key to good shock performance is to remove all the air from shock body and reservoir.

19. Push the floating piston to the bottom of the remote reservoir. Oil will rise in the main shock body almost to the top.
20. Fill the shock body with SHOCK ABSORBER OIL (P/N 293 600 035) until level with bottom of threads.
21. Lubricate seal around piston and valve stack and gently push into main shock body.
22. Stroke the piston and valve stack slowly to remove any trapped air. Using a small hammer or wrench, gently tap on the rod mounting eyelet to help remove air.
23. Again, push the floating piston to the bottom of the remote reservoir.
24. Pull shock rod as far out as possible and replace the shock cover and torque to 65 N•m (48 lbf•ft) . Oil must spill from the shock body before the seal cover O-ring seals the shock.
25. Lubricate the O-ring on remote reservoir cover with shock oil and install the remote reservoir cover.
26. Push down the cover and install the retaining circlip.
27. Using the FLOATING PISTON PULLER (P/N 529 035 901), pull the cover to seat it against the retaining circlip.

**⚠ WARNING**

Make sure the cover is firmly seated against the retaining circlip before filling with gas.

28. Install the air inlet valve.
29. Pressurize the shock at 2070 kPa (300 PSI) with nitrogen (N). Use the correct GAS FILL TOOL KIT (P/N 503 190 102).



30. Carefully inspect damper for gas or oil leaks. Any leaks must be corrected before continuing. If no leak is detected, install the safety screw into the air inlet valve and clean the shock with the PULLEY FLANGE CLEANER (P/N 413 711 809).
31. After recharging is complete, the rebuilt shock should be bench-tested. Stroke the shock to ensure full travel, smooth compression and rebound action. If the damper rod moves in or out erratically this could indicate air is trapped inside. If the damper rod will not move or has partial travel then it may be hydraulically locked. In either event the shock must be taken apart.

**Section 07 CHASSIS**

## Subsection 02 (REAR SUSPENSION)

## Shock Absorber Calibration Charts (All HPG T/A)

<b>MX Z RENEGADE X</b>						
	<b>BRP P/N</b>	<b>INSTALLATION DISTANCE OF FLOATING PISTON (IFP)</b>	<b>COMPRESSION</b>	<b>REBOUND</b>	<b>SLIT</b>	<b>PRESSURE</b>
<b>FRONT SUSPENSION</b>						
<b>FRONT</b>	505 072 678 (Kayaba shock)	164 mm (6-15/32 in)	1 x 30 x .203 1 x 14 x .152 4 x 30 x .152 1 x 28 x .114 1 x 16 x .152	1 x 26 x .203 1 x 15 x .114 2 x 26 x .152 1 x 15 x .254	No slit	2070 kPa (300 PSI)
<b>REAR SUSPENSION</b>						
<b>CENTER</b>	503 192 035 (C-36 Kayaba shock)	119.5 mm (4-11/16 in)	6 x 30 x .203 1 x 17 x .152 5 x 30 x .203 1 x 26 x .114 1 x 22 x .114	1 x 26 x .203 1 x 15 x .114 3 x 26 x .203 1 x 16 x .203	1	2070 kPa (300 PSI)
<b>REAR</b>	503 192 025 (C-46 Kayaba shock)	54.5 mm (2-9/64 in)	5 x 30 x .254 1 x 15 x .152 4 x 30 x .254 1 x 26 x .114 1 x 16 x .152	1 x 26 x .203 1 x 16 x .114 4 x 26 x .254 1 x 16 x .203	1	2070 kPa (300 PSI)

<b>MX Z 50<sup>TH</sup>/MX Z TNT (CA/US)</b>						
	<b>BRP P/N</b>	<b>INSTALLATION DISTANCE OF FLOATING PISTON (IFP)</b>	<b>COMPRESSION</b>	<b>REBOUND</b>	<b>SLIT</b>	<b>PRESSURE</b>
<b>FRONT SUSPENSION</b>						
<b>FRONT</b>	505 071 991 (Kayaba shock)	167 mm (6-9/16 in)	1 x 30 x .203 1 x 14 x .152 4 x 30 x .152 1 x 28 x .114 1 x 16 x .152	1 x 26 x .203 1 x 15 x .114 4 x 26 x .152 1 x 16 x .254	1	2070 kPa (300 PSI)
<b>REAR SUSPENSION</b>						
<b>CENTER</b>	503 191 791 (C-36 Kayaba shock)	119.5 mm (4-11/16 in)	2 x 30 x .203 1 x 14 x .152 6 x 30 x .152 1 x 26 x .114 1 x 18 x .114	1 x 26 x .203 1 x 15 x .114 3 x 26 x .254 1 x 16 x .203	1	2070 kPa (300 PSI)
<b>REAR</b>	503 192 023 (C-36 Kayaba shock)	171.5 mm (6-3/4 in)	7 x 30 x .203 1 x 17 x .152 4 x 30 x .203 1 x 26 x .114 1 x 16 x .152	1 x 26 x .203 1 x 16 x .114 4 x 26 x .254 1 x 16 x .203	1	2070 kPa (300 PSI)

**Section 07 CHASSIS**  
Subsection 02 (REAR SUSPENSION)

**MX Z TNT (EUR)/MX Z X**

	BRP P/N	INSTALLATION DISTANCE OF FLOATING PISTON (IFP)	COMPRESSION	REBOUND	SLIT	PRESSURE
<b>FRONT SUSPENSION</b>						
FRONT	505 072 678 (Kayaba shock)	164 mm (6-15/32 in)	1 x 30 x .203 1 x 14 x .152 4 x 30 x .152 1 x 28 x .114 1 x 16 x .152	1 x 26 x .203 1 x 15 x .114 2 x 26 x .152 1 x 15 x .254	No slit	2070 kPa (300 PSI)
<b>REAR SUSPENSION</b>						
CENTER	503 191 791 (C-36 Kayaba shock)	119.5 mm (4-11/16 in)	2 x 30 x .203 1 x 14 x .152 6 x 30 x .152 1 x 26 x .114 1 x 18 x .114	1 x 26 x .203 1 x 15 x .114 3 x 26 x .254 1 x 16 x .203	1	2070 kPa (300 PSI)
REAR	503 192 024 (C-46 Kayaba shock)	54.5 mm (2-9/64 in)	3 x 30 x .203 1 x 30 x .152 1 x 15 x .152 2 x 30 x .203 1 x 30 x .152 1 x 26 x .114 1 x 16 x .152	1 x 26 x .203 1 x 16 x .114 5 x 26 x .254 1 x 16 x .203	1	2070 kPa (300 PSI)

**SUMMIT 50<sup>TH</sup>/SUMMIT X**

	BRP P/N	INSTALLATION DISTANCE OF FLOATING PISTON (IFP)	COMPRESSION	REBOUND	SLIT	PRESSURE
<b>FRONT SUSPENSION</b>						
FRONT	505 072 232 (Kayaba shock)	167 mm (6-9/16 in)	1 x 30 x .152 1 x 14 x .152 6 x 30 x .152 1 x 16 x .152	1 x 26 x .203 1 x 15 x .114 4 x 26 x .152 1 x 16 x .203	1	2070 kPa (300 PSI)
<b>REAR SUSPENSION</b>						
CENTER	503 191 532 (C-36 Kayaba shock)	119.5 mm (4-11/16 in)	1 x 30 x .203 1 x 14 x .152 5 x 30 x .203 1 x 28 x .114 1 x 24 x .114	1 x 26 x .254 1 x 15 x .114 4 x 26 x .254 1 x 16 x .203	1	2070 kPa (300 PSI)
REAR	503 191 534 (C-36 Kayaba shock)	171.5 mm (6-3/4 in)	1 x 30 x .203 1 x 14 x .152 4 x 30 x .203 1 x 28 x .114 1 x 18 x .114	5 x 26 x .203 1 x 16 x .203	1	2070 kPa (300 PSI)

## Section 07 CHASSIS

### Subsection 02 (REAR SUSPENSION)

SUMMIT HILLCLIMB						
	BRP P/N	INSTALLATION DISTANCE OF FLOATING PISTON (IFP)	COMPRESSION	REBOUND	SLIT	PRESSURE
FRONT SUSPENSION						
FRONT	505 072 678 (Kayaba shock)	164 mm (6-15/32 in)	1 x 30 x .203 1 x 14 x .152 4 x 30 x .152 1 x 28 x .114 1 x 16 x .152	1 x 26 x .203 1 x 15 x .114 2 x 26 x .152 1 x 15 x .254	No slit	2070 kPa (300 PSI)
REAR SUSPENSION						
CENTER	503 191 532 (C-36 Kayaba shock)	119.5 mm (4-11/16 in)	1 x 30 x .203 1 x 14 x .152 5 x 30 x .203 1 x 28 x .114 1 x 24 x .114	1 x 26 x .254 1 x 15 x .114 4 x 26 x .254 1 x 16 x .203	1	2070 kPa (300 PSI)
REAR	503 192 069 (C-36 Kayaba shock)	54.5 mm (2-9/64 in)	3 x 30 x .203 1 x 15 x .152 3 x 30 x .203 1 x 28 x .114 1 x 26 x .114 1 x 16 x .114	2 x 26 x .254 1 x 16 x .114 2 x 26 x .254 1 x 17 x .114	1	2070 kPa (300 PSI)


### Rear Shock Absorber Installation

Installation is reverse of removal procedure. Pay attention to the following.

To ease shock installation, secure upper side of shock first.

#### GSX, GTX and MX Z

If the shock absorber has a remote reservoir, make sure to install the shock so that reservoir is facing down.




1. Bar axle
2. Bushings
3. Rocker arms
4. Plastic spacers
5. Inner sleeve
6. Reservoir position

### Center Shock Absorber Installation

Installation is reverse of removal procedure. Pay attention to the following details.

*GSX (Sport), GTX (Sport), MX Z (Trail) and SUMMIT (Everest 600 (CA/US))*


1. Position the cam downwards.




1. Cam

#### All Other Models


1. Position the adjustment ring or the cam upwards and the valve towards the tunnel.



**TYPICAL**  
1. Adjustment ring  
2. Valve



1. Rear springs  
2. Cams




**TYPICAL**  
1. Cam

**All SUMMIT**

1. Using **NEW** socket screws, install shock shaft to runners.
2. Position washers in proper position.

3. Remove idler wheels to have access to spring support screws.

IDLER WHEELS	
GSX AND MX Z (EXCEPT RENEGADE AND RENEGADE X)	External and internal idler wheels
GTX AND MX Z (RENEGADE AND RENEGADE X)	Internal idler wheels



1. LH external idler wheel  
2. Idler wheel support  
3. Internal idler wheels  
4. LH spring support

4. Hold the spring supports firmly and remove spring support nuts.



**BOTTOM OF SHOCK ABSORBER**  
1. Washers location

**REAR SPRINGS**

**Rear Spring Removal**


**GSX, GTX and MX Z**

1. Lift rear of vehicle and support it off the ground.
2. Decrease springs preload by turning cams accordingly.



## Section 07 CHASSIS

### Subsection 02 (REAR SUSPENSION)




1. LH idler wheel supports
2. Spring support
3. Spring support nut

5. Move spring supports with spring ends over the idler wheel supports and let them sit on the track.

**NOTE:** If the springs are still loaded, completely loosen track tension in order to make room to unload springs.

6. Remove spring axle screws (one each side).




1. Spring axle screw
2. Upper idler wheel

7. Remove springs and spring axle.

#### SUMMIT

1. Lift rear of vehicle and support it off the ground.
2. Completely loosen track tension by unscrewing both adjustment screws.
3. Decrease springs preload by turning cams accordingly.




#### LH SIDE SHOWN

1. Rear spring
2. Cam

4. Firmly hold the spring support and unscrew its retaining bolt (one each side).

#### WARNING

Supports are spring loaded.



1. Spring support bolt
2. Spring support
3. Spring


5. Remove screws and washers from rear arm top axle.

6. Loosen set screw from locking rings.

7. Remove locking rings.

8. Remove upper idler wheels.

9. Remove springs.




**LH SIDE SHOWN**

1. Locking ring
2. Set screw
3. Upper idler wheel
4. Rear spring

### Rear Spring Installation


Installation is reverse of removal procedure. Pay attention to the following.

1. Respect THIS SIDE OUT inscription on top idler wheels.
2. Make sure that spring end is in cam adjuster.



**GSX, GTX AND MX Z**

1. Rear springs
2. Cams




**SUMMIT — LH SIDE SHOWN**

1. Spring end
2. Cam


3. Install spring supports upwards.

### GTX Series and MX Z (Renegade and Renegade X)




1. Spring supports upwards

### GSX Series and All MX Z except Renegade and Renegade X



1. Spring supports upwards

### SUMMIT



1. Spring supports upwards


## Section 07 CHASSIS

### Subsection 02 (REAR SUSPENSION)

## SLIDER SHOES

### Slider Shoe Inspection

Replace slider shoes when the wear reach 1 mm to 2 mm (.04 in to .08 in) beyond the moulding line.



**TYPICAL**  
1. Slider shoe  
2. Moulding line

**NOTICE** Slider shoes must always be replaced in pairs.


### Slider Shoe Removal

1. Lift rear of vehicle and support it off the ground.
2. Completely loosen track tension.
3. Remove nut and screw of each runner.




REMOVE NUT AND SCREW OF EACH RUNNER

4. At the rear of vehicle, align a track window with slider shoe.



**TYPICAL**  
1. Track window  
2. Slider shoe

5. Using a pry bar or a screwdriver, push slider shoe rearward until it comes in contact with track.



PUSH ON SLIDER SHOE

6. Using locking pliers, pull slider shoe through track window to remove.

**NOTE:** If necessary, lubricate track window to facilitate slider shoe removal.



**PULL ON SLIDER SHOE TO REMOVE**

### Slider Shoe Installation

Installation is reverse of removal procedure. Pay attention to the following detail.


Make sure to insert slider shoe end with hole first.

## FRONT ARM

### Front Arm Removal


*GSX, GTX and MX Z*

1. Remove *SUSPENSION ASSEMBLY*, see procedure in this section.
2. Unfasten stopper strap.




1. Stopper strap
2. Stopper strap bolt

3. Remove upper bolt securing the front shock absorber.



1. Shock absorber upper bolt


4. Unscrew bolts securing the bottom ends of front arm.



1. Front arm lower bolts

### SUMMIT

1. Remove *SUSPENSION ASSEMBLY*, see procedure in this section.
2. Remove bolt securing rocker to front arm.




1. Front arm
2. Rocker

3. Unscrew and remove the front arm lower bolts and washers.


## Section 07 CHASSIS

### Subsection 02 (REAR SUSPENSION)




1. Front arm
2. Lower bolt
3. LH runner

4. Remove the shock absorber upper bolt.




1. Front arm
2. Shock absorber upper bolt

5. Unfasten stopper strap.



1. Stopper strap bolt

6. Remove and discard front arm upper bolts.



1. Bolt


7. Remove front arm.

### Front Arm Installation

Installation is reverse of removal procedure. Pay attention to the following details.

#### *GSX, GTX and MX Z*

1. Install the lower bolts and tighten axles to 125 N•m (92 lbf•ft).




1. Front arm axle
2. Front arm
3. Front arm lower bolt
4. LH runner

2. Install all other remove parts accordingly with their installation procedures.

#### *SUMMIT*

1. Install **NEW** front arm lower bolts.
2. Torque them to 62 N•m (46 lbf•ft).



- 1. Front arm
- 2. Front arm lower bolt (LH side)
- 3. Runner

3. Install all other remove parts accordingly with their installation procedures.

## REAR ARM

### Rear Arm Removal


#### GSX, GTX and MX Z

- 1. Lift rear of vehicle and support it off the ground.
- 2. Completely loosen track tension.
- 3. Remove socket screws securing rear arm to frame.




- 1. Socket bolt

4. Remove rear shock absorber upper bolt.



- 1. Rear shock absorber
- 2. Shock absorber bolt
- 3. Rear arm


5. Remove bolt securing throttle rods to rear arm.



- 1. Throttle rod bolt
- 2. Rear arm
- 3. Throttle rods

6. Remove *REAR SPRING*, see procedure in this section.

7. Remove and discard coupling block screws securing rear arm to pivot arm.



- 1. Rear arm
- 2. LH coupling block bolt
- 3. Pivot arm

8. Remove rear arm.

### SUMMIT

- 1. Lift rear of vehicle and support it off the ground.
- 2. Completely loosen track tension.

## Section 07 CHASSIS


### Subsection 02 (REAR SUSPENSION)

3. Remove *REAR SPRING*, see procedure in this section.
4. Remove the rear shock absorber upper bolt.




1. Rear shock absorber
2. Shock absorber bolt
3. Rear arm

5. Remove throttle rods from rear arm.



1. Throttle rods
2. Rear arm

6. Remove bolts and washers holding rear arm to pivot arm.



1. Rear arm
2. Pivot arm

## Rear Arm Installation

Installation is reverse of removal procedure. Pay attention to the following details.

1. Pivot arm grease fitting must be towards the front of the vehicle.
2. At installation, rear arm stroke limiter must be on rear side.

### *GSX, GTX and MX Z*

3. Install coupling block with **NEW** socket screws.

### *All Models*


4. Install **NEW** rear arm bolts and tighten them.

REAR ARM BOLTS TIGHTENING	
GSX, GTX and MX Z	85 N•m (63 lbf•ft)
SUMMIT	48 N•m (35 lbf•ft)

## Rear Arm Lubrication

Lubricate pivot arm and rear arm at grease fittings using **SUSPENSION SYNTHETIC GREASE (P/N 293 550 033)**.


### *GSX Series and MX Z (50<sup>th</sup>, TNT, X)*




1. Grease fittings

### *GTX Series and MX Z*

*(Adrenaline, Renegade, Renegade X, Trail)*



**SUMMIT**




1. Grease fittings

**PIVOT ARM**

**Pivot Arm Removal**


*GSX, GTX and MX Z*

1. Lift rear of vehicle and support it off the ground.
2. Completely loosen track tension.
3. Remove and discard coupling block screws securing rear arm to pivot arm.



1. Rear arm  
 2. LH coupling block bolt  
 3. Pivot arm

4. Remove bolts and washers holding pivot arm to runners.



1. LH pivot arm bolt  
 2. Pivot arm

5. Separate pivot arm from rear arm.


**Pivot Arm Installation**

The installation is the reverse of the removal procedure.

**COUPLING BLOCKS**

*GSX, GTX and MX Z*

1. Both coupling blocks are identified "R" or "L" (right or left) and have position number (from 1 to 4). At installation make sure to install proper block on proper side with the same adjustment position on both sides.



**TYPICAL**  
 1. Blocks are identified "R" or "L" (right or left)  
 2. Blocks position number (from 1 to 4)


MODELS	BLOCK POSITION
All models	2

2. Insert the dowel pin located on pivot arm with the hole at the back of coupling block.



## Section 07 CHASSIS

### Subsection 02 (REAR SUSPENSION)



1. Coupling block
2. Hole at the back of coupling block
3. Dowel pin on pivot arm

3. Install NEW coupling block screws.


## IDLER WHEELS

Refer to illustration for idler wheels position at installation.


*GSX Series and MX Z  
(50<sup>th</sup>, Adrenaline, Trail, TNT, X)*



*GTX Series and MX Z (Renegade, Renegade X)*



## SUMMIT Series



## IDLER WHEEL SUPPORT

Idler wheel supports are retained with a bolt and a HUCK rivet. To remove HUCK rivet, refer to *FRAME* for proper procedure.

Replace the HUCK rivets by the following fasteners.

NEW FASTENERS	
Hexagonal flanged bolt M6 x 25	(P/N 207 662 544)
Hexagonal flanged elastic stop nut M6	(P/N 233 261 414)


## STOPPER STRAP

Inspect strap for wear or cracks, bolt and nut for tightness. If loose, inspect hole for deformation. Replace as required.

Make sure it is attached through proper hole from the end.

Torque nut to 11 N•m (97 lbf•in).


*GSX, GTX and MX Z*



**POSITION 3**

- 1. Front arm (top)
- 2. Front axle
- 3. Towards the rear of vehicle

**SUMMIT**



**POSITION 2**

- 1. Front arm (top)
- 2. Front axle
- 3. Towards the rear of vehicle

# STEERING SYSTEM

## SERVICE TOOLS

<u>Description</u>	<u>Part Number</u>	<u>Page</u>
HEATED GRIP INSTALLER.....	529 035 897 .....	556

## SERVICE TOOLS – OTHER SUPPLIER

<u>Description</u>	<u>Part Number</u>	<u>Page</u>
MULTILOCK-TERMINAL HOUSING EXTRACTION TOOL AMP ...	755430-2 .....	555


## SERVICE PRODUCTS

<u>Description</u>	<u>Part Number</u>	<u>Page</u>
THERMO LUBE SYNTHETIC GREASE.....	219 700 417 .....	560


## Section 07 CHASSIS

### Subsection 03 (STEERING SYSTEM)


## SKIS




GSX  
GTX  
MX Z



SUMMIT



**STEERING COLUMN AND TIE-RODS**




## Section 07 CHASSIS


### Subsection 03 (STEERING SYSTEM)

## HANDLEBAR


GSX Sport  
GSX Limited  
GTX LE  
GTX Sport




SUMMIT 50th  
SUMMIT Everest  
SUMMIT HillClimb  
SUMMIT X




MX Z 50th  
MX Z Renegade X  
MX Z TNT  
MX Z X



MX Z Adrenaline  
MX Z Renegade  
MX Z Trail




MX Z Renegade X  
MX Z TNT  
MX Z X



European  
models



MX Z Renegade  
MX Z Renegade X  
SUMMIT Everest  
SUMMIT HillClimb  
SUMMIT X



## GENERAL

When removing or replacing a part of steering system (except handle grips and handlebar), perform the steering alignment, refer to *STEERING ALIGNMENT* in this section.

During assembly/installation, use the torque values and service products as in the exploded views.

Clean threads before applying a threadlocker. Refer to *SELF-LOCKING FASTENERS* and *LOCTITE APPLICATION* at the beginning of this manual for complete procedure.

### **⚠ WARNING**

Torque wrench tightening specifications must be strictly adhered to. Locking devices (e.g.: locking tabs, elastic stop nuts, cotter pins, etc.) must be replaced with a new ones.

Hoses or cables removed or disconnected must be installed and routed at the same place.


**NOTICE** Locking ties removed during a procedure must be replaced and installed at the same location.

## ADJUSTMENT

### STEERING ALIGNMENT

Ski alignment is performed by adjusting length of left and right tie-rods. To do this, use the following procedure:


1. Leave the vehicle on the ground on its own weight.
2. Attach ski handles together with a bungee cord.



1. Bungee cord


3. Position handlebar so that it is straight ahead position by measuring from the extremities of the grips to the rear most edge of the tunnel, as shown.

**NOTE:** The reference point must be the same to each side.



1. Same reference point  
A. Equal distance on each side

4. Verify if skis are in straight-ahead position by placing a straight edge against adjusted track and measuring distance between front and rear ski recesses and straight edge.
5. When skis are in straight ahead position, adjust the toe-out.
6. Measure the distance between front and rear ski recesses.
7. Use the following illustration and this equation to determine the perfect steering adjustment.



1. Recesses  
 $A - B = 5 \text{ MM } (.197 \text{ IN})$

#### STEERING ALIGNMENT

Toe-out	5 mm (.197 in)
---------	----------------

8. If adjustment is needed, loosen tie-rod jam nuts then turn tie-rods to change their length.
9. Tighten jam nuts and torque them to 18 N•m (159 lbf•in).


## Section 07 CHASSIS

### Subsection 03 (STEERING SYSTEM)



1. Jam nut

**NOTE:** The maximum tie-rod end length not engaged in the tie rod must not exceed 34 mm (1.339 in).



A. 34 mm (1.339 in) maximum

## PROCEDURES


### SKI RUNNER

#### Ski Runner Inspection


Lift the front of vehicle and check ski runners for wear or damages (missing or broken carbide). Replace if necessary.

#### Ski Runner Removal

1. Lift the front of vehicle and support it off ground.
2. Unscrew the ski runner nuts then remove ski runners.



SKI PILOT 5.7 OR 6.9 (LEFT SIDE) SHOWN  
1. Ski runner nuts



SKI PILOT SL (RIGHT SIDE SHOWN)  
1. Ski runner nuts

### Ski Runner Installation

The installation is the reverse of the removal procedure. Pay attention to the following.

Torque ski runner nuts to 8 N•m (71 lbf•in).


### SKI

#### Ski Inspection

Inspect ski for excessive wear or other damage. Replace if necessary.

#### Ski Removal

1. Lift front of vehicle and support it off ground.
2. Unscrew nut then pull ski bolt out.



TYPICAL — SKI PILOT 5.7 SHOWN

1. Ski bolt
2. Washer
3. Nut
4. Ski leg


3. Remove ski from vehicle.

#### Ski Installation

*All Models except SUMMIT*

1. Make sure bushings are installed in ski holes.
2. Install the ski stopper. Position indicator in front and make sure the bump in the ski is in the groove of the ski stopper.






**TYPICAL — SKI PILOT 5.7 SHOWN**

1. Ski stopper
2. Bushings

3. Install ski bolt and torque it to 48 N•m (35 lbf•ft).

### SUMMIT

1. Make sure bushings are installed in ski holes.
2. Install the ski stopper. Position indicator in front and make sure the bump in the ski is in the groove of the ski stopper.



**TYPICAL**  
1. Ski stopper  
2. Bushings

3. Determine the desired ski stance (2 positions).
4. Install the spacer inside for the narrower stance and outside for the wider stance.


### **⚠ WARNING**

Proceed to the same setting for both skis.



**NARROWER STANCE — LEFT SKI SHOWN**

1. Spacer here for the narrower stance



**WIDER STANCE — LEFT SKI SHOWN**

1. Spacer here for the wider stance

5. Install ski bolt and torque it to 48 N•m (35 lbf•ft).

## SKI HANDLE

### Ski Handle Removal


1. Remove ski from vehicle.
2. Using a 9 mm (3/8 in) drill bit, remove ski handle rivets. Only drill the head of rivet. Do not try to drill all the way through the rivet. Angle the drill bit to reduce the chance of spinning the rivet in the ski.
3. Remove handle from ski.
4. Place handle in hot water for 10 minutes then using a punch, drive the inner part of rivet out of handle.

### Ski Handle Installation

1. To install rivets, use a C-clamp and a short 10 mm socket.
2. Place a rivet in position and insert it into ski and ski handle. Repeat the procedure for the other side.


## Section 07 CHASSIS

### Subsection 03 (STEERING SYSTEM)



1. C-clamp
2. Rivet
3. Handle

3. When both rivets are installed, use the short 10 mm socket to push rivet heads against ski.



1. C-clamp
2. 10 mm socket

## SKI LEG

To replace a ski leg, refer to *FRONT SUSPENSION* section.

## HANDLEBAR GRIP

Two handlebar grip types are available, with or without integrated elements.


**NOTE:** To verify or replace heating elements, refer to *LIGHTS, GAUGE AND ACCESSORIES* section.

### Handlebar Grip Removal (Integrated Heating Element)

**NOTICE** Removing grip from handlebar might damage the heating element. Do not remove needlessly.

#### Throttle Side

Loosen engine stop switch and throttle lever.



1. Engine stop switch screw
2. Throttle lever screw
3. Cut this locking tie

Move them towards the steering column.  
Remove the steering cover.  
Unplug the heating element connector.




- GSX LIMITED SHOWN**
1. Heating element connector

Insert the open side of a 23 mm (7/8 in) wrench against the inner end of grip.

**NOTICE** Pay attention not to damage wires with the wrench.


Using a plastic hammer, tap on the side of the wrench end to make the grip slide out.



## Section 07 CHASSIS

### Subsection 03 (STEERING SYSTEM)


Using a tool such as the MULTILOCK-TERMINAL HOUSING EXTRACTION TOOL AMP (P/N 755430-2), push the 3 wires of the grip harness out of connector housing. Note the position of the wires for reinstallation.



TYPICAL


#### Brake Side

Unscrew master cylinder from handlebar.



1. Master cylinder screws
2. Cut this locking tie

Loosen multifunction switch screws.



1. Multifunction switch screws

Move multifunction switch towards the steering column.

Remove the steering cover.

Unplug the heating element connector.



GSX LIMITED SHOWN

1. Heating element connector

Insert the open side of a 23 mm (7/8 in) wrench against the inner end of grip.

**NOTICE** Pay attention not to damage wires with the wrench.

Using a plastic hammer, tap on the side of the wrench end to make the grip slide out.

Using a tool such as the MULTILOCK-TERMINAL HOUSING EXTRACTION TOOL AMP (P/N 755430-2), push the 3 wires of the grip harness out of connector housing. Note the position of the wires for reinstallation.




TYPICAL

#### Handlebar Grip Removal (Without Integrated Heating Element)

Remove grips by pulling while using compressed air, which will inflate or loosen the fit between the grip and handlebar, as shown on picture.

## Section 07 CHASSIS

### Subsection 03 (STEERING SYSTEM)



1. Blow air in the grip hole

#### Handlebar Grip Installation (With Integrated Heating Element)

*GSX (Limited, Limited Touring, Sport) and  
MX Z (Adrenaline, Renegade, Trail)*

Clean handlebar ends and inside of grip with isopropyl alcohol. Let dry before installation.

**NOTICE** Handlebar end and inside of heating grip must be clean and dry before installing heating grip to ensure proper adhesion.


Use the HEATED GRIP INSTALLER (P/N 529 035 897) to properly install grip.



**NOTICE** Installing grip without the insertion tool is likely to damage its heating element.

Position the insertion tool at the outside end of grip.

Using a plastic hammer, tap on tool to push grip on. Continue to tap until grip bottoms.



1. Heated grip installer

Properly route harness at the front of steering. Reinstall terminals and re-plug connectors. Test grips to ensure they heat properly.

**NOTE:** Note that grips will not work if the engine is at idle speed. Electricity is supplied to grips only if engine is over 2000 RPM.

Install all other removed parts.

#### Handlebar Grip Installation (Without Integrated Heating Element)

Insert the handlebar grip on handlebar while blowing compressed air to inflate or loosen the fit between grip and handlebar.



## HANDLEBAR

### Handlebar Removal


**NOTE:** If the handlebar must be changed, remove all components (handlebar grip, throttle lever housing, etc.) before removing it from vehicle.

1. Remove steering cover.
2. Unplug all connectors.



mm2008-048-004\_j  
**GSX LIMITED SHOWN**

3. Remove handlebar retaining clamp screws.



- mm2008-048-009\_a
1. Handlebar
  2. Retaining clamps
  3. Screws

4. Remove handlebar from handlebar extension.

### Handlebar Inspection

1. Inspect the handlebar for:
  - Damages
  - Cracks
  - Bending.
2. Replace if any of these problems is detected.

### **⚠ WARNING**

Do not try to repair a defective handlebar.

3. Check handlebar clamps for cracks or distortion, replace if necessary.


### Handlebar Installation

The installation is the reverse of the removal procedure. However, pay attention to the following.

#### Handlebar Strap

*MX Z (Renegade, Renegade X) and SUMMIT (Everest, X)*


1. Ensure to position strap symmetrically each side of handlebar retaining clamps.



mm2009-030-009\_j

- A. Equal distance

2. Tilt strap  $5^\circ \pm 5^\circ$  towards driver relative to handlebar extension.



mm2008-090-010\_a


- A.  $5^\circ \pm 5^\circ$

3. Retaining clip and hardware must be installed in the same position on both strap ends.

### HANDLEBAR EXTENSION

#### Handlebar Extension Removal

1. Remove *HANDLEBAR* from handlebar extension, see procedure above in this section.
2. Unscrew bolts retaining the extension to steering column.



mm2008-049-010\_a

**SUMMIT X SHOWN**

1. Steering column
2. Handlebar extension clamps
3. Handlebar extension

## Section 07 CHASSIS

### Subsection 03 (STEERING SYSTEM)

3. Remove handlebar extension from vehicle.

#### Handlebar Extension Inspection

1. Check handlebar extension for:
  - Cracks
  - Bending
  - Other damages.
2. Replace if any of these problems is detected.


#### **⚠ WARNING**

Do not try to repair a defective handlebar extension.

#### Handlebar Extension Installation

The installation is the reverse of the removal procedure. However, pay attention to the following.

1. When installing handlebar extension, ensure to leave a gap between handlebar extension and stop block on steering column.



1. Bottom of handlebar extension
  2. Steering column stop block
  3. Front of vehicle
- A. 1 mm (.039 in) minimum

#### TIE-ROD

**NOTE:** The same procedure is applied on RH and LH side.


#### Tie-rod Inspection

Check tie-rod ends for looseness. If play is excessive, replace tie-rod.


1. Check if the tie-rod is bend, crack or otherwise damage. Replace if necessary.

#### Tie-rod Removal

1. Remove the tie-rod ends from the steering column and ski leg.



1. Tie-rod
2. Steering column




1. Tie-rod
2. Ski leg

2. Remove tie-rod from vehicle.

#### Tie-rod Installation

1. The installation is the reverse of the removal procedure. However, pay attention to the following.
2. Adjust the length of all tie-rod end to 30 mm (1.181 in) without tightening the jam nuts.




- A. 30 mm (1.181 in)

#### **⚠ WARNING**


The maximum tie-rod end length not engaged in the tie rod must not exceed 34 mm (1.339 in).

3. Install tie-rod with the groove on ski leg side.



1. Tie-rod groove  
2. Ski leg

4. On ski leg side, install hardened washers as shown.




1. Large hardened washer  
2. Small hardened washer

5. Install nuts retaining tie-rod ends. Torque them to 48 N•m (35 lbf•ft).  
6. Perform the steering alignment, refer to *STEERING ALIGNMENT* in this section.

## STEERING COLUMN

### Steering Column Removal

1. Refer to *BODY* section to remove the following parts:
  - Seat
  - RH side panel
  - Hood
  - Console.
2. Remove *HANDLEBAR EXTENSION* from steering column, see procedure in this section.
3. Remove screws securing steering column upper support.
4. Remove screws securing side frame members to rear frame member.




1. Steering column support  
2. RH side frame member  
3. Rear frame member

5. Remove trim panels covering the aft end of the rear frame members by pulling upward then pulling out (one each side).



6. Remove elastic nut and shoulder bushing retaining the rear frame members (one each side) to the tunnel (discard nuts, keep shoulder bushings).




1. Shoulder bushing  
2. Elastic nut

7. Remove the secondary air intake silencer. Refer to *AIR INTAKE SYSTEM* section.
8. Remove tuned pipe. Refer to *EXHAUST SYSTEM* section.

## Section 07 CHASSIS

### Subsection 03 (STEERING SYSTEM)

9. Remove the tie-rod ends from the steering column.



1. Tie-rod ends  
2. Steering column

10. Remove screws securing the steering column lower support.



1. Steering column support screws  
2. Steering column

11. Remove lower support.

12. Remove the steering column plate.



1. Steering column plate  
2. Steering column

13. Pull steering column from top.

## Steering Column Inspection

Check if steering column is:

- Cracked
- Bent
- Twist
- Otherwise damaged.

Replace steering column if necessary.

### **⚠ WARNING**

Do not try to repair a defective steering column.

## Steering Column Installation

The installation is the reverse of the removal procedure. However, pay attention to the followings.

1. Apply THERMO LUBE SYNTHETIC GREASE (P/N 219 700 417) on vibration dampers before installing upper and lower supports.
2. Tighten lower support bolts to 10N•m (89 lbf•in).
3. Install rear frame members.
4. Tighten the upper support bolts to 18N•m (159 lbf•in).
5. Install shoulder bushings and **NEW** elastic nuts on the rear frame members (one each side).
6. Torque elastic nuts securing the fuel tank to 33N•m (24 lbf•ft).
7. Install all other removed parts.



# BODY

## SERVICE TOOLS

Description	Part Number	Page
FUEL TANK WRENCH.....	529 035 891 .....	571
SUPERTANIUM™ DRILL BIT .....	529 031 800 .....	566-567

## GENERAL

### CLEANING

#### Seat Cleaning

It is recommended to clean the seat with a solution of warm soapy water, using a soft clean cloth.

**NOTICE** Avoid use of harsh detergents such as strong soaps, degreasing solvents, abrasive cleaners, paint thinners, etc. that may cause damage to the seat cover.

#### Plastic Cleaning

Clean the vehicle thoroughly, removing all dirt and grease accumulation.

To clean use a soft clean cloth and either soapy water or isopropyl alcohol.

To remove grease, oil or glue use isopropyl alcohol.

**NOTICE** Do not apply isopropyl alcohol or acetone directly on decals.


**NOTICE** The following products must not be applied on the plastic components used on the vehicles:

- Gasoline
- Brake fluid
- Kerosene
- Diesel fuel
- Lighter fluid
- Varsol
- Naphtha
- Acetone
- Strong detergents
- Abrasive cleaners
- Waxes containing an abrasive or a cleaning agent in their formula.

Apply a non abrasive wax on glossy finish only.

## BODY PARTS REPAIR

The very first step before repairing plastic materials is to find out exactly which type of material is involved.



TYPICAL — GSX LIMITED SHOWN

PLASTIC PARTS		
PARTS		MATERIAL
1	Side panel	Polypropylene GTX LE: Surlyn/polypropylene
2	Console	Surlyn
3	Gauge support	Polypropylene
4	Hood	Surlyn
5	Front bottom pan	Polypropylene
6	Side bottom pan	Polypropylene
7	Trunk	Polypropylene

**NOTICE** Some repair products are not compatible with certain plastics.

**⚠ WARNING**  
Polycarbonate windshields must never be repaired by welding or otherwise.

The following company provides a complete line of products to repair plastic materials:

## Section 07 CHASSIS

### Subsection 04 (BODY)

CREST INDUSTRIES, INC.  
Trenton, MI 48183  
Phone: 734 479-4141  
Toll Free: 1 800 822-4100  
Fax: 734 479-4040  
E-Mail: info@crestauto.com  
www.crestauto.com

## PROCEDURES

### DECAL

#### Decal Replacement

1. To remove a decal; heat old decal with a heat gun and peel off slowly.
2. Using isopropyl alcohol, clean the surface and dry thoroughly.
3. Apply liquid soap to new decal and carefully position the decal. Using a sponge or a squeegee, remove the air bubbles and surplus water working from the center toward the edges. Allow to air dry.


**NOTICE** Do not apply isopropyl alcohol or solvent directly on decals. Use only in a well ventilated area.

### SIDE PANEL

#### Side Panel Removal

**NOTE:** The same procedure applies for RH or LH side.

1. Stretch and unhook the latches.



1. Latches

2. Open side panel.
3. Lift up the side panel and move the lower hinge out of its slot.

**NOTE:** On GTX LE, move lower and center hinges out of slots.

4. Free the upper hinge from its slot by lowering the side panel.

### Side Panel Installation

The installation is the reverse of the removal procedure.

## REWIND STARTER HANDLE HOUSING

### Rewind Starter Handle Housing Removal

1. Open RH side panel.
2. Remove screws retaining housing to oil reservoir.



1. Screws

3. Pull on housing to release it from oil reservoir.



1. Housing

4. Remove rewind starter handle. Refer to *REWIND STARTER* section.

## Rewind Starter Handle Housing Installation


Installation is the reverse of removal procedure. Pay attention to the following details.

1. To properly install rewind starter handle housing, it must be pushed vigorously into oil reservoir. Ensure it is properly set in place before installing hardware.
2. Torque screws to 1 N•m (9 lbf•in).

## HOOD

### Hood Removal

*All Models except GTX LE*



1. Hood

1. Stand in front of vehicle.
2. Pull outwards on both sides of hood aft section.




3. Slide hood forwards.
4. Remove hood from vehicle.

## GTX LE



1. Hood

1. Pull up the rear end of the hood on both sides.
2. Lift the rear end of the hood until it disengages from the bottom pan.



Step 1: Pull up  
Step 2: Lift

### Hood Installation

The installation is the reverse of removal procedure.


## Section 07 CHASSIS

### Subsection 04 (BODY)

## BOTTOM PAN COVER

### Bottom Pan Cover Removal

All Models except GTX LE



1. Bottom pan cover


1. Remove HOOD, see procedure above.
2. Remove screws that hold bottom pan cover.



1. Bottom pan cover screws  
2. Bottom pan cover

3. Remove bottom pan cover from vehicle.

GTX LE



1. Bottom pan cover


1. Lower both locks located under the front



LH SIDE SHOWN

1. Bottom pan cover lock
2. Front bumper
3. Bottom pan cover


2. Pull locks toward the front of vehicle.



LH SIDE SHOWN

1. Bottom pan cover lock
2. Front bumper

3. Move the ends of cover away to release cover tabs.



RH END SHOWN

1. Bottom pan cover end
2. Cover tab

4. Hold both ends of the cover and pull the cover in your direction.


**NOTE:** Four retaining tabs lock the cover to the bottom pan. The cover could be hard to remove, pull it vigorously.

## Bottom Pan Cover Installation

The installation is the reverse of the removal procedure. However, pay attention to the following.

### GTX LE

1. When installing bottom pan cover, make sure to insert cover tabs into bottom pan slots.



#### LH SIDE SHOWN

1. Bottom pan cover tabs
2. Bottom pan slots

2. Replace front locks in their original position.
3. Insert both cover tabs in their slots.



#### RH END SHOWN

1. Bottom pan cover end
2. Cover tab

## FRONT BUMPER

### Front Bumper Removal

#### All Models except GTX LE

1. Remove *HOOD*, see procedure in this section.
2. Remove *BOTTOM PAN COVER*, see procedure in this section.
3. Remove existing rivets by drilling them.



1. Front bumper rivets

4. Remove front bumper bolts.




1. Front bumper bolt

5. Remove bumper from vehicle by pulling it toward the front.

### GTX LE

1. Remove *HOOD* and *BOTTOM PAN COVER*, see procedures in this section.
2. Remove screws securing front bumper to frame.



1. Front bumper
2. Front bumper screws

3. Remove bumper from vehicle by pulling it toward the front of vehicle.

## Section 07 CHASSIS

### Subsection 04 (BODY)

#### Front Bumper Installation

##### All Models except GTX LE

Install bumper on vehicle.

Install rivets.

Install bumper bolts and nuts.


Tighten bumper nuts to 10 N•m (89 lbf•in).

Install bottom pan cover.

Install hood.

##### GTX LE

1. Install bumper on vehicle. Position the narrow flat side on top.




1. Narrow flat side
2. Bottom pan

2. Tighten bumper screws to 10 N•m (89 lbf•in).
3. Install bottom pan cover and hood.

#### FRONT BOTTOM PAN

##### Front Bottom Pan Removal


##### All Models except GTX LE



1. Front bottom pan


1. Lift front of vehicle until skis are off the ground.

2. Place the front portion of frame on a wooden box to support it securely.



3. Remove *FRONT BUMPER*, see procedure in this section.
4. Remove muffler and tuned pipe. Refer to *EXHAUST SYSTEM* section.
5. Remove front shock absorbers.
6. Using an angle drill and a SUPERTANIUM™ DRILL BIT (P/N 529 031 800), remove all rivets retaining bottom pan.


**NOTE:** Refer to *FRAME* for proper procedure when drilling rivets retaining plastic.



- RH SIDE SHOWN**  
1. Drill these rivets

## Section 07 CHASSIS

### Subsection 04 (BODY)




UNDERNEATH FRONT OF VEHICLE

1. Drill these rivets


7. Remove bottom pan.

GTX LE



1. Front bottom pan

1. Lift front of vehicle until skis are off the ground.
2. Place the front portion of frame on a wooden box to support it securely.




3. Remove *FRONT BUMPER*, see procedure in this section.

4. Remove muffler and tuned pipe. Refer to *EX-HAUST SYSTEM* section.

5. Remove front shock absorbers.


6. Using an angle drill and a SUPERTANIUM™ DRILL BIT (P/N 529 031 800), remove all rivets retaining front bottom pan.

**NOTE:** Refer to *FRAME* for proper procedure when drilling rivets retaining plastic.



RH SIDE SHOWN - UPPER SUSPENSION ARM REMOVED FOR CLARITY

1. Drill these rivets



UNDERNEATH FRONT OF VEHICLE

1. Drill these rivets

7. Remove screws securing the top of front bottom pan.



1. Retaining screw (one each side)

8. Remove bottom pan.

## Section 07 CHASSIS


### Subsection 04 (BODY)

#### Front Bottom Pan Installation

The installation is the reverse of removal procedure. However, pay attention to the following.

##### *GTX LE*

Above shock absorber upper bracket, install the front bottom pad behind the side bottom pan to have a good fit.




1. Front bottom pan over side bottom pan
2. Front bottom pan behind side bottom pan
3. Front bottom pan
4. RH side bottom pan

#### WINDSHIELD

##### Windshield Removal

Place your hands on each side of windshield. Pull the windshield until its pins come out of rubber grommets.

**NOTE:** On GSX and GTX LE, free both deflectors first.



- TYPICAL**
1. Windshield deflector
  2. Mirror

##### Windshield Installation


The installation is the reverse of removal procedure.

**NOTE:** Make sure not to push grommets through gauge support holes.

#### GAUGE SUPPORT


##### Gauge Support Removal

*All Models except GTX LE*



1. Gauge support

1. Remove *WINDSHIELD*, see procedure in this section.
2. Remove *HOOD*, see procedure in this section.
3. Remove the multifunction gauge. Refer to *LIGHTS, GAUGE AND ACCESSORIES* section.
4. Unplug headlight connectors.



1. Headlight connectors

5. Remove the gauge support side screws.



**LH SIDE SHOWN**


1. Gauge support side screws



## Section 07 CHASSIS

### Subsection 04 (BODY)

6. Remove the screw under front of headlights.



1. Remove this screw

7. Slide gauge support forwards the lift it.

8. On GSX models, unplug the 12-volt power outlet connectors.

#### GTX LE



1. Gauge support


1. Remove *WINDSHIELD*, see procedure in this section.

2. Remove *CONSOLE*, see procedure in this section.

3. Remove the multifunction gauge. Refer to *LIGHTS, GAUGE AND ACCESSORIES* section.


4. Unplug headlight connectors.

5. Remove screws securing the gauge support.



**RH SIDE SHOWN**


1. Retaining screw  
2. Gauge support



1. Front retaining screws

6. Unplug the 12-volt power outlet, the DESS post and the visor outlet.

7. On LH and RH sides, press and hold the tabs securing gauge support to secondary air intake silencer.




**RH SIDE SHOWN**

1. Press this tab

## Section 07 CHASSIS

### Subsection 04 (BODY)



LH SIDE SHOWN  
1. Press this tab


8. Slide the gauge support toward the front of vehicle then lift its rear portion to remove the gauge support completely.

### Gauge Support Installation

The installation is the reverse of removal procedure. However, pay attention to the following.


#### GTX LE

1. Align gauge support tabs with secondary air intake silencer slots.




RH SIDE SHOWN  
1. Gauge support tabs  
2. Secondary air intake silencer slots

2. Push the gauge support until both tabs are locked.



1. RH tab




1. LH tab

3. Install all other removed parts using proper installation procedures.

## CONSOLE

### Console Removal


All Models except GTX LE



1. Console


1. Remove LH and RH side panels.
2. Remove seat.
3. Remove the GAUGE SUPPORT, see procedure in this section.

4. Remove screws securing both sides of console front section.




1. Remove these screws


5. Remove fuel tank cap.  
6. Using the FUEL TANK WRENCH (P/N 529 035 891), unscrew the fuel tank nut.



7. Unlock console clips located under gauge support (two each side).



1. Clip near the front of console  
2. Console  
3. Gauge support



1. Rear clip  
2. Console  
3. Gauge support

8. Lift up the console and unplug all connectors.  
9. Install fuel tank cap.

**GTX LE**




1. Console

1. Remove LH and RH side panels.  
2. Remove seat.  
3. Remove fuel tank cap.  
4. Using the FUEL TANK WRENCH (P/N 529 035 891), unscrew the fuel tank nut.

## Section 07 CHASSIS

### Subsection 04 (BODY)




5. Lift up the rear of console and slide it toward the rear of the vehicle.
6. Install fuel tank cap.

### Console Installation

The installation is the reverse of removal procedure.


### REAR RACK (GTX SPORT/LE)



1. Rear rack


### Rear Rack Removal

1. Remove passenger's seat.
2. Drill rivets (4) securing the radiator cover.




1. Radiator cover rivets

3. Remove the rear bumper.




1. Rear bumper screws (4 each side)
2. Rear bumper

4. Remove screws (6) securing the rear rack assembly to tunnel.



1. Rear rack
2. Rear rack screws (3 each side)


5. Remove rear rack.



1. Rear rack assembly


### Rear Rack Disassembly

1. Remove the taillight cover by pulling up the rear end of cover.




1. Taillight cover

2. Remove screw securing taillight compartment to radiator cover.




1. Taillight compartment screw  
2. Taillight

3. Turn rear rack up side down.
4. Remove screws retaining radiator cover to rear rack arms.




1. Radiator cover  
2. Retaining screws

5. Detach taillight harness to remove radiator cover.



1. Retaining clips  
2. Taillight harness

6. Unplug taillight connectors.
7. Remove screws securing taillight, rack arms and taillight compartment together.



1. Taillight connectors  
2. Remove taillight screws

8. Pull harness inside taillight compartment and separate parts.

### Rear Rack Assembly and Installation

The assembly/installation is the reverse of the disassembly and removal procedures.

# FRAME


## SERVICE TOOLS

<b>Description</b>	<b>Part Number</b>	<b>Page</b>
SUPERTANIUM DRILL BIT.....	529 031 800 .....	577

## SERVICE PRODUCTS

<b>Description</b>	<b>Part Number</b>	<b>Page</b>
XP-S SYNTHETIC CHAINCASE OIL .....	413 803 300 .....	577

**Section 07 CHASSIS**  
Subsection 05 (FRAME)



## GENERAL

During assembly/installation, use the torque values and the service products as in the exploded views.

Clean threads before applying a threadlocker. Refer to *SELF-LOCKING FASTENERS* and *LOCTITE APPLICATION* at the beginning of this manual for complete procedure.

### **⚠ WARNING**

Torque wrench tightening specifications must be strictly adhered to.

Locking devices (e.g.: locking tabs, elastic stop nuts, cotter pins, etc.) must be replaced with new ones.

Hoses or cables removed or disconnected must be installed and routed at the same place.

**NOTICE** Locking ties removed during a procedure must be replaced and installed at the same location.

## RIVET DRILLING PROCEDURE

For proper drilling instructions and to prevent premature wear, follow the procedure below.

**NOTICE** When removing rivets, make sure do not enlarge or deform the holes.

### Self-Percing Rivet


#### Recommended Method

1. Using a grinding disk, grind the rivet end.



1. Grind this side
2. Pop rivet
3. STAVEX rivet

2. Support the frame around the rivet head with a socket on the opposite side to avoid warpage.



1. 11 mm socket over a rivet head
2. Rivet heads

3. Drive out remaining rivet using a punch.

#### Alternative Method

1. Use the SUPERTANIUM DRILL BIT (P/N 529 031 800), available in a 5 mm (3/16 in) size and shipped in packs of 2.
2. Partially drill rivet end — not the rivet head.
3. Always use a variable speed drill.

**NOTICE** High speed drilling will cause excessive heat which may destroy the cutting edge of the bit; therefore, avoid using pneumatic drills.

4. Maintain a slow to medium speed at all times when drilling. The proper speed is attained when a constant chip is ejected.

**NOTE:** To increase bit life, use XP-S SYNTHETIC CHAINCASE OIL (P/N 413 803 300) as a cutting oil.

5. Cut rivet using a chisel.
6. Remove riveted part.
7. Drive out remaining rivet head using a punch.

### Pop Rivets

1. Use the SUPERTANIUM DRILL BIT (P/N 529 031 800), available in a 5 mm (3/16 in) size and shipped in packs of 2.
2. Always use a variable speed drill.
3. Always drill rivet head.
4. Maintain a slow to medium speed at all times when drilling. The proper speed is attained when a constant chip is ejected.
5. When rivet is located on plastic part, use pliers to avoid rivet turning and heating plastic.
6. Use a small punch to push the rivet end.




## Section 07 CHASSIS

### Subsection 05 (FRAME)

## HUCK Rivets

### Recommended Method

1. Using a cut-off tool, cut the rivet attachment without touching the shoulder.



1. Rivet attachment shoulder
2. Cutter wheel
3. Rivet attachment

**NOTE:** Apply a thin layer of grease on cutter wheel to increase its durability.

2. Break the rivet attachment shoulder using a chisel.
3. Use a small punch to push the rivet stem.

### Alternative Method

1. Measure outside diameter of rivet stem and select appropriate drill bit.
2. Drill the rivet stem — not the rivet head until rivet attachment is freed.
3. Always use a variable speed drill.
4. Maintain a slow to medium speed at all times when drilling. The proper speed is attained when a constant chip is ejected.

**NOTE:** When possible, use an angle grinder to grind rivet head or use an air hammer to cut the rivet attachment.

## PROCEDURES

### FRAME

#### Frame Cleaning

Clean frame and tunnel with appropriate cleaners and rinse with high pressure hose.

**NOTE:** For bare aluminum frames use only aluminum cleaner and follow instructions on container.

**NOTICE** Never direct high-pressure water jet towards decals. They will peel off.


## Frame Welding

No welds should be done on aluminum frame except if mentioned or required on a BRP Bulletin.

## REAR BUMPER

### Rear Bumper Removal

1. Underneath tunnel, remove bolts retaining rear bumper to tunnel.



TYPICAL — MX Z TRAIL MODEL SHOWN  
1. Rear bumper bolts on right side

2. Pull rear bumper to remove it from vehicle.

### Rear Bumper Installation


The installation is the reverse of the removal procedure.

**NOTE:** Install all bolts before torquing them.

## REAR FRAME MEMBER


### Rear Frame Member Removal

1. Refer to *BODY* section to remove the following:
  - Seat
  - Gauge support
  - Console.
2. Remove trim panel at the bottom of rear frame member (one each side).




1. Trim panel
2. Rear frame member

3. Remove nut and shouldered washer securing rear frame member (one each side).



1. Rear frame member
2. Nut to remove
3. Shouldered washer
4. Fuel tank

4. Remove screws securing the rear frame member to steering column support and side frame members.



1. Rear frame member
2. LH side frame member
3. Steering column support
4. Bolts to remove

5. Remove rear frame member.

## Rear Frame Member Installation


The installation is the reverse of the removal procedure.

**NOTE:** Install all bolts and nuts before tightening them.


## FRONT FRAME MEMBER

### Front Frame Member Removal

1. Refer to *BODY* section to remove the following:
  - Hood
  - Console
  - Gauge support.
2. Remove the secondary air intake silencer. Refer to *AIR INTAKE SYSTEM* section.
3. Remove the tuned pipe. Refer to *EXHAUST SYSTEM* section.
4. Lift front of vehicle until skis are off the ground.
5. Place the front portion of frame on a wooden box to support it securely.




6. Remove front shock absorbers.
7. Drill the rivet retaining the front bottom pan to front frame member (one each side).



## Section 07 CHASSIS


### Subsection 05 (FRAME)

8. Remove HUCK rivets (six each side), see removal procedure at the beginning of this section.



1. HUCK rivets

9. Remove bolts securing front frame member, rear frame member and steering column support.



1. Front frame member  
2. Bolts to remove  
3. Rear frame member  
4. Steering column

10. Remove the front frame member.

### Front Frame Member Installation

The installation is the reverse of the removal procedure. However, pay attention to the following.

1. Replace the HUCK rivets with the following parts.

NEW FASTENERS	
Hexagonal flanged bolt M6 x 20	(P/N 207 662 044)
Hexagonal flanged elastic stop nut M6	(P/N 233 261 414)


**NOTE:** Unless stated otherwise, install bolt heads toward outside of the vehicle.

2. Torque new fasteners to 10 N•m (89 lbf•in).


## FRONT CROSS MEMBER

### Front Cross Member Removal

1. Lift front of vehicle until skis are off the ground.
2. Place the front portion of frame on a wooden box to support it securely.




3. Remove the muffler and the tuned pipe. Refer to *EXHAUST SYSTEM* section.
4. Remove the RH front suspension assembly by doing the following:
  - 4.1 Detach tie-rod end from steering column.



1. Tie-rod  
2. Steering column  
3. Tie-rod end nut

- 4.2 Remove shock absorber upper bolt.
- 4.3 Remove bolt linking stabilizer link and stabilizer lever.




1. Stabilizer lever  
2. Stabilizer link

4.4 Remove upper and lower suspension arms bolts. Refer to *FRONT SUSPENSION* section.

4.5 Pull suspension arms to remove the RH front suspension assembly.

**NOTE:** Repeat same procedure for the LH front suspension.

5. Remove bolts securing the bottom of steering column.




1. Steering column bolts  
2. Steering column  
3. Lower suspension arm support


6. Remove the front bottom pan. Refer to *BODY* section.

**NOTE:** Keep the front bumper installed on front bottom pan.

7. Drill the following rivets.




RH SIDE



LH SIDE

8. Remove screws securing front cross member to frame (2 each side).




LH SIDE SHOWN

1. Hexagonal flanged bolt  
2. Torx screw

9. Remove HUCK rivets (six each side), see removal procedure at the beginning of this section.


## Section 07 CHASSIS

### Subsection 05 (FRAME)




LH SIDE SHOWN  
1. HUCK rivets

10. Grind rivets securing the lower suspension arm support to engine member.



1. Rivets  
2. Lower suspension arm support

11. Remove the following nuts.



12. Remove the front cross member.

### Front Cross Member Installation

The installation is the reverse of the removal procedure. However, pay attention to the following.

1. Replace the HUCK rivets with the following parts.

#### NEW FASTENERS

Hexagonal flanged bolt M6 x 20	(P/N 207 662 044)
Hexagonal flanged elastic stop nut M6	(P/N 233 261 414)


**NOTE:** Unless stated otherwise, install bolt heads toward outside of the vehicle.

2. Torque new fasteners to 10 N•m (89 lbf•in).
3. Reinstall all removed parts by using the appropriate installation procedure.

## ENGINE MEMBER


### Engine Member Removal

1. Remove engine from vehicle. Refer to *ENGINE REMOVAL AND INSTALLATION* section.
2. Remove the *FRONT CROSS MEMBER*, see procedure in this section.
3. Remove stabilizer bar.
4. Remove screws retaining side bottom pan to headlight housing.




LH SIDE SHOWN  
1. Side bottom pan  
2. Headlight housing  
3. Gauge support


5. Remove both side bottom pans by drilling the following rivets.



LH SIDE BOTTOM PAN




RH SIDE SHOWN  
1. HUCK rivets




RH SIDE BOTTOM PAN

6. On LH side, remove front and rear engine rubber mounts.




LH SIDE SHOWN  
1. HUCK rivets



1. Engine rubber mounts

7. Remove HUCK rivets, see removal procedure at the beginning of this section.



9. Remove the engine member.

### Engine Member Installation

The installation is the reverse of the removal procedure. However, pay attention to the following.

1. Replace the HUCK rivets with the following parts.

## Section 07 CHASSIS

### Subsection 05 (FRAME)

NEW FASTENERS	
Hexagonal flanged bolt M6 x 20	(P/N 207 662 044)
Hexagonal flanged elastic stop nut M6	(P/N 233 261 414)

**NOTE:** Install bolt heads toward outside of the vehicle, except the one securing chaincase.

2. Torque new fasteners to 10 N•m (89 lbf•in).
3. Reinstall all removed parts by using the appropriate installation procedure.



**Section 08 TECHNICAL SPECIFICATIONS**  
Subsection 01 (500SS MODELS)

# 500SS MODELS

MODEL	GSX 500SS	GTX 500SS	MX Z 500SS	
	Sport	Sport	TNT	Trail
<b>ENGINE</b>				
Engine type	593			
Number of cylinders	2			
Bore	76 mm (2.992 in)			
Stroke	65.8 mm (2.591 in)			
Displacement	597 cm <sup>3</sup> (36.43 in <sup>3</sup> )			
Compression ratio	12.00 ± 0.5			
Maximum power engine speed	8000 ± 100 RPM			
Combustion chamber volume	27.52 ml to 28.37 ml (.93 U.S. oz to .96 U.S. oz)			
RAVE spring	Color	Brown		
	Wire diameter	0.9 mm (.035 in)		
	Minimum free length	48.5 mm (1.909 in)		
Piston ring type	Semi-trapezoidal			
Ring end gap	New	0.4 mm to 0.55 mm (.0157 in to .0217 in)		
	Wear limit	1 mm (.039 in)		
Ring/piston groove clearance	New	0.04 mm to 0.09 mm (.0016 in to .0035 in)		
	Wear limit	0.2 mm (.0079 in)		
Piston/cylinder wall clearance	New	0.094 mm to 0.146 mm (.0037 in to .0057 in)		
	Wear limit	0.18 mm (.0071 in)		
Piston skirt wear	Wear limit	0.15 mm (.006 in)		
Cylinder head warpage	Wear limit	0.5 mm (.02 in)		
Cylinder taper	New (max.)	0.05 mm (.002 in)		
	Wear limit	0.1 mm (.0039 in)		
Cylinder out of round	New (max.)	0.01 mm (.0004 in)		
	Wear limit	0.08 mm (.0031 in)		
Crankshaft end play	New	MIN.: 0.10 mm (.0039 in) MAX.: 0.30 mm (.0118 in)		
Crankshaft deflection	MAX.	MAG: 0.05 mm (.002 in) CENTER: 0.08 mm (.0031 in) PTO: 0.06 mm (.0024 in)		
Connecting rod big end axial play	New	0.36 mm to 0.74 mm (.0142 in to .0291 in)		
	Wear limit	1.2 mm (.0472 in)		
<b>COOLING SYSTEM</b>				
Coolant	Type	Ethyl glycol and distilled water (50%/50%). Use BRP premix coolant (P/N 219 700 362) or coolant specifically formulated for aluminum engines		
	Quantity	4.5 L (1.19 U.S. gal.) GTX: 4.6 L (1.22 U.S. gal.)		
Thermostat opening temperature	37°C (99°F)			
Radiator cap opening pressure	90 kPa (13 PSI)			



**Section 08 TECHNICAL SPECIFICATIONS****Subsection 01 (500SS MODELS)**

MODEL	GSX 500SS	GTX 500SS	MX Z 500SS	
	Sport	Sport	TNT	Trail
<b>LUBRICATION SYSTEM</b>				
Injection oil	Type	XP-S injection oil (P/N 413 802 900)		
	Quantity	3.7 L (1 U.S. gal.)		
<b>FUEL SYSTEM</b>				
Carburetor type		TM40		
Main jet		420		
Needle jet		P-0M		
Pilot jet		17.5		
Jet needle identification		9CEY01 – 58		
Clip position number		3		
Slide cut-away		2.0		
Idle throttle slide height		1.5 mm ± 0.1 mm (.059 in ± .004 in)		
Float adjustment		Not adjustable		
Air or pilot screw adjustment		1.5 ± 1/16 turn		
Idle speed		1600 ± 200 RPM		
Fuel type		Regular unleaded gasoline		
Fuel octane rating	Inside North America ((R+M)/2)	87 or higher		
	Outside North America (RON)	92 or higher		
Fuel tank capacity		40 L (10.6 U.S. gal.)		
Gas/oil ratio		Injection		
<b>ELECTRICAL SYSTEM</b>				
Magneto generator output		360 W @ 6000 RPM		
Ignition type		C.D.I.		
Spark plug	Make and type	NGK BR10ECS		
	Gap	Not adjustable 0.7 mm to 0.8 mm (.028 in to .031 in)		
Ignition timing BTDC		2.49 mm (.098 in) @ 3500 RPM		
Trigger coil		190 to 300 Ω		
Lighting coil		0.1 to 1.0 Ω		
High tension coil	Primary	0.3 to 0.7 Ω		
	Secondary	18 to 26 KΩ (with caps)		
Battery		12 V, 18 A•h (with electric starter)		
Headlamp		2 x 60/55 W (H4)		
Taillight and stoplight		5/21 W		

## Section 08 TECHNICAL SPECIFICATIONS

### Subsection 01 (500SS MODELS)

MODEL		GSX 500SS	GTX 500SS	MX Z 500SS	
		Sport	Sport	TNT	Trail
<b>ELECTRICAL SYSTEM (cont'd)</b>					
Fuse	Main	30 A (with electric starter)			
	ECM	5 A (with electric starter)			
	Headlamp	15 A			
	Accessories/ taillight	20 A			
	Fuel level sensor	0.25 A (if applicable)			
<b>DRIVE SYSTEM</b>					
Chaincase oil	Type	XP-S synthetic chaincase oil (P/N 413 803 300)			
	Quantity	250 ml (8.5 U.S. oz)			
Chain drive ratio		24/45	23/45	25/45 EUR: 23/45	23/45
Chain	Pitch	3/8			
	Type/links qty/plate qty	Silent 13/104			
Drive pulley type		TRA III			
Drive pulley calibration	Clutch engagement	3400 ± 100 RPM		3800 ± 100 RPM	
	Spring color	Blue/Purple		Purple/Purple	
	Spring length	96.6 mm (3.803 in)		106.98 mm (4.212 in)	
	Pin	Solid (P/N 417 004 308)			
	Ramp	412			
	Screw position	3			
Driven pulley type	Type	QRS			
	Spring color	Black			
	Spring preload	0			
	Cam angle	42°			
Pulley distance	Z	Not adjustable 21 mm (.827 in)			
Offset	X	Not adjustable 37.1 mm (1.461 in)			
Drive belt part number		(P/N 417 300 197)			
Drive belt	Width	37.3 mm (1.469 in)			
	Wear limit	34.9 mm (1.374 in)			
Drive belt adjustment	Deflection	32 mm ± 5 mm (1.26 in ± .197 in)			
	Force	11.3 kgf (24.9 lbf)			
Track	Width	381 mm (15 in)			
	Length	3 m (120 in) GTX: 3.5 m (137 in)			
	Profile height	25.4 mm (1 in) TNT (EUR): 31.8 mm (1.25 in)			

## Section 08 TECHNICAL SPECIFICATIONS

### Subsection 01 (500SS MODELS)

MODEL		GSX 500SS	GTX 500SS	MX Z 500SS	
		Sport	Sport	TNT	Trail
<b>DRIVE SYSTEM (cont'd)</b>					
Track adjustment	Deflection	30 mm to 35 mm (1.181 in to 1.378 in)			
	Force	7.3 kgf (16.1 lbf)			
<b>BRAKE SYSTEM</b>					
Brake lining minimum thickness		1 mm (.039 in)			
Brake disk minimum thickness		4.5 mm (.177 in)			
Brake fluid	Type	DOT 4			
	Quantity	65 ml (2.2 U.S. oz)			
<b>SUSPENSION</b>					
<i>FRONT</i>					
Suspension type		REV-XP			
Suspension maximum travel		229 mm (9 in)			
Shock absorber type		Motion control		H.P.G. T/A (aluminum) EUR: H.P.G. clicker T/A (aluminum)	Motion control
Spring color		—		Silver/Silver/Green EUR: White/Silver/Green	—
Sway bar type		Link			
<i>REAR</i>					
Suspension type		SC-5			
Suspension maximum travel		381 mm (15 in)			
Shock absorber type	Center	Motion control		H.P.G. T/A (aluminum)	Motion control
	Rear	Motion control	H.P.G. VR	H.P.G. T/A (aluminum) EUR: H.P.G. racing clicker (aluminum)	Motion control
Spring color		Center Gold/Red/Red			
Stroke limiter standard position		3			
<b>STEERING SYSTEM</b>					
Ski type		Pilot 5.7	Pilot SL	Pilot 5.7	Pilot 5.7
Toe-out		5 mm (.197 in)			
Camber		0°			
<b>WEIGHT AND DIMENSIONS</b>					
Mass (dry)		198 kg (437 lb)	211 kg (465 lb)	181 kg (399 lb)	188 kg (414 lb)
Length		289 cm (113.8 in) GTX: 311 cm (122.4 in)			
Width		122 cm (48 in)			
Height		126 cm (49.6 in)	120 cm (47.2 in)	113 cm (44.5 in)	120 cm (47.2 in)
Ski stance (carbide to carbide)		119.5 cm (47.05 in)			

---

**Section 08 TECHNICAL SPECIFICATIONS**Subsection 01 (500SS MODELS)

---

MODEL	GSX 500SS	GTX 500SS	MX Z 500SS	
	Sport	Sport	TNT	Trail
<b>MATERIAL</b>				
Frame	Aluminum			
Bottom pan and side panels	Polypropylene			
Hood	Surlyn			

## Section 08 TECHNICAL SPECIFICATIONS

### Subsection 02 (600 MODELS)

# 600 MODELS

MODEL		SUMMIT
		Everest 600
<b>ENGINE</b>		
Engine type		593
Number of cylinders		2
Bore		76 mm (2.992 in)
Stroke		65.8 mm (2.591 in)
Displacement		597 cm <sup>3</sup> (36.43 in <sup>3</sup> )
Compression ratio		12.00 ± 0.5
Maximum power engine speed		8000 ± 100 RPM
Combustion chamber volume		27.52 ml to 28.37 ml (.93 U.S. oz to .96 U.S. oz)
RAVE spring	Color	Brown
	Wire diameter	0.9 mm (.035 in)
	Minimum free length	48.5 mm (1.909 in)
Piston ring type		Semi-trapezoidal
Ring end gap	New	0.4 mm to 0.55 mm (.0157 in to .0217 in)
	Wear limit	1 mm (.039 in)
Ring/piston groove clearance	New	0.04 mm to 0.09 mm (.0016 in to .0035 in)
	Wear limit	0.2 mm (.0079 in)
Piston/cylinder wall clearance	New	0.094 mm to 0.146 mm (.0037 in to .0057 in)
	Wear limit	0.18 mm (.0071 in)
Piston skirt wear	Wear limit	0.15 mm (.006 in)
Cylinder head warpage	Wear limit	0.5 mm (.02 in)
Cylinder taper	New (max.)	0.05 mm (.002 in)
	Wear limit	0.1 mm (.0039 in)
Cylinder out of round	New (max.)	0.01 mm (.0004 in)
	Wear limit	0.08 mm (.0031 in)
Crankshaft end play	New	MIN.: 0.10 mm (.0039 in) MAX.: 0.30 mm (.0118 in)
Crankshaft deflection	MAX.	MAG: 0.05 mm (.002 in) CENTER: 0.08 mm (.0031 in) PTO: 0.06 mm (.0024 in)
Crankshaft end play	New	MIN.: 0.10 mm (.0039 in) MAX.: 0.30 mm (.0118 in)
Crankshaft deflection	MAX.	MAG: 0.05 mm (.002 in) CENTER: 0.08 mm (.0031 in) PTO: 0.06 mm (.0024 in)
Crankshaft end play	New	MIN.: 0.10 mm (.0039 in) MAX.: 0.30 mm (.0118 in)
Crankshaft deflection	MAX.	MAG: 0.05 mm (.002 in) CENTER: 0.08 mm (.0031 in) PTO: 0.06 mm (.0024 in)
Connecting rod big end axial play	New	0.36 mm to 0.74 mm (.0142 in to .0291 in)
	Wear limit	1.2 mm (.0472 in)

**Section 08 TECHNICAL SPECIFICATIONS**

## Subsection 02 (600 MODELS)

MODEL		SUMMIT	
		Everest 600	
<b>COOLING SYSTEM</b>			
Coolant	Type	Ethyl glycol and distilled water (50%/50%). Use BRP premix coolant (P/N 219 700 362) or coolant specifically formulated for aluminum engines	
	Quantity	4.7 L (1.24 U.S. gal.)	
Thermostat opening temperature		37°C (99°F)	
Radiator cap opening pressure		90 kPa (13 PSI)	
<b>LUBRICATION SYSTEM</b>			
Injection oil	Type	XP-S synthetic blend 2-stroke oil (P/N 293 600 100)	
	Quantity	3.7 L (1 U.S. gal.)	
<b>FUEL SYSTEM</b>			
Carburetor type		TM40	
Main jet		420	
Needle jet		P-0M	
Pilot jet		17.5	
Jet needle identification		9CEY01 – 58	
Clip position number		3	
Slide cut-away		2.0	
Idle throttle slide height		1.5 mm ± 0.1 mm (.059 in ± .004 in)	
Float adjustment		Not adjustable	
Air or pilot screw adjustment		1.5 ± 1/16 turn	
Idle speed		1600 ± 200 RPM	
Fuel type		Regular unleaded gasoline	
Fuel octane rating	Inside North America ((R+M)/2)	87 or higher	
	Outside North America (RON)	92 or higher	
Fuel tank capacity		40 L (10.6 U.S. gal.)	
Gas/oil ratio		Injection	
<b>ELECTRICAL SYSTEM</b>			
Magneto generator output		360 W @ 6000 RPM	
Ignition type		C.D.I.	
Spark plug	Make and type	NGK BR10ECS	
	Gap	Not adjustable 0.7 mm to 0.8 mm (.028 in to .031 in)	
Ignition timing BTDC		2.49 mm (.098 in) @ 3500 RPM	
Trigger coil		190 to 300 Ω	
Lighting coil		0.1 to 1.0 Ω	
High tension coil	Primary	0.3 to 0.7 Ω	
	Secondary	18 to 26 KΩ (with caps)	
Battery		12 V, 18 A•h (with electric starter)	
Headlamp		2 x 60/55 W (H4)	
Taillight and stoplight		5/21 W	

## Section 08 TECHNICAL SPECIFICATIONS

### Subsection 02 (600 MODELS)

MODEL		SUMMIT
		Everest 600
<b>ELECTRICAL SYSTEM (cont'd)</b>		
Fuse	Main	30 A (with electric starter)
	ECM	5 A (with electric starter)
	Headlamp	15 A
	Accessories/ Taillight	20 A
	Fuel level sensor	0.25 A (if applicable)
<b>DRIVE SYSTEM</b>		
Chaincase oil	Type	XP-S synthetic chaincase oil (P/N 413 803 300)
	Quantity	250 ml (8.5 U.S. oz)
Chain drive ratio		19/49
Chain	Pitch	3/8
	Type/links qty/plate qty	Silent 13/104
Drive pulley type		TRA III
Drive pulley calibration	Clutch engagement	4100 ± 100 RPM
	Spring color	Green/Pink
	Spring length	118 mm (4.6 in)
	Pin	1 x 417 000 477 + 1 x 206 262 099
	Ramp	417
	Screw position	3
Driven pulley type	Type	QRS
	Spring color	Black
	Spring preload	0
	Cam angle	43-47°
Pulley distance	Z	Not adjustable 21 mm (.827 in)
Offset	X	Not adjustable 37.1 mm (1.461 in)
Drive belt part number		(P/N 417 300 197)
Drive belt	Width	37.3 mm (1.469 in)
	Wear limit	34.9 mm (1.374 in)
Drive belt adjustment	Deflection	32 mm ± 5 mm (1.26 in ± .197 in)
	Force	11.3 kgf (24.9 lbf)
Track	Width	381 mm (15 in)
	Length	3.7 m (146.1 in)
	Profile height	50.8 mm (2 in)
Track adjustment	Deflection	30 mm to 35 mm (1.181 in to 1.378 in)
	Force	7.3 kgf (16.1 lbf)

**Section 08 TECHNICAL SPECIFICATIONS****Subsection 02 (600 MODELS)**

MODEL		SUMMIT
		Everest 600
<b>BRAKE SYSTEM</b>		
Brake lining minimum thickness		1 mm (.039 in)
Brake disk minimum thickness		4.5 mm (.177 in)
Brake fluid	Type	DOT 4
	Quantity	65 ml (2.2 U.S. oz)
<b>SUSPENSION</b>		
<i>FRONT</i>		
Suspension type		REV-XP
Suspension maximum travel		229 mm (9 in)
Shock absorber type		Motion control
Spring color		—
Sway bar type		Link
<i>REAR</i>		
Suspension type		SC-5 M
Suspension maximum travel		356 mm (14 in)
Shock absorber type	Center	Motion control
	Rear	Motion control
Spring color	Center	Short: Silver/Red/Red Long: Gold/Blue/White
Stroke limiter standard position		2
<b>STEERING SYSTEM</b>		
Ski type		Pilot 6.9
Toe-out		5 mm (.197 in)
Camber		0°
<b>VEHICLE INFORMATIONS</b>		
Mass (dry)		193 kg (425 lb)
Length		320 cm (126 in)
Width		122 cm (48 in)
Height		126 cm (49.6 in)
Ski stance (carbide to carbide)		114 cm to 118 cm (44.9 in to 46.5 in)
<b>MATERIAL</b>		
Frame		Aluminum
Bottom pan and side panels		Polypropylene
Hood		Surlyn



## Section 08 TECHNICAL SPECIFICATIONS

### Subsection 03 (600 HO E-TEC MODELS)

# 600 HO E-TEC MODELS

MODEL		GSX 600 HO E-TEC		GTX 600 HO E-TEC	
		Limited		LE	
<b>ENGINE</b>					
Engine type		593			
Number of cylinder		2			
Bore		72 mm (2.835 in)			
Stroke		73 mm (2.874 in)			
Displacement		594.4 cm <sup>3</sup> (36.27 in <sup>3</sup> )			
Compression ratio		12.25 ± 0.5			
Maximum power engine speed		8100 ± 100 RPM			
Combustion chamber volume		25.30 ml to 27.60 ml (.86 U.S. oz to .93 U.S. oz)			
3D RAVE spring	Compression spring	Color	Red		
		Wire diameter	0.8 mm (.031 in)		
		Minimum free length	45 mm (1.772 in)		
	Valve springs	Color	Red		
		Wire diameter	0.7 mm (.0276 in)		
		Minimum free length	35 mm (1.378 in)		
Piston ring type		Semi-trapezoidal			
Ring end gap	New	0.4 mm to 0.55 mm (.016 in to .022 in)			
	Wear limit	1 mm (.039 in)			
Ring/piston groove clearance	New	0.05 mm to 0.1 mm (.002 in to .0039 in)			
	Wear limit	0.2 mm (.0079 in)			
Piston/cylinder wall clearance	New	0.13 mm ± 0.022 mm (.0051 in ± .0009 in)			
	Wear limit	0.2 mm (.0079 in)			
Piston skirt wear	Wear limit	0.15 mm (.006 in)			
Cylinder head warpage	Wear limit	0.5 mm (.0197 in)			
Cylinder taper	New (max.)	0.05 mm (.002 in)			
	Wear limit	0.1 mm (.0039 in)			
Cylinder out of round	New (max.)	0.012 mm (.0005 in)			
	Wear limit	0.08 mm (.0031 in)			
Crankshaft end play	New	MIN.: 0.10 mm (.0039 in) MAX.: 0.30 mm (.0118 in)			
	MAX.	MAG: 0.05 mm (.002 in) CENTER: 0.08 mm (.0031 in) PTO: 0.06 mm (.0024 in)			
Connecting rod big end axial play	New	0.28 mm to 0.68 mm (.011 in to .0268 in)			
	Wear limit	1.2 mm (.0472 in)			

**Section 08 TECHNICAL SPECIFICATIONS****Subsection 03 (600 HO E-TEC MODELS)**

MODEL		GSX 600 HO E-TEC	GTX 600 HO E-TEC
		Limited	LE
<b>COOLING SYSTEM</b>			
Coolant	Type	Ethyl glycol and distilled water (50%/50%). Use BRP premix coolant (P/N 219 700 362) or coolant specifically formulated for aluminum engines	
	Quantity	4.5 L (1.19 U.S. gal.)	5.8 L (1.53 U.S. gal.)
Thermostat opening temperature		37°C (99°F)	
Radiator cap opening pressure		90 kPa (13 PSI)	
<b>LUBRICATION SYSTEM</b>			
Oil injection pump type		Electronic oil injection pump	
Injection oil	Type	XP-S synthetic blend 2-stroke oil (P/N 293 600 100)	
	Quantity	3.7 L (125.1 U.S. oz)	
<b>FUEL SYSTEM</b>			
Fuel delivery		E-TEC direct injection	
Throttle body		Dell'Orto 46 mm	
Fuel pump		In-tank electrical fuel pump	
Idle speed (not adjustable)		1200 ± 200 RPM	
Fuel	Type	Premium unleaded gasoline	
	Octane rating	Inside North America ((R+M)/2)	Recommended: 91, Accepted: 87
		Outside North America (RON)	Recommended: 95, Accepted: 92
Fuel tank capacity		40 L (10.6 U.S. gal.)	
<b>ELECTRICAL SYSTEM</b>			
Lightning system output		12 V/360 W 55 V/1100 W	
Ignition type		Inductive	
Spark plug	Make and type	NGK PZFR6F (engine and spark plug threads are indexed)	
	Gap	Not adjustable 0.7 mm to 0.8 mm (.028 in to .031 in)	
Ignition timing BTDC		28° @ 3500 ± 500 RPM 5.39 mm (.212 in)	
Crankshaft position sensor (CPS)		190 to 290 Ω	
Stator		below 1 Ω	
Headlamp		2 x 60/55 W (H4)	
Taillight and stoplight		5/21 W	
Fuses	RER	5 A	
	Fuel level sensor	0.25 A	

**Section 08 TECHNICAL SPECIFICATIONS**  
Subsection 03 (600 HO E-TEC MODELS)

MODEL		GSX 600 HO E-TEC	GTX 600 HO E-TEC
		Limited	LE
<b>DRIVE SYSTEM</b>			
Chaincase oil	Type	XP-S synthetic chaincase oil (P/N 413 803 300)	
	Quantity	250 ml (8.5 U.S. oz)	
Chain drive ratio		25/45	23/45
Chain	Pitch	3/8	
	Type/links qty/plate qty	Silent 104/13	
Drive pulley type		TRA III	
Drive pulley calibration	Clutch engagement	3400 ± 100 RPM	
	Spring color	Blue/Blue	
	Spring length	99.8 mm (4.512 in)	
	Pin	Solid (P/N 417 004 308)	
	Ramp	412	414
	Screw position	3	
Driven pulley type	Type	QRS	
	Spring color	Green	Black
	Spring preload	0	
	Cam angle	48°	42°
Pulley distance	Z	21 mm (.827 in) (not adjustable)	
Offset	X	37.1 mm (1.461 in) (not adjustable)	
Drive belt part number		(P/N 417 300 383)	
Drive belt	Width	38.3 mm (1.508 in)	
	Wear limit	35.9 mm (1.413 in)	
Drive belt adjustment	Deflection	32 mm ± 5 mm (1.26 in ± .197 in)	
	Force	11.3 kgf (24.9 lbf)	
Track	Width	381 mm (15 in)	
	Length	3 m (120.1 in)	3.5 m (137 in)
	Profile height	25.4 mm (1 in)	
Track adjustment	Deflection	30 mm to 35 mm (1.181 in to 1.378 in)	
	Force	7.3 kgf (16.1 lbf)	
<b>BRAKE SYSTEM</b>			
Brake lining minimum thickness		1 mm (.039 in)	
Brake disk minimum thickness		4.5 mm (.177 in)	
Brake fluid	Type	DOT 4	
	Quantity	60 ml (2.03 U.S. oz)	

**Section 08 TECHNICAL SPECIFICATIONS****Subsection 03 (600 HO E-TEC MODELS)**

MODEL	GSX 600 HO E-TEC		GTX 600 HO E-TEC	
	Limited		LE	
<b>SUSPENSION</b>				
<i>FRONT</i>				
Suspension type	REV-XP			
Suspension maximum travel	229 mm (9 in)			
Shock absorber type	H.P.G.			
Spring color	White/Black/Gold		White/Gold/Red	
Stabilizer bar type	Link			
<i>REAR</i>				
Suspension type	SC-5			
Suspension maximum travel	381 mm (15 in)		331 mm (13 in)	
Shock absorber type	Center	H.P.G.		
	Rear	H.P.G.VR		
Spring color	Center	Gold/Red/Red		
Stroke limiter standard position	3			
<b>STEERING SYSTEM</b>				
Ski type	Pilot 5.7		Pilot SL	
Toe-out	5 mm (.197 in)			
Camber	0°			
<b>WEIGHT AND DIMENSIONS</b>				
Mass (dry)	204 kg (450 lb)		242 kg (534 lb)	
Length	289 cm (113.8 in)		323 cm (127.2 in)	
Width	122 cm (48 in)			
Height	100 cm (39.4 in)		133 cm (52.4 in)	
Ski stance (carbide to carbide)	119.5 cm (47 in)			
<b>MATERIAL</b>				
Frame	Aluminum			
Bottom pans, gauge support and side panels	Polypropylene			
Hood and console	Surlyn			

## Section 08 TECHNICAL SPECIFICATIONS

### Subsection 03 (600 HO E-TEC MODELS)

MODEL		MX Z	
		50 <sup>th</sup>	Adrenaline
<b>ENGINE</b>			
Engine type		593	
Number of cylinder		2	
Bore		72 mm (2.835 in)	
Stroke		73 mm (2.874 in)	
Displacement		594.4 cm <sup>3</sup> (36.27 in <sup>3</sup> )	
Compression ratio		12.25 ± 0.5	
Maximum power engine speed		8100 ± 100 RPM	
Combustion chamber volume		25.30 ml to 27.60 ml (.86 U.S. oz to .93 U.S. oz)	
3D RAVE spring	Compression spring	Color	Red
		Wire diameter	0.8 mm (.031 in)
		Minimum free length	45 mm (1.772 in)
	Valve springs	Color	Red
		Wire diameter	0.7 mm (.0276 in)
		Minimum free length	35 mm (1.378 in)
Piston ring type		Semi-trapezoidal	
Ring end gap	New	0.4 mm to 0.55 mm (.016 in to .022 in)	
	Wear limit	1 mm (.039 in)	
Ring/piston groove clearance	New	0.05 mm to 0.1 mm (.002 in to .0039 in)	
	Wear limit	0.2 mm (.0079 in)	
Piston/cylinder wall clearance	New	0.13 mm ± 0.022 mm (.0051 in ± .0009 in)	
	Wear limit	0.2 mm (.0079 in)	
Piston skirt wear	Wear limit	0.15 mm (.006 in)	
Cylinder head warpage	Wear limit	0.5 mm (.0197 in)	
Cylinder taper	New (max.)	0.05 mm (.002 in)	
	Wear limit	0.1 mm (.0039 in)	
Cylinder out of round	New (max.)	0.012 mm (.0005 in)	
	Wear limit	0.08 mm (.0031 in)	
Crankshaft end play	New	MIN.: 0.10 mm (.0039 in) MAX.: 0.30 mm (.0118 in)	
Crankshaft deflection	MAX.	MAG: 0.05 mm (.002 in) CENTER: 0.08 mm (.0031 in) PTO: 0.06 mm (.0024 in)	
Connecting rod big end axial play	New	0.28 mm to 0.68 mm (.011 in to .0268 in)	
	Wear limit	1.2 mm (.0472 in)	

**Section 08 TECHNICAL SPECIFICATIONS**

## Subsection 03 (600 HO E-TEC MODELS)

MODEL		MX Z	
		50 <sup>th</sup>	Adrenaline
<b>COOLING SYSTEM</b>			
Coolant	Type	Ethyl glycol and distilled water (50%/50%). Use BRP premix coolant (P/N 219 700 362) or coolant specifically formulated for aluminum engines	
	Quantity	4.5 L (1.19 U.S. gal.)	
Thermostat opening temperature		37°C (99°F)	
Radiator cap opening pressure		90 kPa (13 PSI)	
<b>LUBRICATION SYSTEM</b>			
Oil injection pump type		Electronic oil injection pump	
Injection oil	Type	XP-S synthetic blend 2-stroke oil (P/N 293 600 100)	
	Quantity	3.7 L (125.1 U.S. oz)	
<b>FUEL SYSTEM</b>			
Fuel delivery		E-TEC direct injection	
Throttle body		Dell'Orto 46 mm	
Fuel pump		In-tank electrical fuel pump	
Idle speed (not adjustable)		1200 ± 200 RPM	
Fuel	Type	Premium unleaded gasoline	
	Octane rating	Inside North America ((R+M)/2)	Recommended: 91, accepted: 87
		Outside North America (RON)	Recommended: 95, accepted: 92
Fuel tank capacity		40 L (10.6 U.S. gal.)	
<b>ELECTRICAL SYSTEM</b>			
Lightning system output		12 V/360 W 55 V/1100 W	
Ignition type		Inductive	
Spark plug	Make and type	NGK PZFR6F (engine and spark plug threads are indexed)	
	Gap	Not adjustable 0.7 mm to 0.8 mm (.028 in to .031 in)	
Ignition timing BTDC		28° @ 3500 ± 500 RPM 5.39 mm (.212 in)	
Crankshaft position sensor (CPS)		190 to 290 Ω	
Stator		below 1 Ω	
Headlamp		2 x 60/55 W (H4)	
Taillight and stoplight		5/21 W	
Fuses	RER	5 A	
	Fuel level sensor	0.25 A	

**Section 08 TECHNICAL SPECIFICATIONS**  
Subsection 03 (600 HO E-TEC MODELS)

MODEL		MX Z	
		50 <sup>th</sup>	Adrenaline
<b>DRIVE SYSTEM</b>			
Chaincase oil	Type	XP-S synthetic chaincase oil (P/N 413 803 300)	
	Quantity	250 ml (8.5 U.S. oz)	
Chain drive ratio		25/45	
Chain	Pitch	3/8	
	Type/links qty/plate qty	Silent 104/13	
Drive pulley type		TRA III	
Drive pulley calibration	Clutch engagement	3400 ± 100 RPM	
	Spring color	Blue/Blue	
	Spring length	99.8 mm (4.512 in)	
	Pin	Solid (P/N 417 004 308)	
	Ramp	412	
Driven pulley type	Screw position	3	
	Type	ORS	
	Spring color	Green	
Pulley distance	Spring preload	0	
	Cam angle	48°	
Offset	Z	21 mm (.827 in) (not adjustable)	
Drive belt part number	X	37.1 mm (1.461 in) (not adjustable)	
Drive belt	(P/N 417 300 383)		
	Width	38.3 mm (1.508 in)	
Drive belt adjustment	Wear limit	35.9 mm (1.413 in)	
	Deflection	32 mm ± 5 mm (1.26 in ± .197 in)	
Track	Force	11.3 kgf (24.9 lbf)	
	Width	381 mm (15 in)	
	Length	3 m (120.1 in)	
Track adjustment	Profile height	31.8 mm (1.25 in)	25.4 mm (1 in)
	Deflection	30 mm to 35 mm (1.181 in to 1.378 in)	
BRAKE SYSTEM	Force	7.3 kgf (16.1 lbf)	
	Brake lining minimum thickness	1 mm (.039 in)	
Brake disk minimum thickness		4.5 mm (.177 in)	
Brake fluid	Type	DOT 4	
	Quantity	65 ml (2.2 U.S. oz)	

**Section 08 TECHNICAL SPECIFICATIONS****Subsection 03 (600 HO E-TEC MODELS)**

MODEL	MX Z	
	50 <sup>th</sup>	Adrenaline
<b>SUSPENSION</b>		
<i>FRONT</i>		
Suspension type	REV-XP	
Suspension maximum travel	229 mm (9 in)	
Shock absorber type	H.P.G. T/A (aluminum)	H.P.G.
Spring color	Silver/Silver/Green EUR: White/Silver/Green	Silver/Gold/Green
Stabilizer bar type	Link	
<i>REAR</i>		
Suspension type	SC-5	
Suspension maximum travel	381 mm (15 in)	
Shock absorber type	H.P.G. T/A (aluminum)	H.P.G.
	H.P.G. T/A	H.P.G.
Spring color	Center	Gold/Red/Red
Stroke limiter standard position	3	
<b>STEERING SYSTEM</b>		
Ski type	Pilot 5.7	
Toe-out	5 mm (.197 in)	
Camber	0°	
<b>WEIGHT AND DIMENSIONS</b>		
Mass (dry)	201 kg (443 lb)	193 kg (425 lb)
Length	289 cm (114 in)	
Width	122 cm (48 in)	
Height	120.3 cm (47.4 in)	
Ski stance (carbide to carbide)	120 cm (47 in)	
<b>MATERIAL</b>		
Frame	Aluminum	
Bottom pans, gauge support and side panels	Polypropylene	
Hood and console	Surlyn	



## Section 08 TECHNICAL SPECIFICATIONS

### Subsection 03 (600 HO E-TEC MODELS)

MODEL		MX Z	
		TNT	X
<b>ENGINE</b>			
Engine type		593	
Number of cylinder		2	
Bore		72 mm (2.835 in)	
Stroke		73 mm (2.874 in)	
Displacement		594.4 cm <sup>3</sup> (36.27 in <sup>3</sup> )	
Compression ratio		12.25 ± 0.5	
Maximum power engine speed		8100 ± 100 RPM	
Combustion chamber volume		25.30 ml to 27.60 ml (.86 U.S. oz to .93 U.S. oz)	
3D RAVE spring	Compression spring	Color	Red
		Wire diameter	0.8 mm (.031 in)
		Minimum free length	45 mm (1.772 in)
	Valve springs	Color	Red
		Wire diameter	0.7 mm (.0276 in)
		Minimum free length	35 mm (1.378 in)
Piston ring type		Semi-trapezoidal	
Ring end gap	New	0.4 mm to 0.55 mm (.016 in to .022 in)	
	Wear limit	1 mm (.039 in)	
Ring/piston groove clearance	New	0.05 mm to 0.1 mm (.002 in to .0039 in)	
	Wear limit	0.2 mm (.0079 in)	
Piston/cylinder wall clearance	New	0.13 mm ± 0.022 mm (.0051 in ± .0009 in)	
	Wear limit	0.2 mm (.0079 in)	
Piston skirt wear	Wear limit	0.15 mm (.006 in)	
Cylinder head warpage	Wear limit	0.5 mm (.0197 in)	
Cylinder taper	New (max.)	0.05 mm (.002 in)	
	Wear limit	0.1 mm (.0039 in)	
Cylinder out of round	New (max.)	0.012 mm (.0005 in)	
	Wear limit	0.08 mm (.0031 in)	
Crankshaft end play	New	MIN.: 0.10 mm (.0039 in) MAX.: 0.30 mm (.0118 in)	
	MAX.	MAG: 0.05 mm (.002 in) CENTER: 0.08 mm (.0031 in) PTO: 0.06 mm (.0024 in)	
Connecting rod big end axial play	New	0.28 mm to 0.68 mm (.011 in to .0268 in)	
	Wear limit	1.2 mm (.0472 in)	
<b>COOLING SYSTEM</b>			
Coolant	Type	Ethyl glycol and distilled water (50%/50%). Use BRP premix coolant (P/N 219 700 362) or coolant specifically formulated for aluminum engines	
	Quantity	4.5 L (1.19 U.S. gal.)	
Thermostat opening temperature		37°C (99°F)	
Radiator cap opening pressure		90 kPa (13 PSI)	

## Section 08 TECHNICAL SPECIFICATIONS

### Subsection 03 (600 HO E-TEC MODELS)

MODEL		MX Z	
		TNT	X
<b>LUBRICATION SYSTEM</b>			
Oil injection pump type		Electronic oil injection pump	
Injection oil	Type	XP-S synthetic blend 2-stroke oil (P/N 293 600 100)	
	Quantity	3.7 L (125.1 U.S. oz)	
<b>FUEL SYSTEM</b>			
Fuel delivery		E-TEC direct injection	
Throttle body		Dell'Orto 46 mm	
Fuel pump		In-tank electrical fuel pump	
Idle speed (not adjustable)		1200 ± 200 RPM	
Fuel	Type	Premium unleaded gasoline	
	Octane rating	Inside North America ((R+M)/2)	Recommended: 91, accepted: 87
		Outside North America (RON)	Recommended: 95, accepted: 92
Fuel tank capacity		40 L (10.6 U.S. gal.)	
<b>ELECTRICAL SYSTEM</b>			
Lightning system output		12 V/360 W 55 V/1100 W	
Ignition type		Inductive	
Spark plug	Make and type	NGK PZFR6F (engine and spark plug threads are indexed)	
	Gap	Not adjustable 0.7 mm to 0.8 mm (.028 in to .031 in)	
Ignition timing BTDC		28° @ 3500 ± 500 RPM 5.39 mm (.212 in)	
Crankshaft position sensor (CPS)		190 to 290 Ω	
Stator		below 1 Ω	
Headlamp		2 x 60/55 W (H4)	
Taillight and stoplight		5/21 W	
Fuses	RER	5 A	
	Fuel level sensor	0.25 A	
<b>DRIVE SYSTEM</b>			
Chaincase oil	Type	XP-S synthetic chaincase oil (P/N 413 803 300)	
	Quantity	250 ml (8.5 U.S. oz)	
Chain drive ratio		25/45	
Chain	Pitch	3/8	
	Type/links qty/plate qty	Silent 104/13	
Drive pulley type		TRA III	

## Section 08 TECHNICAL SPECIFICATIONS

### Subsection 03 (600 HO E-TEC MODELS)

MODEL		MX Z	
		TNT	X
<b>DRIVE SYSTEM (cont'd)</b>			
Drive pulley calibration	Clutch engagement	3400 ± 100 RPM	
	Spring color	Blue/Blue	
	Spring length	99.8 mm (4.512 in)	
	Pin	Solid (P/N 417 004 308)	
	Ramp	412	
	Screw position	3	
Driven pulley type	Type	QRS	
	Spring color	Green	
	Spring preload	0	
	Cam angle	48°	
Pulley distance	Z	21 mm (.827 in) (not adjustable)	
Offset	X	37.1 mm (1.461 in) (not adjustable)	
Drive belt part number		(P/N 417 300 383)	
Drive belt	Width	38.3 mm (1.508 in)	
	Wear limit	35.9 mm (1.413 in)	
Drive belt adjustment	Deflection	32 mm ± 5 mm (1.26 in ± .197 in)	
	Force	11.3 kgf (24.9 lbf)	
Track	Width	381 mm (15 in)	
	Length	3 m (120.1 in)	
	Profile height	25.4 mm (1 in)	31.8 mm (1.25 in)
Track adjustment	Deflection	30 mm to 35 mm (1.181 in to 1.378 in)	
	Force	7.3 kgf (16.1 lbf)	
<b>BRAKE SYSTEM</b>			
Brake lining minimum thickness		1 mm (.039 in)	
Brake disk minimum thickness		4.5 mm (.177 in)	
Brake fluid	Type	DOT 4	
	Quantity	65 ml (2.2 U.S. oz)	
<b>SUSPENSION</b>			
<i>FRONT</i>			
Suspension type		REV-XP	
Suspension maximum travel		229 mm (9 in)	
Shock absorber type		H.P.G. T/A	H.P.G. racing clicker (aluminum)
Spring color		Silver/Silver/Green EUR: White/Silver/Green	
Stabilizer bar type		Link	

**Section 08 TECHNICAL SPECIFICATIONS**

## Subsection 03 (600 HO E-TEC MODELS)

MODEL	MX Z	
	TNT	X
<b>SUSPENSION (cont'd)</b>		
<i>REAR</i>		
Suspension type	SC-5	
Suspension maximum travel	381 mm (15 in)	
Shock absorber type	H.P.G. T/A (aluminum)	
	H.P.G. T/A	H.P.G. racing clicker (aluminum)
Spring color	Center	Gold/Red/Red
Stroke limiter standard position	3	
<b>STEERING SYSTEM</b>		
Ski type	Pilot 5.7	
Toe-out	5 mm (.197 in)	
Camber	0°	
<b>WEIGHT AND DIMENSIONS</b>		
Mass (dry)	188 kg (414 lb)	
Length	289 cm (113.8 in)	
Width	122 cm (48 in)	
Height	113 cm (44.5 in)	111 cm (44 in)
Ski stance (carbide to carbide)	119.5 cm (47 in)	
<b>MATERIAL</b>		
Frame	Aluminum	
Bottom pans, gauge support and side panels	Polypropylene	
Hood and console	Surlyn	

## Section 08 TECHNICAL SPECIFICATIONS

### Subsection 03 (600 HO E-TEC MODELS)

MODEL		MX Z	
		Renegade	Renegade X
<b>ENGINE</b>			
Engine type		593	
Number of cylinder		2	
Bore		72 mm (2.835 in)	
Stroke		73 mm (2.874 in)	
Displacement		594.4 cm <sup>3</sup> (36.27 in <sup>3</sup> )	
Compression ratio		12.25 ± 0.5	
Maximum power engine speed		8100 ± 100 RPM	
Combustion chamber volume		25.30 ml to 27.60 ml (.86 U.S. oz to .93 U.S. oz)	
3D RAVE spring	Compression spring	Color	Red
		Wire diameter	0.8 mm (.031 in)
		Minimum free length	45 mm (1.772 in)
	Valve springs	Color	Red
		Wire diameter	0.7 mm (.0276 in)
		Minimum free length	35 mm (1.378 in)
Piston ring type		Semi-trapezoidal	
Ring end gap	New	0.4 mm to 0.55 mm (.016 in to .022 in)	
	Wear limit	1 mm (.039 in)	
Ring/piston groove clearance	New	0.05 mm to 0.1 mm (.002 in to .0039 in)	
	Wear limit	0.2 mm (.0079 in)	
Piston/cylinder wall clearance	New	0.13 mm ± 0.022 mm (.0051 in ± .0009 in)	
	Wear limit	0.2 mm (.0079 in)	
Piston skirt wear	Wear limit	0.15 mm (.006 in)	
Cylinder head warpage	Wear limit	0.5 mm (.0197 in)	
Cylinder taper	New (max.)	0.05 mm (.002 in)	
	Wear limit	0.1 mm (.0039 in)	
Cylinder out of round	New (max.)	0.012 mm (.0005 in)	
	Wear limit	0.08 mm (.0031 in)	
Crankshaft end play	New	MIN.: 0.10 mm (.0039 in)	
		MAX.: 0.30 mm (.0118 in)	
Crankshaft deflection	MAX.	MAG: 0.05 mm (.002 in)	
		CENTER: 0.08 mm (.0031 in)	
Connecting rod big end axial play	New	0.28 mm to 0.68 mm (.011 in to .0268 in)	
	Wear limit	1.2 mm (.0472 in)	

**Section 08 TECHNICAL SPECIFICATIONS**

## Subsection 03 (600 HO E-TEC MODELS)

MODEL		MX Z	
		Renegade	Renegade X
<b>COOLING SYSTEM</b>			
Coolant	Type	Ethyl glycol and distilled water (50%/50%). Use BRP premix coolant (P/N 219 700 362) or coolant specifically formulated for aluminum engines	
	Quantity	4.5 L (1.19 U.S. gal.)	
Thermostat opening temperature		37°C (99°F)	
Radiator cap opening pressure		90 kPa (13 PSI)	
<b>LUBRICATION SYSTEM</b>			
Oil injection pump type		Electronic oil injection pump	
Injection oil	Type	XP-S synthetic blend 2-stroke oil (P/N 293 600 100)	
	Quantity	3.7 L (125.1 U.S. oz)	
<b>FUEL SYSTEM</b>			
Fuel delivery		E-TEC direct injection	
Throttle body		Dell'Orto 46 mm	
Fuel pump		In-tank electrical fuel pump	
Idle speed (not adjustable)		1200 ± 200 RPM	
Fuel	Type	Premium unleaded gasoline	
	Octane rating	Inside North America ((R+M)/2)	Recommended: 91, accepted: 87
		Outside North America (RON)	Recommended: 95, accepted: 92
Fuel tank capacity		40 L (10.6 U.S. gal.)	
<b>ELECTRICAL SYSTEM</b>			
Lightning system output		12 V/360 W 55 V/1100 W	
Ignition type		Inductive	
Spark plug	Make and type	NGK PZFR6F (engine and spark plug threads are indexed)	
	Gap	Not adjustable 0.7 mm to 0.8 mm (.028 in to .031 in)	
Ignition timing BTDC		28° @ 3500 ± 500 RPM 5.39 mm (.212 in)	
Crankshaft position sensor (CPS)		190 to 290 Ω	
Stator		below 1 Ω	
Headlamp		2 x 60/55 W (H4)	
Taillight and stoplight		5/21 W	
Fuses	RER	5 A	
	Fuel level sensor	0.25 A	

**Section 08 TECHNICAL SPECIFICATIONS**  
Subsection 03 (600 HO E-TEC MODELS)

MODEL		MX Z	
		Renegade	Renegade X
<b>DRIVE SYSTEM</b>			
Chaincase oil	Type	XP-S synthetic chaincase oil (P/N 413 803 300)	
	Quantity	250 ml (8.5 U.S. oz)	
Chain drive ratio		21/45	
Chain	Pitch	3/8	
	Type/links qty/plate qty	Silent 102/13	
Drive pulley type		TRA III	
Drive pulley calibration	Clutch engagement	3400 ± 100 RPM	
	Spring color	Blue/Blue	
	Spring length	99.8 mm (4.512 in)	
	Pin	Solid (P/N 417 004 308)	
	Ramp	412	
	Screw position	3	
Driven pulley type	Type	QRS	
	Spring color	Green	
	Spring preload	0	
	Cam angle	48°	
Pulley distance	Z	21 mm (.827 in) (not adjustable)	
Offset	X	37.1 mm (1.461 in) (not adjustable)	
Drive belt part number		(P/N 417 300 383)	
Drive belt	Width	38.3 mm (1.508 in)	
	Wear limit	35.9 mm (1.413 in)	
Drive belt adjustment	Deflection	32 mm ± 5 mm (1.26 in ± .197 in)	
	Force	11.3 kgf (24.9 lbf)	
Track	Width	381 mm (15 in)	
	Length	3 m (120.1 in)	
	Profile height	31.8 mm (1.25 in)	
Track adjustment	Deflection	30 mm to 35 mm (1.181 in to 1.378 in)	
	Force	7.3 kgf (16.1 lbf)	
<b>BRAKE SYSTEM</b>			
Brake lining minimum thickness		1 mm (.039 in)	
Brake disk minimum thickness		4.5 mm (.177 in)	
Brake fluid	Type	DOT 4	
	Quantity	65 ml (2.2 U.S. oz)	

**Section 08 TECHNICAL SPECIFICATIONS****Subsection 03 (600 HO E-TEC MODELS)**

MODEL	MX Z	
	Renegade	Renegade X
<b>SUSPENSION</b>		
<i>FRONT</i>		
Suspension type	REV-XP	
Suspension maximum travel	229 mm (9 in)	
Shock absorber type	H.P.G.	H.P.G. racing clicker (aluminum)
Spring color	Silver/Gold/Green	Silver/Silver/Green EUR: White/Silver/Green
Stabilizer bar type	Link	
<i>REAR</i>		
Suspension type	SC-5	
Suspension maximum travel	381 mm (15 in)	
Shock absorber type	H.P.G.	H.P.G. T/A (aluminum)
	H.P.G.	H.P.G. racing clicker (aluminum)
Spring color	Center	White/White/Gold
Stroke limiter standard position	3	
<b>STEERING SYSTEM</b>		
Ski type	Pilot 5.7 EUR: Pilot 6.9	Pilot 5.7
Toe-out	5 mm (.197 in)	
Camber	0°	
<b>WEIGHT AND DIMENSIONS</b>		
Mass (dry)	197 kg (414 lb)	194 kg (428 lb)
Length	311 cm (122.4 in) EUR: 318 cm (125 in)	
Width	122 cm (48 in) EUR: 125 cm (49 in)	
Height	121 cm (47.6 in)	
Ski stance (carbide to carbide)	122 cm (48 in)	
<b>MATERIAL</b>		
Frame	Aluminum	
Bottom pans, gauge support and side panels	Polypropylene	
Hood and console	Surlyn	



## Section 08 TECHNICAL SPECIFICATIONS

### Subsection 03 (600 HO E-TEC MODELS)

MODEL		SUMMIT	
		Everest	X
<b>ENGINE</b>			
Engine type		593	
Number of cylinder		2	
Bore		72 mm (2.835 in)	
Stroke		73 mm (2.874 in)	
Displacement		594.4 cm <sup>3</sup> (36.27 in <sup>3</sup> )	
Compression ratio		12.25 ± 0.5	
Maximum power engine speed		8100 ± 100 RPM	
Combustion chamber volume		25.30 ml to 27.60 ml (.86 U.S. oz to .93 U.S. oz)	
3D RAVE spring	Compression spring	Color	Red
		Wire diameter	0.8 mm (.031 in)
		Minimum free length	45 mm (1.772 in)
	Valve springs	Color	Red
		Wire diameter	0.7 mm (.0276 in)
		Minimum free length	35 mm (1.378 in)
Piston ring type		Semi-trapezoidal	
Ring end gap	New	0.4 mm to 0.55 mm (.016 in to .022 in)	
	Wear limit	1 mm (.039 in)	
Ring/piston groove clearance	New	0.05 mm to 0.1 mm (.002 in to .0039 in)	
	Wear limit	0.2 mm (.0079 in)	
Piston/cylinder wall clearance	New	0.13 mm ± 0.022 mm (.0051 in ± .0009 in)	
	Wear limit	0.2 mm (.0079 in)	
Piston skirt wear	Wear limit	0.15 mm (.006 in)	
Cylinder head warpage	Wear limit	0.5 mm (.0197 in)	
Cylinder taper	New (max.)	0.05 mm (.002 in)	
	Wear limit	0.1 mm (.0039 in)	
Cylinder out of round	New (max.)	0.012 mm (.0005 in)	
	Wear limit	0.08 mm (.0031 in)	
Crankshaft end play	New	MIN.: 0.10 mm (.0039 in)	
		MAX.: 0.30 mm (.0118 in)	
Crankshaft deflection	MAX.	MAG: 0.05 mm (.002 in)	
		CENTER: 0.08 mm (.0031 in)	
		PTO: 0.06 mm (.0024 in)	
Connecting rod big end axial play	New	0.28 mm to 0.68 mm (.011 in to .0268 in)	
	Wear limit	1.2 mm (.0472 in)	

**Section 08 TECHNICAL SPECIFICATIONS****Subsection 03 (600 HO E-TEC MODELS)**

MODEL		SUMMIT	
		Everest	X
<b>COOLING SYSTEM</b>			
Coolant	Type	Ethyl glycol and distilled water (50%/50%). Use BRP premix coolant (P/N 219 700 362) or coolant specifically formulated for aluminum engines	
	Quantity	4.7 L (1.24 U.S. gal.)	4.8 L (1.27 U.S. gal.)
Thermostat opening temperature		37°C (99°F)	
Radiator cap opening pressure		90 kPa (13 PSI)	
<b>LUBRICATION SYSTEM</b>			
Oil injection pump type		Electronic oil injection pump	
Injection oil	Type	XP-S synthetic blend 2-stroke oil (P/N 293 600 100)	
	Quantity	3.7 L (125.1 U.S. oz)	
<b>FUEL SYSTEM</b>			
Fuel delivery		E-TEC direct injection	
Throttle body		Dell'Orto 46 mm	
Fuel pump		In-tank electrical fuel pump	
Idle speed (not adjustable)		1200 ± 200 RPM	
Fuel	Type	Premium unleaded	
	Octane rating	Inside North America ((R+M)/2)	Recommended: 91, accepted: 87
		Outside North America (RON)	Recommended: 95, accepted: 92
Fuel tank capacity		40 L (10.6 U.S. gal.)	
<b>ELECTRICAL SYSTEM</b>			
Lightning system output		12 V/360 W 55 V/1100 W	
Ignition type		Inductive	
Spark plug	Make and type	NGK PZFR6F (engine and spark plug threads are indexed)	
	Gap	Not adjustable 0.7 mm to 0.8 mm (.028 in to .031 in)	
Ignition timing BTDC		28° @ 3500 ± 500 RPM	
Crankshaft position sensor (CPS)		5.39 mm (.212 in)	
Stator		190 to 290 Ω	
Headlamp		below 1 Ω	
Taillight and stoplight		2 x 60/55 W (H4)	
Fuses	RER	5/21 W	
	Fuel level sensor	5 A 0.25 A	

## Section 08 TECHNICAL SPECIFICATIONS

### Subsection 03 (600 HO E-TEC MODELS)

MODEL		SUMMIT	
		Everest	X
<b>DRIVE SYSTEM</b>			
Chaincase oil	Type	XP-S synthetic chaincase oil (P/N 413 803 300)	
	Quantity	250 ml (8.5 U.S. oz)	
Chain drive ratio		19/49	
Chain	Pitch	3/8	
	Type/links qty/plate qty	Silent 104/13	
Drive pulley type		TRA III	
Drive pulley calibration	Clutch engagement	4000 ± 100 RPM	
	Spring color	Purple/Green	
	Spring length	157.9 mm (6.217 in)	
	Pin	1 x 417 222 477 + 1 x 206 261 699	
	Ramp	440	
Driven pulley type	Clutch engagement	4000 ± 100 RPM	
	Spring color	Black	
	Spring preload	0	
	Cam angle	41°/45°	
Pulley distance	Z	21 mm (.827 in) (not adjustable)	
Offset	X	37.1 mm (1.461 in) (not adjustable)	
Drive belt part number		(P/N 417 300 383)	
Drive belt	Width	38.3 mm (1.508 in)	
	Wear limit	35.9 mm (1.413 in)	
Drive belt adjustment	Deflection	32 mm ± 5 mm (1.26 in ± .197 in)	
	Force	11.3 kgf (24.9 lbf)	
Track	Width	381 mm (15 in)	
	Length	3 m (120.1 in)	
	Profile height	31.8 mm (1.25 in)	
Track adjustment	Deflection	30 mm to 35 mm (1.181 in to 1.378 in)	
	Force	7.3 kgf (16.1 lbf)	
<b>BRAKE SYSTEM</b>			
Brake lining minimum thickness		1 mm (.039 in)	
Brake disk minimum thickness		4.5 mm (.177 in)	
Brake fluid	Type	DOT 4	
	Quantity	65 ml (2.2 U.S. oz)	

**Section 08 TECHNICAL SPECIFICATIONS****Subsection 03 (600 HO E-TEC MODELS)**

MODEL	SUMMIT	
	Everest	X
<b>SUSPENSION</b>		
<i>FRONT</i>		
Suspension type	REV-XP	
Suspension maximum travel	229 mm (9 in)	
Shock absorber type	H.P.G.	H.P.G. T/A (aluminum)
Spring color	Silver/Silver/White	
Stabilizer bar type	Link	
<i>REAR</i>		
Suspension type	SC-5 M	
Suspension maximum travel	381 mm (15 in)	
Shock absorber type	H.P.G.	H.P.G. T/A (aluminum)
	H.P.G.	H.P.G. T/A (aluminum)
Spring color	Center	Short: Silver/Red/Red Long: Gold/Blue/White
Stroke limiter standard position	3	
<b>STEERING SYSTEM</b>		
Ski type	Pilot 6.9	
Toe-out	5 mm (.197 in)	
Camber	0°	
<b>WEIGHT AND DIMENSIONS</b>		
Mass (dry)	197 kg (414 lb)	191 kg (421 lb)
Length	320 cm (126 in) EUR: 327 cm (129 in)	320 cm (126 in)
Width	120 cm (48 in)	
Height	130 cm (51.2 in)	
Ski stance (carbide to carbide)	114 cm to 118 cm (44.9 in to 46.5 in)	
<b>MATERIAL</b>		
Frame	Aluminum	
Bottom pans, gauge support and side panels	Polypropylene	
Hood and console	Surlyn	

**Section 08 TECHNICAL SPECIFICATIONS**  
Subsection 04 (800R MODELS)

# 800R MODELS

MODEL		MX Z 800R POWER TEK			
		Adrenaline	X	Renegade	Renegade X
<b>ENGINE</b>					
Engine type		797			
Number of cylinders		2			
Bore		82 mm (3.228 in)			
Stroke		75.7 mm (2.98 in)			
Displacement		799.5 cm <sup>3</sup> (48.79 in <sup>3</sup> )			
Compression ratio		12.2 ± 0.5			
Maximum power engine speed		8150 ± 100 RPM			
Combustion chamber volume		34.08 ml to 37.26 ml (1.15 U.S. oz to 1.26 U.S. oz)			
RAVE spring	Color	Red			
	Wire diameter	0.8 mm (.031 in)			
	Minimum free length	45 mm (1.772 in)			
Piston ring type		Semi-trapezoidal			
Ring end gap	New	0.4 mm to 0.6 mm (.0157 in to .0236 in)			
	Wear limit	1 mm (.039 in)			
Ring/piston groove clearance	New	0.06 mm to 0.1 mm (.0024 in to .0039 in)			
	Wear limit	0.2 mm (.0079 in)			
Piston/cylinder wall clearance	New	0.108 mm to 0.148 mm (.0043 in to .0058 in)			
	Wear limit	0.2 mm (.0079 in)			
Piston skirt wear	Wear limit	0.15 mm (.0059 in)			
Cylinder head warpage	Wear limit	0.5 mm (.0197 in)			
Cylinder taper	New (max.)	0.05 mm (.002 in)			
	Wear limit	0.1 mm (.0039 in)			
Cylinder out of round	New (max.)	0.01 mm (.0004 in)			
	Wear limit	0.08 mm (.0031 in)			
Crankshaft end play	New	MIN.: 0.10 mm (.0039 in)			
		MAX.: 0.30 mm (.0118 in)			
Crankshaft deflection	MAX.	MAG: 0.05 mm (.002 in)			
		CENTER: 0.04 mm (.0016 in)			
		PTO: 0.06 mm (.0024 in)			
Connecting rod big end axial play	New	0.23 mm to 0.62 mm (.0091 in to .0244 in)			
	Wear limit	1.2 mm (.0472 in)			
<b>COOLING SYSTEM</b>					
Coolant	Type	Ethyl glycol and distilled water (50%/50%). Use BRP premix coolant (P/N 219 700 362) or coolant specifically formulated for aluminum engines			
	Quantity	4.5 L (1.19 U.S. gal.)		6.3 L (1.66 U.S. gal.)	
Thermostat opening temperature		37°C (99°F)			
Radiator cap opening pressure		90 kPa (13 PSI)			

## Section 08 TECHNICAL SPECIFICATIONS

### Subsection 04 (800R MODELS)

MODEL		MX Z 800R POWER TEK			
		Adrenaline	X	Renegade	Renegade X
<b>LUBRICATION SYSTEM</b>					
Injection oil	Type	XP-S synthetic blend 2-stroke oil (P/N 293 600 100)			
	Quantity	3.7 L (125.1 U.S. oz)			
<b>FUEL SYSTEM</b>					
Carburetor type		TM40			
Main jet		480			
Needle jet		P-0M			
Pilot jet		17.5			
Jet needle identification		9EG104 - 58			
Clip position number		Not adjustable			
Slide cut-away		2.0			
Idle throttle slide height		1.6 mm $\pm$ 0.1 mm (.063 in $\pm$ .004 in)			
Float adjustment		Not adjustable			
Air or pilot screw adjustment		1.5 $\pm$ 1/16 turn			
Idle speed		1600 $\pm$ 200 RPM			
Fuel type		Premium unleaded gasoline			
Fuel octane rating	Inside North America ((R+M)/2)	91 or higher			
	Outside North America (RON)	95 or higher			
Fuel tank capacity		40 L (10.6 U.S. gal.)			
Gas/oil ratio		Injection			
<b>ELECTRICAL SYSTEM</b>					
Magneto generator output		360 W @ 6000 RPM			
Ignition type		C.D.I.			
Spark plug	Make and type	NGK BR9ECS			
	Gap	Not adjustable 0.7 mm to 0.8 mm (.028 in to .031 in)			
Ignition timing BTDC		2.37 mm (.093 in) @ 3500 RPM			
Trigger coil		190 to 300 $\Omega$			
Lighting coil		0.1 to 1.0 $\Omega$			
High tension coil	Primary	0.3 to 0.7 $\Omega$			
	Secondary	18 to 26 K $\Omega$ (with caps)			
Battery		12 V, 18 A•h (with electric starter) 12 V, 3 A•h (without electric starter)			
Headlamp		2 x 60/55 W (H4)			
Taillight and stoplight		5/21 W			
Fuse	Main	30 A (with electric starter)			
	ECM	5 A (with electric starter)			
	Headlamp	15 A			
	Accessories	20 A			
	Fuel level sensor	0.25 A (if applicable)			

**Section 08 TECHNICAL SPECIFICATIONS**  
Subsection 04 (800R MODELS)

MODEL		MX Z 800R POWER TEK			
		Adrenaline	X	Renegade	Renegade X
<b>DRIVE SYSTEM</b>					
Chaincase oil	Type	XP-S synthetic chaincase oil (P/N 413 803 300)			
	Quantity	250 ml (8.5 U.S. oz)			
Chain drive ratio		27/45		25/45 EUR: 23/45	
Chain	Pitch	3/8			
	Type/links qty/plate qty	Silent 106/13		Silent 104/13	
Drive pulley type		TRA VII			
Drive pulley calibration	Clutch engagement	3800 ± 100 RPM			
	Spring color	Purple/Blue			
	Spring length	114.6 mm (4.512 in)			
	Pin	Solid (P/N 417 222 594)			
	Ramp	414		413	
	Screw position	3			
Driven pulley type	Type	QRS			
	Spring color	Green			
	Spring preload	0			
	Cam angle	47°/44°		44°/42°	
Pulley distance	Z	Not adjustable 21 mm (.827 in)			
Offset	X	Not adjustable 37.1 mm ± 0.5 mm (1.461 in ± .02 in)			
Drive belt part number		(P/N 417 300 383)			
Drive belt	Width	38.3 mm (1.508 in)			
	Wear limit	35.9 mm (1.413 in)			
Drive belt adjustment	Deflection	32 mm ± 5 mm (1.26 in ± .197 in)			
	Force	11.3 kgf (24.9 lbf)			
Track	Width	381 mm (15 in)		406.4 mm (16 in)	
	Length	305 cm (120 in)		349 cm (137 in)	
	Profile height	24.5 mm (1 in)	31.8 mm (1.25 in)	44.5 mm (1.75 in)	31.8 mm (1.25 in) EUR: 44.5 mm (1.75 in)
Track adjustment	Deflection	30 mm to 35 mm (1.181 in to 1.378 in)			
	Force	7.3 kgf (16.1 lbf)			
<b>BRAKE SYSTEM</b>					
Brake lining minimum thickness		1 mm (.039 in)			
Brake disk minimum thickness		4.5 mm (.177 in)			
Brake fluid	Type	DOT 4			
	Quantity	65 ml (2.2 U.S. oz)			

## Section 08 TECHNICAL SPECIFICATIONS

### Subsection 04 (800R MODELS)

MODEL	MX Z 800R POWER TEK				
	Adrenaline	X	Renegade	Renegade X	
<b>SUSPENSION</b>					
<i>FRONT</i>					
Suspension type	REV-XP				
Suspension maximum travel	229 mm (9 in)				
Shock absorber type	H.P.G.	H.P.G. clicker T/A (aluminum)	H.P.G.	H.P.G. clicker T/A (aluminum)	
Spring color	Silver/Gold/Green	Silver/Silver/Green EUR: White/Silver/Green	Silver/Gold/Green	Silver/Silver/Green EUR: White/Silver/Green	
Sway bar type	Link				
<i>REAR</i>					
Suspension type	SC-5				
Suspension maximum travel	381 mm (15 in)		331 mm (13 in)		
Shock absorber type	Center	H.P.G.	H.P.G. T/A (aluminum)	H.P.G.	H.P.G. T/A (aluminum)
	Rear	H.P.G.	H.P.G. racing clicker (aluminum)	H.P.G.	H.P.G. racing clicker (aluminum)
Spring color	Center	Gold/Red/Red		White/White/Gold	
Stroke limiter standard position	3				
<b>STEERING SYSTEM</b>					
Ski type	Pilot 5.7				
Toe-out	5 mm (.197 in)				
Camber	0°				
<b>WEIGHT AND DIMENSIONS</b>					
Mass (dry)	197 kg (434 lb)	193 kg (425 lb)	202 kg (445 lb)	198 kg (437 lb)	
Length	289 cm (113.8 in)		311 cm (122.4 in)	311 cm (122.4 in) EUR: 318 cm (125.2 in)	
Width	122 cm (48 in)			122 cm (48 in) EUR: 125 cm (49 in)	
Height	120 cm (47.2 in)	111 cm (43.7 in)	121 cm (47.6 in)		
Ski stance (carbide to carbide)	119.5 cm (47 in)				
<b>MATERIAL</b>					
Frame	Aluminum				
Bottom pan and side panels	Polypropylene				
Hood	Surlyn				



## Section 08 TECHNICAL SPECIFICATIONS

### Subsection 04 (800R MODELS)

MODEL		SUMMIT 800R POWER TEK			
		50 <sup>th</sup>	Everest	HillClimb	X
<b>ENGINE</b>					
Engine type		797			
Number of cylinders		2			
Bore		82 mm (3.228 in)			
Stroke		75.7 mm (2.98 in)			
Displacement		799.5 cm <sup>3</sup> (48.79 in <sup>3</sup> )			
Compression ratio		12.2 ± 0.5			
Maximum power engine speed		8150 ± 100 RPM			
Combustion chamber volume		34.08 ml to 37.26 ml (1.15 U.S. oz to 1.26 U.S. oz)			
RAVE spring	Color	Red			
	Wire diameter	0.8 mm (.031 in)			
	Minimum free length	45 mm (1.772 in)			
Piston ring type		Semi-trapezoidal			
Ring end gap	New	0.4 mm to 0.6 mm (.0157 in to .0236 in)			
	Wear limit	1 mm (.039 in)			
Ring/piston groove clearance	New	0.06 mm to 0.1 mm (.0024 in to .0039 in)			
	Wear limit	0.2 mm (.0079 in)			
Piston/cylinder wall clearance	New	0.108 mm to 0.148 mm (.0043 in to .0058 in)			
	Wear limit	0.2 mm (.0079 in)			
Piston skirt wear	Wear limit	0.15 mm (.0059 in)			
Cylinder head warpage	Wear limit	0.5 mm (.0197 in)			
Cylinder taper	New (max.)	0.05 mm (.002 in)			
	Wear limit	0.1 mm (.0039 in)			
Cylinder out of round	New (max.)	0.01 mm (.0004 in)			
	Wear limit	0.08 mm (.0031 in)			
Crankshaft end play	New	MIN.: 0.10 mm (.0039 in) MAX.: 0.30 mm (.0118 in)			
Crankshaft deflection	MAX.	MAG: 0.05 mm (.002 in) CENTER: 0.04 mm (.0016 in) PTO: 0.06 mm (.0024 in)			
Connecting rod big end axial play	New	0.23 mm to 0.62 mm (.0091 in to .0244 in)			
	Wear limit	1.2 mm (.0472 in)			
<b>COOLING SYSTEM</b>					
Coolant	Type	Ethyl glycol and distilled water (50%/50%). Use BRP premix coolant (P/N 219 700 362) or coolant specifically formulated for aluminum engines			
	Quantity	146" track: 4.7 L (158.9 U.S. oz) 154" track: 4.8 L (162.3 U.S. oz) 163" track: 4.9 L (165.7 U.S. oz)			
Thermostat opening temperature		37°C (99°F)			
Radiator cap opening pressure		90 kPa (13 PSI)			
<b>LUBRICATION SYSTEM</b>					
Injection oil	Type	XP-S synthetic blend 2-stroke oil (P/N 293 600 100)			
	Quantity	3.7 L (125.1 U.S. oz)			

## Section 08 TECHNICAL SPECIFICATIONS

### Subsection 04 (800R MODELS)

MODEL		SUMMIT 800R POWER TEK			
		50 <sup>th</sup>	Everest	HillClimb	X
<b>FUEL SYSTEM</b>					
Carburetor type		TM40			
Main jet		480			
Needle jet		P-0M			
Pilot jet		17.5			
Jet needle identification		9EG104 – 58			
Clip position number		Not adjustable			
Slide cut-away		2.0			
Idle throttle slide height		2 mm ± 0.1 mm (.079 in ± .004 in)			
Float adjustment		Not adjustable			
Air or pilot screw adjustment		1.5 ± 1/16 turn			
Idle speed		1900 ± 200 RPM			
Fuel type		Premium unleaded gasoline			
Fuel octane rating	Inside North America ((R+M)/2)	91 or higher			
	Outside North America (RON)	95 or higher			
Fuel tank capacity		40 L (10.6 U.S. gal.)			
Gas/oil ratio		Injection			
<b>ELECTRICAL SYSTEM</b>					
Magneto generator output		360 W @ 6000 RPM			
Ignition type		C.D.I.			
Spark plug	Make and type	NGK BR9ECS			
	Gap	Not adjustable 0.70 to 0.80 (.028 to .032)			
Ignition timing BTDC		2.37 mm (.093 in) @ 3500 RPM			
Trigger coil		190 to 300 Ω			
Lighting coil		0.1 to 1.0 Ω			
High tension coil	Primary	0.3 to 0.7 Ω			
	Secondary	18 to 26 KΩ (with caps)			
Battery		12 V, 18 A•h (with electric starter) 12 V, 3 A•h (without electric starter)			
Headlamp		2 x 60/55 W (H4)			
Taillight and stoplight		5/21 W			
Fuse	Main	30 A (with electric starter)			
	ECM	5 A (with electric starter)			
	Headlamp	15 A			
	Accessories	15 A			
	Fuel level sensor	0.25 A (if applicable)			
<b>DRIVE SYSTEM</b>					
Chaincase oil	Type	XP-S synthetic chaincase oil (P/N 413 803 300)			
	Quantity	250 ml (8.5 U.S. oz)			
Chain drive ratio		146" and 154" tracks: 21/45 163" track: 21/49			

**Section 08 TECHNICAL SPECIFICATIONS**  
Subsection 04 (800R MODELS)

MODEL		SUMMIT 800R POWER TEK			
		50 <sup>th</sup>	Everest	HillClimb	X
<b>DRIVE SYSTEM (cont'd)</b>					
Chain	Pitch	3/8			
	Type/links qty/plate qty	Silent 102/13			
Drive pulley type		TRA VII			
Drive pulley calibration	Clutch engagement	3800 ± 100 RPM			
	Spring color	Green/Purple SUMMIT X 154" (EUR): Purple/Blue			
	Wire diameter/spring length	5.72 mm (.225 in)/126.7 mm (4.988 in) 5.54 mm (.218 in)/133.7 mm (5.264 in) SUMMIT X 154" (EUR): 5.385 mm (.212 in)/114.6 mm (4.512 in)			
	Pin type	Hollow/threaded SUMMIT X 154" (EUR): Solid			
	Pin number	1 x 417 222 595 + 1 x 206 261 299 SUMMIT X 154" (EUR): 417 222 594			
	Ramp	441 SUMMIT X 154" (EUR): 413			
	Screw position	1 SUMMIT X 154" (EUR): 3			
Driven pulley type	Type	QRS			
	Spring color	Purple			
	Spring preload	0			
	Cam angle	43°/47° SUMMIT X 154" (EUR): 44°/42°			
Pulley distance	Z	Not adjustable 20.9 mm (.823 in)			
Offset	X	Not adjustable 36.4 mm (1.433 in)			
Drive belt part number		(P/N 417 300 377)			
Drive belt	Width	36.8 mm (1.449 in)			
	Wear limit	34.4 mm (1.354 in)			
Drive belt adjustment	Deflection	32 mm ± 5 mm (1.26 in ± .197 in)			
	Force	11.3 kgf (24.9 lbf)			
Track	Width	406.4 mm (16 in)			
	Length	392 cm (154 in)	146" track: 370 cm (146 in) 154" track: 392 cm (154 in) 163" track: 414 cm (163 in)	392 cm (154 in)	146" track: 370 cm (146 in) 154" track: 392 cm (154 in) 163" track: 414 cm (163 in)
	Profile height	57.2 mm (2.25 in) 163" track: 58.7 mm (2.31 in)			
Track adjustment	Deflection	30 mm to 35 mm (1.181 in to 1.378 in)			
	Force	7.3 kgf (16.1 lbf)			

## Section 08 TECHNICAL SPECIFICATIONS

### Subsection 04 (800R MODELS)

MODEL		SUMMIT 800R POWER TEK			
		50 <sup>th</sup>	Everest	HillClimb	X
<b>BRAKE SYSTEM</b>					
Brake lining minimum thickness		1 mm (.039 in)			
Brake disk minimum thickness		4.5 mm (.177 in)			
Brake fluid	Type	DOT 4			
	Quantity	65 ml (2.2 U.S. oz)			
<b>SUSPENSION</b>					
<i>FRONT</i>					
Suspension type		REV-XP			
Suspension maximum travel		229 mm (9 in)			
Shock absorber type		H.P.G. T/A (aluminum)	H.P.G.	H.P.G. racing clicker (aluminum)	H.P.G. T/A (aluminum)
Spring color		Silver/Silver/White		Silver/Silver/Green	—
Sway bar type		Link			
<i>REAR</i>					
Suspension type		SC-5M			
Suspension maximum travel		381 mm (15 in)	<b>146" track:</b> 356 mm (14 in) <b>154" track:</b> 381 mm (15 in) <b>163" track:</b> 406 mm (16 in)	381 mm (15 in)	<b>146" track:</b> 356 mm (14 in) <b>154" track:</b> 381 mm (15 in) <b>163" track:</b> 406 mm (16 in)
Shock absorber type	Center	H.P.G. T/A (aluminum)	H.P.G.	H.P.G. T/A (aluminum)	H.P.G. T/A (aluminum)
	Rear	H.P.G. T/A (aluminum)	H.P.G.	H.P.G. racing clicker (aluminum)	H.P.G. T/A (aluminum)
Spring color		Center: <b>Short:</b> Silver/Red/Red, <b>long:</b> Gold/Blue/White			
Stroke limiter standard position		2			
<b>STEERING SYSTEM</b>					
Ski type		Pilot 6.9			
Toe-out		5 mm (.197 in)			
Camber		0°			
<b>WEIGHT AND DIMENSIONS</b>					
Mass (dry)		196 kg (432 lb)	<b>146" track:</b> 198 kg (437 lb) <b>154" track:</b> 200 kg (441 lb) <b>163" track:</b> 201 kg (443 lb)	196 kg (432 lb)	<b>146" track:</b> 193 kg (425 lb) <b>154" track:</b> 195 kg (430 lb) <b>163" track:</b> 197 kg (434 lb)
Length		<b>146" track:</b> 320 cm (126 in) <b>154" track:</b> 331 cm (130.3 in) <b>163" track:</b> 342 cm (134.6 in)			
Width		120 cm (47.2 in)			
Height		130 cm (51.2 in) HillClimb: 100 cm (39.4 in)			
Ski stance (carbide to carbide)		108 cm (42.5 in)			

---

**Section 08 TECHNICAL SPECIFICATIONS**Subsection 04 (800R MODELS)

---

MODEL	SUMMIT 800R POWER TEK			
	50 <sup>th</sup>	Everest	HillClimb	X
<b>MATERIAL</b>				
Frame	Aluminum			
Bottom pan and side panels	Polypropylene			
Hood	Surlyn			

# WIRING DIAGRAM INFORMATION

## SERVICE TOOLS

Description	Part Number	Page
CONNECTOR CRIMPING TOOL.....	529 035 909 .....	630
CRIMP PLIERS.....	529 035 730 .....	633
CRIMPER DIE.....	529 035 906 .....	630

## SERVICE TOOLS – OTHER SUPPLIER

Description	Part Number	Page
AMP EXTRACTION TERMINAL TOOL.....	755430-2 .....	631
AMP EXTRACTION TERMINAL TOOL.....	726503-1 .....	632
	755430-2 .....	629–630
SNAP-ON SCREWDRIVER.....	TT600-5 .....	627

## SERVICE PRODUCTS

Description	Part Number	Page
DIELECTRIC GREASE.....	293 550 004 .....	629


## GENERAL

### WIRING DIAGRAM LOCATION

Wiring diagrams are in the manual back cover pocket.


### WIRING DIAGRAM CODES

The wiring diagrams use the following codes.



1. Wire colors
2. Connector location
3. Connector code
4. Terminal position in connector

### Wire Colors



The first color of a wire is the main color, second color is the stripe.

Example: YL/BK is a YELLOW wire with a BLACK stripe.


COLOR CODE					
BE	—	BEIGE	OR	—	ORANGE
BK	—	BLACK	RD	—	RED
BU	—	BLUE	VI	—	VIOLET
BR	—	BROWN	WH	—	WHITE
GN	—	GREEN	YL	—	YELLOW
GY	—	GRAY			

## Section 09 WIRING DIAGRAM


### Subsection 01 (WIRING DIAGRAM INFORMATION)

#### Connector Location

The first digit of the connector identification number presents the location of the connector on the vehicle. It may also describe the part removal that is required to reach the connector.




The location of the connectors are shown on the wiring diagram with a vehicle schematic as shown below.



VEHICLE SCHEMATIC FOR CONNECTOR LOCATION  
(SEE WIRING DIAGRAM)

#### Connector Code


The next letters (up to 8 letters) of the connector identification number represents a connector reference. If there are many connectors in the same area this helps identify which wire is in which connector.



#### Terminal Position in Connector

The third portion of the connector identification number represents the location of the terminal in the connector. This could be identified by either a number or by a letter depending on the type of connector used.

**NOTE:** The terminal position identification may be also at the right most position of the description.



#### SUMITOMO CONNECTOR INFORMATION


##### Disconnecting the Connector

To disconnect the Sumitomo TPS connector from carburetor or throttle body, press the release button on the other side of the connector.



TPS CONNECTOR

1. Release button



TPS CONNECTOR (UNPLUGGED)

1. Release button

**DEUTSCH CONNECTOR INFORMATION**

**Connector Disassembly**


**Male Housing**

Insert SNAP-ON SCREWDRIVER (P/N TT600-5) under lock and twist to lift it.



A01E31A

Pry tab to free connector then pull wire out of housing.




A01E32A

**FEMALE CONNECTOR HOUSING — CUT-AWAY**


**Female Housing**

Using a small hook, pull out the lock.



A01E33A


1. Lock



A01E34A

1. Lock

Pry tab to free connector then pull wire out of housing.



A01E35A


**FEMALE HOUSING — CUT-AWAY**

**PACKARD CONNECTOR INFORMATION**

**Connector Disassembly**

*Multifunction Gauge and ECM (500SS/600/800R)*

Push on both tabs to remove retainer.



A33Z01A

**TYPICAL**


- 1. Retainer
- 2. Tab (one on each side)

Open housing by lifting 4 tabs.




## Section 09 WIRING DIAGRAM

### Subsection 01 (WIRING DIAGRAM INFORMATION)



**TYPICAL**  
1. Tabs (2 on each side)

Lift the top plastic lock of the female terminal to be removed and hold in position. Lift the female terminal to unlock from the housing and push out of housing.




1. Lift and hold plastic lock  
2. Lift to unlock and push out

### Connector Corrosion Protection

*ECM Only (500SS/600/800R)*


Cut the tie rap over the ECM connector.



Open the 3 tabs to open the connector.



Remove at least 2 blue plug pins of the connector (keep them).



Unplug the connector from the ECM.

**Section 09 WIRING DIAGRAM**  
Subsection 01 (WIRING DIAGRAM INFORMATION)

**NOTE:** Any corrosion should be carefully cleaned with a soft brass brush.

Fill the ECM socket with a generous quantity of DIELECTRIC GREASE (P/N 293 550 004).



**SLOWLY** reinstall the connector and make sure some grease come out by both holes previously opened (blue pin).



Reinstall both blue pins.  
Close the connector.




Reinstall a new tie rap on ECM connector.

## AMP MULTILOCK CONNECTOR INFORMATION

### Connector Disassembly


#### Male Housing



Insert AMP EXTRACTION TERMINAL TOOL (P/N 755430-2) under lock and twist to lift it.

## Section 09 WIRING DIAGRAM

### Subsection 01 (WIRING DIAGRAM INFORMATION)



**MALE HOUSING — CUT-AWAY**  
1. Lock

Female terminals can be removed from housing with sharp head pin.

#### Female Housing




Insert AMP EXTRACTION TERMINAL TOOL (P/N 755430-2) under lock and twist to lift it.



**FEMALE HOUSING — CUT-AWAY**  
1. Lock

#### Terminal Crimping


To crimp a new connector terminal, use the CONNECTOR CRIMPING TOOL (P/N 529 035 909) and the CRIMPER DIE (P/N 529 035 906).



**CRIMPING TOOL**

To properly crimp the wires, strictly follow this procedure.

Strip the wire to a maximum of 3 mm (1/8 in).




**TYPICAL**

A. 3 mm (1/8 in) max.


Position wire in terminal.

Squeeze the terminal tabs with your fingers to temporarily retain terminal in place.



A32E3YA

Insert terminal with wire in crimping pliers and position so that top of terminal tabs are flush with pliers edge or a little bit lower as shown.




1. Top of terminal tabs
2. Align tabs with pliers edge

Crimp terminal. Ensure no tiny wire goes out of terminal. This might cause strange problems of the electrical system.

## AMP CONNECTOR (8-CIRCUIT) INFORMATION

### Connector Disassembly

Pry housing to release lock.



A33Z04A

1. Lock

Insert AMP EXTRACTION TERMINAL TOOL (P/N 755430-2) under tab and pry it to free connector. Pull on the female terminal wire to remove female terminal from housing.



A33Z05A

AMP 8-CIRCUIT CONNECTOR — CUT-AWAY


1. Tab

### Terminal Crimping

Refer to AMP MULTILOCK CONNECTOR INFORMATION for procedure.

## AMP CONNECTOR INFORMATION (ECM OF 600 HO E-TEC)

### Connector Identification



1. J1A connector
2. J1B connector
3. J2 connector

## Section 09 WIRING DIAGRAM

### Subsection 01 (WIRING DIAGRAM INFORMATION)

#### Disconnecting the Connectors

##### *J1A and J1B Connectors*

Depress both latches and pull connector housing.




mmr2009-042-002\_a

1. Latches

##### *J2 Connector*


Using a small screwdriver, open the connector clip.



mmr2009-042-003\_a

1. Connector clip  
2. Connector clip

Pull the clip completely to remove the connector.




mmr2009-042-004\_a

Step 1: Pull clip completely  
Step 2: Lift the connector

#### Connector Disassembly

##### *J1A and J1B Connectors*

Push the lock mechanism to open it.




mmr2009-042-007\_a

1. Lock mechanism

Pull on wire to extract terminal from connector housing.


##### *J2 Connector*

Using the AMP EXTRACTION TERMINAL TOOL (P/N 726503-1), release both locking tabs of connector. Pull terminal from housing.



mmr2009-042-009

AMP EXTRACTION TERMINAL TOOL



mmr2009-042-006\_a


1. Locking tabs

#### Connector Assembly

##### *J1A and J1B Connectors*


Push terminal through seal until it is seated in connector housing.

Close the lock mechanism.



1. Insert terminal into housing
2. Push here to close the lock mechanism


**NOTE:** If the lock mechanism does engage it is likely due to an improperly inserted terminal. Look at the end of connector to see if a terminal is partially out. If, so push it fully into connector then lock mechanism.



A. 10 mm (1/2 in)

**NOTE:** Make sure not to cut wire strands while stripping the wire.

Install the appropriate terminal on the wire according to the requirement. Refer to appropriate *PARTS CATALOG*.



1. Terminal fully inserted in connector


### J2 Connector

Align terminal with connector housing and push terminal with seal into connector housing until seated.

## BATTERY CABLE TERMINAL INFORMATION

### Terminal Installation

Carefully strip the wire approximately to 10 mm (1/2 in) in length, using a wire stripping tool or sharp blade/knife.



### INSTALLATION OF TERMINAL


Follow the instructions provided with the CRIMP PLIERS (P/N 529 035 730) to select the proper position of the tool.



**NOTE:** Different wires require different crimp pliers settings, so make sure to follow the instruction supplied with the tool.

## Section 09 WIRING DIAGRAM


### Subsection 01 (WIRING DIAGRAM INFORMATION)



#### POSITIONING THE CRIMP PLIERS

Step 1: Press  
Step 2: Rotate

After positioning the crimp pliers, crimp the terminal already installed on wire.



#### CRIMPING OF WIRE



#### PROPERLY CRIMPED WIRE

To verify, if the wire is properly crimped, apply some pulling force on wire and the terminal at the same time from both directions.

**NOTICE** Never solder the wire to the terminal. Soldering can change the property of the wire and it can become brittle and break.

Install the protective heat shrink rubber tube on the terminal. Heat the heat shrink rubber tube using the heat gun so that it grasps the wire and the terminal.

**NOTICE** Make sure that the protective heat shrink rubber tube has been properly installed and no part of wire is exposed.

# 2009 REV-XP 800R

F



E

D

COLOR CODE	
BE	BEIGE
BK	BLACK
BR	BROWN
BU	BLUE
GN	GREEN
GY	GRAY
OR	ORANGE
PK	PINK
RD	RED
VI	VIOLET
YL	YELLOW
LT	LIGHT COLOR
SP	SPLICE


## STEER

S-HG1:








COLOR CODE	
BE	BEIGE
BK	BLACK
BR	BROWN
BU	BLUE
GN	GREEN
GY	GRAY
OR	ORANGE
PK	PINK
RD	RED
VI	VIOLET
YL	YELLOW
LT	LIGHT COLOR
SP	SPLICE




STEERING HARNESS FOR STANDARD GAUGE








CONNECTOR LOCATION	
1	ENGINE RELATED CONNECTORS
2	LH SIDE PANEL
3	RH SIDE PANEL
4	HANDLEBAR AREA
5	BEHIND MULTI-FUNCTION GAUGE
6	REAR PART OF FRAME

STEERING HARNESS



STEERING HARNESS FOR PREMIUM GAUGE






SP RD/YL 2


5-HG

ELECTRIC START ONLY


C




B





A





mnr2009-094-006











C


B

A


# 2009 REV-XP/XR 600 HO E-TEC

F


## ELECTRIC START MODEL




E




## MANUAL START MODEL




D





## FUEL PUMP




RD/OR






## CONNECTOR LOCATION

1	ENGINE RELATED CONNECTOR
2	LH SIDE PANEL
3	RH SIDE PANEL
4	HANDLEBAR AREA
5	BEHIND MULTI-FUNCTION GAUGE
6	REAR PART OF FRAME




COLOR CODE	
BE	BEIGE
BK	BLACK
BR	BROWN
BU	BLUE
GN	GREEN
GY	GRAY
OR	ORANGE
PK	PINK
RD	RED
VI	VIOLET
YL	YELLOW
LT	LIGHT COLOR
SP	SPLICE




C

B


A




MAGNETO WIRE COLOR		
POS	REV 1	REV 2
1	BK	YL/WH
2	YL/BK	OR/WH
3	BR	BR/WH
4	WH	BR
5	YL	OR
6	BK/YL	YL










VRT/RER  
IP UP  
IP DOWN  
VER UP  
VER DOWN  
DE




# 2009 REV-XP/XR 600 HO E-TE


F

## PASSENGER SEAT HARNESS


E



D




## HO E-TEC



CONNECTOR LOCATION	
1	ENGINE
2	LH SIDE
3	RH SIDE
4	HANDLEBAR
5	BEHIND M
6	REAR PAIR

## WIRING HARNESS



CONNECTOR LOCATION

1 ENGINE RELATED CONNECTORS


2 LH SIDE PANEL

3 RH SIDE PANEL


4 HANDLEBAR AREA

5 BEHIND MULTI-FUNCTION GAUGE


6 REAR PART OF FRAME




5-HG2



# PREMIUM STEERING HARNESS





HEATING GRIP, LEVER AND MODE/SET SWITCH



C



ACC

B


FROM MAIN HARNESS


A

mmr2009-094-008




# ACCESSORIES OUTLET HARNESS







5-HG1



5-AC1



ENGINE STOP SWITCH





5-GD1

OUTLET

ET

# STANDARD STEERING HARNESS








# 2009 REV-XP 500SS/600

E




D





FUSES




CONNECTOR LOCATION	
1	ENGINE RELATED CONNECTORS
2	LH SIDE PANEL
3	RH SIDE PANEL
4	HANDLEBAR AREA
5	BEHIND MULTI-FUNCTION GAUGE
6	REAR PART OF FRAME

COLOR CODE	
BE	BEIGE
BK	BLACK
BR	BROWN
BU	BLUE
GN	GREEN
GY	GRAY
OR	ORANGE
PK	PINK
RD	RED
VI	VIOLET
YL	YELLOW
LT	LIGHT COLOR
SP	SPLICE


## STEERING HARNESS

5-HG1






RD/OR





SP RD/YL

- 5- RD/YL 13
- RD/OR 11
- RD/YL 4
- RD/GY 5




E

D





mnr2009-094-005









B

A